

4 Settings

Refer to the standard product operation manual for settings.

5 How to Order

Refer to the standard product catalogue for 'How to Order'.

6 Outline Dimensions (mm)

Refer to the standard product catalogue for general dimensions.

7 Maintenance

7.1 General Maintenance

Caution

- Not following proper maintenance procedures could cause the product to malfunction and lead to equipment damage.
- If handled improperly, compressed air can be dangerous.
- Maintenance of pneumatic systems should be performed only by qualified personnel.
- Before performing maintenance, turn off the power supply and be sure to cut off the supply pressure. Confirm that the air is released to atmosphere.
- After installation and maintenance, apply operating pressure and power to the equipment and perform appropriate functional and leakage tests to make sure the equipment is installed correctly.
- If any electrical connections are disturbed during maintenance, ensure they are reconnected correctly and safety checks are carried out as required to ensure continued compliance with applicable national regulations.
- Do not make any modification to the product.
- Do not disassemble the product, unless required by installation or maintenance instructions.
- Do not use a product which looks or contains damage, this will invalidate the certification. If damage is seen, please replace the product immediately.
- Periodically check the product for any damage or rust appearing. This could result in an increase in friction and lead to dangerous conditions. Replace the whole actuator if any of these conditions appear.
- Periodically check the condition of the rod seal and for the presence of lubrication, where possible. If these areas appear to be dry, please

follow the lubrication procedure.

- Replace the seals, when air leakage is above the allowable value given in the table below:

	Allowable Leakage
Internal Leakage	10 cm ³ / min (ANR)
External Leakage	5 cm ³ / min (ANR)


7.2 Disassembly Procedure

- Disassemble the cylinder, remove the old grease and place all the parts on a clean cloth in a clean environment. Use a set of snap ring pliers to remove the snap ring. Remove the old tube gaskets, rod seal, piston seal, wear ring using a fine screwdriver where necessary.


Caution

- If a magnet is present on the piston do not remove it. The magnet is not replaceable.


7.2.1 Model: C(D)Q2* 12~100(TF)*D(C)(M)Z




7.2.2 Models: C(D)Q2B 125~200(TF)*DC(M)Z, C(D)Q2* 32~100(TF)*DC(M)Z / Long Stroke type



7.2.3 Model: C(D)Q2W* 12~200(TF)*D(C)(M)Z / Double Rod type



7.2.4 Model: C(D)Q2BS 32~100(TF)*DC(M) / Anti-Lateral Load type



1	Rod Seal	8	Piston Rod
2	Piston Seal	9	Bumper A
3	Tube Gasket	10	Bumper B
4	Wear Ring	11	Snap Ring
5	Cylinder Tube	12	Magnet
6	Collar Assembly	13	Spacer (when fitted)
7	Piston		

7.3 Seal Replacement Part Numbers

Warning

Only use SMC seal kits as listed in the table below:

Description	Applicable Bore [mm]	Part Number
Standard Single Rod	Ø 12 ~ Ø 200	CQ2B*-PS
Anti-Lateral Load Type	Ø 32 ~ Ø 100	CQ2B*-PS
Long Stroke Type	Ø 32 ~ Ø 100	CQ2A*-L-PS
Standard Double Rod Type	Ø 12 ~ Ø 100	CQ2WB*-PS

Note 4: The * represents the Bore Size (e.g. Ø50 is 50, Ø100 is 100).

7.4 Lubrication Procedure

- Apply lubricant to:
 - The rod seal and the rod seal groove on the rod cover.
 - The piston outer surface and piston seal groove.
 - The piston seal and tube gaskets.
 - The piston rod surface and cylinder tube internal surface.
- Lubricate the parts with the grease packs provided with the seal kit. For additional grease use the grease pack listed below.

Product	Grease Pack Number	Weight [g]
Standard	GR-S-010	10
	GR-S-020	20
-XC85	GR-H-010	10

The amount of lubricant to be applied is listed in the following table.

Bore [mm]	Required amount of grease up to minimum stroke [g]	For each additional 5mm Stroke [g]
Ø 12	5 mm Stroke	0.07
Ø 16		0.10
Ø 20		0.12
Ø 25		0.18
Ø 32		0.25
Ø 40	10 mm Stroke	0.36
Ø 50		0.67
Ø 63		0.77
Ø 80		1.14
Ø 100		1.51
Ø 125		2.35
Ø 140		2.95
Ø 160		3.87
Ø 180		4.89
Ø 200		6.04

7.5 Reassembly Procedure

- Inserting the collar assembly into the piston rod assembly. Apply grease to the end of the piston rod, especially on the 30° chamfer and on the flats. Insert with care the piston rod into the collar assembly to prevent any damage to the rod seal.

- Inserting piston rod assembly and collar assembly into the cylinder tube.

Insert slowly with care the piston assembly and the collar assembly into the cylinder tube to prevent any damage of the piston seal and tube gasket.

- Installing snap ring. Use appropriate pliers (tool for C-shape snap ring) for installation.

Caution

When installing the snap ring, be aware that the snap ring may come off the pliers and could result in operator injury or equipment damage. Also make sure ring is firmly seated in ring groove.

- Checking assembly. Make sure that no air is leaking from packing seals and that the cylinder operates smoothly at minimum operating pressure. Check for cylinder smooth movement and for air leakage.

8 Limitations of Use

8.1 Limited warranty and Disclaimer/Compliance Requirements

Refer to Handling Precautions for SMC Products located on www.smcworld.com.

8.2 Obligations of the end-user

- Ensure the product is used within the specification outlined.
- Ensure that the maintenance periods are suitable for the application.
- Ensure any cleaning processes to remove dust layers are made with the atmosphere in mind (e.g. using a damp cloth to avoid static build up).
- Ensure that the application does not introduce additional hazards by mounting, loading, impacts or other methods.
- Ensure that there is sufficient ventilation and air circulation around the product.
- If the product is subject to direct heat sources in the application, they should be shielded so that the actuator temperature stays within the stated operating range.

Caution

- SMC products are not intended for use as instruments for legal metrology.** Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country.

Danger

- Do not exceed any of the specifications listed in Section 2 of this document as this will be deemed improper use.
- Air equipment has an air leakage during operation within certain limits. Do not use this equipment when the air itself introduces additional hazards and could lead to an explosion.
- Use only ATEX certified auto switches. These should be ordered separately.
- Do not use this product in the presence of strong magnetic fields that could generate a surface temperature higher than the product specification.
- Avoid applications where the piston rod end and the adjoining part in the application can create a possible ignition source.
- Do not install or use these actuators where there is the possibility for the piston rod to impact foreign objects.
- In the event of damage or failure of any parts located in the vicinity where this product has been installed, it is the responsibility of the user to determine whether or not this has compromised the safety and condition of this product and/or the application.
- External impact on the cylinder body could result in a spark and/or cylinder damage. Avoid any application where foreign objects can hit or impact the cylinder. In such situations the application should install a suitable guard to prevent this occurrence.
- Do not use this equipment where vibration could lead to failure.

9 Contacts

Refer to Declaration of Conformity and www.smcworld.com for contacts.

SMC Corporation

URL : <http://www.smcworld.com> (Global) <http://www.smceu.com> (Europe)
 'SMC Corporation, Akihabara UDX15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101 0021
 Specifications are subject to change without prior notice from the manufacturer.
 © 2018 SMC Corporation All Rights Reserved.
 Template DKP50047-F-085H