

3 Installation - continued

*: Guideline for tightening torque

Number of turns when the fitting is screwed into the body with 2 to 3 windings of sealant tape applied to threaded portion of the piping. The value may differ for types other than sealant type.

3.3.3 LVC tightening torque for piping

- Tighten the nut until it touches the end surface of the body, and then tighten it an additional 1/8 turn. If the nut won't turn any further, then it means enough tightening has occurred. Refer to the proper tightening torques shown below.

Body class	Torque (N.m)
2	1.5 to 2
3	3 to 3.5
4	7.5 to 9
5	11 o 13
6	5.5 to 6

Table 12

3.4 Tubing

- Connect tubing with special tools

Refer to the catalogue "High-Purity Fluoropolymer Fittings Hyper Fittings/LQ1, 2 Series Work Procedure Instructions" (M-E05-1) for connecting tubing and special tools. (Downloadable from the SMC website.)

Caution

Refer to the applicable tubing sizes shown below for tubing to be used.

	Connecting tubing size	O.D. [mm]		Internal thickness [mm]	
		Standard size	Tolerance	Standard size	Tolerance
Metric size	Ø3 x Ø2	3.0	+0.2 -0.1	0.5	±0.06
	Ø4 x Ø3	4.0			
	Ø6 x Ø4	6.0			
	Ø8 x Ø6	8.0		1.0	
	Ø10 x Ø8	10.0			
	Ø12 x Ø10	12.0			
	Ø19 x Ø16	19.0			
Ø25 x Ø22	25.0	-0.1	1.5	±0.15	

	1/8" x 0.086"	3.18	+0.2 -0.1	0.5	±0.1
Inch size	1/4" x 5/32"	6.35	+0.3 -0.1	1.2	±0.12
	3/8" x 1/4"	9.53		1.6	±0.15
	1/2" x 3/8"	12.7			
	3/4" x 5/8"	19.0			
	1" x 7/8"	25.4			

Table 13

3.5 Lubrication

Caution

- SMC products have been lubricated for life at manufacture, and do not require lubrication in service.

3.6 Mounting

Tighten mounting screws to appropriate tightening torque shown in the table below.

3.6.1 Stainless steel body

Model	Mounting	Tightening torque (N.m) ^(Note)
LVA10/20	M5x0.8	3 ±0.7
LVA30	M6x1.0	5 ±0.7
LVA40/50/60	M8x1.25	12 +3/-1

Table 14

3.6.2 PFA body with SUS plate

Model	Mounting	Tightening torque (N.m) ^(Note)
LVA200	M5x0.8	3 ±0.7

Table 15

Note) The value shown is applicable to metal plate panel. Please adjust the torque to meet the requirements of the panel material.

3 Installation - continued

3.7 Handling

- When the diaphragm is made of PTFE; please note that when the product is shipped from the factory, gases such as N₂ and air may leak from the valve at a rate of 1 cm³/min (when pressurised).
- In the LV□ series, water hammering may occur depending on the fluid pressure conditions. In most cases, improvement is possible by adjusting the pilot pressure with a speed controller, etc., but the flow rate, pressure and piping conditions should be reviewed.
- After a long period of non-use, perform a test run before beginning regular operation.

3.8 Operating air supply

Warning

- Use clean air

If the compressed air supply includes chemicals, synthetic materials (including organic solvents), salinity, corrosive gas etc., it can lead to damage or malfunction.

Caution

- Install an air filter for supply air

Install an air filter at the upstream side of the valve. Select an air filter with a filtration size of 5 µm or smaller.

3.9 Effect of back pressure

Use the valve within the allowable operating pressure range as the valve may not close correctly when closing if an excessive back pressure is applied and the valve may open if an excessive reverse pressure is applied.

4 Settings

4.1 Suck back type

A change of volume inside the suck back valve pulls in liquid at the end of the nozzle to prevent dripping.



Figure 2 - Example LVC

4.2 Flow rate adjuster

The flow rate is adjusted by controlling the diaphragm stroke.

- To adjust the flow rate for valves with flow rate adjustment, open gradually starting from the fully closed condition. Ensure lock nut is loosened.
- Opening is accomplished by turning the adjustment knob counter-clockwise.
- Do not apply excessive force to the adjustment knob when approaching the fully open or closed state. This may result in deformation of the orifice sealing surface or damage to the threaded part of the adjustment mechanism.
- Once the required flow rate is achieved, the adjuster can be locked in position by tightening the lock nut in a clockwise direction.
- The product is supplied in the fully closed position.
- The valve may vibrate if operated at very low flow rates, depending on the operating conditions. Therefore, review the flow rate, operating pressure and piping conditions.




Figure 3 - Example LVA

4 Settings - continued

4.3 By-pass

- The by-pass feature allows a small amount of fluid from the inlet side to flow continuously to the outlet side.
- To adjust the fluid flow for valves with the by-pass feature, open gradually starting from the fully closed condition. Ensure lock nut is loosened.
- Opening is accomplished by turning the adjustment knob counter-clockwise.
- Do not apply excessive force to the adjustment knob when approaching the fully open or closed state. This may result in deformation of the orifice sheet surface or damage to the threaded part of the adjustment mechanism.
- Once the required by-pass flow is achieved, the adjuster can be locked in position by tightening the lock nut in a clockwise direction.
- The product is supplied in the fully closed position.




Figure 4 - Example LVA

5 How to Order

Refer to catalogue for 'How to Order'.

6 Outline Dimensions (mm)

Refer to catalogue for outline dimensions.

7 Maintenance

7.1 General Maintenance

Caution

- Not following proper maintenance procedures could cause the

product to malfunction and lead to equipment damage.

- If handled improperly, compressed air can be dangerous.
- Maintenance of pneumatic systems should be performed only by qualified personnel.
- Before performing maintenance, turn off the power supply and be sure to cut off the supply pressure. Confirm that the air is released to atmosphere.
- After installation and maintenance, apply operating pressure and power to the equipment and perform appropriate functional and leakage tests to make sure the equipment is installed correctly.
- If any electrical connections are disturbed during maintenance, ensure they are reconnected correctly and safety checks are carried out as required to ensure continued compliance with applicable national regulations.
- Do not make any modification to the product.
- Do not disassemble the product, unless required by installation or maintenance instructions.

- Perform work after removing residual chemicals and carefully replacing them with DI water (Deionised water) or air, etc.
- In order to obtain optimum performance from valves, perform periodic inspections to confirm that there are no leaks from valves or fittings, etc.
- Removal of drainage
Flush drainage from filters regularly.

7.2 Return of the product

Warning

If the product to be returned is contaminated or is possibly contaminated with substances that are harmful to humans, for safety reasons, please contact SMC beforehand and then employ a specialist cleaning company to decontaminate the product. After the decontamination prescribed above has been carried out, submit a Product Return Request Sheet or the Detoxification/Decontamination Certificate to SMC and await SMC's approval and further instructions before attempting to return the item. Please refer to the International Chemical Safety Cards (ICSC) for a list of harmful substances. If you have any further questions, please don't hesitate to contact your SMC sales representative.

8 Limitations of Use

8.1 Limited warranty and Disclaimer/Compliance Requirements

Refer to Handling Precautions for SMC Products.

Caution

8.2 Fluids

- Operate after confirming the compatibility of the product's component materials with fluids, using the check list "Applicable Fluids: High Purity Air and Manually Operated Chemical Liquid Valves Material and Fluid Compatibility Check List" in the catalogue. Please contact SMC regarding fluids other than those in the check list.
- Operate within the indicated fluid temperature range.

8.4 Liquid closed circuit

When fluid is circulating, install a by-pass valve or relief valve in the system, so that it does not form a closed circuit of liquid, as valve will malfunction.

8.5 Countermeasures against static electricity

Since static electricity may be generated depending on the fluid being used, implement suitable countermeasures.

8.6 Return of the valve to the original position (N.C./N.O. type only)

The valve moves to the original position by spring return.

9 Contacts

Refer to Declaration of Conformity and www.smcworld.com for contacts.

SMC Corporation

URL : <http://www.smcworld.com> (Global) <http://www.smceu.com> (Europe)
 SMC Corporation, Akihabara UDX15F, 4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101 0021
 Specifications are subject to change without prior notice from the manufacturer.
 © 2019 SMC Corporation All Rights Reserved.
 Template DKP50047-F-085H