

# **Operation Manual**

PRODUCT NAME

# **AC Servo Motor Driver**

MODEL / Series/ Product Number

# **LECYU Series**



# **SMC** Corporation

**SMC** 

### Introduction

This manual describes information required for designing, testing, adjusting, and maintaining LECYU Series driver.

Keep this manual in a location where it can be accessed for reference whenever required. Manuals outlined on the following page must also be used as required by the application.

### Description of Technical Terms

The following table shows the meanings of terms used in this manual.

Term	Meaning
M-III Model	MECHATROLINK-III communications reference used for driver interface
Servo ON	Power to motor ON
Servo OFF	Power to motor OFF
Base Block (BB)	Power supply to motor is turned OFF by shutting off the base current to the power transistor in the current amplifier.
Servo Lock	A state in which the motor is stopped and is in position loop with a position reference of 0.
Main Circuit Cable	Cables which connect to the main circuit terminals, including main circuit power supply cables, control power supply cables, motor cables, and others.
Transmission Cycle	The transmission cycle is the cycle in the MAC (Media Access Control) layer. It is the communication cycle for physically sending data to the transmission path. The transmission cycle is unaffected by the services pro- vided by the application layer.
Communication Cycle	The communication cycle is the cycle for application layer. The communication cycle is set to an integral multiple of the transmission cycle.
Synchronous Commands (Classification S)	For commands of this type, commands are sent and response are received every communication cycle. The WDT (Watchdog Timer) in the frames are refreshed and checked every communication cycle. Synchronous commands can be used only during synchronous communications (Phase 3).
Asynchronous Commands (Classification A)	For commands of this type, commands are sent and response are received asynchronously to the communication cycle. Subsequent commands can be sent after confirming the completion of processing of the slave station that received the command. The WDT (Watchdog Timer) in the frames are not checked.
Common Commands	Commands that are common for MECHATROLINK-III communications, independent of profiles
Servo Commands	Commands that are defined in the standard servo profile and specific to DRIVERs
Motion Commands	Among servo commands, the following commands are called motion commands. INTERPOLATE, POSING, FEED, EX_FEED, EX_POSING, ZRET, VELCTRL, TRQCTRL

- Notation Used in this Manual
  - Notation for Reverse Signals

The names of reverse signals (i.e., ones that are valid when low) are written with a forward slash (/) before the signal name.

Notation Example  $\overline{BK} = /BK$ 

Notation for Parameters

The notation depends on whether the parameter requires a value setting (parameter for numeric settings) or requires the selection of a function (parameter for selecting functions).

Control methods for which the parameter applies. Speed : Speed control Position : Position control Torque : Torque control					
	Emergency Stop	Torque	Speed	Position Torque	
Pn406	Setting Range	Setting Unit	Factory Setting	When Enabled	Classification
1	0% to 800%	1%	800	After change	Setup
		Λ			
Indicates range for	the setting the parameter.	cates the imum setting unit he parameter.	ndicates the arameter setting efore shipment.	ndicates when a hange to the arameter will be ffective.	Indicates the parameter classification.
Parameters for Selecting Functions					
	Parameter	Me	aning	When Enabled	Classification
Pn002	n.0000 [Factory setting]	Uses the absolu absolute encode	te encoder as an er.	After restart	Setup
	n.0100	Uses the absolu incremental enc	te encoder as an oder.	1	COUP
Parameter number The notation "n.					

#### · Parameters for Numeric Settings

• Use the Sigma Win+ Select  $\Sigma V$  as an object series when you use Sigma Win+. Refer to the table for the following type when you select the model (parameter edit at offline etc.).

Driver type	Driver select		Motor select	
Differ type	SMC	Sigma Win+	SMC	Sigma Win+
	LECYM2-**	SGDV-***11* Y572AA	V5	SGDV-R90A11B
			V7	SGDV-1R6A11B
MECHAT ROLINK I			V8	SGDV-2R8A11B
			V9	SGDV-5R5A11A
			V5	SGDV-R90A21B
	LECYU2-**	SGDV-****21* Y572AA	V7	SGDV-1R6A21B
MECHATROLINK			V8	SGDV-2R8A21B
			V9	SGDV-5R5A21A

#### Trademarks •

MECHATROLINK is a trademark of the MECHATROLINK Members Association.



# LECYU2-DD Series / Driver Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger."

They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC), Japan Industrial Standards (JIS)\*1) and other safety regulations\*2).

- \*1) ISO 4414: Pneumatic fluid power -- General rules relating to systems
  - ISO 4413: Hydraulic fluid power -- General rules relating to systems
  - IEC 60204-1: Safety of machinery -- Electrical equipment of machines (Part 1: General requirements)
  - ISO 10218-1992: Manipulating industrial robots -- Safety
  - JIS B 8370: General rules for pneumatic equipment.
  - JIS B 8361: General rules for hydraulic equipment.
  - JIS B 9960-1: Safety of machinery Electrical equipment for machines. (Part 1: General requirements)
  - JIS B 8433-1993: Manipulating industrial robots Safety. etc.
- \*2) Labor Safety and Sanitation Law, etc.

$\triangle$	Caution	Caution indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
$\wedge$	Warning	<b>Warning</b> indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.
$\overline{\mathbb{A}}$	Danger	<b>Danger</b> indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.
	IMPORTANT	Indicates <b>important</b> information that should be memorized, as well as precautions, such as alarm displays, that do not involve potential damage to equipment.



1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results.

The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product.

This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment. The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
 4. Contact SMC beforehand and take specific product precautions of and take specific product of safety measures if the product is to be removed.

4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

1) Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.



2) Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
3) An application which could have negative effects on people, property, or animals requiring special safety analysis.

4) Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

Note that the <u>A</u>CAUTION level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

What must not be done and what must be done are indicated by the following diagrammatic symbols.



In this Instruction Manual, instructions at a lower level than the above, instructions for other functions, and so on are classified into "POINT".

After reading this installation guide, always keep it accessible to the operator.



### **A**Caution

The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

### Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

### Limited warranty and Disclaimer

The warranty period of the product is 1 year in service or 1.5 years after the product is delivered.\*3) Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.

For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.

Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.

\*3) Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

### **Compliance Requirements**

When the product is exported, strictly follow the laws required by the Ministry of Economy, Trade and Industry (Foreign Exchange and Foreign Trade Control Law).

This section describes important precautions that must be followed during storage, transportation, installation, wiring, operation, maintenance, inspection, and disposal. Be sure to always observe these precautions thoroughly.

	<b>A</b> Warning
•	Never touch any electric actuators during operation.
	Failure to observe this warning may result in injury.
•	Before starting operation with a machine connected, make sure that an emergency stop can be applied at any time.
	Failure to observe this warning may result in injury or damage to the equipment.
•	Never touch the inside of the driver.
	Failure to observe this warning may result in electric shock.
•	Do not remove the cover of the power supply terminal block while the power is ON.
	Failure to observe this warning may result in electric shock.
•	After the power is turned OFF or after a voltage resistance test, do not touch terminals while the CHARGE lamp is ON.
	Residual voltage may cause electric shock.
•	Follow the procedures and instructions provided in the manuals for the products being used in the trial operation.
	Failure to do so may result not only in faulty operation and damage to equipment, but also in personal injury.
•	The multiturn limit value need not be changed except for special applications.
	Changing it inappropriately or unintentionally can be dangerous.
•	If the Multiturn Limit Disagreement alarm occurs, check the setting of parameter Pn205 in the DRIVER to be sure that it is correct.
	If Fn013 is executed when an incorrect value is set in Pn205, an incorrect value will be set in the encoder. The alarm will disappear even if an incorrect value is set, but incorrect positions will be detected, resulting in a dangerous situation where the machine will move to unexpected positions.
•	Do not remove the top front cover, cables, connectors, or optional items from the DRIVER while the power is ON.
	Failure to observe this warning may result in electric shock.
•	Do not damage, pull, exert excessive force on, or place heavy objects on the cables.
	Failure to observe this warning may result in electric shock, stopping operation of the product, or fire.
•	Do not modify the product.
	Failure to observe this warning may result in injury, damage to the equipment, or fire.
•	Provide appropriate brake devices on the machine side to ensure safety. The holding lock on a electric actuators with a lock is not a braking device for ensuring safety.
	Failure to observe this warning may result in injury.
•	Do not come close to the machine immediately after resetting an instantaneous power interruption to avoid an unexpected restart. Take appropriate measures to ensure safety against an unexpected restart.
	Failure to observe this warning may result in injury.
·	Connect the ground terminal according to local electrical codes (100 $\Omega$ or less for a DRIVER with a 100 V, 200 V power supply).
-	Improper grounding may result in electric snock or fire.
n .	Failure to observe this warning may result in electric shock or injury
L.	The person who designs a system using the safety function (Hard Wire Baseblock function) must
•	have full knowledge of the related safety standards and full understanding of the instructions in this manual. Failure to observe this warning may result in injury or damage to the equipment.

7 SMC

### Storage and Transportation

### 

• Do not store or install the product in the following locations.

Failure to observe this caution may result in fire, electric shock, or damage to the equipment.

- · Locations subject to direct sunlight
- Locations subject to temperatures outside the range specified in the storage/installation temperature conditions
- Locations subject to humidity outside the range specified in the storage/installation humidity conditions
- · Locations subject to condensation as the result of extreme changes in temperature
- · Locations subject to corrosive or flammable gases
- · Locations subject to dust, salts, or iron dust
- · Locations subject to exposure to water, oil, or chemicals
- · Locations subject to shock or vibration
- $\cdot\,$  Do not hold the product by the cables, motor while transporting it.
  - Failure to observe this caution may result in injury or malfunction.
- Do not place any load exceeding the limit specified on the packing box.
- Failure to observe this caution may result in injury or malfunction.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, pallets, or plywood, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.

Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30minutes or more. If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, or iodine can contribute to the erosion of the capacitors.

### Installation

### 

<ul> <li>Never use the product in an environment subject to water, corrosive gases, flammable gases, or compustibles</li> </ul>
Failure to observe this caution may result in electric shock or fire.
<ul> <li>Do not step on or place a heavy object on the product.</li> </ul>
Failure to observe this caution may result in injury or malfunction.
<ul> <li>Do not cover the inlet or outlet ports and prevent any foreign objects from entering the product.</li> </ul>
Failure to observe this caution may cause internal elements to deteriorate resulting in malfunction or fire.
<ul> <li>Be sure to install the product in the correct direction.</li> </ul>
Failure to observe this caution may result in malfunction.
<ul> <li>Provide the specified clearances between the DRIVER and the control panel or with other devices.</li> </ul>
Failure to observe this caution may result in fire or malfunction.
<ul> <li>Do not apply any strong impact.</li> </ul>
Failure to observe this caution may result in malfunction.

### Wiring

### 

- · Be sure to wire correctly and securely.
- Failure to observe this caution may result in electric actuators overrun, injury, or malfunction.
  Do not connect a commercial power supply to the U, V, or W terminals for the motor cable connection.
- Failure to observe this caution may result in injury or fire.Securely connect the main circuit terminals.
- Securely connect the main circuit terminals.
   Failure to observe this caution may result in fire.
- Do not bundle or run the main circuit cables together with the I/O signal cables or the encoder cables in the same duct. Keep the main circuit cables separated from the I/O signal cables and the encoder cables with a gap of at least 30 cm.
  - Placing these cables too close to each other may result in malfunction.
- Use shielded twisted-pair cables or screened unshielded twisted-pair cables for I/O signal cables and the encoder cables.
- The maximum wiring length is 3 m for I/O signal cables, 50 m for encoder cables or servomotor main circuit cables.
- Do not touch the power supply terminals while the CHARGE lamp is ON after turning power OFF because high voltage may still remain in the DRIVER.
- Make sure the charge indicator is OFF first before starting to do wiring or inspections.
- Be sure to observe the following precautions when wiring the DRIVER main circuit terminal blocks.
  Do not turn the DRIVER power ON until all wiring, including the main circuit terminal blocks, has
  - been completed.
  - Remove detachable main circuit terminals from the DRIVER prior to wiring.
  - Insert only one power line per opening in the main circuit terminals.
  - Make sure that no part of the core wire comes into contact with (i.e., short-circuits) adjacent wires.
- Install a battery at either the host controller or the DRIVER, but not both.
   It is dangerous to install batteries at both ends simultaneously, because that sets up a loop circuit between the batteries.
- Always use the specified power supply voltage.
   An incorrect voltage may result in fire or malfunction.
- Make sure that the polarity is correct.
- Incorrect polarity may cause ruptures or damage.
- Take appropriate measures to ensure that the input power supply is supplied within the specified voltage fluctuation range. Be particularly careful in places where the power supply is unstable. An incorrect power supply may result in damage to the equipment.
- Install external breakers or other safety devices against short-circuiting in external wiring. Failure to observe this caution may result in fire.
- Take appropriate and sufficient countermeasures for each form of potential interference when installing systems in the following locations.
  - · Locations subject to static electricity or other forms of noise
  - Locations subject to strong electromagnetic fields and magnetic fields
  - · Locations subject to possible exposure to radioactivity
  - Locations close to power supplies
  - Failure to observe this caution may result in damage to the equipment.
- Do not reverse the polarity of the battery when connecting it.
- Failure to observe this caution may damage the battery, the DRIVER or electric actuaters, or cause an explosion.
- Wiring or inspection must be performed by a technical expert.
- · Use a 24-VDC power supply with double insulation or reinforced insulation.

Operation

### **A**Caution

<ul> <li>Always use the electric actuators and DRIVER in one of the specified combinations.</li> </ul>				
Failure to observe this caution may result in fire or malfunction.				
<ul> <li>During trial operation, confirm that the holding lock works correctly. Furthermore, secure system safety</li> </ul>				
Before starting operation with a machine connected, change the parameter settings to match the				
narameters of the machine				
Starting operation without matching the proper settings may cause the machine to run out of control or				
malfunction.				
<ul> <li>Do not turn the power ON and OFF more than necessary.</li> </ul>				
Do not use the DRIVER for applications that require the power to turn ON and OFF frequently. Such applications will cause elements in the DRIVER to deteriorate.				
As a guideline, at least one hour should be allowed between the power being turned ON and OFF once actual operation has been started.				
<ul> <li>When carrying out JOG operation (Fn002), origin search (Fn003), or EasyFFT (Fn206), forcing movable machine parts to stop does not work for forward overtravel or reverse overtravel. Take necessary precautions.</li> </ul>				
Failure to observe this caution may result in damage to the equipment.				
· When using the electric actuators for a vertical axis, install safety devices to prevent workpieces from falling				
due to alarms or overtravels. Set the servomotor so that it will stop in the zero clamp state when				
overtravel occurs.				
Failure to observe this caution may cause workpieces to fall due to overtravel.				
When not using the turning-less function, set the correct moment of inertia ratio (Pn103).				
Setting an incorrect moment of inertia ratio may cause machine vibration.				
• Do not touch the DRIVER heat sinks, regenerative option, or servomotor while power is ON or soon				
after the power is turned OFF.				
Panule to observe tills caution may result in burns due to high temperatures.				
<ul> <li>Do not make any exiteme aujustments of setting changes of parameters.</li> <li>Eailure to observe this caution may result in injury or damage to the equipment due to unstable.</li> </ul>				
operation.				
<ul> <li>When an alarm occurs, remove the cause, reset the alarm after confirming safety, and then resume operation.</li> </ul>				
Failure to observe this caution may result in damage to the equipment, fire, or injury.				
Do not use the holding lock of the electric actuators for braking.				
Failure to observe this caution may result in malfunction.				
<ul> <li>An alarm or warning may occur if communications are performed with the host controller while the</li> </ul>				
SigmaWin+ is operating. If an alarm or warning occurs, it may stop the current process and stop the system.				
Maintenance and Inspection				
Do not disassemble the DRIV/ER and the servemeter				

- Do not disassemble the DRIVER and the servomotor.
- Failure to observe this caution may result in electric shock or injury.Do not attempt to change wiring while the power is ON.
- Failure to observe this caution may result in electric shock or injury.
- When replacing the DRIVER, resume operation only after copying the previous DRIVER parameters to the new DRIVER.
  - Failure to observe this caution may result in damage to the equipment.

### Disposal

## **A**Caution

 $\cdot\,$  When disposing of the products, treat them as ordinary industrial waste.

### General Precautions

<b>∆</b> Caution
<ul> <li>The products shown in illustrations in this manual are sometimes shown without covers or protective guards. Always replace the cover or protective guard as specified first, and then operate the products in accordance with the manual.</li> </ul>
The drawings presented in this manual are typical examples and may not match the product you received.



### Harmonized Standards

• European Directives

# CE

	Model	European Directives	Harmonized Standards
	LECY==-V= (SGDV)	Machinery Directive 2006/42/EC	EN ISO13849-1: 2008 EN 954-1
DRIVER		EMC Directive 2004/108/EC	EN 55011 /A2 group 1, class A EN 61000-6-2 EN 61800-3
		Low Voltage Directive 2006/95/EC	EN 50178 EN 61800-5-1
Servomotor	LE-V□-□ (SGMJV)	EMC Directive 2004/108/EC	EN 55011 /A2 group 1, class A EN 61000-6-2 EN 61800-3
		Low Voltage Directive 2006/95/EC	EN 60034-1 EN 60034-5

### • Safety Standards

	Model	Safety Standards	Standards
DRIVER	LECY□□-V□ (SGDV)	Safety of Machinery	EN ISO13849-1: 2008 EN 954-1 IEC 60204-1
		Functional Safety	IEC 61508 series IEC 62061 IEC 61800-5-2
		EMC	IEC 61326-3-1

### • Safe Performance

Items	Standards	Performance Level
Safety Integrity Level	IEC 61508	SIL2
	IEC 62061	SILCL2
Probability of Dangerous Failure per Hour	IEC 61508 IEC 62061	PFH ⇐ 1.7×10 <sup>-9</sup> [1/h] (0.17% of SIL2)
Category	EN 954-1	Category 3
Performance Level	EN ISO 13849-1	PL d (Category 3)
Mean Time to Dangerous Failure of Each Channel	EN ISO 13849-1	MTTFd: High
Average Diagnostic Coverage	EN ISO 13849-1	DCave: Low
Stop Category	IEC 60204-1	Stop category 0
Safety Function	IEC 61800-5-2	STO
Proof test Interval	IEC 61508	10 years

# Contents

Introduction	1
Safety	4
Harmonized Standards	12

1. Outline	1-2
1 1 LECY Series DRIVERs	1-2
1.2 Part Names	1-2
1.3 DRIVER Ratings and Specifications	1-3
1.3.1 Ratings	1-3
1.3.3 MECHATROLINK-III Function Specifications	1-7
1.4 DRIVER Internal Block Diagrams	1-8
1.4.1 Three-phase 200 V, LECYU2-V5, LECYU2-V7 Models	1-8
1.4.2 Three-phase 200 V, LECYU2-V8 Model 1.4.3 Three-phase 200 V, LECYU2-V9 Models	1-8 1-9
1.5 Examples of Servo System Configurations	1-10
1.5.1 Connecting to LECYU2-V D DRIVER	1-10
1.6 DRIVER Model Designation	1-12
1.7 Inspection and Maintenance	1-13
1.8 Installation Environment and Applicable Standards	1-14
1.8.2 Installation Conditions for Applicable Standards	1-14
1.8.3 Conditions Corresponding to Low Voltage Directive	1-15
1.9 DRIVER Installation.	1-16
1.9.2 Installation Standards.	1-16

# 2. Panel Display and Operation of Sigma Win+.....2-2

2.1 Panel Display	2-2
2.1.1 Status Display	2-2
2.1.2 Alarm and Warning Display	2-2
2.1.3 Hard Wire Base Block Display	2-2
2.1.4 Overtravel Display	2-2
2.2 Operation of SigmaWin+ <sup>SM</sup>	2-3
2.2.1 Compatible Devices	2-3
2.2.2 Hardware requirements	2-3
2.2.3 Installing SigmaWin+ Program	2-3
2.2.4 Starting SigmaWin+	2-12
2.3 Utility Functions	2-15
2.4 Parameters	2-15
2.4.1 Parameter Classification	2-15
2.4.2 Notation for Parameters	2-16
2.4.3 Setting Parameters	2-16
2.5 Monitor Displays	2-16

Wiring and Connection	3-2
3.1 Main Circuit Wiring	
3.1.1 Main Circuit Terminals	
3.1.2 Using a Standard Power Supply (Three-phase 200 V)	
3.1.3 Using the DRIVER with Single-phase, 200 V Power Input	3-7
3.1.4 Using the DRIVER with a DC Power Input	3-10
3.1.5 Using More Than One DRIVER	3-12
3.1.6 General Precautions for Wiring	3-13
3.1.7 Specifications of motor cables and encoder cables	3-14
3.2 I/O Signal Connections	3-16
3.2.1 /O Signal (CN1) Names and Functions	3-16
3.2.2 Safety Function Signal (CN8) Names and Functions	3-17
3.2.3 Example of I/O Signal Connections	3-18
3.3 I/O Signal Allocations	3-19
3.3.1 Input Signal Allocations	3-19
3.3.2 Output Signal Allocations	3-21
3.4 Examples of Connection to PC or PLC etc	3-22
3.4.1 Sequence Input Circuit	3-22
3.4.2 Sequence Output Circuit	3-23
3.5 Wiring MECHATROLINK-III Communications	3-25
3.6 Encoder Connection	
3.6.1 Encoder Signal (CN2) Names and Functions	3-26
3.6.2 Encoder Connection Examples	
3.7 Connecting Regenerative resistors	3-28
3 7 1 Connecting Regenerative Resistors	3-29
3.7.2 Setting Regenerative resistor Capacity.	
3.8 Noise Control and Measures for Harmonic Suppression	3-31
3.8.1 Wiring for Noise Control	3_31
3.8.2 Precautions on Connecting Noise Filter	
3.8.3 EMC Installation Conditions.	
3.9 Specification of option cables	3-41

### 4. Operation......4-3

4.1 MECHATROLINK-III Communications Settings	4-3
4.1.1 Setting Switches S1, S2, and S3	4-3
4.2 MECHATROLINK-III Commands	4-4
4 3 Basic Functions Settings	4_4
4.3.1 Servomotor Rotation Direction	+ + م_م
4.3.2 Overtravel	
4.3.3 Software Limit Settings	4-8
4.3.4 Holding Locks	4-9
4.3.5 Stopping Servomotors after SV OFF Command or Alarm Occurrence	4-14
4.3.6 Instantaneous Power Interruption Settings	4-16
4.3.7 SEMI F47 Function	
(Torque Limit Function for Low DC Power Supply Voltage for Main Circuit)	4-17
4.3.8 Setting Motor Overload Detection Level	4-19
4.4 Trial Operation	4-21
4.4.1 Inspection and Checking before Trial Operation	4-21
4.4.2 Trial Operation via MECHATROLINK-III	4-22
4.4.3 Electronic Gear	4-23
4.4.4 Encoder Output Pulses	4-25
4.4.5 Setting Encoder Output Pulse	4-26
4.5 Test Without Motor Function	4-27
4.5.1 Motor Information	4-27
4.5.2 Motor Position and Speed Responses	4-28
4.5.3 Limitations	4-29
4.6 Limiting Torque	4-30
4.6.1 Internal Torque Limit	4-30

4.6.2 External Torque Limit	4-31
4.6.3 Checking Output Torque Limiting during Operation	
4.7 Absolute Encoders	4-33
4.7.1 Connecting the Absolute Encoder	4-34
4.7.2 Absolute Data Request (SENS ON Command)	
4.7.3 Battery Replacement	4-36
4.7.4 Absolute Encoder Setup and Reinitialization	4-38
4.7.5 Multiturn Limit Setting	4-39
4.7.6 Multiturn Limit Disagreement Alarm (A.CC0)	4-40
4.7.7 Absolute Encoder Origin Offset	4-41
4.7.8 Absolute Data Reception Sequence	4-41
4.8 Other Output Signals	4-45
4.8.1 Servo Alarm Output Signal (ALM)	4-45
4.8.2 Warning Output Signal (/WARN)	4-45
4.8.3 Rotation Detection Output Signal (/TGON)	4-46
4.8.4 Servo Ready Output Signal (/S-RDY)	4-46
4.8.5 Speed Coincidence Output Signal (/V-CMP)	4-47
4.8.6 Positioning Completed Output Signal (/COIN)	4-48
4.8.7 Positioning Near Output Signal (/NEAR)	4-49
4.8.8 Speed Limit Detection Signal (/VLT)	4-50
4.9 Safety Function	4-52
4.9.1 Hard Wire Base Block (HWBB) Function	4-52
4.9.2 External Device Monitor (EDM1)	4-59
4.9.3 Application Example of Safety Functions	4-61
4.9.4 Confirming Safety Functions	4-62
4.9.5 Connecting a Safety Function Device	4-63
4.9.6 Precautions for Safety Function	4-64

### 

5.1 Type of Adjustments and Basic Adjustment Procedure	5-2
5.1.1 Adjustments	5-2
5.1.2 Basic Adjustment Procedure	5-3
5.1.3 Monitoring Operation during Adjustment	5-4
5.1.4 Safety Precautions on Adjustment of Servo Gains	5-7
5.2 Tuning-less Function	5-10
5.2.1 Tuning-less Function	5-10
5.2.2 Tuning-less Levels Setting (Fn200) Procedure	5-13
5.2.3 Related Parameters	5-15
5.3 Advanced Autotuning (Fn201)	5-16
5.3.1 Advanced Autotuning.	5-16
5.3.2 Advanced Autotuning Procedure	5-19
5.3.3 Related Parameters	5-32
5.4 Advanced Autotuning by Reference (Fn202)	5-33
5.4.1 Advanced Autotuning by Reference	5-33
5.4.2 Advanced Autotuning by Reference Procedure	5-35
5.4.3 Related Parameters	5-40
5.5 One-parameter Tuning (Fn203)	5-41
5.5.1 One-parameter Tuning	
5.5.2 One-parameter Tuning Procedure	5-42
5.5.3 One-parameter Tuning Example	5-45
5.5.4 Related Parameters	5-46
5.6 Anti-Resonance Control Adjustment Function (Fn204)	5-47
5.6.1 Anti-Resonance Control Adjustment Function	
5.6.2 Anti-Resonance Control Adjustment Function Operating Procedure	
5.6.3 Related Parameters	5-48
5.7 Vibration Suppression Function (Fn205)	5-49
5.7.1 Vibration Suppression Function	
5.7.2 Vibration Suppression Function Operating Procedure	
5.7.3 Related Parameters	5-52
5.8 Additional Adjustment Function	5-53
5.8.1 Switching Gain Settings	5-53
5.8.2 Manual Adjustment of Friction Compensation	
1	

5.8.3 Current Control Mode Selection Function	5-60
5.8.4 Current Gain Level Setting	5-60
5.8.5 Speed Detection Method Selection	5-60
5.8.6 Backlash Compensation Function	5-61
5.8.7 Torque Reference Filter	5-68
•	

### 

6.1 List of Utility Functions	6-2
6.2 Alarm History Display (Fn000)	6-3
6.3 JOG Operation (Fn002)	6-4
6.4 Origin Search (Fn003)	6-5
6.5 Program JOG Operation (Fn004)	6-6
6.6 Initializing Parameter Settings (Fn005)	6-10
6.7 Clearing Alarm History (Fn006)	6-11
6.8 Offset Adjustment of Analog Monitor Output (Fn00C)	6-12
6.9 Gain Adjustment of Analog Monitor Output (Fn00D)	6-14
6.10 Automatic Offset-Signal Adjustment of the Motor Current	
Detection Signal (Fn00E).	6-16
6.11 Manual Offset-Signal Adjustment of the Motor Current	
Detection Signal (Fn00F)	6-17
6.12 Write Prohibited Setting (Fn010)	6-18
6.13 Product Information Display (Fn011)	6-20
6.14 Resetting Configuration Errors in Option Modules (Fn014)	6-21
6.15 Vibration Detection Level Initialization (Fn01B)	6-22
6.16 Origin Setting (Fn020)	6-24
6.17 Software Reset (Fn030)	6-25
6.18 EasyFFT (Fn206)	6-26
6.19 Online Vibration Monitor (Fn207)	6-28

7. Monitor Displays	7-2
7.1 Monitor Displays	7-2
7.1.1 System Monitor	7-2
7.1.2 Status Monitor	
7.1.3 Motion Monitor	7-2
7.1.4 Input Signal Monitor	7-2
7.1.5 Output Signal Monitor	7-3

8.	MECHATROLINK-II Command	8-4
	8.1 Lavers.	8-4
	8.2 Frame Structure	8-4
	8.3 State Transition Diagram	8-5
	8.4 Command and Response Timing	8-6
	8.4.1 Command Data Execution Timing	8-6
	8.4.2 Monitored Data Input Timing	8-6
	8.4.3 Supporting the Transmission Cycle of 125 µs	8-7
	8.5 List of Commands	8-8
	8.5.1 Command Types	8-8
	8.5.2 Main Commands	8-8
	8.5.3 Subcommands	8-10
	8.5.4 Combinations of Main Commands and Subcommands	8-11
	8.6 Common Command Format	8-12

	8-14
8.7.1 Command Code (CMD/RCMD)	8-14
8.7.2 Watchdog Data (WDT/RWDT)	8-15
8.7.3 Command Control (CMD_CTRL).	8-15
8.7.4 Command Status (CMD_STAT)	8-16
8.8 Command Header Section of Subcommand Area	8-20
8.8.1 Subcommand Codes (SUB_CMD/SUB_RCMD)	8-20
8.8.3 Subcommand Status (SUB_STAT)	
8 9 Servo Command Format	8-22
8 10 Command Header Section	8_23
8 10 1 Servo Command Control (SVCMD_CTRL)	8_23
8.10.2 Servo Command Status (SVCMD_STAT)	
8.10.3 Supplementary Information on CMD PAUSE and CMD CANCEL	8-27
8.10.4 Supplementary Information on Latching Operation	8-30
8.11 Servo Command I/O Signal (SVCMD IO)	8-31
8.11.1 Bit Allocation of Servo Command Output Signals	8-31
8.11.2 Bit Allocation of Servo Command I/O Signal Monitoring	8-33
8.12 Command Data	8-36
8.12.1 Data Order	8-36
8.12.2 Specifying Units	8-36
8.12.3 Specifying Monitor Data	8-37
8.12.4 Position Data	8-37
8.13 Common Commands	8-38
8.13.1 Common Commands	8-38
8.13.3 Read ID Command (ID RD: 03H)	
8 13 4 Setup Device Command (CONFIG: 04H)	
8.13.5 Read Alarm or Warning Command (ALM RD: 05H)	
8.13.6 Clear Alarm or Warning Command (ALM_CLR: 06H)	8-51
8.13.7 Start Synchronous Communication Command (SYNC_SET: 0DH)	8-52
• • • •	
8.13.8 Establish Connection Command (CONNECT: 0EH)	8-53
8.13.8 Establish Connection Command (CONNECT: 0EH) 8.13.9 Disconnection Command (DISCONNECT: 0FH)	
8.13.8 Establish Connection Command (CONNECT: 0EH) 8.13.9 Disconnection Command (DISCONNECT: 0FH) 8.13.10 Read Memory Command (MEM_RD: 1DH)	8-53 8-55 8-56
8.13.8 Establish Connection Command (CONNECT: 0EH) 8.13.9 Disconnection Command (DISCONNECT: 0FH) 8.13.10 Read Memory Command (MEM_RD: 1DH) 8.13.11 Write Memory Command (MEM_WR: 1EH) 8.14 Son of Commande	
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>9.14.1 Table of Serve Commande</li> </ul>	
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> </ul>	8-53 8-55 8-56 8-56 8-58 8-61 8-61 8-62
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands.</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> </ul>	8-53 8-55 8-55 8-56 8-58 8-61 
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-64 8-65
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-65 8-67
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_OFF: 24H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-62 8-62 8-64 8-65 8-67 8-68
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-65 8-67 8-68 8-69
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_ON: 31H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-68 8-69 8-70
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_ON: 31H)</li> <li>8.14.9 Servo OFF Command (SV_OFF: 32H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-69 8-70 8-70
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.11 Interpolation Command (ROS)</li> </ul>	8-53 8-55 8-56 8-56 8-61 8-61 8-61 8-62 8-64 8-65 8-65 8-69 8-69 8-70 8-71 8-73 8-73
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands.</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OFF: 32H)</li> <li>8.14.9 Servo OFF Command (SV_OFF: 32H)</li> <li>8.14.11 Positioning Command (POSING: 35H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-65 8-67 8-68 8-69 8-70 8-71 8-73 8-74 8-74 8-76
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OFF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.11 Positioning Command (POSING: 35H)</li> <li>8.14.13 External Input Feed Command (EX_EFED: 37H)</li> </ul>	8-53 8-55 8-56 8-56 8-61 8-61 8-61 8-62 8-64 8-65 8-65 8-67 8-68 8-69 8-70 8-71 8-73 8-74 8-74 8-76 8-78
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li></ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-69 8-70 8-71 8-73 8-74 8-74 8-78 8-78 8-80
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OFF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.11 Positioning Command (POSING: 35H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.14 External Input Positioning Command (ZRET: 3AH)</li> </ul>	8-53 8-55 8-56 8-56 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-69 8-70 8-71 8-73 8-74 8-74 8-78 8-78 8-80 8-80 8-80 8-80
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_OFF: 24H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OFF: 32H)</li> <li>8.14.9 Servo OFF Command (SV_OFF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.14 External Input Positioning Command (EX_POSING: 39H)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (VELCTRL: 3CH)</li> </ul>	8-53 8-55 8-56 8-56 8-61 8-61 8-61 8-62 8-64 8-65 8-65 8-69 8-70 8-71 8-73 8-74 8-73 8-74 8-78 8-88 8-80 8-82 8-82 8-85
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_OFF: 24H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OFF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.14 External Input Positioning Command (ZRET: 3AH)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (VELCTRL: 3CH)</li> <li>8.14.17 Torque (Force) Control Command (TRQCTRL: 3DH)</li> </ul>	8-53 8-55 8-56 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-69 8-70 8-71 8-73 8-74 8-73 8-74 8-78 8-80 8-80 8-82 8-85 8-86
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_ON: 31H)</li> <li>8.14.9 Servo OFF Command (SV_OFF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_POSING: 37H)</li> <li>8.14.14 External Input Feed Command (ZRET: 3AH)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (ZRET: 3AH)</li> <li>8.14.17 Torque (Force) Control Command (SVPRM_RD: 40H)</li> <li>9.14.18 Read Servo Parameter Command (SVPRM_RD: 40H)</li> </ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-70 8-71 8-73 8-74 8-76 8-78 8-78 8-88 8-80 8-82 8-82 8-85 8-86 8-86 8-86 8-86 8-86 8-86
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.14 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (ZRET: 3AH)</li> <li>8.14.17 Torque (Force) Control Command (TRQCTRL: 3DH)</li> <li>8.14.18 Read Servo Parameter Command (SVPRM_RD: 40H)</li> <li>8.14.19 Write Servo Parameter Command (SVPRM_WR: 41H)</li> <li>8.14.19 Write Servo Parameter Command (SVPRM_WR: 41H)</li> </ul>	8-53 8-55 8-56 8-56 8-61 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-70 8-71 8-73 8-74 8-74 8-76 8-78 8-80 8-80 8-80 8-82 8-85 8-86 8-87 8-88
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands.</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor ON Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_ON: 31H)</li> <li>8.14.9 Servo OFF Command (NTERPOLATE: 34H)</li> <li>8.14.10 Interpolation Command (POSING: 33FI)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.14 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (ZRET: 3AH)</li> <li>8.14.17 Torque (Force) Control Command (TRQCTRL: 3DH)</li> <li>8.14.18 Read Servo Parameter Command (SVPRM_RD: 40H)</li> <li>8.14.20 Motion Command Data Setting Method.</li> </ul>	8-53 8-55 8-56 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-70 8-70 8-71 8-73 8-74 8-76 8-78 8-80 8-80 8-80 8-80 8-82 8-85 8-86
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.11 Positioning Command (POSING: 35H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.14 External Input Feed Command (ZRET: 3AH)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (ZRET: 3CH)</li> <li>8.14.17 Torque (Force) Control Command (SVPRM_RD: 40H)</li> <li>8.14.19 Write Servo Parameter Command (SVPRM_RD: 40H)</li> <li>8.14.19 Write Servo Parameter Command (SVPRM_RD: 40H)</li> <li>8.14.20 Motion Command Data Setting Method.</li> </ul>	8-53 8-55 8-56 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-70 8-70 8-71 8-73 8-74 8-73 8-74 8-76 8-78 8-80 8-82 8-80 8-82 8-85 8-86 8-87 8-88 8-89 8-91 8-91
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands.</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OFF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.11 Positioning Command (POSING: 35H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (ZRET: 3AH)</li> <li>8.14.17 Torque (Force) Control Command (SVPRM_RD: 40H)</li> <li>8.14.19 Write Servo Parameter Command (SVPRM_RD: 40H)</li> <li>8.14.20 Motion Command (NOP: 00H)</li> <li>8.15.1 No Operation Subcommand (NOP: 00H)</li> <li>8.15.2 Read Alarm or Warning Subcommand (ALM, PD: 0EH)</li> </ul>	8-53 8-55 8-56 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-69 8-70 8-71 8-73 8-74 8-73 8-74 8-76 8-78 8-80 8-82 8-85 8-86 8-87 8-88 8-89 8-91 8-92 8-92
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li> <li>8.13.9 Disconnection Command (DISCONNECT: 0FH)</li> <li>8.13.10 Read Memory Command (MEM_RD: 1DH)</li> <li>8.13.11 Write Memory Command (MEM_WR: 1EH)</li> <li>8.14 Servo Commands.</li> <li>8.14.1 Table of Servo Commands.</li> <li>8.14.2 Set Coordinates Command (POS_SET: 20H)</li> <li>8.14.3 Apply Lock Command (BRK_ON: 21H)</li> <li>8.14.4 Release Lock Command (BRK_OFF: 22H)</li> <li>8.14.5 Turn Sensor ON Command (SENS_ON: 23H)</li> <li>8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)</li> <li>8.14.7 Servo Status Monitor Command (SMON: 30H)</li> <li>8.14.8 Servo ON Command (SV_OFF: 32H)</li> <li>8.14.9 Servo OFF Command (SV_OFF: 32H)</li> <li>8.14.10 Interpolation Command (INTERPOLATE: 34H)</li> <li>8.14.12 Feed Command (FEED: 36H)</li> <li>8.14.13 External Input Feed Command (EX_FEED: 37H)</li> <li>8.14.15 Zero Point Return Command (ZRET: 3AH)</li> <li>8.14.16 Velocity Control Command (ZRET: 3AH)</li> <li>8.14.17 Torque (Force) Control Command (SVPRM_RD: 40H)</li> <li>8.14.19 Write Servo Parameter Command (SVPRM_RD: 40H)</li> <li>8.14.20 Motion Command Data Setting Method.</li> <li>8.15.1 No Operation Subcommand (NOP: 00H)</li> <li>8.15.2 Read Alarm or Warning Subcommand (ALM_RD: 05H)</li> <li>8.15.3 Clear Alarm or Warning Subcommand (ALM_RD: 05H)</li> </ul>	8-53 8-55 8-56 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-70 8-71 8-73 8-74 8-73 8-74 8-78 8-80 8-82 8-85 8-86 8-87 8-88 8-89 8-89 8-91 8-92 8-93 8-94
<ul> <li>8.13.8 Establish Connection Command (CONNECT: 0EH)</li></ul>	8-53 8-55 8-56 8-58 8-61 8-61 8-61 8-62 8-64 8-65 8-67 8-68 8-70 8-71 8-73 8-74 8-76 8-78 8-78 8-82 8-82 8-82 8-85 8-82 8-85 8-89 8-91 8-91 8-94 8-94 8-95

8.15.5 Write Memory Subcommand (MEM_WR: 1EH)	8-96
8.15.6 Servo Status Monitor Subcommand (SMON: 30H)	8-97
8.15.7 Read Servo Parameter Subcommand (SVPRM_RD: 40H)	8-98
8.15.8 Write Servo Parameter Subcommand (SVPRM_WR: 41H)	8-99
8.16 Preparing for Operation	8-100
8.16.1 Setting MECHATROLINK-III Communications	8-100
8.16.2 Checking the Communications Status	8-100
8.17 Parameter Management and Operation Sequence	8-101
8.17.1 Operation Sequence for Managing Parameters Using a PC or PLCetc	8-101
8.17.2 Operation Sequence for Managing Parameters Using a DRIVER	8-102
8.18 Setting the Zero Point before Starting Operation	8-103
8.19 Operation Sequence when Turning the Servo ON	8-104
8.20 Operation Sequence when OT (Overtravel Limit Switch) Signal is Input.	8-104
8.21 Operation Sequence at Emergency Stop (Main Circuit OFF)	8-104
8.22 Operation Sequence when a Safety Signal is Input	8-105
8.23 Operation Sequence at Occurrence of Alarm	8-107
8.24 Notes when the Positioning Completed State (PSET = 1)	
is Established while Canceling a Motion Command	8-107
8.25 Function/Command Related Parameters	8-108
8.25.1 Interpolation Command	8-108
8.25.2 Positioning Command	8-109
8.25.3 Torque (Force) Limiting Function	8-111
6.25.4 Torgue (Force) Feedforward Function	8-113
8.25.5 Software Limit Function	8-114
8.25.6 Latch Function	8-116
8.25.7 Acceleration/Deceleration Parameter High-speed Switching Function	8-121
8.26 Detecting Alarms/Warnings Related to Communications or Commands.	8-125
8.26.1 Communication Related Alarms	8-125
8.26.2 Warnings Related to Communication and Commands	8-127
8.27 Common Parameters	8-128
8.27.1 Overview	8-128
8.27.2 List of Common Parameters	8-129
8.27.3 Common Parameters and Corresponding Device Parameters	8-138
8.28 Virtual Memory Space	8-140
8.29 Information Allocated to Virtual Memory	8-141
8.29.1 ID Information Area	8-141
8.29.2 Common Parameter Area	8-142
8.29.3 Adjustment Operation Area	8-143

9. Troubleshooting	9-2
9.1 Alarm Displays	9-2
9.1.1 List of Alarms	
9.1.2 Troubleshooting of Alarms	9-5
9.2 Warning Displays	9-24
9.2.1 List of Warnings	9-24
9.2.2 Troubleshooting of Warnings	9-26
9.3 Monitoring Communication Data on Occurrence of an Alarm or Warnir	ıg9-32
9.4 Troubleshooting Malfunction Based on Operation and	•
Conditions of the Servomotor	9-33

10. List of Parameters	10-2
10.1 List of Parameters.	10-2
10.1.1 Utility Functions	
10.1.2 Parameters	10-3
10.1.3 MECHATROLINK-III Common Parameters	10-37
10.2 Parameter Recording Table	10-45

1. Outline	2
1.1 LECY Series DRIVERs	2
1.2 Part Names	2
1.3 DRIVER Ratings and Specifications	3
1.3.1 Ratings	3
1.3.2 Basic Specifications	4
1.3.3 MECHATROLINK-III Function Specifications	7
1.4 DRIVER Internal Block Diagrams	8
1.4.1 Three-phase 200 V, LECYU2-V5, LECYU2-V7 Models	8
1.4.2 Three-phase 200 V, LECYU2-V8 Model	8
1.4.3 Three-phase 200 V, LECYU2-V9 Models	9
1.5 Examples of Servo System Configurations	
1.5.1 Connecting to LECYU2-V□ DRIVER	
1.6 DRIVER Model Designation	12
1.7 Inspection and Maintenance	
1.8 Installation Environment and Applicable Standards	14
1.8.1 DRIVER Installation Environment	14
1.8.2 Installation Conditions for Applicable Standards	15
1.8.3 Conditions Corresponding to Low Voltage Directive	15
1.9 DRIVER Installation	16
1.9.1 Orientation	16
1.9.2 Installation Standards	16

### 1. Outline

#### **1.1 LECY Series DRIVERs**

The LECY Series DRIVERs are designed for applications that require frequent high-speed, high-precision positioning. The DRIVER makes the most of machine performance in the shortest time possible, thus contributing to improving productivity.

#### 1.2 Part Names

This section describes the part names of LECYU DRIVER for MECHATROLINK-III communications reference.





### 1.3 DRIVER Ratings and Specifications

This section describes the ratings and specifications of DRIVERs.

### 1.3.1 Ratings

Ratings of DRIVERs are as shown below.

LECYU (Three Phase, 200 V)	V5	V7	V8	V9
Continuous Output Current [Arms]	0.91	1.6	2.8	5.5
Instantaneous Max. Output Current [Arms]	2.9	5.8	9.3	16.9
Regenerative Resistor *	None or external		Built-in or external	
Main Circuit Power Supply	Three-phase, 200 to 230 VAC,-15% to +10%			50/60 Hz
Control Power Supply	Single-phase, 200 to 230 VAC,-15% to +10% 50/60 Hz			50/60 Hz
Overvoltage Category	III			

 $\ast$  Refer to 3.7 Connecting Regenerative resistors for details.



### 1.3.2 Basic Specifications

Basic specifications of DRIVERs are shown below.

Drive Method		Sine-wave current drive with PWM control of IGBT		
Feedback		Encoder: 20-bit (absolute)		
Surrounding Air Temper- ature		$0^{\circ}$ C to +55°C		
	Storage Te	mperature	-20°C to +85°C	
	Ambient H	umidity	90% RH or less	With no freezing or condensation
	Storage Hu	imidity	90% RH or less	with no neezing of condensation
	Vibration R	esistance	4.9 m/s <sup>2</sup>	
Operating	Shock Res	istance	19.6 m/s <sup>2</sup>	
Conditions	Protection	Class	IP10	An environment that satisfies the following conditions. • Free of corrosive or flammable gases
	Pollution Degree		2	<ul><li>Free of exposure to water, oil, or chemicals</li><li>Free of dust, salts, or iron dust</li></ul>
	Altitude		1000 m or less	
	Others		Free of static electricity, strong electromagnetic fields, magnetic fields or exposure to radioactivity	
Harmonized Standards		EN50178, EN55011/A2 group1 classA, EN61000-6-2, EN61800-3, EN61800-5-1, EN954-1, IEC61508-1 to 4		
Mounting			Base-mounted	
	Speed Con	trol Range	1:5000 (The lower limit of the speed control range must be lower than the point at which the rated torque does not cause the servomotor to stop.)	
	Speed Regu- lation <sup>*1</sup>	Load Regulation	0% to 100% load: $\pm 0.01\%$ max. (at rated speed)	
Perfor		Voltage Regulation	Rated voltage $\pm 10\%$ : 0% (at rated speed)	
mance		Temperature Regulation	$25 \pm 25$ °C: $\pm 0.1\%$	$25 \pm 25$ °C: $\pm 0.1\%$ max. (at rated speed)
	Torque Control Tolerance (Repeatability)		±1%	
Soft Start Time Setting		0 to 10 s (Can be s	et individually for acceleration and deceleration.)	

Encoder Output Pulse		Phase A, B, C: line driver Encoder output pulse: any setting ratio (Refer to 4.4.5.)			
			Number of Channels	7 ch	
	Sequence Input	Input Signals which can be allocated	Functions	<ul> <li>Homing deceleration switch (/DEC)</li> <li>External latch (/EXT 1 to 3)</li> <li>Forward run prohibited (P-OT), reverse run prohibited (N-OT)</li> <li>Forward external torque limit (/P-CL), reverse external torque limit (/N-CL)</li> <li>Signal allocations can be performed, and positive and negative logic can be changed.</li> </ul>	
I/O		Fixed Output	Servo alarm (ALM	I) output	
Signal s			Number of Channels	3 ch	
	Sequence Output	Output Signals which can be allocated	Functions	<ul> <li>Positioning completion (/COIN)</li> <li>Speed coincidence detection (/V-CMP)</li> <li>Rotation detection (/TGON)</li> <li>Servo ready (/S-RDY)</li> <li>Torque limit detection (/CLT)</li> <li>Speed limit detection (/VLT)</li> <li>Brake (/BK)</li> <li>Warning (/WARN)</li> <li>Near (/NEAR)</li> <li>Signal allocations can be performed, and positive and negative logic can be changed.</li> </ul>	
		Interface	personal computer (can be connected with SigmaWin+)		
RS4 Com	RS422A Commu- nications	RS422A Commu- nications	N = Up to 15 stations possible at RS422A		
Communi - cations Function	(CN3)	Axis Address Setting	Set by parameter		
	USB	Interface	Personal computer	(can be connected with SigmaWin+)	
Commu- nications (CN7)		Communica- tions Standard	Complies with standard USB1.1. (12 Mbps)		
LED Display	1	•	Panel display (seven-segment), CHARGE, L1, L2, and CN indicators		
MECHATRO	DLINK-III	0.11.1	Rotary Switch (S1 and S2)	Position: 16 positions × 2 (Refer to $4.1.1$ )	
Communica	tions Setting	Switches	DIP Switch (S3)	Number of pins: Four pins (Refer to 4.1.1)	
Analog Monitor (CN5)		Number of points: 2 Output voltage: ± 10VDC (linearity effective range ± 8 V) Resolution: 16 bits Accuracy: ± 20 mV (Typ) Max. output current: ± 10 mA Settling time (± 1%): 1.2 ms (Typ)			
Dynamic Brake (DB)		Activated when a servo alarm or overtravelling occurs or when the power supply for the main circuit or servomotor is OFF.			
Regenerativ	e Processin	g	Included *2		
Overtravel Prevention (OT)		Dynamic brake stop, deceleration to a stop, or free run to a stop at P-OT or N-OT			
Protective Function		Overcurrent, overvoltage, insufficient voltage, overload, regeneration error, and so on.			



#### (cont'd)

Utility Function		Gain adjustment, alarm history, JOG operation, origin search, and so on.
	Input	/HWBB1, /HWBB2: Baseblock signal for power module
Safety Function	Output	EDM1: Monitoring status of internal safety circuit (fixed output)
	Standards *3	EN954 Category 3, IEC61508 SIL2

\*1. Speed regulation by load regulation is defined as follows:

No-load motor speed - Total load motor speed × 100% Speed regulation =

Rated motor speed

\*2. Refer to *1.3.1 Ratings* for details on regenerative resistors.\*3. Perform risk assessment for the system and be sure that the safety requirements are fulfilled.

### 1.3.3 MECHATROLINK-III Function Specifications

Function		Specifications
MECHATROLINK-III Communication	Communication Protocol	MECHATROLINK-III
	Station Address	03H to EFH (Max. number of stations: 62) Use the rotary switches S1 and S2 to set the station address.
	Baud Rate	100 Mpbs
	Transmission Cycle	125 $\mu s,~250~\mu s,~500~\mu s,~750~\mu s,$ and 1.0 ms to 4.0 ms (increments of 0.5 ms)
	Number of Transmis- sion Bytes	16, 32, or 48 bytes per station Use the DIP switch S3 to select the number of words.
Reference Method	Control Method	Position, speed, or torque control with MECHATROLINK- II communication
	Reference Input	MECHATROLINK-I, MECHATROLINK-II commands (sequence, motion, data setting/reference, monitoring, or adjustment)
	Profile	MECHATROLINK-III standard servo profile MECHATROLINK-II-compatible profile

The following table shows the specifications of MECHATROLINK-III.

### 1.4 DRIVER Internal Block Diagrams



1.4.2 Three-phase 200 V, LECYU2-V8 Model





### 1.4.3 Three-phase 200 V, LECYU2-V9 Models

### 1.5 Examples of Servo System Configurations

This section describes examples of basic servo system configuration.

### 1.5.1 Connecting to LECYU2-VI DRIVER

(1) Using a Three-phase, 200-V Power Supply



- \*1. Use a 24-VDC power supply. (Not included.)
- \*2. Before connecting an external regenerative resistors to the DRIVER, refer to 3.7 Connecting Regenerative Resistors.



(2) Using a Single-phase, 200-V Power Supply

The LECY Series 200 V DRIVER generally specifies a three-phase power input but some models can be used with a single-phase 200 V power supply. Refer to 3.1.3 Using the DRIVER with Single-phase, 200 V Power Input for details.



- \*1. Use a 24-VDC power supply. (Not included.)
- \*2. Before connecting an external regenerative option to the DRIVER, refer to 3.7 Connecting Regenerative Resistors.

### 1.6 DRIVER Model Designation

This section shows DRIVER model designation.



\*1. The lineup is done the standard item.

\*2. These amplifiers can be powered with single or three-phase.

\*If the I/O connector (CN1) is required, please order product code "LE-CYNA". (The I/O connector is not included)

### 1.7 Inspection and Maintenance

This section describes the inspection and maintenance of DRIVER.

#### (1) DRIVER Inspection

For inspection and maintenance of the DRIVER, follow the inspection procedures in the following table at least once every year. Other routine inspections are not required.

Item	Frequency	Procedure	Comments
Exterior		Check for dust, dirt, and oil on the surfaces.	Clean with compressed air.
Loose Screws	At least once a year	Check for loose terminal block and connector screws.	Tighten any loose screws.

#### (2) DRIVER's Parts Replacement Schedule

The following electric or electronic parts are subject to mechanical wear or deterioration over time. To avoid failure, replace these parts at the frequency indicated.

Refer to the standard replacement period in the following table and contact your Yaskawa representative. After an examination of the part in question, we will determine whether the parts should be replaced or not.



Part	Standard Replacement Period	Operating Conditions
Cooling Fan	4 to 5 years	
Smoothing Capacitor	7 to 8 years	Surrounding Air Temperature: Annual average of
Other Aluminum Electrolytic Capacitor	5 years	30°C • Load Factor: 80% max.
Relays	_	• Operation Rate: 20 hours/day max.
Fuses	10 years	
Battery	3 years*	

\* It is a standard value in the state of no energizing (state not to turn on power to the driver). The lifetime changes by condition and environment.

#### 1.8 Installation Environment and Applicable Standards

#### 1.8.1 DRIVER Installation Environment

- Surrounding air temperature: 0 to 55°C
- · Ambient humidity: 90% RH or less (with no condensation)
- Altitude: 1,000 m or less
- Vibration resistance: 4.9 m/s<sup>2</sup>
- Shock resistance:  $19.6 \text{ m/s}^2$

#### · Installation Precautions

• Mounting in a Control Panel

To prevent the temperature around the DRIVER from exceeding 55°C, take into account the size of the control panel, the layout of the DRIVER, and the cooling method. For details, refer to 1.9 DRIVER Installation.

• Mounting Near a Heating Unit

To prevent the temperature around the DRIVER from exceeding 55°C, suppress radiant heat from the heating unit and temperature rise due to convection.

• Mounting Near a Vibration Source

To prevent vibration from being transmitted to the DRIVER, install a vibration isolator underneath the DRIVER.

• Mounting to a Location Exposed to Corrosive Gas

Take measures to prevent exposure to corrosive gas. Corrosive gases will not immediately affect the DRIVER, but will eventually cause electronic components and contactor-related devices to malfunction.

• Other Locations

Do not mount the DRIVER in locations subject to high temperatures, high humidity, dripping water, cutting oil, dust, iron filings, or radiation.

#### <Note>

When storing the DRIVER with the power OFF, store it in an environment with the following temperature and humidity:

• -20 to +85°C, 90% RH or less. (with no condensation)

1-14

#### 1.8.2 Installation Conditions for Applicable Standards

Applicable	EN50178, EN55011/A2 group1 classA, EN61000-6-2, EN61800-3,
Standards	EN61800-5-1, EN954-1, IEC61508-1 to 4
Operating	Overvoltage Category: III
Operating	Pollution degree: 2
Conditions	Protection class: IP10
	Low Voltage Directive:
Installation Conditions	Satisfy the conditions outlined in 1.8.3 Conditions Corresponding to Low Voltage Directive of this manual.
	EMC Directive:
	Certification is required after installation in the user's machine under the conditions outlined in 3.8.3 EMC Installation
	Conditions of this manual.

### 1.8.3 Conditions Corresponding to Low Voltage Directive

To adapt DRIVERs to the Low Voltage Directive, make sure that the following environmental conditions are met.

- Installation category: III
- Pollution degree: 2
- Protection class: 10
- Altitude: 1000 m max.

Be sure to install a fuse for the main circuit power-supply as well as meeting these environmental conditions. To choose the fuse capacity, refer to 3.1.2 Using a Standard Power Supply (Three-phase 200 V).
## 1.9 DRIVER Installation

### 1.9.1 Orientation

Mount the DRIVER with a vertical orientation.

Firmly secure the DRIVER to the mounting surface, using either two or four mounting holes depending on the DRIVER capacity.



### 1.9.2 Installation Standards

Observe the standards for mounting DRIVERs in control panels, including those for the mounting DRIVERs side by side in one control panel as shown in the following illustration.

#### DRIVER Mounting Orientation

Mount the DRIVER vertically to the wall, with the front panel (the side with the panel operator display) facing out.

## Cooling

Refer to the following diagram and leave sufficient space for cooling by fans and natural convection.

#### • Mounting DRIVERs Side by Side in a Control Panel



Leave sufficient space on each side and at the top and the bottom of each DRIVER. The width on each side varies in accordance with the models of the DRIVERS used.

DRIVER Model	Side		Top and hottom	
LECY 2-	Left Right		Top and bottom	
V5, V7, V8	1 mm or more		10 mm on mono	
V9	1 mm or more	10 mm or more	40 mm or more	

Also install cooling fans above the DRIVERs to disperse local pockets of warmer air around the DRIVERs.



• Inside the Control Panel

The conditions inside the control panel should be the same as the environmental conditions of the DRIVER. Refer to *1.8.1 DRIVER Installation Environment*.

The DRIVERs have an Installation Environment monitor. With this monitor, operation conditions in the nstallation environment can be observed and measured.

The value shown on this monitor should be equal to or less than 100% for optimum operating conditions. If this value is over 100%, one of the following measures must be taken to ensure safe operation and a long product life.

• Improve air circulation around DRIVERs.

Minimum Air Circulation Rate

Top (10 mm): 0.5 m/s

Bottom (10 mm): 0.2 m/s

To improve the air circulation to meet these minimum standards and to lower the percentage shown on the monitor, widen the space between the DRIVERs or lower the temperature of the surrounding air.

<Note>

For every increase of 10°C, the percentage shown on the monitor will also increase by approximately ten.

2. Panel Display and Operation of SigmaWin+	2
2.1 Panel Display	2
2.1.1 Status Display	2
2.1.2 Alarm and Warning Display	2
2.1.3 Hard Wire Base Block Display	2
2.1.4 Overtravel Display	2
2.2 Operation of SigmaWin+ <sup>TM</sup>	
2.2.1 Compatible Devices	
2.2.2 Hardware requirements	
2.2.3 Installing SigmaWin+ Program	
2.2.4 Starting SigmaWin+	12
2.3 Utility Functions	15
2.4 Parameters	15
2.4.1 Parameter Classification	15
2.4.2 Notation for Parameters	16
2.4.3 Setting Parameters	16
2.5 Monitor Displays	16

## 2. Panel Display and Operation of SigmaWin+

## 2.1 Panel Display

The servo status can be checked on the panel display of the DRIVER. Also, if an alarm or warning occurs, its alarm or warning number is displayed.

## 2.1.1 Status Display

The display shows the following status.

Display	Meaning
	Rotation Detection (/TGON) Lights if motor speed exceeds the value set in Pn502. (Factory setting: 20 min <sup>-1</sup> )
	Baseblock Lights for baseblock (Servomotor power OFF).
	Reference Input Lights when a reference is being input.
_   _ .	CONNECT Lights during connection.

## 2.1.2 Alarm and Warning Display

If an alarm or warning occurs, the display will change in the following order. Example: Alarm A.E60



"6" of the figure, "b" of the alphabet, and "d" are displayed as follows.



## 2.1.3 Hard Wire Base Block Display

If a hard wire base block (HWBB) occurs, the display will change in the following order.



### 2.1.4 Overtravel Display

If overtravelling occurs, the display will change in the following order.

①Overtravel at forward rotation (P-OT)
③Overtravel at forward/reverse rotation

status	→₽┐
--------	-----

•	Current status	→₽→п
---	-------------------	------

② Overtravel at reverse rotation (N-OT)

$$\rightarrow n$$

## 2.2 Operation of SigmaWin+<sup>™</sup>

SigmaWin+ is a setup software for setup and optimum DRIVER tuning of LECY series. Please download the install program from our home page.

SigmaWin+<sup>TM</sup> is the registered trademarks of YASKAWA ELECTRIC Corporation.

## 2.2.1 Compatible Devices

- LECYM series
- LECYU series

## 2.2.2 Hardware requirements

When using setup software (SigmaWin+<sup>TM</sup>), use a DOS/V PC/AT compatible PC that meets the following operating conditions.

	Equipment	Description	
		• Windows® XP *5	
	OS	Windows® Vista	
		• Windows® 7 (32 bit/ 64 bit)	
PC *1 *2 *3		350 MB or more of free space	
*4	Hard Disk	(When the software is installed, 400MB or more is empty	
		recommended.)	
	Communication	Lice LICD port	
	interface	Use USB polt	
		XVGA monitor (1024×768 or more, "The small font is used.")	
Display		256 color or more (65536 color or more is recommended)	
		Connectable with the above personal computer.	
Keyboard		Connectable with the above personal computer.	
Mouse		Connectable with the above personal computer.	
Printer		Connectable with the above personal computer.	
USB cable		LEC-JZ-CVUSB *6	
Other		Adobe Reader Ver.5.0 or more (*Ver.6.0 is excluded.)	

\*1. Windows, Windows Vista and Windows 7 are the registered trademarks of Microsoft Corporation in the United States and other countries.

- \*2. On some personal computers, SigmaWin+ may not run properly.
- \*3. 64-bit Windows® XP and 64-bit Windows® Vista are not supported.
- \*4. Use Windows® XP: Please use it by the administrator authority (When installing and using it.).
- \*5. In PC that uses the program to correct the problem of HotfixQ328310, it is likely to fail in the installation. In that case, please use the program to correct the problem of HotfixQ329623.
- \*6. Order USB cable separately.

## 2.2.3 Installing SigmaWin+ Program

To install SigmaWin+, run the setup file for SigmaWin+. And the installation process will begin. In this process, SigmaWin+ and the related files will be installed, or stored on the hard disk.

Operating conflicts may arise with the other programs during installation. Be sure to close all other programs before installing SigmaWin+.

SMC

Install the program using the following procedure.

- 1. Please download the install program from our home page.
- 2. "SETUP.EXE" of the file is double-clicked.

Signalirin+ English Edition setup		
SigmaWin+ English Edition Ve	ar1.00	
Sign/Win+ English Edition :	edup 🖬	
20	Welcome to the InstalSheld Waved for SigneWin+ English Edition	
	The InstallSheld® Witaed will instal Signa/Wita-English Editors on your poepades. To continues, dick Next.	
	Since Next	

A message will appear, welcoming you to the SigmaWin+ program.

igmaWin+ En	glish Edition Ver1.00	
	0	
	Signa/Wine English Edition onlas	
	Choose Destination Location	
	Selectricide: where Setup will includ lifes.	
	Setup will install Signal-Vin+ English Editors in the following tokies	
	To install to this fulder, click Next. To install to a different folder, click Biowse and select and her folder.	
	. Dantin dan Kullar	
	Difference Chairford DC	
	Unrageer service	
	Lexist 2 red 4	
	c Bark E Berch Carrel	
	- Town [ _ Town ]	

3. Click Next to continue.s

4. Follow the onscreen instructions to choose a destination folder to copy the SigmaWin+ file to, and click Next to continue.

Signal-Final English Edition selep		
SigmaWin+ English	t Edition Ver1.00	
	instalies Reduk Falline autor	
	Series Type Orces the samp type that best sub, your read.	
	Claik the tape of Serup you peeles.	
	Cancor Sing Part and Part Part of Sing Part and Sing Part and Sing Part of Sing Par	
	-0.21x3	
	(gack Ment) Concel	

5. Select the setup type. Choose "Normal Setup" and click Next.

😹 Signadelan English Editor setup	
SigmaWin+ English Edition Ver1 00	
Signari in Chighan Dalation (Cr1.00	
Signaterine English Edition astop	
Select Program Fakler	
Hearo referi a program tóde:	
Setup will add pogram journ to the Program Fulder listed below. You may tupe a new fulder	
name, as relactions from the estimated tables for. Click Next to continue.	
Brigan Follow	
Description of the second seco	
Egiting Fiddes	
State State Look Language	
AND	
(Book Metri Carcel	

6. Select the program group to create the SigmaWin+ icon. "YE\_Applications" is the default setting. After selecting the program group or folder, click **Next** to continue.

Signal Fire English Edition setup			
SigmaWin+ Englis	sh Edition Ver1.00		
- inginiario in Canigin			
	Signal/in- English Editor setup	×	
	Sellep Statur	N.	
	Signativite + English Editor Setup is performing the requested operations.		
	hat the Simplefier Facility Faller		
	100		
	seguration of the second se		
		Carcel	

Then the PC files are copied. The percentage of the copying that has been completed is shown.

Note: If new versions of the PC support files are needed to install SigmaWin+, a window will appear asking whether to overwrite the current version or to cancel the installation. SigmaWin+ may not run correctly if the new versions of the support files are not installed.

If SigmaWin+ has been successfully installed, one of two dialog boxes is displayed.

SigmaWin+ English Edition Veri	1.00	AL A
Signalwine English Editor robo	•	
년 전 <sup>·</sup>	ratal/Shield Wased Complete	
	dan ga kan ferdind i natilego (gunivi) - English Editor ne puz mingdan	
	State Contraction Const.	
	(a)	



If dialog box (a) is displayed, click **Finish** to complete the setup.

7. If dialog box (b) is displayed, select **Yes** when asked if you want to restart the computer and then click **Finish** to complete the setup.

The LECY\* USB driver cannot be installed by using the SigmaWin+ installer.

When a SigmaWin+ equipped PC is connected to the LECY\* through a USB connection, use the following procedure to install the USB driver.

The installation method will vary depending on the operating system (hereinafter referred to as OS). Use the correct procedure for your OS.

The installation procedure is explained assuming that the SigmaWin+ installed folder directory is "C:¥Program Files¥SigmaIDE" and that the CD-ROM drive is D drive. Use the folder directory and drive according to the settings of your PC.

### - For Windows 7/Vista

- 1. Turn on the power to the PC to start Windows 7 or Vista.
- 2. Confirm that SigmaWin+ has been installed. If it has not yet been installed, please install.
- 3. Connect the LECY\* to the PC using a USB cable, and then turn on the power to the LECY\*. The following message will appear.

リ Driver Software Installation	<b>×</b>
Device driver software was	not successfully installed
YASKAWA SIGMA SERIES	XNo driver found
You can change your setting to auto Change setting What can I do if my device did not in	omatically search Windows Update for drivers
	Close

## 4. Click Close.

5. On the Start menu, right-click Computer and select Properties. The property window will appear.6. Select Device Manager. The following window will appear.

Bevice Manager	
File Action View Help	
⊨ ⇒   π   🖻   🛛 🖬   👰   😭 🕀 📭	
Human Interface Devices	
Gamma IDE ATA/ATAPI controllers	
Keyboards	
Mice and other pointing devices	
Monitors	
🖗 👰 Network adapters	
Other devices	
VASKAWA SIGMA SERIES	
Ports (COM & LPT)	
Processors	
Sound, video and game controllers	
> 📲 System devices	
🔈 🚽 Universal Serial Bus controllers	

7. Right-click YASKAWA SIGMA SERIES and select Update Drive Software...

8. Select Browse my computer for driver software. The following window will appear.

DIOW	se for unver softwar	e on your comput	er		
Search	for driver software in this l	ocation:			
D:\Dr	iver\USB		•	Browse	

- 9. Select the Include subfolders check box. Click Browse to select the folder.
  - < For Windows 7 (32 bit) or Windows Vista >
  - "C:\Program Files\SigmaIDE\SigmaWinPlus\Driver\USB"
  - < For Windows 7 (64 bit) >
  - "C:\Program Files (x86)\SigmaIDE\SigmaWinPlus\Driver\USB\x64"
- 10. Click Next.

Installation starts by copying the necessary files. Wait until a message appears informing you that the installation is finished.

< If a Security Error Message is Displayed >

Select Install this driver software anyway.

	×
😡 🗕 Update Driver Software - SIGMA Series USB Device	
Windows has successfully updated your driver software	
Windows has finished installing the driver software for this device:	
SIGMA Series USB Device	
	Close

11. When the installation is finished, click **Close**. This completes the driver installation.

## - For Windows XP

1. Turn on the power to the PC to start Windows XP.

2. Confirm that SigmaWin+ has been installed. If it has not yet been installed, please install.

3. Connect the LECY\* to the PC using a USB cable, and then turn on the power to the LECY\*. The Found New Hardware Wizard will appear.

Found New Hardware Wizard					
	Welcome to the Found New Hardware Wizard				
	This wizard helps you install software for:				
	SIGMA Series USB Device				
	<ul> <li>If your hardware came with an installation CD or floppy disk, insert it now.</li> <li>What do you want the wizard to do?</li> <li>Install the software automatically (Recommended)</li> <li>Install from a list or specific location (Advanced)</li> </ul>				
	Click Next to continue.				
	< <u>B</u> ack <u>N</u> ext > Cancel				

4. Confirm that the Install from a list or specified location [Advanced] option is selected, and then click Next. The next Wizard will appear.

Found New Hardware Wizard
Please choose your search and installation options.
⊙ Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM)
✓ Include this location in the search:
D:\Driver\USB\Win2000_XP Browse
Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
<u>≺B</u> ack <u>N</u> ext≻ Cancel

- 5. Select the **Search for the best driver in these locations.** option and then select the **Include this location in the search:** check box. Click **Browse** to select the folder "C:¥Program Files¥SigmaIDE¥SigmaWinPlus¥Driver¥USB".
- 6. Click **Next**. The Wizard starts installation by copying the necessary files. Wait until a message appears informing you that the installation is finished.

Found New Hardware Wizard					
	Completing the Found New Hardware Wizard				
	The wizard has finished installing the software for:				
	SIGMA Series USB Device				
	Click Finish to close the wizard.				

- 7. When the installation is finished, click Finish. This completes the driver installation.
- Confirming the Installation Status

Use the following procedure to make sure that the system recognizes the LECY\* as a USB device and that the USB driver is installed correctly.

- 1. Click the Start button, point to Settings, and click Control Panel.
- 2. Double-click the System icon. The System Properties window will appear.
- 3. Click the **Hardware** tab and then click **Device Manager**. The Device Manager window will appear.



4. Double-click SIGMA Series USB Device in the YASKAWA ELECTRIC CORP. USB Device folder. The SIGMA Series USB Device Properties window will appear.

2-11

SIGMA Se	ries USB Device I	Properties		? X	
General	Driver				
÷	SIGMA Series US	iB Device			
	Device type:	YASKAWA ELI	ECTRIC CORP. U	SB Device	
	Manufacturer:	YASKAWA ELI	ECTRIC CORPOR	RATION	
	Location:	YASKAWA SIG	MA SERIES		
This If you start	Device status This device is working properly. If you are having problems with this device, click Troubleshooter to start the troubleshooter. Troubleshooter				
Device	usage:				
Use th	is device (enable)				
			ОК	Cancel	

5. Make sure "This device is working properly." is displayed in the **Device status** field. When "This device is working properly." is displayed, the LECY\* is ready to be used through a USB connection. If it is not displayed, reinstall the USB driver.

### 2.2.4 Starting SigmaWin+

(1) Start SigmaWin+

Start SigmaWin+:

- from the Start menu
- from a shortcut

- From the Start Menu

- To start SigmaWin+ from the Start menu:
- 1. Click the Start button, and point to Programs.
- 2. Open the YE\_Applications folder.
- 3. Click SigmaWin+.
- From a Shortcut
  - To start SigmaWin+ from a shortcut on the desktop:
  - 1. Open the YE\_Applications folder on the desktop.
  - 2. Click SigmaWin+.
- (2) Selecting a DRIVER

When SigmaWin+ is in initially started, the Connect dialog box appears. Enter the settings for communications between SigmaWin+ and the DRIVER by means of a communication port.

i usa l	P. com/ 89, 2220			Ct Search
late No.	Servopack	Sevender	Application module	Axtx name

Select the method to set up the DRIVER: online or offline. Online is the default setting.

Online: Select when setting up or tuning the servo drive with the DRIVER connected Offline: Select when editing parameters or checking screens for tracing or mechanical analysis without the DRIVER connected

<When Offline is selected>



Select the  $\Sigma V$  and click Starting. The SigmaWin+ main window will appear.

				C Search
Use	♀ COM4.RS-232C	MECHATROLINK-I		
lads No.	Servopack	Servanatar	Application module	Axtx name

<When Online is selected>

Enter the necessary settings for communication setup.

(1) Click Search.



(2) Click  $\Sigma V$ . Then Click Search.

After the DRIVERs have been successfully connected to SigmaWin+, a list of the connected DRIVERs will appear on the screen.

068	🖳 COM1/RS-422   💦	MECHATROLINK-I		Cl2 Search
Usie No.	Servopack	Servanolar	Application module	Axis name
	SODV-1R6A01A	S0M4S-01 ACA21		

DRIVER Selection Box

(3) Select the DRIVER to be connected and then click Connect, or just doubleclick the DRIVER to be connected. The SigmaWin+ main window will appear. Click Cancel to close the dialog box.

Operation examples of utility functions, parameters and monitor displays when using a SigmaWin+ are described in this chapter.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL Σ-V Component.

### 2.3 Utility Functions

The utility functions are related to the setup and adjustment of the DRIVER. Refer to *6 utility functions* for details.

## 2.4 Parameters

This section describes the classifications, methods of notation, and settings for parameters given in this manual.

## 2.4.1 Parameter Classification

Parameters of the LECY Series DRIVER are classified into two types of parameters. One type of parameters is required for setting up the basic conditions for operation and the other type is required for tuning parameters that are required to adjust servomotor characteristics.

Classification	Meaning	Display Method	Setting Method
Setup Parameters	Parameters required for setup.	Always displayed (Factory setting: $Pn00B.0 = 0$ )	Set each parameter individu- ally.
Tuning Parameters	Parameters for tuning con- trol gain and other parame- ters.	Set Pn00B.0 to 1.	There is no need to set each parameter individually.

There are two types of notation used for parameters, one for parameter that requires a value setting (parameter for numeric settings) and one for parameter that requires the selection of a function (parameter for selecting functions).

The notation and settings for both types of parameters are described next.

## 2.4.2 Notation for Parameters

## (1) Parameters for Numeric Settings



## 2.4.3 Setting Parameters

In the SigmaWin+ $\Sigma$ -V component main window, click **Parameters** and then click **Edit Parameters**. The Parameter Editing window for the online mode appears.

For more information on the usage of the setting parameters, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component.

### 2.5 Monitor Displays

The monitor displays can be used for monitoring the reference values, I/O signal status, and DRIVER internal status.

The System Monitor window will automatically open when the SigmaWin+ starts. Or, in the SigmaWin+  $\Sigma$ -V component window, click **Monitor**, point to **Monitor**, and then click **System Monitor**.

For more information on the usage of the monitor display, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component.

3.	Wiring and Connection	2
	3.1 Main Circuit Wiring	2
	3.1.1 Main Circuit Terminals	2
	3.1.2 Using a Standard Power Supply (Three-phase 200 V)	3
	3.1.3 Using the DRIVER with Single-phase, 200 V Power Input	7
	3.1.4 Using the DRIVER with a DC Power Input	10
	3.1.5 Using More Than One DRIVER	12
	3.1.6 General Precautions for Wiring	13
	3.1.7 Specifications of motor cables and encoder cables	14
	3.2 I/O Signal Connections	16
	3.2.1 /O Signal (CN1) Names and Functions	16
	3.2.2 Safety Function Signal (CN8) Names and Functions	17
	3.2.3 Example of I/O Signal Connections	18
	3.3 I/O Signal Allocations	19
	3.3.1 Input Signal Allocations	19
	3.3.2 Output Signal Allocations	21
	3.4 Examples of Connection to PC or PLCetc	22
	3.4.1 Sequence Input Circuit	22
	3.4.2 Sequence Output Circuit	23
	3.5 Wiring MECHATROLINK-III Communications	25
	3.6 Encoder Connection	26
	3.6.1 Encoder Signal (CN2) Names and Functions	26
	3.6.2 Encoder Connection Examples	27
	3.7 Connecting Regenerative resistors	28
	3.7.1 Connecting Regenerative Resistors	29
	3.7.2 Setting Regenerative resistors Capacity	30
	3.8 Noise Control and Measures for Harmonic Suppression	31
	3.8.1 Wiring for Noise Control	31
	3.8.2 Precautions on Connecting Noise Filter	33
	3.8.3 EMC Installation Conditions	35
	3.9 Specification of option cables	41

# 3. Wiring and Connection

## 3.1 Main Circuit Wiring

The names and specifications of the main circuit terminals are given below. Also this section describes the general precautions for wiring and precautions under special environments.

3.1.1 Main Circuit Terminals



Terminal Symbols	Name	Specification
L1, L2, L3	Main circuit power input terminals	Three-phase 200 to 230 V, +10% to -15% (50/60 Hz)
L1C, L2C	Control power input terminals	Single-phase 200 to 230 V, +10% to -15% (50/60 Hz)
B1/⊕, B2 <sup>*1</sup>	Regenerative resistor connection terminals	If the internal regenerative resistor is insufficient, connect a regenerative resistor between $B1/\bigoplus$ and $B2$ . If LECYM2-V9 is used, remove the lead or shorting bar between B2 and B3, and connect a regenerative resistor between $B1/\bigoplus$ and B2. Note: The Regenerative resistor is not included.
⊖1, ⊖2	DC reactor connection terminal for power supply harmonic suppression	connection terminals are short-circuited when the DRIVER is shipped from the factory: $\Theta 1$ and $\Theta 2$ .
B1/	Main circuit positive terminal	Use when DC power supply input is used.
⊖2 or⊖	Main circuit negative terminal	
U, V, W	Servomotor connection terminals	Use for connecting to the servomotor.
	Ground terminals (× 2)	Use for connecting the power supply ground terminal and servomotor ground terminal.

\*1. Do not short-circuit between  $B1/\bigoplus$  and B2. It may damage the DRIVER.



## 3.1.2 Using a Standard Power Supply (Three-phase 200 V)

## (1) Wire Types

Use the following type of wire for main circuit.

	Cable Type	Allowship Conductor Terroperature °C
Symbol	Symbol Name Allowable Conductor I	
IV	600 V grade polyvinyl chloride insulated wire	60
HIV	600 V grade heat-resistant polyvinyl chloride insulated wire	75

The following table shows the wire sizes and allowable currents for three wires. Use wires with specifications equal to or less than those shown in the table.

- 600 V	grade heat-resistant	polyvinyl chloride	insulated wire (HIV)
	0		

AWG Size	Wire size (Nominal Cross	Configuration (Number of	Conductive Resistance	Allowable Current at Surrounding Air Temperature (A)			
7 11 10 0120	Section Area) (mm <sup>2</sup> )	Wires/mm <sup>2</sup> )	(Ω/km)	30°C	40°C	50°C	
20	0.5	19/0.18	39.5	6.6	5.6	4.5	
19	0.75	30/0.18	26.0	8.8	7.0	5.5	
18	0.9	37/0.18	24.4	9.0	7.7	6.0	
16	1.25	50/0.18	15.6	12.0	11.0	8.5	
14	2.0	7/0.6	9.53	23	20	16	

Note: The values in the table are for reference only.

## (2) Main Circuit Wires

This section describes the main circuit wires for DRIVERs.

The specified wire sizes are for use when the three lead cables are bundled and when the rated electric current is applied with a surrounding air temperature of 40°C.
 Use a wire with a minimum withstand voltage of 600 V for the main circuit.
 If cables are bundled in PVC or metal ducts, take into account the reduction of the allowable current.
 Use a heat-resistant wire under high surrounding air or panel temperatures, where polyvinyl chloride insulated wires will rapidly deteriorate.

## - Three-phase, 200 V

Terminal	Name	LECYM2-DD				
Symbols	Nume	V5	V7	V8	V9	
L1, L2, L3	Main circuit power in- put terminals	HIV1.25		HIV	/2.0	
L1C, L2C	Control power input terminals	HIV1.25				
U, V, W	Servomotor connec- tion terminals	HIV1.25 HIV2.0		/2.0		
B1/⊕ , B2	External regenerative resistor connection terminals	HIV1.25				
	Ground terminal	HIV2.0 or larger				

(3) Typical Main Circuit Wiring Examples

Note the following points when designing the power ON sequence.

- Design the power ON sequence so that main power is turned OFF when a servo alarm signal (ALM) is output.
- The ALM signal is output for a maximum of five seconds when the control power is turned ON. Take this into consideration when designing the power ON sequence. Design the sequence so the ALM signal is activated and the alarm detection relay (1Ry) is turned OFF to stop the main circuit's power supply to the DRIVER.



• Select the power supply specifications for the parts in accordance with the input power supply.



• When turning ON the control power supply and the main circuit power supply, turn them ON at the same time or turn the main circuit power supply after the control power supply. When turning OFF the power supplies, first turn the power for the main circuit OFF and then turn OFF the control power supply.

The typical main circuit wiring examples are shown below.



• Do not touch the power supply terminals after turning OFF the power. High voltage may still remain in the DRIVER, resulting in electric shock. When the voltage is discharged, the charge indicator will turn OFF. Make sure the charge indicator is OFF before starting wiring or inspections.

- Three-phase200V,LECYU2-V□



\* For the LECYU2-V5, V7, V8, terminals B2 and B3 are not short-circuited.

Do not short-circuit these terminals.

### (4) Power Supply Capacities and Power Losses

The following table shows the DRIVER's power supply capacities and power losses.

Main Circuit Power Supply	Maximum Applicable Servomotor Capacity [kW]	DRIVER Model LECYU2-□□	Power Supply Capacity per DRIVER [kVA]	Output Current [Arms]	Main Circuit Power Loss [W]	Regenerative Resistor Power Loss [W]	Control Circuit Power Loss [W]	Total Power Loss [W]	
	0.1	V5	0.3	0.91	7.3	-	-		24.3
Three-	0.2	V7	0.6	1.6	13.5			17	30.5
200 V	0.4	V8	1	2.8	24.0		1/	41.0	
	0.75	V9	1.6	5.5	43.8	8	•	68.8	

Note 1. LECYU2-V5, V7, and V8 do not have built-in regenerative resistors. Connect an external regenerative resistors if the regenerative energy exceeds the specified value.

Regenerative resistor power losses are the allowable losses. Take the following actions if this value is exceeded.
 Remove the lead or shorting bar between terminals B2 and B3 on the DRIVER main circuit for LECYU2-V9.
 Install an external regenerative resistors. Refer to 3.7 Connecting Regenerative Resistors for details.

3. Both the regenerative resistor unit and the external regenerative resistors are not included.



(5) How to Select Molded-case Circuit Breaker and Fuse Capacities

The following table shows the DRIVER's current capacities and inrush current. Select a molded-case circuit breaker and fuses in accordance with these specifications.

Main Circuit	Maximum		Power Sup-	Current	Capacity	Inrush Current		
Power Supply	Servomotor Capacity [kW]	Model per LECYU2 DRIVER -□□ [kVA]		Main Circuit [Arms]	Control Circuit [Arms]	Main Circuit [A0-p]	Control Circuit [A0-p]	
	0.1	V5	0.3	1.0				
Three-	0.2	V7	0.6	2.0	0.2	0.2 22	70	
phase, 200 V	0.4	V8	1	3.0	0.2 33			
	0.75	V9	1.6	6.0			33	

Note 1. To comply with the EU low voltage directive, connect a fuse to the input side as protection against accidents caused by short-circuits.

Select fuses or molded-case circuit breakers that are compliant with UL standards.

The table above also provides the net values of current capacity and inrush current. Select a fuse and a moldedcase circuit breaker which meet the breaking characteristics shown below.

- Main circuit, control circuit: No breaking at three times the current values shown in the table for 5 s.

- Inrush current: No breaking at the current values shown in the table for 20 ms.

## 3.1.3 Using the DRIVER with Single-phase, 200 V Power Input

LECYU2 series three-phase 200 V power input DRIVER can be used also with a single-phase 200 V power supply.

When using the DRIVER with single-phase, 200 V power input, set parameter Pn00B.2 to 1.

- (1) Parameter Setting
  - Single-phase Power Input Selection

Parameter		Meaning	When Enabled	Classification
Pn00B	n.□0□□ [Factory setting]	Enables use of three-phase power supply for three-phase DRIVER.	After restart	Setun
	n.¤1¤¤	Enables use of single-phase power supply for three-phase DRIVER.	1 Hiter restart	Setup



## (2) Main Circuit Power Input Terminals

Connect a single-phase 200 V power supply of the following specifications to L1 and L2 terminals.

The specifications of the power supplies other than the main circuit power supply are the same as for three- phase power supply input.

Terminal Sym- bols	Name	Specifications		
L1, L2 Main circuit power input terminals		Single-phase 200 V to 230 V, +10% to -15% (50/60 Hz)		
L3 <sup>*1</sup>	_	None		

- \*1. Do not use L3 terminal.
- (3) Main Circuit Wire for DRIVERs

Terminal	Name	Model LECYU2-				
Symbols	hame		V7	V8	V9	
L1, L2	Main circuit power input terminals	HIV1.25 HIV2.0			/2.0	
L1C, L2C	Control power input terminals	HIV1.25				
U, V, W	Servomotor connection terminals	HIV1.25			HIV2.0	
B1/⊕, B2	External regenerative resistors con- nection terminals	HIV1.25				
٢	Ground terminal		HIV2.0	or larger		

- (4) Wiring Example with Single-phase 200-V Power Supply Input
  - DRIVER with Single-phase, 200-V Power Supply





(5) Power Supply Capacities and Power Losses

The following table shows DRIVER's power supply capacities and power losses when using single- phase 200 V power supply.

Main Circuit Power Supply	Maximum Applicable Servomotor Capacity [kW]	DRIVER Model LECYU2-□□	Power Supply Capacity per DRIVER [kVA]	Output Current [Arms]	Main Circuit Power Loss [W]	Regenerative Resistor Power Loss [W]	Control Circuit Power Loss [W]	Total Power Loss [W]
Single-phas	0.1	V5	0.3	0.91	7.4			24.4
e, 200 V	0.2	V7	0.7	1.6	13.7	-	17	30.7
	0.4	V8	1.2	2.8	24.9			41.9
	0.75	V7	1.9	5.5	52.7	8		77.7

Note 1. LECYU2-V5, V7, and V8 DRIVERs do not have built-in regenerative resistors. If the regenerative energy exceeds the specified value, connect an external regenerative resistors between B1/⊕ and B2.

Regenerative resistor power losses are allowable losses. Take the following action if this value is exceeded.
 Remove the lead or shorting bar between terminals B2 and B3 on the DRIVER main circuit of LECYU2-V7 DRIVER.

- Install an external regenerative resistors between external regenerative resistors connection terminals  $B1/\oplus$  and B2.

(6) How to Select Molded-case Circuit Breaker and Fuse Capacities

The following table shows the DRIVER's current capacities and inrush current when using single-phase 200 V power supply. Select a molded-case circuit breaker and fuses in accordance with these specifications.

Main Circuit	Maximum	Power Supp		Current Capacity		Inrush Current	
Power Supply	Applicable Servomotor Capacity [kW]	DRIVER Model LECYU2-□□	Capacity per DRIVER [kVA]	Main Circuit [Arms]	Control Circuit [Arms]	Main Circuit [A0-p]	Control Circuit [A0-p]
Single-phase, 200 V	0.1	V1	0.3	2		22	70
	0.2	V2	0.7	3	0.2		
	0.4	V4	1.2	5	0.2	33	
	0.75	V7	1.9	9			33

Note 1. To comply with the EU low voltage directive, connect a fuse to the input side as protection against accidents caused by short-circuits. Select the fuse for the input side that are compliant with UL standards. The table above also provides the net values of current capacity and inrush current. Select a fuse and a molded- case circuit breaker which meet the breaking characteristics shown below.

•Main circuit, control circuit: No breaking at three times the current values shown in the table for 5 s. •Inrush current: No breaking at the current values shown in the table for 20 ms.

## 3.1.4 Using the DRIVER with a DC Power Input

(1) Parameter Setting

When using a DC power supply, make sure to set the parameter Pn001.2 to 1 (DC power input supported) before inputting DC power.

Parameter		Meaning	When Enabled	Classification
Pn001	n.口0口口	Enables use of AC power input.	A fter restart	Setun
FIIUUT	$n.\Box 1 \Box \Box$ Enables use of DC power input.		inter restart	Betup

Observe the following precautions.

<ul> <li>Either AC or DC power can be input to the 200-V DRIVERs. Always set Pn001.2 to 1 to specify a DC power input before inputting DC power. If DC power is input without changing the parameter setting, the DRIVER's internal elements will burn and may cause fire or damage to the equipment.</li> <li>With a DC power input, time is required to discharge electricity after the main power supply is turned OFF. A high residual voltage may remain in the DRIVER after the power supply is turned OFF. Be careful not to get an electric shock.</li> <li>Install fuses on the wires if DC power is used.</li> <li>Servomotor returns a regenerated energy to the power supply. The DRIVER that can use a DC power</li> </ul>
<ul> <li>supply is not capable of processing the regenerated energy. Provide measures to process the regenerated energy on the power supply.</li> <li>With a DC power input, connect an external inrush current limit circuit.</li> <li>Failure to observe this caution may result in damage to the equipment.</li> </ul>

(2) DC Power Supply Input Terminals for the Main and Control Circuits

Terminal Symbols	Name	Specifications
B1/⊕	Main circuit positive terminal	270 to 320 VDC
⊖2	Main circuit negative terminal	0 VDC
L1C, L2C	Control power input terminal	200 to 230 VAC

(3) Wiring Example with DC Power Supply Input



1FLT: Noise filter

1PL: Indicator lamp 1SA: Surge absorber 2SA: Surge absorber 3SA: Surge absorber

2KM: Magnetic contactor (for main circuit power supply)

1KM: Magnetic contactor (for control power supply)

1Ry: Relay

1D: Flywheel diode

### 3.1.5 Using More Than One DRIVER

This section shows an example of the wiring and the precautions when more than one DRIVER is used.

## (1) Wiring Example

Connect the alarm output (ALM) terminals for three DRIVERs in series to enable alarm detection relay 1RY to operate. When the alarm occurs, the ALM output signal transistor is turned OFF.



(2) Precautions

Multiple DRIVERs can share a single molded-case circuit breaker (1QF) or noise filter. Always select a molded-case circuit breaker or noise filter that has enough capacity for the total power supply capacity (load conditions) of the DRIVERs.

## 3.1.6 General Precautions for Wiring

IMPORTANT	<ul> <li>Use a molded-case circuit breaker (1QF) or fuse to protect the main circuit. The DRIVER connects directly to a commercial power supply; it is not isolated through a transformer or other device. Always use a molded-case circuit breaker (1QF) or fuse to protect the servo system from accidents involving different power system voltages or other accidents.</li> <li>Install a ground fault detector. The DRIVER does not have a built-in protective circuit for grounding. To configure a safer system, install a ground fault detector against overloads and short-circuiting, or install a ground fault detector combined with a molded-case circuit breaker.</li> <li>Do not turn the power ON and OFF more than necessary.</li> <li>Do not use the DRIVER for applications that require the power to turn ON and OFF frequently. Such applications will cause elements in the DRIVER to deteriorate.</li> <li>As a guideline, at least one hour should be allowed between the power being turned ON and OFF once actual operation has been started.</li> </ul>
-----------	--

To ensure safe, stable application of the servo system, observe the following precautions when wiring. Design and arrange the system so that each cable will be as short as possible.

- Use shielded twisted-pair cables or screened unshielded twisted-pair cables for I/O signal cables and encoder cables.
- The maximum wiring length is 3 m for I/O signal cables, 50 m for encoder cables or motor cables.
- Observe the following precautions when wiring the ground.
- Use a cable as thick as possible (at least 2.0 mm<sup>2</sup>).
- Grounding to a resistance of  $100 \Omega$  or less for 200-V DRIVER is recommended.
- Be sure to ground at only one point.
- Ground the servomotor directly if the servomotor is insulated from the machine.

The signal cable conductors are as thin as 0.2 mm<sup>2</sup> or 0.3 mm<sup>2</sup>. Do not impose excessive bending force or tension.

3.1.7 Specifications of motor cables and encoder cables							
		Servo		Order No.			
Name	Lock	motor	Length	Standard	Robot	Specifications	Details
Hamo	Look	Rated	Longar	LE-CYn-SnA-n	LE-CYn-RnA-n		Dotano
		Output	-				
			3m	LE-CYM-S3A-5	LE-CYM-R3A-5		
		100W	5m	LE-CYM-S5A-5	LE-CYM-R5A-5		
			10m	LE-CYM-SAA-5	LE-CYM-RAA-5		
			20m	LE-CYM-SCA-5	LE-CYM-RCA-5	DDIVED End	
			3m	LE-CYM-S3A-7	LE-CYM-R3A-7	Servomotor End	
Motor	without	200W	5m	LE-CYM-S5A-7	LE-CYM-R5A-7	50 mm L	(1)
cable	lock	400W	10m	LE-CYM-SAA-7	LE-CYM-RAA-7		(.)
			20m	LE-CYM-SCA-7	LE-CYM-RCA-7	Wire Markers	
			3m	LE-CYM-S3A-9	LE-CYM-R3A-9	M4 Crimped Terminals	
		750\\/	5m	LE-CYM-S5A-9	LE-CYM-R5A-9	-	
		75000	10m	LE-CYM-SAA-9	LE-CYM-RAA-9		
		20m	LE-CYM-SCA-9	LE-CYM-RCA-9			
		3m	LE-CYB-S3A-5	LE-CYB-R3A-5			
		100W	5m	LE-CYB-S5A-5	LE-CYB-R5A-5		
			10m	LE-CYB-SAA-5	LE-CYB-RAA-5		
			20m	LE-CYB-SCA-5	LE-CYB-RCA-5	DRIVER End	
Matar			3m	LE-CYB-S3A-7	LE-CYB-R3A-7	50 mm L	
	with	200W	5m	LE-CYB-S5A-7	LE-CYB-R5A-7		(2)
	lock	400W	10m	LE-CYB-SAA-7	LE-CYB-RAA-7		(2)
WITTIOCK			20m	LE-CYB-SCA-7	LE-CYB-RCA-7	Wire Markers	
			3m	LE-CYB-S3A-9	LE-CYB-R3A-9	M4 Crimped Terminal	
		75014	5m	LE-CYB-S5A-9	LE-CYB-R5A-9		
		75000	10m	LE-CYB-SAA-9	LE-CYB-RAA-9		
			20m	LE-CYB-SCA-9	LE-CYB-RCA-9		
Encoder			3m	LE-CYE-S3A	LE-CYE-R3A	DRIVER End Encoder End	
	1( 2(	100W 200W	5m	LE-CYE-S5A	LE-CYE-R5A		(3)
cable	40 75	00W 50W	10m	LE-CYE-SAA	LE-CYE-RAA	Battery Case Plug Connector (Battery attached) Connector	(3)
	10011		20m	LE-CYE-SCA	LE-CYE-RCA	(Crimped)(Molex Japan Co., Ltd.) (Molex Japan Co., Lt	

# 3.1.7 Specifications of motor cables and encoder cables

## (1) Wiring Specifications for Motor cable

DRIVER-end L	eads	Ser	vomotor-e	nd Conne	ector
Wire Color	Signal		Signal	Pin No.	
Green/yellow	FG		FG	1	
Blue	Phase W		Phase W	2	
White	Phase V		Phase V	3	
Red	Phase U		Phase U	4	
			-	5	

6

\_

# (3) Wiring Specifications for Encoder cable - Standard type DRIVER End

BAT (+)

1

DRIVER E	nd			Encoder (S	ervomotor) End
Pin No.	Signal			Pin No.	Wire Color
6	/PS	HA-	_	5	Light blue/white
5	PS		_	4	Light blue
4	BAT ()		_	8	Orange/white
3	BAT (+)	l√ ÷≯†	_	9	Orange
2	PG 0V	$\mapsto$	$\rightarrow$	3	Black
1	PG 5V		$\rightarrow$	6	Red
Shell	FG	Shield I I	$\rightarrow$	Shell	FG
Batter	ry Case	Wire			
Pin No.	Signal				
2	BAT ()	┝───┘│			
	DAT()	1			

## (2) Wiring Specifications for Motor cable with lock

DRIVER-end Le	ads	Servomotor-end Connector			
Wire Color	Signal		Signal	Pin No.	
Green/yellow	FG		FG	1	
Blue	Phase W	]	Phase W	2	
White	Phase V		Phase V	3	
Red	Phase U	]	Phase U	4	
Black	ロック		ロック	5	
Black	ロック	]	ロック	6	

Note: No polarity for connection to a lock.

## - Robot type

DRIVER E	nd		Encoder (S	ervomotor) End
Pin No.	Signal		Pin No.	Wire Color
6	/PS		- 5	Black/pink
5	PS		- 4	Red/pink
4	BAT ()		- 8	Black/light blue
3	BAT (+)		9	Red/light blue
2	PG 0V	$\rightarrow$	- 3	Green
1	PG 5V		6	Orange
Shell	FG	Shield	Shell	FG
Batter	ry Case	Wire		
Pin No.	Signal			
2	BAT ()			
1	BAT (+)			



## 3.2 I/O Signal Connections

This section describes the names and functions of I/O signals (CN1). Also connection examples by control method are shown.

## 3.2.1 /O Signal (CN1) Names and Functions

The following table shows the names and functions of I/O signals (CN1).

(1) Input Signals

Signal	Pin No.	Name	Function	Refer- ence Section
P-OT (/SI1) N-OT (/SI2)	7 8	Forward run prohibited, Reverse run prohibited	With overtravel prevention: Stops servomotor when movable part travels beyond the allowable range of motion.	4.3.1
/DEC (/SI3)	9	Homing deceleration switch signal	Connects the deceleration limit switch for homing.	-
/EXT 1 (/SI4) /EXT 2 (/SI5) /EXT 3 (/SI6)	10 11 12	External latch signal 1 External latch signal 2 External latch signal 3	Connects the external signals that latch the current feedback pulse counter.	_
/SI0	13	General-purpose input signal	Used for general-purpose input. Monitored in the I/O monitor field of MECHATROLINK-II.	-
+24VIN	6	Control power supply for sequence signal	Control power supply input for sequence signals. Allowable voltage fluctuation range: 11 to 25 V Note: The 24 VDC power supply is not included.	3.4.1
/P-CL /N-CL	Can be allocated	Forward external torque limit Reverse external torque limit	The allocation of an input signal to a pin can be changed in accordance with the function required.	_

Note 1. The allocation of the input signals (/SI1 to /SI6) can be changed. For details, refer to 3.3.1 Input Signal Allocations.

2. If the Forward run prohibited/ Reverse run prohibited function is used, the DRIVER is stopped by software controls, not by electrical or mechanical means. If the application does not satisfy the safety requirements, add an external circuit for safety reasons as required.

## (2) Output Signals

Signal	Pin No.	Name	Function	Refer- ence Section
ALM+ ALM-	3 4	Servo alarm output signal	Turns OFF when an error is detected.	-
/BK+ (/SO1+) /BK- (/SO1-)	1 2	Lock interlock signal	Controls the lock. The lock is released when the signal turns ON. Allocation can be changed to general-purpose output signals (/SO1+, /SO1-).	4.3.2
/SO2+ /SO2- /SO3+ /SO3-	23 24 25 26	General-purpose output signal	Used for general-purpose output. Note: Set the parameter to allocate a function.	_
/COIN /V-CMP /TGON /S-RDY /CLT /VLT /WARN /NEAR	Can be allocated	Positioning comple- tion Speed coincidence detection Rotation detection servo ready Torque limit Speed limit detection Warning Near	The allocation of an output signal to a pin can be changed in accordance with the function required.	_
PAO /PAO	17 18	Phase-A signal	Encoder output pulse signals for two-phase pulse train with	
PBO /PBO	19 20	Phase-B signal	90° phase differential	4.4.4 4.7.8
PCO /PCO	21 22	Phase-C signal	Origin pulse output signal	
SG	16	Signal ground	Connects to the 0 V pin on the control circuit of the PC or PLCetc.	-
FG	Shell	Frame ground	Connected to frame ground if the shielded wire of the I/O sig- nal cable is connected to the connector shell.	-

Note: The allocation of the output signals (/SO1 to /SO3) can be changed. For details, refer to 3.3.2 Output Signal Allocations.

## 3.2.2 Safety Function Signal (CN8) Names and Functions

The following table shows the terminal layout of safety function signals (CN8).

Signal Name	Pin No.	Function	
/HWBB1+	4	Hard wire baseblock input 1	For hard wire baseblock input. Baseblock (motor current off) when OFF.
/HWBB1-	3		
/HWBB2+	6	Hard wire baseblock input 2	
/HWBB2-	5		
EDM1+	8	Monitored circuit status output 1	ON when the /HWBB1 and the /HWBB2 signals are input and the DRIVER enters a baseblock state.
EDM1-	7		
-	1*	_	
-	2*	_	

\* Do not use pins 1 and 2 because they are connected to the internal circuits.

### 3.2.3 Example of I/O Signal Connections

The following diagram shows a typical connection example.



- \*1.  $\blacksquare$  represents twisted-pair wires.
- **\*3.** The 24-VDC power supply is not included. Use a 24-VDC power supply with double insulation or reinforced insulation.
- \*4. When using the safety function, a safety function device must be connected and the wiring that is necessary to activate the safety function must be done to turn ON the servomotor power. When not using the safety function, use the DRIVER with the Safety Jumper Connector (provided as an accessory) inserted into the CN8.
- **\*5.** Always use line receivers to receive the output signals.
- Note: The functions allocated to the input signals /DEC, P-OT, N-OT, /EXT1, /EXT2, and /EXT3 and the output signals /SO1, /SO2, and /SO3 can be changed by using the parameters. Refer to 3.3.1 Input Signal Allocations and 3.3.2 Output Signal Allocations.

3-18
#### 3.3 I/O Signal Allocations

This section describes the I/O signal allocations.

# 3.3.1 Input Signal Allocations

IMPORTANT	<ul> <li>Inverting the polarity of the forward run prohibited and reverse run prohibited signals from the factory setting will prevent the overtravel function from working in case of signal line disconnections or other failures.</li> <li>If this setting is absolutely necessary, check the operation and confirm that there are no safety problems.</li> <li>When two or more signals are allocated to the same input circuit, input signal level is valid for all allocated signals, resulting in an unexpected machine operation.</li> </ul>
-----------	--

Input signals are allocated as shown in the following table.

Refer to the Interpreting the Input Signal Allocation Tables and change the allocations accordingly.

# <Interpreting the Input Signal Allocation Tables>



Input Signal Names and Parameters	Valid- ity Level	Input Signal	CN1 Pin Numbers						Connection Not Required (DRIVER judges the connec- tion)		
			13	7	8	9	10	11	12	Always ON	Always OFF
Forward Run Prohibited	Н	P-OT	0	1	2	3	4	5	6	7	8
Pn50A.3	L	/P-OT	9	Α	В	С	D	Е	F		8
Reverse Run Prohibit-	Н	N-OT	0	1	2	3	4	5	6	7	8
ed Pn50B.0	L	/N-OT	0	А	В	С	D	Е	F		
Forward External	L	/P-CL	0	1	2	3	4	5	6	7	8
Torque Limit Pn50B.2	Н	P-CL	9	А	В	С	D	Е	F		
Reserve External	L	/N-CL	0	1	2	3	4	5	6	7	8
Pn50B.3	Н	N-CL	9	А	В	С	D	Е	F		
Homing Deceleration	L	/DEC	0	1	2	3	4	5	6	_	0
LS Pn511.0	Н	DEC	9	А	В	С	D	Е	F		8
External Latch Signal 1	L	EXT1	*	*	*	*	4	5	6	7	8
Pn511.1	Н	/EXT1	*	*	*	*	D	Е	F	/	0
External Latch Signal 2	L	EXT2	*	*	*	*	4	5	6	7	8
Pn511.2	Н	/EXT2	*	*	*	*	D	Е	F	,	0
External Latch Signal 3	L	EXT3	*	*	*	*	4	5	6	7	8
Pn511.3	Н	/EXT3	*	*	*	*	D	Е	F	· · · /	0

\* Always set to "Invalid."

# 3.3.2 Output Signal Allocations

IMPORTANT	<ul> <li>The signals not detected are considered as "Invalid." For example, Positioning Completion (/COIN) signal in speed control is "Invalid."</li> <li>Inverting the polarity of the lock signal (/BK), i.e. positive logic, will prevent the holding lock from working in case of its signal line disconnection. If this setting is absolutely necessary, check the operation and confirm that there are no safety problems.</li> <li>When two or more signals are allocated to the same output circuit, a signal is output with OR logic circuit.</li> </ul>

Output signals are allocated as shown in the following table.

Refer to the Interpreting the Output Signal Allocation Tables and change the allocations accordingly.

<Interpreting the Output Signal Allocation Tables>

The parameter set values to be used are shown. Signals are allocated to CN1 pins according to the selected set values.

Values in cells in bold lines are the factory settings.

			V		
Output Signal Names	Output Signal	(	Invalid		
and Parameters		1/ (2)	23/ (24)	25/ (26)	(not use)
Lock Pn50F.2	/BK	1	2	3	0

Output Signal Names	Output Signal	(	CN1 Pin Numbers				
and Parameters	Output Signal	1/ (2)	23/ (24)	25/ (26)	Invalid (not use) 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		
Positioning Completion <b>Pn50E.0</b>	/COIN	1	2	3	0		
Speed Coincidence Detection <b>Pn50E.1</b>	/V-CMP	1	2	3	0		
Rotation Detection Pn50E.2	/TGON	1	2	3	0		
Servo Ready Pn50E.3	/S-RDY	1	2	3	0		
Torque Limit Detection Pn50F.0	/CLT	1	2	3	0		
Speed Limit Detection Pn50F.1	/VLT	1	2	3	0		
Brake Pn50F.2	/BK	1	2	3	0		
Warning Pn50F.3	/WARN	1	2	3	0		
Near Pn510.0	/NEAR	1	2	3	0		
Pn512.0=1	Polarity inversion	on of CN1-1(2)			0		
Pn512.1=1	Polarity	inversion of CN1-	-23(24)		(Not invert at		
Pn512.2=1		Polarity inversio	n of CN1-25(26)		factory setting)		



#### 3.4 Examples of Connection to PC or PLC...etc

This section shows examples of DRIVER I/O signal connection to the PC or PLC...etc.

#### 3.4.1 Sequence Input Circuit

(1) Photocoupler Input Circuit

CN1 connector terminals 6 to 13 are explained below.

The sequence input circuit interface is connected through a relay or open-collector transistor circuit. When connecting through a relay, use a low-current relay. If a low-current relay is not used, a faulty contact may result.



Note: The 24 VDC external power supply capacity must be 50 mA minimum.

The DRIVER's input circuit uses bidirectional photocoupler. Select either the sink circuit or the source circuit according to the specifications required for each machine.

- Note: The connection example in 3.2.3 shows sink circuits.
  - The ON/OFF polarity differs between when a sink circuit is connected and when a source circuit is connected.



Input Signal Polarities				Input Signal Polarities			
Signal	Level	Voltage Level	Contact	Signal	Level	Voltage Level	Contact
ON	Low (L) level	0 V	Close	ON	High (H) level	24 V	Close
OFF	High (H) level	24 V	Open	OFF	Low (L) level	0 V	Open

# (2) Safety Input Circuit



As for wiring input signals for safety function, input signals make common 0 V. It is necessary to make an input signal redundant.

#### 3.4.2 Sequence Output Circuit

Three types of DRIVER output circuit are available.



Incorrect wiring or incorrect voltage application to the output circuit may cause short-circuit.

If a short-circuit occurs as a result of any of these causes, the holding lock will not work. This could damage the machine or cause an accident resulting in death or injury.

#### (1) Photocoupler Output Circuit

Photocoupler output circuits are used for servo alarm (ALM), servo ready (/S-RDY), and other sequence output signal circuits. Connect a photocoupler output circuit through a relay or line receiver circuit.



Note: The maximum allowable voltage and the allowable range of current capacity for photocoupler output circuits are as follows.

- Voltage: 30 VDC
- Current: 5 to 50 mA DC

#### (2) Line Driver Output Circuit

CN1 connector terminals, 17-18 (phase-A signal), 19-20 (phase-B signal), and 21-22 (phase-C signal) are explained below.

These terminals output the following signals via the line-driver output circuits.

Output signals for which encoder serial data is converted as two phases pulses (PAO, /PAO, PBO, /PBO)
Origin pulse signals (PCO, /PCO)

Connect the line-driver output circuit through a line receiver circuit at the PC or PLC...etc.



(3) Safety Output Circuit

The external device monitor (EDM1) for safety output signals is explained below. A configuration example for the EDM1 output signal is shown in the following diagram. **Output signal is the source output. It is not able to use the sink output.** 



- Specifications

Туре	Signal Name	Pin No.	Output Status	Meaning
Output EDM1	CN8-8	ON	Both the /HWBB1 and /HWBB2 signals are working nor- mally.	
		CN8-7	OFF	The /HWBB1 signal, the /HWBB2 signal, or both are not working normally.

Electrical characteristics of EDM1 signal are as follows.

Items	Characteristic	Remarks
Maximum Allowable Voltage	30 VDC	-
Maximum Current	50 mADC	-
Maximum Voltage Drop at ON	1.0 V	Voltage between EDM1+ to EDM1- at current is 50 mA.
Maximum Delay Time	20 ms	Time from the change in /HWBB1 or /HWBB2 until the change in EDM1.

#### 3.5 Wiring MECHATROLINK-III Communications

The following diagram shows an example of connections between a PC or PLC...etc and a DRIVER using MECHATROLINK-III communications cables (CN6A, CN6B).



Note 1. The length of the cable between stations (L1, L2 ... Ln) must be 75 m maximum.

For removing the MECHATROLINK-III communications cable connectors from the DRIVER, refer to the following procedure.

Slide the lock injector of the connector to the DRIVER side to unlock and remove the MECHATROLINK-III communications cable connectors.



Note: The MECHATROLINK-III communications cable connector may be damaged if it is removed without being unlocking.



# 3.6 Encoder Connection

This section describes the encoder signal (CN2) names, functions, and connection examples.

# 3.6.1 Encoder Signal (CN2) Names and Functions

The following table shows the names and functions of encoder signals (CN2).

Signal Name	Pin No.	Function
PG 5 V	1	Encoder power supply +5 V
PG 0 V	2	Encoder power supply 0 V
BAT (+)	3	Battery (+)
BAT (-)	4	Battery (-)
PS	5	Serial data (+)
/PS	6	Serial data (-)
Shield	Shell	-



#### 3.6.2 Encoder Connection Examples

The following diagrams show connection examples of the encoder, the DRIVER, and the PC or PLC...etc.



- \*1. The pin arrangement for wiring connectors varies in accordance with the servomotor that is used.
  \*2. \_\_\_\_\_\_: represents shielded twisted-pair wires.
- \*2.  $\frac{1}{1}$ : represents snielded twisted-pair wires.
- **\*3.** Do not connect the battery with 14 and 15 pins (CN1).

#### 3.7 Connecting Regenerative resistors

If the built-in regenerative resistor is insufficient, connect an external regenerative resistor by one of the following methods and set the regenerative resistors capacity (Pn600). Precautions on selecting a regenerative resistor and its specifications are shown below.



• Be sure to connect the regenerative resistor correctly. Do not short-circuit between B1/ €and B2. Doing so may result in fire or damage to the regenerative resistor or DRIVER.

#### - Regenerative resistors Selection

Select regenerative resistors in the following manner. External regenerative resistors are to be provided by users.

Voltage	DRIVER Model LECYU2-□□	Built-in Regenerative Resistor	Necessity of External Regenerative resistors	Necessity of External Regenerative resistors
Three-phase	V5, V7, V8	None	Basically Not Required	No built-in regenerative resistor is provided. Install external Regenerative resistors when the smoothing capacitor in DRIVER cannot process all the regenerative power.
200 V	V9	Standard Equipment *		A built-in regenerative resistor is provided as standard. Install external regenerative resistors when the built-in regenerative resistor cannot process all the regenerative power.

\* For specifications of built-in regenerative resistors, refer to the next.

#### - Specifications of Built-in Regenerative Resistor

The following table shows the specifications of the DRIVER's built-in resistor and the amount of regenerative power (average values) that it can process.

Applicable DRIVER		Specifications of Built-in Resistor		Regenerative Power Processed	Minimum Allowable
LECY	/U2-00	Resistance $[\Omega]$	Capacity [W]	by Built-in Resistor [W] *	Resistance $[\Omega]$
Three-phase	V5, V7, V8	-	-	-	40
200 V	V9	50	40	8	40

\*1: The average regenerative power that can be handled is 20% of the rated capacity of the regenerative resistor built into the DRIVER.

# 3.7.1 Connecting Regenerative Resistors

The following instructions show how to connect the regenerative resistors and DRIVERs.

## (1) DRIVERs: Model LECYU2-V5, V7, V8

Connect an external regenerative resistors between the  $B1/\odot$  and B2 terminals on the DRIVER. After connecting a option, select the capacity. For more information on how to set the capacity of regenerative resistors, refer to 3.7.2 *Setting Regenerative resistors Capacity*.



# (2) DRIVER: Model LECYU2-V9

Disconnect the wiring between the DRIVER's B2 and B3 terminals and connect an external regenerative resistors between the B1/@ and B2 terminals. After connecting the option, select the capacity. For more information on how to set the capacity of regenerative resistors, refer to 3.7.2 Setting Regenerative resistors Capacity.

Note: Be sure to take out the lead wire between the B2 and B3 terminals.



#### 3.7.2 Setting Regenerative resistors Capacity

When using an external regenerative resistors, set the Pn600 so that the regenerative resistors capacity is equivalent to the resistor capacity.

MARNING	
<ul> <li>If parameter Pn600 is set to 0 while an external regenerative resistors is connected, the regenerative over load alarm (A.320) may not be detected. If the regenerative overload alarm (A.320) is not detected correctly, the external regenerative resistors may be damaged and an injury or fire may result.</li> </ul>	-

	Regenerative resistors	s Capacity	Speed	Position Torque	Classification
Pn600	Setting Range	Unit	Factory Setting	When Enabled	
	0 to DRIVER capacity	10 W	0	Immediately	Setup

Be sure to set the regenerative resistors capacity (Pn600) to a value that is in accordance with the allowable capacity of the actual external regenerative resistors being used.

The setting will vary with the cooling method of external regenerative resistors:

- For natural convection cooling: Set the value to a maximum 20% of the actually installed regenerative option capacity (W).
- For forced convection cooling: Set the value to a maximum 50% of the actually installed regenerative option capacity (W).

Example: Set 20 W (100 W  $\times$  20%) for the 100-W external regenerative resistors with natural convection cooling method: Pn600 = 2 (unit: 10 W)

Note 1. If Pn600 is not set to the optimum value, alarm A.320 will occur.

2. When set to the factory setting (Pn600 = 0), the DRIVER's built-in option has been used.



• When the external regenerative resistors for power are used at the rated load ratio, the resistor temperature increases to between 200 °C and 300 °C. The resistors must be used at or below the rated values. Check with the manufacturer for the resistor's load characteristics.

• For safety, use the external regenerative resistors with thermoswitches.

#### 3.8 Noise Control and Measures for Harmonic Suppression

This section describes the wiring for noise control and the DC reactor for harmonic suppression.

## 3.8.1 Wiring for Noise Control

IMPORTANT	<ul> <li>Because the DRIVER is designed as an industrial device, it provides no mechanism to prevent noise interference.</li> <li>The DRIVER uses high-speed switching elements in the main circuit. Therefore peripheral devices may receive switching noise. If the equipment is to be used near private houses or if radio interference is a problem, take countermeasures against noise.</li> </ul>
	<ul> <li>If installation conditions by the EMC directive must be met, refer to 3.8.3 EMC Installation Conditions.</li> </ul>

The DRIVER uses microprocessors. Therefore it may receive switching noise from peripheral devices.

To prevent the noise from the DRIVER or the peripheral devices from causing a malfunction of any one of these devices, take the following precautions against noise as required.

- Position the input reference device and noise filter as close to the DRIVER as possible.
- Always install a surge absorber in the relay, solenoid and electromagnetic contactor coils.
- Do not bundle or run the main circuit cables together with the I/O signal cables or the encoder cables in the same duct. Keep the main circuit cables separated from the I/O signal cables and the encoder cables with a gap of at least 30 cm.
- Do not share the power supply with an electric welder or electrical discharge machine. When the DRIVER is placed near a high-frequency generator, install a noise filter on the input side of the main circuit power supply cables and control power supply cables. As for the wiring of noise filter, refer to (1) Noise Filter shown below.
- Take the grounding measures correctly. As for the grounding, refer to (2) Correct Grounding.

#### (1) Noise Filter

The DRIVER has a built-in microprocessor (CPU), so protect it from external noise as much as possible by installing a noise filter in the appropriate place.



The following is an example of wiring for noise control.

- \*1. For ground wires connected to the ground plate, use a thick wire with a thickness of at least 2.0 mm<sup>2</sup> (preferably, plain stitch cooper wire).
- \*2.  $\neq$  should be twisted-pair wires.
- \*3. When using a noise filter, follow the precautions in 3.8.2 Precautions on Connecting Noise Filter.

#### (2) Correct Grounding

Take the following grounding measures to prevent the malfunction due to noise.

- Grounding the Motor Frame

Always connect servomotor frame terminal FG to the DRIVER ground terminal  $\oplus$ . Also be sure to ground the ground terminal  $\oplus$ .

If the servomotor is grounded via the machine, a switching noise current will flow from the DRIVER main circuit through servomotor stray capacitance. The above grounding is required to prevent the adverse effects of switching noise.

- Noise on the I/O Signal Cable

If the I/O signal cable receives noise, ground the 0 V line (SG) of the I/O signal cable. If the motor cable is accommodated in a metal conduit, ground the conduit and its junction box. For all grounding, ground at one point only.



#### 3.8.2 Precautions on Connecting Noise Filter

This section describes the precautions on installing a noise filter.

(1) Noise Filter Brake Power Supply

Use the following noise filter at the brake power input for 400-W or less servomotors with holding locks. MODEL: FN2070-6/07 (Manufactured by SCHAFFNER Electronic.)

(2) Precautions on Using Noise Filters

Always observe the following installation and wiring instructions.



Some noise filters have large leakage currents. The grounding measures taken also affects the extent of the leakage current. If necessary, select an appropriate leakage current detector or leakage current breaker taking into account the grounding measures that are used and leakage current from the noise filter. Contact the manufacturer of the noise filter for details.

Do not put the input and output lines in the same duct or bundle them together.



Separate the noise filter ground wire from the output lines.

Do not accommodate the noise filter ground wire, output lines and other signal lines in the same duct or bundle them together.



Connect the noise filter ground wire directly to the ground plate. Do not connect the noise filter ground wire to other ground wires.



If a noise filter is located inside a control panel, first connect the noise filter ground wire and the ground wires from other devices inside the control panel to the ground plate for the control panel, then ground the plates.



# 3.8.3 EMC Installation Conditions

This section describes the recommended installation conditions that satisfy EMC guidelines for each model of the DRIVER.

This section describes the EMC installation conditions. The actual EMC level may differ depending on the actual system's configuration, wiring, and other conditions. However, because this product is built-in, check that the following conditions are still met after being installed in the user's product.

The applicable standards are EN55011/A2 group 1 class A, EN61800-3, and EN61000-6-2.







Symbol	Cable Name	Specification
1	I/O signal cable	Shield cable
2	Safety signal cable	Shield cable
3	Motor cable	Shield cable
4	Encoder cable	Shield cable
5	Main circuit cable	Shield cable
6	MECHATROLINK-III communication cable	Shield cable

#### (3) Other Precautions

- Attachment Methods of Ferrite Cores



- Recommended Ferrite Core

Cable Name	Ferrite Core Model	Manufacturer
Motor cable	ESD-SR-250	NEC TOKIN Corp.

# - Recommended Noise Filter

Noise	Filter	Selection
110150	1 IIIUI	Delection

Main Circuit	Driver Model	Recommended Noise Filter			Dotaila
Power Supply	LECYU2-	Model	Specifications	Leakage Current	Details
Single phase	V5, V7	FN2070-6/07	Single-phase 250V 6A	0.734 mA	[1]
200 V	V8	FN2070-10/07	Single-phase 250V 10A	230VAC/50Hz	
200 V	V9	FN2070-16/07	Single-phase 250V 16A		
	V5, V7, V8	FN258L-7/07	Three-phase 80V 7A	0.5 mA	[2]
Three-phase				440VAC/50Hz	
200 V	V9	FN258L-16/07	Three-phase 480V 16A	0.8 mA	
			-	440VAC/50Hz	

Note: RoHS-compliant models are not available. Contact the manufactures when in need of a RoHS-compliant model.



Some noise filters have large amounts of leakage current. The grounding measures taken also affect the extent of the leakage current. If necessary, select an appropriate current detector or leakage current breaker taking into account the grounding measures that are used and leakage current from the noise filter. Contact the manufacturer of the noise filter for details.

# External Dimensions (Units: mm) [1] FN Type (by Schaffner EMC, Inc.)



Cable Color	Terminal		
Cable Color	Line	Load	
Brown (BN)	P	Ρ'	
Blue (BU)	N	N'	
Green/yellow	F		
(GNYE)	E	_	

# [2] FN Type

		FN Type [by Schaffner EMC, Inc.]		
Mode	əl	FN258L-7/07	FN258L-16/07	
Dimensional Drawings				
	Code	Dimer	nsions	
	Α	255±1	305±1	
	В	126±0.8	142±0.8	
	С	50±0.6	55±0.6	
	D	225±0.8	275±0.8	
	E	240±0.5	290±0.5	
	F	25±0.3	30±0.3	
External	G	6.5:	±0.2	
Dimensione	н	300	±10	
Dimensions ·	J	1±	0.1	
	K	-	-	
	L	9:	E1	
	Μ	-	-	
	N	-	-	
	0	M	5	
	Р	AWG16	AWG14	
	Q	-	_	

#### - Recommended Surge Absorber

The surge absorber (for Lightning surge) absorbs lightning surge and prevents faulty operation in or damage to electronic circuits.

Main Circuit Power Supply	Recommended Surge Absorber		
Single-phase 200V	LT-C12G801WS [by SOSHIN ELECTRIC CO., LTD.]		
Three-phase 200V	LT-C32G801WS [by SOSHIN ELECTRIC CO., LTD.]		



\*: No L2 is on the LT-C12G801WS surge absorber.

- Fixing the Cable

Fix and ground the cable shield using a piece of conductive metal.

• Example of Cable Clamp



- Shield Box

A shield box, which is a closed metallic enclosure, is effective as reinforced shielding against electromagnetic interference (EMI) from DRIVERs. The structure of the box should allow the main body, door, and cooling unit to be attached to the ground.

The box opening should be as small as possible.

<Note>

Do not connect the the analog monitor cable to the DRIVER during operations. Connect them only when the machinery is stopped during maintenance.

# 3.9 Specification of option cables

- Cables for CN1 CN6 CN7 CN8 (MECHATROLINK-III Communications Reference DRIVERs)



Name		Length	Order No.	Specifications	Details
CN1 Cables for I/O Signals	Connector Kit		LE-CYNA	Soldered	(1)
CN7 Connection Cables for Personal Computer		2.5m	LEC-JZ-CVUSB	Cable with Connectors at Both Ends	(2)
CN6A CN6B MECHATROLINK-III Communication Cable	Cables with Connectors at Both Ends	0.2m ~ 3.0m	LEC-CYU-□	∎∘∲∰00œ∳≡	(3)
CN8 Cable for Safety Function Device	Cables with Connector*1	3m	LEC-JZ-CVSAF	E	(4)

\*1 : When using the safety function, connect this cable to the safety devices.

Even when not using the safety function, use DRIVERs with the Safe Jumper Connector connected.

· External Dimensions of Connector (Units: mm)

# (1) Connector Kit for CN1

Use the following connector and cable to assemble the cable.

The CN1 connector kit includes one case and one connector.

Connector Kit	Case		Connector	
Model	Model	Qty	Model	Qty
LE-CSNA	10326-52A0-008*	1 set	10126-3000PE*	1
			(Soldered)	
	*			

: Manufactured by Sumitomo 3M Ltd.

Cable Size

39.0

Item	Specifications
Cable	Use twisted-pair or twisted-pair
	shielded wire.
Applicable Wires	AWG24, 26, 28, 30
Cable Finished Diameter	16 dia. max.

# External Dimensions of Case (Units: mm)



# (2) Connection Cable for Personal Computer for CN7 (Model: LEC-JZ-CVUSB)

- External Dimensions (Units: mm)



# (3) Cable with Connectors at Both Ends for CN6

(Model: LEC-CYU- $\Box$ )

- External Dimensions (Units: mm)



Model	Cable Length (L)
LEC-CYU-L	0.2m
LEC-CYU-J	0.5m
LEC-CYU-1	1m
LEC-CYU-3	3m



Use a MECHATROLINK-III communications cable specified by this company. When using other cables, noise resistance may be reduced, and operation cannot be guaranteed.

# (4) Cable with Connector for CN8

(Model: LEC-JZ-CVSAF)

- External Dimensions (Units: mm)



Pin Layout



# Specifications

Pin No.	Signal	Lead Color	Marking Color
1	Not used	-	-
2	Not used	_	_
3	/HWBB1-	White	Black
4	/HWBB1+	White	Red
5	/HWBB2-	Gray	Black
6	/HWBB2+	Gray	Red
7	EDM1-	Orange	Black
8	EDM1+	Orange	Red

4.	Operation		3
	4.1 MECHATROLINK-III Communications Settings		3
	4.1.1 Setting Switches S1, S2, and S3		3
	4.2 MECHATROLINK-III Commands	•••••	4
	4.3 Basic Functions Settings	•••••	4
	4.3.1 Servomotor Rotation Direction	•••••	4
	4.3.2 Overtravel		5
	4.3.3 Software Limit Settings	8	8
	4.3.4 Holding Locks	!	9
	4.3.5 Stopping Servomotors after SV_OFF Command or Alarm Occurrence	14	4
	4.3.6 Instantaneous Power Interruption Settings	1	5
	4.3.7 SEMI F47 Function (Torque Limit Function for Low DC Power Supply Voltage for M	lair	1
	Circuit)	1′	7
	4.3.8 Setting Motor Overload Detection Level	19	9
	4.4 Trial Operation	2	1
	4.4.1 Inspection and Checking before Trial Operation	2	1
	4.4.2 Trial Operation via MECHATROLINK-III.	22	2
	4.4.2 Electronic Gear	2	3
	4.4.4 Encoder Output Pulses	2:	5
	4.4.5 Setting Encoder Output Pulse	2	5
	4.5 Lest Without Motor Function	2	/
	4.5.1 Motor Information.	2	/
	4.5.2 Motor Position and Speed Responses	23 2	8 0
	4.5.5 Limitations	2: 21	9 0
	4.6 1 Internal Tarque Limit	יכ יכ	J N
	4.6.1 Internal Torque Limit	יכ 2	յ 1
	4.6.2 Checking Output Torque Limiting during Operation	נ יצ	1 7
	4.0.5 Checking Output Torque Emitting during Operation	נב יב	2 2
	4.7.1 Connecting the Absolute Encoder		5 4
	4.7.2 Absolute Data Request (SENS ON Command)	יכ יצ	т 5
	4.7.3 Battery Renlacement	J. 31	6
	4.7.4 Absolute Encoder Setup and Reinitialization	3	8
	4 7 5 Multiturn Limit Setting	30	9
	4.7.6 Multiturn Limit Disagreement Alarm (A.CC0)	4	0
	4.7.7 Absolute Encoder Origin Offset	4	1
	4.7.8 Absolute Data Reception Sequence	4	1
	4.8 Other Output Signals	4	5
	4.8.1 Servo Alarm Output Signal (ALM)	4	5
	4.8.2 Warning Output Signal (/WARN)	4	5
	4.8.3 Rotation Detection Output Signal (/TGON)	4	6
	4.8.4 Servo Ready Output Signal (/S-RDY)	4	6
	4.8.5 Speed Coincidence Output Signal (/V-CMP)	4	7
	4.8.6 Positioning Completed Output Signal (/COIN)	4	8
	4.8.7 Positioning Near Output Signal (/NEAR)	4	9
	4.8.8 Speed Limit Detection Signal (/VLT)	5	0
	4.9 Safety Function	52	2
	4.9.1 Hard Wire Base Block (HWBB) Function	5	2



4.9.2 External Device Monitor (EDM1)	
4.9.3 Application Example of Safety Functions	61
4.9.4 Confirming Safety Functions	
4.9.5 Connecting a Safety Function Device	63
4.9.6 Precautions for Safety Function	64

# 4. Operation

- 4.1 MECHATROLINK-III Communications Settings
  - This section describes the switch settings necessary for MECHATROLINK-III communications.
  - 4.1.1 Setting Switches S1, S2, and S3

The DIP switch S3 is used to make the settings for MECHATROLINK-III communications. The station address is set using the rotary switches S1 and S2.



(1) Settings of the Rotary Switches S1 and S2 Set the station address using the rotary switches S1 and S2.

Station Address	S1	S2
00H to 02H: Disabled	0	0 to 2
(Do not use these addresses.)		
03H (Factory setting)	0	3
04H	0	4
•		
•		
•		
EFH	Е	F
F0H to FFH: Disabled	F	0 to F
(Do not use these addresses.)		

- (2) Settings of the DIP Switch S3
  - The following table shows the settings of the DIP switch (S3).

Switch No. Function Setting Descrip		Description	Factory setting			
		1	2	Number of transmission bytes		
Pins 1 and 2		OFF	OFF	16 byte		
	Sets the number of transmission bytes.	ON	OFF	32 byte	1: OFF 2: ON	
		OFF	ON	48 byte		
		ON	ON	Reserved. (Do not change.)		
Pin 3	Reserved. (Do not change.)				OFF	
in 4 Reserved. (Do not change.)				OFF		



- When using the MECHATROLINK-II-compatible profile, set the number of transmission bytes to either 16 or 32.
- Turn the power OFF and then ON again to enable the new settings.

# 4.2 MECHATROLINK-III Commands

For information on the MECHATROLINK-III commands, refer to 8. Commands.

# 4.3 Basic Functions Settings

4.3.1 Servomotor Rotation Direction

The servomotor rotation direction can be reversed with parameter Pn000.0 without changing the polarity of the speed/position reference. This causes the rotation direction of the servomotor to change, but the polarity of the signal, such as encoder output pulses, output from the DRIVER does not change. (refer to *4.4.4 Encoder Output Pulses*)

Parameter		Forward/ Reverse Ref- erence	Direction of Motor Rotation and Encoder Output Pulse	Applicable Over- travel (OT)
Pn000	n.□□□0 Sets CCW as for-	Forward Reference	Motor speed Torque reference CCW Motor speed Torque reference Motor speed Torque reference PAO PBO PBO Phase B advanced	P-OT
	ward direction. [Factory setting]	Reverse Reference	Wotor speed Torque reference Encoder output pulse PAO Phase A advanced CW Motor speed	N-OT
	n.  1 Sets CW as for- ward direction. (Reverse Rotation Mode)	Forward Reference	Motor speed Torque reference CW Motor speed Motor speed Motor speed Motor speed Time PAO PBO PBO Phase B advanced	P-OT
		Reverse Reference	Motor speed Torque reference Encoder output pulse PAO Phase A advanced CCW Motor speed	N-OT

Note: SigmaWin+ trace waveforms are shown in the above table.

# 4.3.2 Overtravel

The overtravel limit function forces movable machine parts to stop if they exceed the allowable range of motion and turn ON a limit switch.



# (1)Signal Setting

Туре	Name	Connector Pin Number	Setting	Meaning
Input	P-OT	CN1-7	ON	Forward run allowed. Normal operation status.
			OFF	Forward run prohibited. Forward overtravel.
	N-OT	CN1-8	ON	Reverse run allowed. Normal operation status.
			OFF	Reverse run prohibited. Reverse overtravel.

Rotation in the opposite direction is possible during overtravel by inputting the reference.

#### (2) Overtravel Function Setting

Parameters Pn50A and Pn50B can be set to enable or disable the overtravel function.

If the overtravel function is not used, no wiring for overtravel input signals will be required.

Parameter		arameter	Meaning	When Enabled	Classification
	Pn50A	n.1□□□ [Factory setting]	Inputs the Forward Run Prohibited (P-OT) signal from CN1-7.		
	FIIJUA	n.8口口口	Disables the Forward Run Prohibited (P-OT) signal. Allows constant forward rotation.		Setun
	Pn50B	n.□□□2 [Factory setting]	Inputs the Reverse Run Prohibited (N-OT) signal from CN1-8.	Anter restart	Betup
	THOOD	n.口口口8	Disables the Reverse Run Prohibited (N-OT) signal. Allows constant reverse rotation.		

A parameter can be used to re-allocate input connector number for the P-OT and N-OT signals. Refer to *3.3.1 Input Signal Allocations* for details.



(3)Servomotor Stopping Method When Overtravel is Used

There are three servomotor stopping methods when an overtravel is used.

- Dynamic brake
- By short-circuiting the electric circuits, the servomotor comes to a quick stop.
- Decelerate to a stop
  - Stops by using emergency stop torque.
- Coast to a stop

Stops naturally, with no control, by using the friction resistance of the servomotor in operation.

After servomotor stopping, there are two modes.

- Coast mode
- Stopped naturally, with no control, by using the friction resistance of the servomotor in operation.
- Zero clamp mode

A mode forms a position loop by using the position reference zero.

The servomotor stopping method when an overtravel (P-OT, N-OT) signal is input while the servomotor is operating can be set with parameter Pn001.

Parameter		Stop Method Mode After Stop- ping		When Enabled	Classification
	n.□□00 [Factory setting]	DB			Setup
Pn001	n.□□01		Coast	After restart	
	n.□□02	Coast		1 11001 1 050000	
	n.□□1□	Deceleration to a ston	Zero clamp		
	n.□□2□	Deceleration to a stop	Coast		

- A servomotor under torque control cannot be decelerated to a stop. The servomotor is stopped with the dynamic braking (DB) or coasts to a stop according to the setting of Pn001.0. After the servomotor stops, the servomotor will enter a coast state.

- For details on servomotor stopping methods after the SV\_OFF command is received or an alarm occurs, refer to 4.3.5 Stopping Servomotors after SV\_OFF Command or Alarm Occurrence.

-When Servomotor Stopping Method is Set to Decelerate to Stop Emergency stop torque can be set with Pn406.

	Emergency Stop Torque		Speed Posi	Classification	
Pn406	Setting Range	Setting Unit	Factory Setting When Enabled		
	0 to 800	1%	800	Immediately	Setup

- The setting unit is a percentage of the rated torque.

- The factory setting is 800% so that the setting is large enough a value to operate the servomotor at maximum torque. The maximum value of emergency stop torque that is actually available, however, is limited to the maximum torque of the servomotor.

#### (4) Overtravel Warning Function

This function detects an overtravel warning (A.9A0) if overtravel occurs while the servomotor power is ON. Using this function enables notifying the host PC or PLC...etc when the DRIVER detects overtravel even if the overtravel signal is ON only momentarily.

To use the overtravel warning function, set digit 4 of Pn00D to 1 (detects overtravel warning).

Note: The overtravel warning function is supported by software version 001A or later. The software version can be checked with SigmaWin+. For details, refer to 6.13 Product Information Display (Fn012).

#### - Warning Output Timing

Command	Motion command			ALM_CLR command	
Servomotor power	OFF		0	N	
Overtravel input signal (P-OT, N-OT signals)	Disabled Enabled	Disabled	Enabled	Disabled	
Overtravel warning (A.9A0)	Norm	al operation 🗳	Warni	ng status	Normal operation
Warning no	t detected.				

<Notes>

- · Warnings are detected for overtravel in the same direction as the reference.
- Warnings are not detected for overtravel in the reverse direction from the reference.
  - Example: A warning will not be output for a forward reference even if the N-OT signal (reverse run prohibited) turns ON.
- A warning can be detected in either the forward or reverse direction, when there is no reference.
- A warning will not be detected when the servomotor power is OFF even if overtravel occurs.
- A warning will not be detected when the servomotor power changes from OFF to ON even if overtravel status exists.
- To clear the overtravel warning, send a Clear Warning or Alarm command (ALM\_CLR) regardless of the status of the servomotor power and the overtravel signal. If the warning is cleared by this method during an overtravel state, the occurrence of the warning will not be indicated until the overtravelling is corrected and reset.
- The overtravel warning will be detected when the software limit is in effect.

# The overtravel warning function only detects warnings. It does not affect on stopping for overtravel or motion operations at the host PC or PLC...etc. The next step (e.g., the next motion or other command) can be executed even if an overtravel warning exists. However, depending on the processing specifications and programming for warnings in the host PC or PLC...etc, operation may be affected when an overtravel warning occurs (e.g., motion may stop or not stop). Confirm the specifications and programming in the host PC or PLC...etc. When an overtravel occurs, the DRIVER will perform stop processing for overtravel. Therefore, when an overtravel warning occurs, the servomotor may not reach the target position specified by the host PC or

PLC...etc. Check the feedback position to make sure that the axis is stopped at a safe position.

#### -Related Parameter

Parameter		Meaning	When Enabled	Classification
Pn00D	n.0□□□ [Factory setting]	Does not detect overtravel warning.	Immediately	Setup
	n.1口口口	Detects overtravel warning.		

# 4.3.3 Software Limit Settings

The software limits set limits in software for machine movement that do not use the overtravel signals (P-OT and N-OT). If a software limit is exceeded, an emergency stop will be executed in the same way as it is for overtravel.

(1)Software Limit Function

The software limit function can be enabled or disabled.

Use the parameter Pn801.0 to enable the software limit function.

The software limit function can be enabled under the following conditions. Under all other circumstances, the software limits will not be enabled even if a software limit is exceeded.

- The ZRET command has been executed.
- REFE = 1 using the POS\_SET command.

Enable or disable the software limits using one of the following settings.

Parameter		Description	When Enabled	Classification
Pn801	n.口口口0	Software limits enabled in both direction.		
	n.□□□1	Forward software limit enabled.		
	n.□□□2	Reverse software limit enabled.	Immediately	Setup
	n.□□□3 [Factory setting]	Both software limits disabled.		

# (2)Software Limit Check using References

Enable or disable software limit checks when target position references such as POSING or INTERPOLATE are input. When the input target position exceeds the software limit, a deceleration stop will be performed from the software limit set position.

Parameter		arameter	Description	When Enabled	Classification
	Pn801	n.□0□□ [Factory setting]	No software limit check using references.	Immediately	Setup
		n.□1□□	Software limit check using references.		

## (3)Software Limit Setting

Set software limits value in the positive and negative directions.

Because the limit zone is set according to the forward or reverse direction, the reverse limit must be less than the forward limit.

	Forward Software Limit			Position	Classification		
Pn804	Setting Range	Setting Unit	Factory Setting	When Enabled			
	-1073741823 to 1073741823	1 Reference Unit	819191808	Immediately	Setup		
					Classification		
	Reverse Software Li	nit		Position	Classification		
Pn806	Reverse Software Lin Setting Range	nit Setting Unit	Factory Setting	Position When Enabled	Classification		

#### 4.3.4 Holding Locks

A holding lock is a lock used to hold the position of the movable part of the machine when the DRIVER is turned OFF so that movable part does not move due to gravity or external forces. Holding locks are built into servomotors with locks.

The holding lock is used in the following cases.





There is a delay in the braking operation. Set the following ON/OFF timing.



- \*1. The operation delay time of the lock depends on the model. For details, refer to *Lock Operation Delay Time* shown below.
- \*2. After the SV\_ON command has been sent and 50 ms has passed since the lock was released, output the reference from the host PC or PLC...etc to the DRIVER.
- **\*3.** Use Pn506, Pn507, and Pn508 to set the timing of when the lock will be activated and when the servomotor power will be turned OFF.

Lock	Operation	Delay	Time
------	-----------	-------	------

Model	Voltage	Lock Release Time (ms)	Lock Applied Time (ms)
LECYU2-V5, V7, V8	24 VDC	60	100
LECYU2-V9		80	100

Note: The above operation delay time is an example when the power supply is turned ON and OFF on the DC side. Be sure to evaluate the above times on the actual equipment before using the application.

# (1) Wiring Example

Use the lock signal (/BK) and the lock power supply to form a lock ON/OFF circuit. The following diagram shows a standard wiring example.

Servomotor with holding DRIVER brake Power supply L1 υ L2 v М L3 w L1C 1 L2C CN2 ENC ΒK 4 V CN1 BK-R (/BK+) 1D 0 V (/BK-) DC side AC side Î Lock power Blue or supply BK-RY yellow Red White AC DC Black

The timing can be easily set using the lock signal (/BK).

BK-R Y: Lock control relay 24 VDC power supply is not included.




## (2) Lock signal (/BK) Setting

This output signal controls the lock. The allocation of the /BK signal can be changed. Refer to (3) Lock Sig- nal (/BK) Allocation for allocation.

The /BK signal turns OFF (applies the lock) when an alarm is detected or the SV\_OFF command is received. The lock OFF timing can be adjusted with Pn506.

Туре	Name	Connector Pin Number	Setting	Meaning
Output	/BK	CN1-1, CN1-2	ON (closed)	Releases the lock.
			OFF (open)	Applies the lock.



# (3) Lock signal (/BK) Allocation

Parameter		Connector Pin Number		Meaning	When	Classifica
		+ Terminal	- Terminal		Lilableu	- 1011
	n.□0□□	-	-	The /BK signal is not used.		
Pn50F	n.□1□□ [Factory setting]	n.□1□□ [Factory CN1-1 setting]		The /BK signal is output from output terminal CN1-1, 2.	After	Sotup
	n.□2□□	CN1-23	CN1-24	The /BK signal is output from output terminal CN1-23, 24.	restart	Setup
	n.¤3¤¤	n.□3□□ CN1-25		The /BK signal is output from output terminal CN1-25, 26.		

Use parameter Pn50F.2 to allocate the /BK signal.



When multiple signals are allocated to the same output terminal, the signals are output with OR logic. For the /BK signal, do not use the output terminal that is already being used for another signal.

# (4) Lock ON Timing after the Servomotor Stops

When the servomotor stops, the /BK signal turns OFF at the same time as the SV\_OFF command is received. Use parameter Pn506 to change the timing to turn OFF the servomotor power after the SV\_OFF command has been received.

	Lock Reference-Serv	o OFF Delay Time	Speed	Position Torque	Classification
Pn506	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 50	10 ms	0	Immediately	Setup

• When using the servomotor to control a vertical axis, the machine movable part may shift slightly depending on the lock ON timing due to gravity or an external force. To eliminate this slight shift, set parameter so that the power to the servomotor turns OFF after the lock is applied.



• This parameter changes the lock ON timing while the servomotor is stopped.



The servomotor will turn OFF immediately when an alarm occurs, regardless of the setting of this parameter. The machine movable part may shift due to gravity or external force before the lock operates. (5) Lock signal (/BK) Output Timing during Servomotor Rotation

If an alarm occurs while the servomotor is rotating, the servomotor will come to a stop and the lock signal (/BK) will be turned OFF. The timing of lock signal (/BK) output can be adjusted by setting the lock reference output speed level (Pn507) and the waiting time for lock signal when motor running (Pn508).

Note: If the servomotor is set so that it comes to a zero-speed stop for an alarm, follow the information in (4) Lock ON *Timing after the Servomotor Stops* after the servomotor comes to a stop for a zero position reference.

	Lock Reference Outp	out Speed Level	Speed	Classification	
Pn507	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 10000	1 min <sup>-1</sup>	100	Immediately	Setup
Pn508	Waiting Time for Lock signal When Motor Running Speed		Position Torque	Classification	
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	10 to 100	10 ms	50	Immediately	Setup

/BK Signal Output Conditions When Servomotor Rotating

The /BK signal goes to high level (lock ON) when either of the fol- lowing conditions is satisfied:

- When the motor speed falls below the level set in Pn507 after the power to the servomotor is turned OFF.
- When the time set in Pn508 is exceeded after the power to the servomotor is turned OFF.



• The servomotor will be limited to its maximum speed even if the value set in Pn507 is higher than the maximum speed.

IMPORTANT

 Do not allocate the rotation detection signal (/TGON) and the lock signal (/BK) to the same terminal. The /TGON signal will otherwise be turned ON by the falling speed on a vertical axis, and the lock may not operate.
 For the /BK signal, do not use the terminal that is already being used for another signal

For the /BK signal, do not use the terminal that is already being used for another signal.

# 4.3.5 Stopping Servomotors after SV\_OFF Command or Alarm Occurrence

The servomotor stopping method can be selected after the SV\_OFF command is received or an alarm occurs.

<ul> <li>Dynamic braking (DB) is used for emergency stops. The DB circuit will operate fre- quently if the power is turned ON and OFF or the SV_ON command and SV_OFF command are received with a reference input applied to start and stop the servomo- tor, which may result in deterioration of the internal elements in the DRIVER. Use</li> </ul>
speed input references or position references to start and stop the servomotor.
• If the main circuit power supply or the control power supply is turned OFF but the SV_OFF command has not been received, the stopping method for servomotor cannot be set in the parameters. Use the following method to stop the servomotor.
If turning OFF the main circuit power supply, but the SV_OFF command has not been received, the servomotor will be stopped by dynamic braking.
<ul> <li>If turning OFF the control power supply, the servomotor will be stopped by dynamic braking.</li> </ul>
<ul> <li>If the servomotor must be stopped by coasting rather than by dynamic braking when the main circuit power supply or the control power supply is turned OFF but the SV_OFF command has not been received, arrange the sequence externally so the current will be cut off for servomotor wires U, V, and W.</li> </ul>
<ul> <li>To minimize the coasting distance of the servomotor to come to a stop when an alarm occurs, the zero-speed stopping method is factory-set for alarms to which the zero- speed stop method is applicable. The DB stopping method may be more suitable than the zero-speed stopping method, however, depending on the application.</li> </ul>
For example, for multiple axes coupling operation (a twin-drive operation), machinery
damage may result if a zero-speed stop alarm occurs for one of the coupled shafts
and the other shaft stops by dynamic brake. In such cases, change the method to the
DB stopping method.

## (1) Stopping Method for Servomotor after SV\_OFF Command is Received

Use Pn001.0 to select the stopping method for the servomotor after the SV\_OFF command is received.

Parameter		Stop Mode	Mode After Stopping	When Enabled	Classification
Pn001	n.□□□0 [Factory setting]	DB	DB	After restart	Setup
	n.□□□1		Coast		
	n.□□□2	Coast	Coast		

Note: Similar to the Coast Mode, the  $n.\Box\Box\Box0$  setting (which stops the servomotor by dynamic braking and then holds it in Dynamic Brake Mode) does not generate any braking force when the servomotor stops or when it rotates at very low speed.

(2) Stopping Method for Servomotor When an Alarm Occurs

There are two types of alarms (Gr.1 and Gr.2) that depend on the stopping method when an alarm occurs. Select the stopping method for the servomotor when an alarm occurs using Pn001.0 and Pn00B.1.

The stopping method for the servomotor for a Gr.1 alarm is set to Pn001.0. The stopping method for the servomotor for a Gr.2 alarm is set to Pn00B.1.

Refer to the information on alarm stopping methods in 9.1.1 List of Alarms.

- Stopping Method for Servomotor for Gr.1 Alarms

The stopping method of the servomotor when a Gr.1 alarm occurs is the same as that in (1) Stopping Method for Servomotor after SV\_OFF Command is Received.

	Parameter	Stop Mode	Mode After Stop- ping	When Enabled	Classification
Pn001	n.□□□0 [Factory setting]	DB	DB	After restart	Setup
	n.□□□1		Coast		
	n.□□□2	Coast	Coast		

- Stopping Method for Servomotor for Gr.2 Alarms

Parar	Parameter		Mode After	When	Classifica-
Pn00B	Pn001		Stopping	Enabled	tion
n.口口0口	n.□□□0 [Factory setting]	Zero-speed stop-	DB		
[Factory setting]	n.□□□1	ping*	Canat	After	Cotum
	n.□□□2		Coast		
n 🗆 🗆 1 🗆	n.□□□0 [Factory setting]	DB	DB	restart	Setup
	n.□□□1		Const		
	n.□□□2	Coast	Coust		

\* Zero-speed stopping: The speed reference is set to 0 to stop quickly.

Note: The setting of Pn00B.1 is effective for position control and speed control. Pn00B.1 will be ignored for torque control and only the setting of Pn001.0 will be valid.

# 4.3.6 Instantaneous Power Interruption Settings

Determines whether to continue operation or turn OFF the servomotor's power when the power supply voltage to the DRIVER's main circuit is interrupted.

Pn509	Instantaneous Power	Cut Hold Time	Speed	Position Torque	Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	-
	20 to 1000	1 ms	20	Immediately	Setup

If the power interruption time is shorter than the set value in Pn509, the servomotor will continue operation. If it is longer than the set value, the servomotor's power will be turned OFF during the power interruption. The servomotor is turned ON when power supply to the main circuit recovers.



Note: If the instantaneous power interruption is longer than the set value of Pn509, the /S-RDY signal turns OFF.



If the uninterruptible power supplies are used for the control power supply and main circuit power supply, the DRIVER can withstand an instantaneous power interruption period in excess of 1000 ms.

4.3.7 SEMI F47 Function (Torque Limit Function for Low DC Power Supply Voltage for Main Circuit)

The torque limit function detects an undervoltage warning and limits the output current if the DC power sup- ply voltage for the main circuit in the DRIVER drops to a specified value because the power was momentarily interrupted or the power supply voltage for the main circuit was temporality lowered.

This function complies with SEMI F47 standards for semiconductor production equipment.

Combining this function with the parameter for Instantaneous Power Cut Hold Time allows the servomotor to continue operating without stopping for an alarm or without recovery work even if the power supply voltage drops.

<ul> <li>This function is able to cope with instantaneous power interruptions in the voltage and time ranges stipulated in SEMI F47. An uninterruptible power supply (UPS) is required as a backup for instantaneous power interruptions that exceed these voltage and time ranges</li> </ul>
<ul> <li>This function is intended for voltage drops in the main circuit power supply.</li> <li>Set the host PC or PLCetc and DRIVER torque limit so that a torque reference that exceeds the specified acceleration will not be output when the power supply for the main circuit is restored.</li> </ul>
<ul> <li>Do not limit the torque to values lower than the holding torque for the vertical axis.</li> <li>This function limits torque within the range of the DRIVER's capability when the power is cut. It is not intended for use under all load and operating conditions. Use the actual machine to set parameters while confirming correct operation.</li> </ul>
<ul> <li>Setting the Instantaneous Power Cut Hold Time lengthens the amount of time from when the power supply is turned OFF until the motor current turns OFF. Send the SV_OFF command to instantly stop the motor current.</li> </ul>

#### (1) Execution Method

This function can be executed either with the host PC or PLC...etc and the DRIVER or with the DRIVER only.

- With the Host PC or PLC...etc and the DRIVER

The host PC or PLC...etc limits the torque in response to an undervoltage warning. The host PC or PLC...etc removes the torque limit after the undervoltage warning is cleared.



- With the DRIVER only

The torque is limited in the DRIVER in response to an undervoltage warning.

The DRIVER controls the torque limit value in the set time after the undervoltage warning is cleared. Use Pn008.1 to specify whether the function is executed by the host PC or PLC...etc and DRIVER or by the DRIVER only.



#### (2) Related Parameters

Parameter		Meaning	When Enabled	Classification
	n.□□0□ [Factory setting]	Does not detect undervoltage.		
Pn008	n.口口1口	Detects warning and limits torque by host PC or PLCetc.	After restart	Setup
	n.口口2口	Detects warning and limits torque by Pn424 and Pn425. (Only in the DRIVER)		

	Torque Limit at Main Circuit Voltage Drop         Speed         Position         Torque				Classification
Pn424	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 100	1%*	50	Immediately	Setup
	Release Time for Tor Voltage Drop	que Limit at Main Circ	Speed Speed	Position	Classification
Pn425	Setting Range	Setting Unit	Factory Setting	When Enabled	1
	0 to 1000	1 ms	100	Immediately	Setup

\* The setting unit is a percentage of the rated torque.

Pn509	Instantaneous Power	r Cut Hold Time	Speed	Position Torque	Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	20 to 1000	1 ms	20	Immediately	Setup

Note: When using SEMI F47 function, set 1000 ms.

4.3.8 Setting Motor Overload Detection Level

In this DRIVER, the detection timing of the warnings and alarms can be changed by changing how to detect an overload warning (A.910) and overload (low load) alarm (A.720). The overload characteristics and the detection level of the overload (high load) alarm (A.710) cannot be changed.

(1) Changing Detection Timing of Overload Warning (A.910)

The overload warning level is set by default to 20% so that an overload warning is detected in 20% of the time required to detect an overload alarm. The time required to detect an overload warning can be changed by changing the setting of the overload warning level (Pn52B). This protective function enables the warning out- put signal (/WARN) to serve as a protective function and to be output at the best timing for your system.

The following graph shows an example of the detection of an overload warning when the overload warning level (Pn52B) is changed from 20% to 50%. An overload warning is detected in half of the time required to detect an overload alarm.



Pn52B	Overload Warning Le	evel	Speed	Position Torque	Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 100	1%	20	Immediately	Setup

Overload characteristics for LECYU2 series



#### 4 Operation

#### (2) Changing Detection Timing of Overload (Low Load) Alarm (A.720)

An overload (low load) alarm (A.720) can be detected earlier to protect the servomotor from overloading. The time required to detect an overload alarm can be shortened by using the derated motor base current obtained with the following equation.

Note: The detection level of the overload (high load) alarm (A.710) cannot be changed.

Motor base current  $\times$  Derating of base current at detecting overload of motor (Pn52C) = Derated motor base current

Motor base current: Threshold value of motor current to start calculation for overload alarm Derating of base current at detecting overload of motor (Pn52C): Derating of motor base current

The following graph shows an example of the detection of an overload alarm when Pn52C is set to 50%. The calculation for the overload of motors starts at 50% of the motor base current and then an overload alarm will be detected earlier.

Changing the setting of Pn52C will change the detection timing of the overload alarm, so the time required to detect the overload warning will also be changed.



Note: Refer to Overload Characteristics listed in the (1) Changing Detection Timing of Overload Warning (A.910).

DmE20	Derating of Base Cur Motor	Classification			
Ph52C	Setting Range	Setting Unit	Factory Setting	When Enabled	
	10 to 100	1%	100 After restart		Setup

As a guideline of motor heating conditions, the relationship between the heat sink sizes and deratings of base current is shown in a graph.

Set Pn52C to a value in accordance with the heat sink size and derating shown in the graph, so that an overload alarm can be detected at the best timing to protect the servomotor from overloading.



### 4.4 Trial Operation

This section describes a trial operation using MECHATROLINK-III communications.

4.4.1 Inspection and Checking before Trial Operation

To ensure safe and correct trial operation, inspect and check the following items before starting trial operation.

### (1) DRIVERs

Inspect and check the following items, and take appropriate measures before performing trial operation if any problem exists.

- Are all wiring and connections correct?
- Is the correct power supply voltage being supplied to the DRIVER?



# 4.4.2 Trial Operation via MECHATROLINK-III

The following table provides the procedures for trial operation via MECHATROLINK-III.

Step	Description	Reference
1	Confirm that the wiring is correct, and then connect the I/O signal con- nector (CN1 connector).	3 Wiring and Connection
2	Turn ON the power to the DRIVER. And then, turn ON the power of the host PC or PLCetc. If the power is supplied to the DRIVER's control circuit, the seven-segment LED indicator will light up as shown here.	_
	If the power is supplied to the DRIVER's main circuit, the CHARGE indicator on the DRIVER will light up. If communications are established, the L1 and L2, LED indicators corresponding to the connector CN6A and CN6B connected to the MECHATROLINK- III cable will light up. If the L1 and L2, LED indicators do not light up, recheck the settings of MECHATROLINK-III setting switches S1, S2, and S3, and then turn the power OFF and ON again.	
3	Send the CONNECT command from the host PC or PLCetc. If the DRIVER correctly receives the CONNECT command, the CN, LED indicator will light up. If the CN does not light up, the set value of the CONNECT command is incorrect. Reset the CONNECT command, and then resend it from the host PC or PLCetc. Check the product type using an ID_RD command.	8 MECHATROLINK-III Commands
5	<ul> <li>Set the following items to the necessary settings for a trial operation.</li> <li>Electronic gear settings</li> <li>Rotational direction of servomotor</li> </ul>	4.4.3 Electronic Gear 4.3.1 Servomotor Rotation Direction 4.3.2 Overtravel
6	<ul> <li>Overtravel</li> <li>Save these settings (step 5).</li> <li>If saving the settings in the host PC or PLCetc, use the SVPRM_WR command(set the mode to RAM area).</li> <li>If saving settings in the DRIVER, use the SVPRM_WR command (set the mode to the non-volatile memory area).</li> </ul>	8 MECHATROLINK-III Commands
7	Send the CONFIG command to enable the settings.	
8	Send the SENS_ON command to obtain the position data (encoder ready response).	
9	Send the SV_ON command. A reply showing that the servomotor has switched to Drive status and that SVON=1 (servomotor power is ON) is received.	
10	Run the servomotor at low speed. <example a="" command="" positioning="" using=""> Command used: POSING Command setting: Option = 0, Positioning position =10000 (If using the absolute encoder, add 10000 to the present position), rapid traverse speed= 400</example>	_
11	<ul> <li>Check the following points while running the servomotor at low speed (step 10).</li> <li>Confirm that the rotational direction of the servomotor correctly coincides with the forward rotation or reverse rotation reference. If they do not coincide, reset the direction.</li> <li>Confirm that no unusual vibrations, noises, or temperature rises occur. If any abnormalities are seen, correct the conditions.</li> <li>Note: Because the running-in of the load machine is not sufficient at the time of the trial operation, the servomotor may become overloaded.</li> </ul>	4.3.1 Servomotor Rotation Direction 9.4 Troubleshooting Malfunction Based on Operation and Conditions of the Servomotor



### 4.4.2 Electronic Gear

The electronic gear enables the workpiece travel distance per reference unit input from the host PC or PLC...etc. The minimum unit of the position data moving a load is called a reference unit.

The section indicates the difference between using and not using an electronic gear when a workpiece is moved 10 mm in the following configuration.
When the Electronic Gear is Not Used:
<ol> <li>Calculate the revolutions.</li> <li>1 revolution is 6 mm. Therefore, 10 ÷ 6 = 10/6 revolutions.</li> </ol>
<ul> <li>Calculate the required reference units. 1048576 reference units is 1 revolution. Therefore, 10/6 × 1048576 = 1747626.66 reference units.</li> </ul>
③ Input 1747627 references as reference units.
Reference units must be calculated per reference. $\rightarrow$ complicated
When the Electronic Gear is Used:
The reference unit is 1 $\mu$ m. Therefore, to move the workpiece 10 mm (10000 $\mu$ m), 1 reference unit = 1 $\mu$ m, so 10000 $\div$ 1 = 10000 reference units. Input 10000 reference units.
Calculation of reference units per reference is not required. $\rightarrow$ simplified

# (1) Electronic Gear Ratio

Set the electronic gear ratio using Pn20E and Pn210.

	Electronic Gear Ratio	Position	Classification		
Pn20E	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 1073741824	1	4	After restart	Setup
	Electronic Gear Ratio (Denominator)			Position	Classification
Pn210	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 1073741824	1	1	After restart	Setup

If the gear ratio of the servomotor and the load shaft is given as n/m where m is the rotation of the servomotor and n is the rotation of the load shaft,

Electronic gear ratio: 
$$\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Encoder resolution}{Travel distance per load} \times \frac{m}{n}$$
  
shaft revolution (reference units)

- Encoder Resolution

Encoder resolution is 1048576.



Electronic gear ratio setting range:  $0.001 \le$  Electronic gear ratio (B/A)  $\le$  4000 If the electronic gear ratio is outside this range, a parameter setting error 1 (A.040) will be output.

# (2) Electronic Gear Ratio Setting Examples

The following examples show electronic gear ratio settings for different load configurations.

		Ball Screw	
Step	Operation	Reference unit: 0.001 mm Load shaft 20-bit encoder Ball screw pitch: 6 mm	
1	Check machine specifica- tions.	• Ball screw pitch: 6 mm • Gear ratio: 1/1	
2	Check the encoder reso- lution.	1048576 (20-bit)	
3	Determine the reference unit used.	Reference unit: 0.001 mm (1 µm)	
4	Calculate the travel dis- tance per load shaft revo- lution. (Reference unit)	6 mm/0.001 mm=6000	
5	Calculate the electronic gear ratio.	$\frac{B}{A} = \frac{1048576}{6000} \times \frac{1}{1}$	
6	Set parameters.	Pn20E: 1048576 Pn210: 6000	

4.4.4 Encoder Output Pulses

The encoder pulse output is a signal that is output from the encoder and processed inside the DRIVER. It is then output externally in the form of two phase pulse signal (phases A and B) with a 90° phase differential. It is used as the position feedback to the host PC or PLC...etc.

Signals and output phase form are as shown below.

(1) Signals

Туре	Signal Name	Connector Pin Number	Name	Remarks	
Output	PAO	CN1-17	Encoder output pulse: phase A These encoder pulse output pins ou		
	/PAO	CN1-18	Encoder output puise, phase M	revolution that is set in Pn212. Phase	
	PBO	CN1-19	A and phase B are different from		
	/PBO	CN1-20	Encoder output puise: phase B	angle of 90°.	
	РСО	CN1-21	Encoder output pulse: phase C	One pulse is output per motor rota-	
	/PCO	CN1-22	Encoder output puise. pliase C	tion.	



(2) Output Phase Form



Note: The pulse width for phase C (origin pulse) changes according to the setting of the encoder output pulses (Pn212) and becomes the same as that for phase A.

Even in reverse rotation mode (Pn000.0 = 1), the output phase form is the same as that for the standard setting (Pn000.0 = 0) above.

**D** IMPORTANT If using the DRIVER's phase-C pulse output for a zero point return, rotate the servomotor two or more times before starting a zero point return. If the servomotor cannot be rotated two or more times, perform a zero point return at a motor speed of 600 min<sup>-1</sup> or below. If the motor speed is faster than 600 min<sup>-1</sup>, the phase-C pulse may not be output correctly.

### 4.4.5 Setting Encoder Output Pulse

Set the encoder output pulse using the following parameter.

Pn212	Encoder Output Puls	es	Speed	Position Torque	Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	16 to 1073741824	1 P/rev	2048	After restart	Setup

Pulses from the encoder per revolution are divided inside the DRIVER by the number set in this parame- ter before being output. Set the number of encoder output pulses according to the system specifications of the machine or host PC or PLC...etc.

According to the encoder resolution, the number of encoder output pulses are limited.

Catting Dance of		Encoder Resolution	Upper Limit of Servomotor Speed for Set Encoder Output Pulses (min <sup>-1</sup> )	
Encoder Output Pulses (P/Rev)	Setting Unit	20 bits (1,048,576 pulses)		
16 to 2048	1	-	6000	
16 to 16384	1	0	6000	
16386 to 32768	2	0	3000	
32772 to 65536	4	0	1500	
65544 to 131072	8	0	750	
131088 to 262144	16	0	375	

Note 1. The setting range varies with the encoder resolution for the servomotor used.

An encoder output pulse setting error (A.041) will occur if the setting is outside the allowable range or does not satisfy the setting conditions.

Pn212 = 25000 (P/Rev) is accepted, but

Pn212 = 25001 (P/Rev) is not accepted. The alarm A.041 is output because the setting unit differs from that in the above table.

2. The upper limit of the pulse frequency is approx. 1.6 Mpps.

The servomotor speed is limited if the setting value of the encoder output pulses (Pn212) is large. An overspeed of encoder output pulse rate alarm (A.511) will occur if the motor speed exceeds the upper limit specified in the above table.

Output Example: When Pn212 = 16 (16-pulse output per one revolution), PAO and PBO are output as shown below.



### 4.5 Test Without Motor Function

The test without a motor is used to check the operation of the host PC or PLC...etc and peripheral devices by simulating the operation of the servomotor in the DRIVER, i.e., without actually operating a servomotor. This function enables you to check wiring, verify the system while debugging, and verify parameters, thus shortening the time required for setup work and preventing damage to the machine that may result from possible mal- functions. The operation of the motor can be checked during performing this function regardless of whether the motor is actually connected or not.



Use Pn00C.0 to enable or disable the test without a motor.

Parameter		Meaning	When Enabled	Classification
Pn00C	n.□□□0 [Factory setting]	Disables the test without a motor.	After restart	Setup
	n.□□□1	Enables the test without a motor.		

### 4.5.1 Motor Information

The motor information that is used for a test without a motor is given below.

(1) When Motor is Connected

If a motor is connected, the information from the connected motor is used for the motor and encoder scale information. The set values of Pn00C.1 and Pn00C.2 are not used.

(2) When Motor is Not Connected

The information for the virtual motor that is stored in the DRIVER is used. The set values of Pn00C.1 and Pn00C.2 are used for the encoder information.

-Encoder Resolution

The encoder information for the motor is set in Pn00C.1.

Parameter		Meaning	When Enabled	Classification
Pn00C	n.□□0□ [Factory setting]	Sets the encoder resolution for the test without a motor to 13 bits.	After restart	Setup
	n.□□1□	Sets the encoder resolution for the test without a motor to 20 bits.		F

# -Encoder Type

The encoder information for the motor is set in Pn00C.2.

Parameter		Meaning	When Enabled	Classification
Pn00C	n.□0□□ [Factory setting]	Sets an incremental encoder as an encoder type for the test without a motor.	After restart	Setun
Phooe	n.□1□□	Sets an absolute encoder as an encoder type for the test without a motor.	1110011050010	Secup

# 4.5.2 Motor Position and Speed Responses

For the test without a motor, the following responses are simulated for references from the host PC or PLC...etc according to the gain settings for position or speed control.

- Servomotor position
- Servomotor speed

The load model, however, will be a rigid system with the moment of inertia ratio that is set in Pn103.

## 4.5.3 Limitations

The following functions cannot be used during the test without a motor.

- Regeneration and dynamic brake operation
- Brake output signal (The brake output signal can be checked with the I/O signal monitor function of the SigmaWin+.)
- Items marked with " $\times$ " in the following utility function table.

Contents	Can be used or not	
Contento	Motor not connected	Motor con- nected
Alarm history display	0	0
JOG operation	0	0
Origin search	0	0
Program JOG operation	0	0
Initializing parameter settings	0	0
Clearing alarm history	0	0
Absolute encoder multiturn reset and encoder alarm reset	Х	0
Offset adjustment of analog monitor output	0	0
Gain adjustment of analog monitor output	0	0
Automatic offset-signal adjustment of the motor current detection signal	Х	0
Manual offset-signal adjustment of the motor current detection signal	Х	0
Write prohibited setting	0	0
Product Information display	0	0
Multiturn limit value setting change when a multiturn limit disagreement alarm occurs	Х	0
Resetting configuration error in option modules	0	0
Vibration detection level initialization	Х	Х
Origin setting	Х	0
Software reset	0	0
Tuning-less levels setting	Х	Х
Advanced autotuning	Х	Х
Advanced autotuning by reference	Х	Х
One-parameter tuning	Х	Х
Anti-resonance control adjustment function	Х	Х
Vibration suppression function	Х	Х
EasyFFT	Х	Х
Online vibration monitor	Х	Х

Note: O: Can be used

 $\times$  : Cannot be used

## 4.6 Limiting Torque

### The DRIVER provides the following four methods for limiting output torque to protect the machine.

Limiting Method	Description	Reference Sec- tion
Internal torque limit	Always limits torque by setting the parameter.	4.6.1
External torque limit	Limits torque by input signal from the host PC or PLCetc.	4.6.2
Torque limit with the command data (TLIM) *	Limits torque by using the command data (TLIM) for torque limiting function settable commands.	_
Torque limit with P_CL and N_CL signals of the servo command output signals (SVCMD_IO)*	Limits torque by using P_CL and N_CL signals of the servo command output signals (SVCMD_IO).	_

\* For details, refer to 8 MECHATROLINK-III Commands.

Note: The maximum torque of the servomotor is used when the set value exceeds the maximum torque.

### 4.6.1 Internal Torque Limit

This function always limits maximum output torque by setting values of following parameters.

	Forward Torque Limit Spec			Position	Torque	Classification
Pn402	Setting Range	Setting Unit	Factory Setting	When E	nabled	
	0 to 800	1%	800	Immed	liately	Setup
	Reverse Torque Limit		Speed	Position	Torque	Classification
Pn403	Setting Range	Setting Unit	Factory Setting	When Enabled		
	0 to 800	1%	800	Immed	liately	Setup

### The setting unit is a percentage of the rated torque.

Note: If the settings of Pn402 and Pn403 are too low, the torque may be insufficient for acceleration or deceleration of the servomotor.

#### Torque waveform



### 4.6.2 External Torque Limit

Use this function to limit torque by inputting a signal from the host PC or PLC...etc at specific times during machine operation. For example, some pressure must continually be applied (but not enough to damage the workpiece) when the robot is holding a workpiece or when a device is stopping on contact.

#### (1) Input Signals

Use the following input signals to limit a torque by external torque limit.

Туре	Signal Name	Connector Pin Number	Setting	Meaning	Limit value
Input	Input /P-CL	Must be allocated	ON (closed)	Forward external torque limit ON	The smaller value of these set- tings: Pn402 or Pn404
input //			OFF (open)	Forward external torque limit OFF	Pn402
Input /N-CL	/N-CL	Must be allocated	ON (closed)	Reverse external torque limit ON	The smaller value of these set- tings: Pn403 or Pn405
	ATT OL	Whist be unocated	OFF (open)	Reverse external torque limit OFF	Pn403

Note: Use parameter Pn50B.2 and Pn50B.3 to allocate the /P-CL signal and the /N-CL signal for use. For details, refer to *3.3.1 Input Signal Allocations*.

# (2) Related Parameters

Set the following parameters for external torque limit.

	Forward Torque Limit		Speed	Position Torque	Classification
Pn402	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 800	1%	800	Immediately	Setup
	Reverse Torque Limi	t	Speed	Position Torque	Classification
Pn403	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 800	1%	800	Immediately	Setup
	Forward External Tor	que Limit	Speed	Position Torque	Classification
Pn404	Setting Range Setting Unit		Factory Setting	When Enabled	
	0 to 800	1%	100	Immediately	Setup
	Reverse External Torque Limit		Speed	Position Torque	Classification
Pn405	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 800	1%	100	Immediately	Setup

The setting unit is a percentage of the rated torque.

Note: If the settings of Pn402, Pn403, Pn404, and Pn405 are too low, the torque may be insufficient for acceleration or deceleration of the servomotor.

(3) Changes in Output Torque during External Torque Limiting

The following diagrams show the change in output torque when the internal torque limit is set to 800%. In this example, the servomotor rotation direction is Pn000.0 = 0 (Sets CCW as forward direction).



### 4.6.3 Checking Output Torque Limiting during Operation The following signal can be output to indicate that the servomotor output torque is being limited.

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output	/CLT	Must be allocated	ON (closed)	Servomotor output torque is being lim- ited.
			OFF (open)	Servomotor output torque is not being limited.

Note: Use parameter Pn50F.0 to allocate the /CLT signal for use. For details, refer to 3.3.2 Output Signal Allocations.



# 4.7 Absolute Encoders

If using an absolute encoder, a system to detect the absolute position can be designed for use with the host PC or PLC...etc. As a result, an operation can be performed without a zero point return operation immediately after the power is turned ON.

A battery case is required to save position data in the absolute encoder. The battery is attached to the battery case of the encoder cable.

Set Pn002.2 to 0 (factory setting) to use the absolute encoder.

Parameter		Meaning	When Enabled	Classification	
Pn002	n.□0□□ [Factory setting]	Uses the absolute encoder as an absolute encoder.	After restart	Setup	
	n.□1□□	Uses the absolute encoder as an incremental encoder.			

A battery is not required when using the absolute encoder as an incremental encoder.

# 4.7.1 Connecting the Absolute Encoder

The following diagram shows the connection between a servomotor with an absolute encoder, the DRIVER, and the host PC or PLC...etc.





\*1. The absolute encoder pin numbers for the connector wiring depend on the servomotors.

**\*3.** When using an absolute encoder, provide power by installing an encoder cable with a Battery Case.

# 4.7.2 Absolute Data Request (SENS ON Command)

The Turn Sensor ON command (SENS\_ON) must be sent to obtain absolute data as an output from the DRIVER.



The SENS\_ON command is sent at the following timing.

The servomotor will not be turned ON even if the SV\_ON command is received during this interval.

\* Send the SENS\_OFF command to turn OFF the control power supply.

### 4.7.3 Battery Replacement

If the battery voltage drops to approximately 2.7 V or less, an absolute encoder battery error alarm (A.830) or an absolute encoder battery error warning (A.930) will be displayed.

If this alarm or warning is displayed, replace the batteries using the following procedure. Use Pn008.0 to set either an alarm (A.830) or a warning (A.930).

Parameter		Meaning	When Enabled	Classification
Pn008	n.□□□0 [Factory setting]	Outputs the alarm A.830 when the battery voltage drops.	A fter restart	Setup
Ph008	n.□□□1	Outputs the warning A.930 when the battery voltage drops.	The result	betup

- If Pn008.0 is set to 0, alarm detection will be enabled for 4 seconds after the ALM signal outputs max. 5 sec- onds when the control power is turned ON. No battery-related alarm will be displayed even if the battery voltage drops below the specified value after these 4
- seconds.
- If Pn008.0 is set to 1, alarm detection will be always enabled after the ALM signal outputs max. 5 seconds when the control power supply is turned ON.



#### (1) Battery Replacement Procedure

- 1. Turn ON the control power supply of the DRIVER only.
- 2. Open the battery case cover.



3. Remove the old battery and mount the new LEC-JZ-CVBAT battery as shown below.



4. Close the battery case cover.



- 5. After replacing the battery, turn OFF the control power supply to clear the absolute encoder battery error alarm (A.830).
- 6. Turn ON the control power supply again.
- 7. Check that the alarm display has been cleared and that the DRIVER operates normally.



If the DRIVER control power supply is turned OFF and the battery is disconnected (which includes disconnecting the encoder cable), the absolute encoder data will be deleted.

### 4.7.4 Absolute Encoder Setup and Reinitialization



The rotational data will be a value between -2 and +2 rotations when the absolute encoder setup is executed. The reference position of the machine system will change. Set the reference position of the host PC or PLC...etc to the position after setup.
 If the machine is started without adjusting the position of the host PC or PLC...etc, unexpected operation may cause injury or damage to the machine. Take sufficient care when operating the machine.

#### Setting up and reinitialization of the absolute encoder are necessary in the following cases.

- When starting the machine for the first time
- When an encoder backup error alarm (A.810) is generated
- When an encoder checksum error alarm (A.820) is generated
- · When initializing the rotational serial data of the absolute encoder

Set up the absolute encoder with Fn008.

- (1) Precautions on Setup and Reinitialization
  - The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
  - Set up or reinitialize the encoder when the servomotor power is OFF.
  - If the following absolute encoder alarms are displayed, cancel the alarm by using the same method as the set up (initializing) with Fn008. They cannot be canceled with the DRIVER Clear Warning or Alarm command (ALM\_CLR).
    - Encoder backup error alarm (A.810)
    - Encoder checksum error alarm (A.820)
  - Any other alarms (A.8  $\square$   $\square$ ) that monitor the inside of the encoder should be canceled by turning OFF the power.
- (2) Procedure for Setup and Reinitialization

Follow the steps below to setup or reinitialize the absolute encoder.

This setting can be performed using the Write Memory command (MEM\_WR). For details, refer to 8 *MECHATROLINK-III Commands*.

In the SigmaWin+  $\Sigma$ -V component main window, click Setup, point to Set Absolute Encoder and click Reset Absolute Encoder.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.2 Setting the Absolute Encoder.

## 4.7.5 Multiturn Limit Setting

The multiturn limit setting is used in position control applications for a turntable or other rotating device. For example, consider a machine that moves the turntable in the following diagram in only one direction.



Because the turntable moves in only one direction, the upper limit for revolutions that can be counted by an absolute encoder will eventually be exceeded. The multiturn limit setting is used in cases like this to prevent fractions from being produced by the integral ratio of the motor revolutions and turntable revolutions.

For a machine with a gear ratio of n:m, as shown above, the value of m minus 1 will be the setting for the multiturn limit setting (Pn205).

Multiturn limit setting (Pn205) = m-1

The case in which the relationship between the turntable revolutions and motor revolutions is m = 100 and n = 3 is shown in the following graph.



	Multiturn Limit Setting		Speed	Position Torque	Classification
Pn205	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 65535	1 Rev	65535	After restart	Setup

Note: This parameter is valid when the absolute encoder is used.

The range of the data will vary when this parameter is set to anything other than the factory setting.

- 1. When the motor rotates in the reverse direction with the rotational data at 0, the rotational data will change to the setting of Pn205.
- 2. When the motor rotates in the forward direction with the rotational data at the Pn205 setting, the rotational data will change to 0.



Set the value, the desired rotational amount -1, to Pn205.



## 4.7.6 Multiturn Limit Disagreement Alarm (A.CC0)

When the multiturn limit set value is changed with parameter Pn205, a multiturn limit disagreement alarm (A.CC0) will be displayed because the value differs from that of the encoder.

Alarm Display	Alarm Name	Alarm Output	Meaning
A.CC0	Multiturn Limit Disagreement	OFF (H)	Different multiturn limits have been set in the encoder and DRIVER.

If this alarm is displayed, perform the operation described below and change the multiturn limit value in the encoder to the value set in Pn205.

This setting can be performed using the Write Memory command (MEM\_WR). For details, refer to  $\Sigma$ -*V* Series User's Manual MECHATROLINK-III Standard Servo Profile Commands (No: SIEP S800000 63).

This setting can be performed with the adjustment command (ADJ). For information the adjustment command (ADJ), refer to *8 MECHATROLINK-III Commands*.

In the SigmaWin+  $\Sigma$ -V component main window, click Setup, print to Set Absolute Encoder and click Multi-Turn Limit Setting.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.2 Setting the Absolute Encoder.

4.7.7 Absolute Encoder Origin Offset

If using the absolute encoder, the positions of the encoder and the offset of the machine coordinate system (APOS) can be set. Use Pn808 to make the setting. After the SENS\_ON command is received by MECHA-TROLINK communications, this parameter will be enabled.

	Absolute Encoder C	Absolute Encoder Origin Offset		Position	
Pn80	8 Setting Range	Setting Unit	Factory Setting	When Enabled	
	-1073741823 to 1073741823	1 reference unit	0	Immediately	Setup

<Example>

If the encoder position (X) is set at the origin of the machine coordinate system (0), Pn808 = X.



## 4.7.8 Absolute Data Reception Sequence

The sequence in which the DRIVER receives outputs from the absolute encoder and transmits them to host controller is shown below.

### (1) Outline of Absolute Data

The serial data, pulses, etc., of the absolute encoder that are output from the DRIVER are output from the PAO, PBO, and PCO signals as shown below.



Phase-C Output Specifications

The pulse width of phase C (origin pulse) changes depending on the encoder output pulse (Pn212), becoming the same width as phase A.

The output timing is one of the following.

- Synchronized with the rising edge of phase A
- Synchronized with the falling edge of phase A
- Synchronized with the rising edge of phase B
- Synchronized with the falling edge of phase B

Note: When host controller receives the data of absolute encoder, do not perform counter reset using the output of PCO signal.



- (2) Absolute Data Reception Sequence
  - 1. Send the Turn Sensor ON (SENS\_ON) command from the host controller.
  - 2. After 100 ms, the system is set to rotational serial data reception standby and the incremental pulse up/ down counter is cleared to zero.
  - 3. Eight characters of rotational serial data is received.
  - 4. The system enters a normal incremental operation state about 400 ms after the last rotational serial data is received.



Note: The output pulses are phase-B advanced if the servomotor is turning forward regardless of the setting in Pn000.0.

Rotational serial data:

Indicates how many turns the motor shaft has made from the reference position, which was the position at setup.

Initial incremental pulses:

Initial incremental pulses which provide absolute data are the number of pulses required to rotate the motor shaft from the servomotor origin to the present position.

Just as with normal incremental pulses, these pulses are divided by the dividing circuit inside the DRIVER and then output.

The initial incremental pulse speed depends on the setting of the encoder output pulses (Pn212). Use the following formula to obtain the initial incremental pulse speed.

Setting of the Encoder Output Pulses (Pn212)	Formula of the Initial Incremental Pulse Speed
16 to 16384	(680 × Pn212) / 16384 [kpps]
16386 to 32768	(680 × Pn212) / 32768 [kpps]
32772 to 65536	(680 × Pn212) / 65536 [kpps]
65544 to 131072	(680 × Pn212) / 131072 [kpps]
131088 to 262144	(680 × Pn212) / 262144 [kpps]



Final absolute data PM is calculated by following formula.  $P_E=M \times R+P_O$  $P_S=M_S \times R+P_S'$  $P_M=P_E-P_S$ 



Signal	Meaning		
PE	Current value read by encoder		
Μ	Rotational serial data		
Po	Number of initial incremental pulses		
Ps	Absolute data read at setup (This is saved and controlled by the host controller.)		
Ms	Rotational data read at setup		
Ps'	Number of initial incremental pulses read at setup		
Рм	Current value required for the user's system		
R	Number of pulses per encoder revolution (pulse count after dividing, value of		
	Pn212)		

Note: The following formula applies in reverse mode. (Pn000.0 = 1)

 $P_E = -M \times R + P_O$ 

 $\mathbf{P}\mathbf{S} = \mathbf{M}\mathbf{S} \times \mathbf{R} + \mathbf{P}\mathbf{S}'$ 

 $P_M = P_E - P_S$ 

#### (3) Rotational Serial Data Specifications and Initial Incremental Pulses

Rotational Serial Data Specifications

The rotational serial data is output from PAO signal.

Data Transfer Method	Start-stop Synchronization (ASYNC)		
Baud rate	9600 bps		
Start bits	1 bit		
Stop bits	1 bit		
Parity	Even		
Character code	ASCII 7-bit code		
Data format	<ul> <li>8 characters, as shown below.</li> <li>"O" to "9" Rotational data in five digits</li> <li>"CR" in five digits</li> <li>"CR"</li></ul>		

Initial Incremental Pulses

The initial incremental pulses are output after division inside the DRIVER in the same way as for normal incremental pulses. Refer to *4.4.4 Encoder Output Pulses* for details.

(4) Transferring Alarm Contents

If an absolute encoder is used, the contents of alarms detected by the DRIVER are transmitted in serial data to the host controller from the PAO output when the Turn Sensor OFF command (SENS\_OFF) is received.

Note: The SENS\_OFF command cannot be received while the servomotor power is ON.

Output example of alarm contents are as shown below.



Turn Sensor OFF (SENS_OFF)	Erro	ON r detection	OFF
Panel Display	or 📙	$\textcircled{B} \rightarrow \fbox{Overspeed} \rightarrow \fbox{Overspeed}$	
PAO Output	Incremental pulse	Enlarged view Seria "A" "L" "M" "5" Upper 2	Serial Data al Data Format '1" "." "CR" digits

### 4.8 Other Output Signals

This section explains other output signals.

Use these signals according to the application needs, e.g., for machine protection.

## 4.8.1 Servo Alarm Output Signal (ALM)

This section describes signals that are output when the DRIVER detects errors and resetting methods.

(1) Servo Alarm Output Signal (ALM)

This signal is output when the DRIVER detects an error.

0	Configure an external circuit so that this alarm output turns OFF the main circuit power supply for the DRIVER whenever an error occurs.
IMPORTANT	

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output	ALM	CN1-3 4	ON (closed)	Normal DRIVER status
		ALM CIVI-5, 4	OFF (open)	DRIVER alarm status

(2) Alarm Reset Method

If a servo alarm (ALM) occurs, use one of the following methods to reset the alarm after eliminating the cause of the alarm.



Be sure to eliminate the cause of the alarm before resetting it. If the alarm is reset and operation continued without eliminating the cause of the alarm, it may result in damage to the equipment or fire.

- Resetting Alarms by Sending Clear Warning or Alarm Command (ALM\_CLR) For details, refer to 8 MECHATROLINK-III Commands.
- Resetting Alarms Using the SigmaWin+

In the SigmaWin+  $\Sigma$ -V component main window, click **Alarm** and then click **Display Alarm**. To clear an alarm, click **Reset** after removing the cause of the alarm. For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4. 2 Alarm Display.

# 4.8.2 Warning Output Signal (/WARN)

This signal is for a warning issued before the occurrence of an alarm. Refer to 9.2.1 List of Warnings.

(1) Signal Specifications

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output	/WARN	Must be allocated	ON (closed)	Warning status
Output	/ •••	What be anotated	OFF (open)	Normal status

Note: Use parameter Pn50F.3 to allocate the /WARN signal for use. For details, refer to 3.3.2 Output Signal Allocations.

# 4.8.3 Rotation Detection Output Signal (/TGON)

This output signal indicates that the servomotor is rotating at the speed set for Pn502 or a higher speed.

(1) Signal Specifications

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output /	/TGON	Must be allocated	ON (closed)	Servomotor is rotating with the motor speed above the setting in Pn502.
			OFF (open)	Servomotor is rotating with the motor speed below the setting in Pn502.

Note: Use parameter Pn50E.2 to allocate the /TGON signal for use. For details, refer to 3.3.2 Output Signal Allocations.

### (2) Related Parameter

Set the range in which the /TGON signal is output using the following parameter.

	Rotation Detection Le	evel	Speed	Position Torque	Classification
Pn502	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 10000	1 min <sup>-1</sup>	20	Immediately	Setup

## 4.8.4 Servo Ready Output Signal (/S-RDY)

This signal is turned ON when the DRIVER is ready to accept the servo ON (SV\_ON) command. The /S-RDY signal is turned ON under the following conditions.

- The main circuit power supply is ON.
- No hard wire base block state
- No servo alarms

- The Turn Sensor ON (SENS\_ON) command is received. (When an absolute encoder is used.)

If an absolute encoder is used, the output of absolute data to the host PC or PLC...etc must have been completed when the SENS\_ON command is received.

For details on the hard wire base block function, refer to 4.9.1 Hard Wire Base Block (HWBB) Function.

## (1) Signal Specifications

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output //	/S-RDY Must be allocated	Must be allocated	ON (closed)	The SERVOPACK is ready to accept the SV_ON command.
		With the anotated	OFF (open)	The SERVOPACK is not ready to accept the SV_ON command.

Note 1. Use parameter Pn50E.3 to allocate the /S-RDY signal for use. For details, refer to 3.3.2 Output Signal Allocations.

2. For details on the hard wire base block function and the servo ready output signal, refer to *4.9.1 Hard Wire Base Block (HWBB) Function.*
# 4.8.5 Speed Coincidence Output Signal (/V-CMP)

The speed coincidence output signal (/V-CMP) is output when the actual servomotor speed is the same as the reference speed. The host PC or PLC...etc uses the signal as an interlock. This signal is the output signal during speed control.

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output /V-CMP		Must be allocated	ON (closed)	Speed coincides.
			OFF (open)	Speed does not coincide.

Note: Use parameter Pn50E.1 to allocate the /V-CMP signal for use. Refer to 3.3.2 Output Signal Allocations for details.

	Speed Coincidence S	Signal Output Width	Speed	Classification	
Pn503	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 100	1 min <sup>-1</sup>	10	Immediately	Setup

The /V-CMP signal is output when the difference between the reference speed and actual motor speed is below this setting.



# <Example>

The /V-CMP signal is output at 1900 to 2100 min<sup>-1</sup> if the Pn503 is set to 100 and the reference speed is 2000 min<sup>-1</sup>.



4.8.6 Positioning Completed Output Signal (/COIN)

This signal indicates that servomotor movement has been completed during position control.

When the difference between the number of references output by the host PC or PLC...etc and the travel distance of the servomotor (position error) drops below the set value in the parameter, the positioning completion signal will be output.

Use this signal to check the completion of positioning from the host PC or PLC...etc.

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output /COIN		Must be allocated	ON (closed)	Positioning has been completed.
Output /COIN		White the anocated	OFF (open)	Positioning is not completed.

Note: Use parameter Pn50E.0 to allocate the /COIN signal for use. Refer to 3.3.2 Output Signal Allocations for details.

B 500	Positioning Complete	ed Width		Position	Classification
Pn522	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 1073741824	1 reference unit	7	Immediately	Setup

The positioning completed width setting has no effect on final positioning accuracy.



Note: If the parameter is set to a value that is too large, a positioning completed signal might be output if the position error is low during a low speed operation. This will cause the positioning completed signal to be output continuously. If this signal is output unexpectedly, reduce the set value until it is no longer output.

If the position error is kept to a minimum when the positioning completed width is small, use Pn207.3 to change output timing for the /COIN signal.

Pa	arameter	Name	Meaning	When Enabled	Classification
	n.0□□□ [Factory setting]		When the absolute value of the position error is below the positioning completed width (Pn522).		
Pn207	n.1口口口	/COIN Output Timing	When the absolute value of the position error is below the positioning completed width (Pn522), and the reference after applying the position reference filter is 0.	After restart	Setup
	n.2□□□		When the absolute value of the position error is below the positioning completed width (Pn522), and the position reference input is 0.		



# 4.8.7 Positioning Near Output Signal (/NEAR)

Before confirming that the positioning completed signal has been received, the host PC or PLC...etc first receives a positioning near signal and can prepare the operating sequence after positioning has been completed. The time required for this sequence after positioning can be shortened.

This signal is generally used in combination with the positioning completed output signal.

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output /NEAR	/NFAR	IEAR Must be allocated	ON (closed)	The servomotor has reached a point near to positioning completed.
			OFF (open)	The servomotor has not reached a point near to positioning completed.

Note: Use parameter Pn510.0 to allocate the /NEAR signal for use. Refer to 3.3.2 Output Signal Allocations for details.

	NEAR Signal Width			Position	Classification
Pn524	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 1073741824	1 reference unit	1073741824	Immediately	Setup

The positioning near signal (/NEAR) is output when the difference between the number of references output by the host PC or PLC...etc and the travel distance of the servomotor (position error) is less than the set value.



Note: Normally, the value of Pn524 should be larger than that for the positioning completed width (Pn522).

4.8.8 Speed Limit Detection Signal (/VLT)

This function limits the speed of the servomotor to protect the machine.

A servomotor in torque control is controlled to output the specified torque, but the motor speed is not controlled. Therefore, if an excessive reference torque is set for the load torque on the machinery side, the speed of the servomotor may increase greatly. If that may occur, use this function to limit the speed.

Note: The actual limit value of motor speed depends on the load conditions of the servomotor.



Refer to the following parameters for speed limit.

(1) Signals Output during Servomotor Speed Limit

The following signal is output when the motor speed reaches the limit speed.

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output	/VLT	Must be allocated	ON (closed)	Servomotor speed limit being applied.
			OFF (open)	Servomotor speed limit not being applied.

Note: Use parameter Pn50F.1 to allocate the /VLT signal for use. For details, refer to 3.3.2 Output Signal Allocations.

# (2) Speed Limit Setting

Select the speed limit mode with Pn002.1.

Parameter		Meaning	When Enabled	Classification
Pn002	n.□□0□ [Factory setting]	VLIM (the speed limit value during torque control) is not available. Uses the value set in Pn407 as the speed limit (internal speed limit function).	After restart Setup	
	n.□□1□	VLIM operates as the speed limit value (external speed limit function).		

- Internal Speed Limit Function

If the internal speed limit function is selected in Pn002.1, set the limit of the maximum speed of the servomotor in Pn407. The limit of the speed in Pn408.1 can be either the maximum speed of the servomotor or the overspeed alarm detection speed. Select the overspeed alarm detection speed to limit the speed to the maxi- mum speed of the servomotor or the equivalent.

	Speed Limit During T	Classification			
Pn407	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 10000	1 min <sup>-1</sup>	10000	Immediately	Setup

Note: The servomotor's maximum speed or the overspeed alarm detection speed will be used when the setting in this parameter exceeds the maximum speed of the servomotor used.

Parameter		Meaning	When Enabled	Classification
Pn408	n.□□0□ [Factory setting]	Uses the smaller value of the maximum motor speed and the value of Pn407 as the speed limit value.	After restart	Setup
Pn408	n.口口1口	Uses the smaller value of the overspeed alarm detec- tion speed and the value of Pn407 as speed limit value.		Setup

- External Speed Limit Function

If the external speed limit function is selected in Pn002.1, the motor speed is controlled by the speed limit value (VLIM). For details, refer to *8 MECHATROLINK-III Commands*.

#### 4.9 Safety Function

The safety function is incorporated in the DRIVER to reduce the risk associated with the machine by protecting workers from injury and by securing safe machine operation. Especially when working in hazardous areas inside the safeguard, as for machine maintenance, it can be used to avoid adverse machine movement.

#### 4.9.1 Hard Wire Base Block (HWBB) Function

The Hard Wire Base Block function (hereinafter referred to as HWBB function) is a safety function designed to baseblock the servomotor (shut off the motor current) by using the hardwired circuits. Each circuit for two channel input signals blocks the run signal to turn off the power module that controls the motor current, and the motor current is shut off. (Refer to the diagram below.)



For safety function signal connections, the input signal is the 0 V common and the output signal is the source output. This is the opposite of other signals described in this manual. To avoid confusion, the ON and OFF status of signals for safety functions are defined as follows: ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

- OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.
- (1) Risk Assessment

When using the HWBB function, be sure to perform a risk assessment of the servo system in advance. Make sure that the safety level of the standards is met. For details about the standards, refer to *Harmonized Standards* at the front of this manual.

Note: To meet the performance level d (PLd) in EN ISO 13849-1, the EDM signal must be monitored by a host PC or PLC...etc.If the EDM signal is not monitored by a host PC or PLC...etc, the system only qualifies for the performance level c (PLc).



The following risks can be estimated even if the HWBB function is used. These risks must be included in the risk assessment.

- The servomotor will move in an application where external force is applied to the servomotor (for example, gravity on the vertical axis). Take measures to secure the servomotor, such as installing a mechanical brake.
- The servomotor may move within the electric angle of 180 degrees in case of the power module failure, etc. Make sure that safety is ensured even in that situation. The rotation angle depends on the motor type. The maximum rotation angle is given below.
   Rotational motor: 1/6 rotation max. (rotation angle at the motor shaft)
- The HWBB function does not shut off the power to the DRIVER or electrically isolate it. Take measures to shut off the power to the DRIVER when performing maintenance on it.
- (2) Hard Wire Base Block (HWBB) State

The DRIVER will be in the following state if the HWBB function operates. If the /HWBB1 or /HWBB2 signal is OFF, the HWBB function will operate and the DRIVER will enter a hard wire baseblock (HWBB) state.



The HWBB function operates after the servomotor power is turned OFF.

The HWBB function operates while the servomotor power is ON.

/HWBB1 /HWBB2	ON (Normal operation)	OFF (Motor current shut-off request.)
M-III command	Motion command, etc.	SMON command, etc.
Servo command status SV_ON	1	0
Servo command input signal monitoring ESTP	0	1
DRIVER state	Operation	HWBB state



(3) Resetting the HWBB State

Usually after the servo OFF command (SV\_OFF: 32H) is received and the servomotor power is OFF, the DRIVER will then enter a hard wire baseblock (HWBB) state with the /HWBB1 and /HWBB2 signals turned OFF. By then turning the /HWBB1 and /HWBB2 signals ON in this state, the DRIVER will enter a baseblock (BB) state and can accept the servo ON command (SV\_ON: 31H).



If the /HWBB1 and /HWBB2 signals are OFF and the servo ON command is received, the HWBB state will be maintained after the /HWBB1 and /HWBB2 signals are turned ON.

Send the servo OFF command, and the DRIVER is placed in a BB state. Then send the servo ON command again.



Note: Even if the servomotor power is turned OFF by turning OFF the main circuit power, the HWBB status is retained until a servo OFF command is received.

(4) Related Commands

If the HWBB function is working with the /HWBB1 or /HWBB2 signal turned OFF, the setting of ESTP of the servo command input signal monitoring changes to 1, so the status of the upper level apparatus can be known by looking at the setting of this bit.

If the status becomes HWBB status during the execution of the next command, a command warning is issued.

If a warning is given, clear the alarm to return to normal operational status. After stopping or canceling the action command, using the sequence of commands to return to the HWBB status is recommended.

Object Action Commands
Servo ON (SV_ON)
Interpolating (INTERPORATE)
Positioning (POSING)
Constant speed feed (FEED)
Constant speed feed with position detection function (EX_FEED)
Interpolating with position detection function (LATCH)
External input positioning (EX_POSING)
Homing (ZRET)

(5) Error Detection in HWBB Signal

If only the /HWBB1 or /HWBB2 signal is input, an A.Eb1 alarm (Safety Function Signal Input Timing Error) will occur unless the other signal is input within 10 seconds. This makes it possible to detect failures, such as disconnection of the HWBB signals.

▲ CAUTION

The safety function signal input timing error alarm (A.Eb1) is not a safety-related part of a control system. Keep this in mind in the system design.

(6) Connection Example and Specifications of Input Signals (HWBB Signals)

The input signals must be redundant. A connection example and specifications of input signals (HWBB signals) are shown below.

<b>D</b> IMPORTANT	For safety function signal connections, the input signal is the 0 V common and the output signal is the source output. This is opposite to other signals described in this manual. To avoid confusion, the ON and OFF status of signals for safety functions are defined as follows:
	ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.
	OFF: The state in which the relay contacts are open or the transistor is OFF and no cur- rent flows into the signal line.

- Connection Example



- Specifications

Туре	Signal Name	Connector Pin Number	Setting	Meaning
	/HWBB1	CN8-4 CN8-3	ON (closed)	Does not use the HWBB function. (normal operation)
Input			OFF (open)	Uses the HWBB function. (motor current shut-off request)
mput	/HWBB2	CN8-6 CN8-5	ON (closed)	Does not use the HWBB function. (normal operation)
			OFF (open)	Uses the HWBB function. (motor current shut-off request)

The input signals (HWBB signals) have the following electrical characteristics.

Items	Characteristics	Remarks
Internal Impedance	3.3 kΩ	-
Operation Movable Volt- age Range	+11 V to + 25 V	_
Maximum Delay Time	20 ms	Time from the /HWBB1 and /HWBB2 signals are OFF to the HWBB function operates.

If the HWBB function is requested by turning OFF the /HWBB1 and /HWBB2 input signals on the two channels, the power supply to the servomotor will be turned OFF within 20 ms (see below).



- Note 1. The OFF status is not recognized if the total OFF time of the /HWBB1 and /HWBB2 signals is 0.5 ms or shorter.
  - 2. The status of the input signals can be checked using monitor displays. Refer to 7.5 Monitoring Safety Input Signals.
- (7) Operation with Utility Functions

The HWBB function works while the DRIVER operates in the utility function.

If any of the following utility functions is being used with the /HWBB1 and /HWBB2 signals turned OFF, the DRIVER cannot be operated by turning ON the /HWBB1 and /HWBB2 signals. Cancel the utility function first, and then set the DRIVER to the utility function again and restart operation.

- JOG operation (Fn002)
- Origin search (Fn003)
- Program JOG operation (Fn004)
- Advanced autotuning (Fn201)
- EasyFFT (Fn206)
- Automatic offset-signal adjustment of motor current detection signal (Fn00E)
- (8) Servo Ready Output (/S-RDY)

The servo ON (SV\_ON) command will not be accepted in the HWBB state. Therefore, the servo ready output will turn OFF. The servo ready output will turn ON if the servomotor power is OFF (set to BB state) when both the /HWBB1 and /HWBB2 signals are ON.

The following diagram shows an example where the main circuit power supply is turned ON, the Turn Sensor ON (SENS\_ON) command is sent (with an absolute encoder), and no servo alarm occurs.



(9) Lock signal (/BK)

When the /HWBB1 or /HWBB2 signal is OFF and the HWBB function operates, the lock signal (/BK) will turn OFF. At that time, Pn506 (lock Reference - servo OFF delay time) will be disabled. Therefore, the servo- motor may be moved by external force until the actual lock becomes effective after the lock signal (/BK) turns OFF.



(10) Dynamic Brake

If the dynamic brake is enabled in Pn001.0 (Stopping Method for Servomotor after SV\_OFF Command is Received), the servomotor will come to a stop under the control of the dynamic brake when the HWBB function works while the /HWBB1 or /HWBB2 signal is OFF.



- The dynamic brake is not a safety-related part of a control system. Be sure to design the system so that the system will not be put into danger if the servomotor coasts to a stop in the HWBB state. Usually, use a sequence in which the HWBB state occurs after the servomotor is stopped using the reference.
- If the application frequently uses the HWBB function, do not use the dynamic brake to stop the servomotor. Otherwise element deterioration in the DRIVER may result. To prevent internal elements from deteriorating, use a sequence in which the HWBB state occurs after the servomotor has come to a stop.

(11) Servo Alarm Output Signal (ALM)

In the HWBB state, the servo alarm output signal (ALM) is not sent.



4.9.2 External Device Monitor (EDM1)

The external device monitor (EDM1) functions to monitor failures in the HWBB function. Connect the monitor to feedback signals to the safety function device.

- Note: To meet the performance level d (PLd) in EN ISO13849-1, the EDM signal must be monitored by a PC or PLC...etc. If the EDM signal is not monitored by a PC or PLC...etc, the system only qualifies for the performance level c (PLc).
- Failure Detection Signal for EDM1 Signal

The relation of the EDM1, /HWBB1, and /HWBB2 signals is shown below.

Detection of failures in the EDM1 circuit can be checked using the following four status of the EDM1 signal in the table. Failures can be detected if the failure status can be confirmed, e.g., when the power supply is turned ON.

Signal Name	Logic				
/HWBB1	ON	ON	OFF	OFF	
/HWBB2	ON	OFF	ON	OFF	
EDM1	OFF	OFF	OFF	ON	

🕂 WARNING

• The EDM1 signal is not a safety output. Use it only for monitoring a failure.



# (1) Connection Example and Specifications of EDM1 Output Signal

Connection example and specifications of EDM1 output signal are explained below.



#### - Connection Example

EDM1 output signal is used for source circuit.EDM1 output signal can't use for sink circuit.



# - Specifications

Туре	Signal Name	Connector Pin Number	Setting	Meaning
Output	EDM1	CN8-8 CN8-7	ON (closed)	Both the /HWBB1 and the /HWBB2 signals are working normally.
			OFF (open)	The /HWBB1 signal, the /HWBB2 signal or both are not working normally.

Electrical characteristics of EDM1 signal are as follows.

Items	Characteristics	Remarks
Maximum Allowable Voltage	30 VDC	-
Maximum Current	50 mADC	-
Maximum Voltage Drop at ON	1.0 V	Voltage between EDM1+ and EDM1- when current is 50 mA
Maximum Delay Time	20 ms	Time from the change in /HWBB1 or /HWBB2 until the change in EDM1



#### 4.9.3 Application Example of Safety Functions

An example of using safety functions is shown below.

#### (1) Connection Example

In the following example, a safety unit is used and the HWBB function operates when the guard opens.



When a guard opens, both of signals, the /HWBB1 and the /HWBB2, turn OFF, and the EDM1 signal turns ON. Since the feedback is ON when the guard closes, the safety unit is reset, and the /HWBB1 and the / HWBB2 signals turn ON, and the operation becomes possible.

- Note: The EDM1 signal is used as a sourcing output. Connect the EDM1 so that the current flows from EMD1+ to EMD1-.
- (2) Failure Detection Method

In case of a failure such as the /HWBB1 or the /HWBB2 signal remains ON, the safety unit is not reset when the guard closes because the EDM1 signal keeps OFF. Therefore starting is impossible, then the failure is detected.

In this case, an error in the external device, disconnection or short-circuiting of the external wiring, or a failure in the DRIVER must be considered. Find the cause and correct the problem.



4.9.4 Confirming Safety Functions

When starting the equipment or replacing the DRIVER for maintenance, be sure to conduct the following confirmation test on the HWBB function after wiring.

- When the /HWBB1 and /HWBB2 signals turn OFF, check that the digital operator displays "Hbb" and that the servomotor does not operate.
- Check with the display of the feedback circuit input of the connected device to confirm that the EDM1 signal is OFF while in normal operation.



# 4.9.5 Connecting a Safety Function Device

Connect a safety function device using the following procedure.

1. Remove the servomotor connection terminal connector while pressing the lock. Applicable DRIVERs: LECYU2-V5, V7, V8

For DRIVER models not listed above, it is not necessary to remove the servomotor connection terminal connector. Go to step 2.



2. Remove the safety function's jumper connector from CN8.



- 3. Connect a safety function device to CN8.
  - Note: When not using the safety function, use the DRIVER with the safety function's jumper connector inserted in CN8. If the DRIVER is used without the jumper connector inserted into CN8, no current will flow to the servomotor and no torque will be output.

#### 4.9.6 Precautions for Safety Function



**4**-64

5.	Adjustments	2
	5.1 Type of Adjustments and Basic Adjustment Procedure	2
	5.1.1 Adjustments	2
	5.1.2 Basic Adjustment Procedure	3
	5.1.3 Monitoring Operation during Adjustment	4
	5.1.4 Safety Precautions on Adjustment of Servo Gains	7
	5.2 Tuning-less Function	10
	5.2.1 Tuning-less Function	10
	5.2.2 Tuning-less Levels Setting (Fn200) Procedure	13
	5.2.3 Related Parameters	15
	5.3 Advanced Autotuning (Fn201)	16
	5.3.1 Advanced Autotuning.	16
	5.3.2 Advanced Autotuning Procedure	19
	5.3.3 Related Parameters	32
	5.4 Advanced Autotuning by Reference (Fn202)	33
	5.4.1 Advanced Autotuning by Reference.	33
	5.4.2 Advanced Autotuning by Reference Procedure.	35
	5.4.3 Related Parameters	40
	5.5 One-parameter Tuning (Fn203)	41
	5.5.1 One-parameter Tuning	41
	5.5.2 One-parameter Tuning Procedure	42
	5.5.3 One-parameter Tuning Example	45
	5.5.4 Related Parameters	46
	5.6 Anti-Resonance Control Adjustment Function (Fn204)	47
	5.6.1 Anti-Resonance Control Adjustment Function	47
	5.6.2 Anti-Resonance Control Adjustment Function Operating Procedure	48
	5.6.3 Related Parameters	48
	5.7 Vibration Suppression Function (Fn205)	49
	5.7.1 Vibration Suppression Function	49
	5.7.2 Vibration Suppression Function Operating Procedure	50
	5.7.3 Related Parameters	52
	5.8 Additional Adjustment Function	53
	5.8.1 Switching Gain Settings	53
	5.8.2 Manual Adjustment of Friction Compensation	58
	5.8.3 Current Control Mode Selection Function	60
	5.8.4 Current Gain Level Setting	60
	5.8.5 Speed Detection Method Selection	60
	5.8.6 Backlash Compensation Function	61
	5.8.7 Torque Reference Filter	68

# 5. Adjustments

#### 5.1 Type of Adjustments and Basic Adjustment Procedure

This section describes type of adjustments and the basic adjustment procedure.

5.1.1 Adjustments

Adjustments (tuning) are performed to optimize the responsiveness of the DRIVER. The responsiveness is determined by the servo gain that is set in the DRIVER. The servo gain is set using a combination of parameters, such as speed loop gain, position loop gain, filters, friction compensation, and moment of inertia ratio. These parameters influence each other. Therefore, the servo gain must be set considering the balance between the set values.

Generally, the responsiveness of a machine with high rigidity can be improved by increasing the servo gain. If the servo gain of a machine with low rigidity is increased, however, the machine will vibrate and the respon- siveness may not be improved. In such case, it is possible to suppress the vibration with a variety of vibration suppression functions in the DRIVER.

The servo gains are factory-set to appropriate values for stable operation. The following utility function can be used to adjust the servo gain to increase the responsiveness of the machine in accordance with the actual conditions. With this function, parameters related to adjustment above will be adjusted automatically and the need to adjust them individually will be eliminated.

Utility Function for Adjustment	Outline	Applicable Control Method
Tuning-less Levels Setting (Fn200)	This function is enabled when the factory settings are used. This func- tion can be used to obtain a stable response regardless of the type of machine or changes in the load.	Speed and Position
Advanced Autotuning (Fn201)	<ul> <li>The following parameters are automatically adjusted using internal references in the SERVOPACK during automatic operation.</li> <li>Moment of inertia ratio</li> <li>Gains (position loop gain, speed loop gain, etc.)</li> <li>Filters (torque reference filter, notch filter)</li> <li>Friction compensation</li> <li>Anti-resonance control adjustment function</li> <li>Vibration suppression function</li> </ul>	Speed and Position
Advanced Autotuning by Reference (Fn202)	<ul> <li>The following parameters are automatically adjusted with the position reference input from the host controller while the machine is in operation.</li> <li>Gains (position loop gain, speed loop gain, etc.)</li> <li>Filters (torque reference filter, notch filter)</li> <li>Friction compensation</li> <li>Anti-resonance control adjustment function</li> <li>Vibration suppression function</li> </ul>	Position
One-parameter Tuning (Fn203)	<ul> <li>The following parameters are manually adjusted with the position or speed reference input from the host controller while the machine is in operation.</li> <li>Gains (position loop gain, speed loop gain, etc.)</li> <li>Filters (torque reference filter, notch filter)</li> <li>Friction compensation</li> <li>Anti-resonance control adjustment function</li> </ul>	Speed and Position
Anti-Resonance Control Adjustment Function (Fn204)	This function effectively suppresses continuous vibration.	Speed and Position
Vibration Suppression Function (Fn205)	This function effectively suppresses residual vibration if it occurs when positioning.	Position

This section describes the following utility adjustment functions.

#### 5.1.2 Basic Adjustment Procedure

The basic adjustment procedure is shown in the following flowchart. Make suitable adjustments considering the conditions and operating requirements of the machine.



5-3

5.1.3 Monitoring Operation during Adjustment

Check the operating status of the machine and signal waveform when adjusting the servo gain. Connect a measuring instrument, such as a memory recorder, to connector CN5 analog monitor connector on the DRIVER to monitor analog signal waveform.

The settings and parameters for monitoring analog signals are described in the following sections.

(1) Connector CN5 for Analog Monitor

To monitor analog signals, connect a measuring instrument with cable (YASKAWA CONTROLS CO., LTD) to the connector CN5.



(2) Monitor Signal

The shaded parts in the following diagram indicate analog output signals that can be monitored.



DRIVER

The following signals can be monitored by selecting functions with parameters Pn006 and Pn007.
Pn006 is used for analog monitor 1 and Pn007 is used for analog monitor 2.

Parameter		Description				
i ui		Monitor Signal	Unit	Remarks		
	n.□□00 [Pn007 Factory Setting]	Motor rotating speed	1 V/1000 min <sup>-1</sup>	_		
	n.□□01	Speed reference	1 V/1000 min <sup>-1</sup>	-		
	n.□□02 [Pn006 Factory Setting]	Torque reference	1 V/100% rated torque	_		
	n.□□03	Position error	0.05 V/1 reference unit	0 V at speed/torque control		
	n.□□04	Position amplifier error	0.05 V/1 encoder pulse unit	Position error after electronic gear conversion		
Pn006 Pn007	n.□□05	Position reference speed	1 V/1000 min <sup>-1</sup>	_		
	n.□□06	Reserved (Do not change.)	_	_		
	n.□□07	Motor-load position error	0.01 V/1 reference unit	_		
	n.□□08	Positioning completed	Positioning completed: 5 V Positioning not com- pleted: 0 V	Completion indicated by out- put voltage.		
	n.□□09	Speed feedforward	1 V/1000 min <sup>-1</sup>	—		
	n.□□0A	Torque feedforward	1 V/100% rated torque	_		
	n.□□0B	Active gain *1	1st gain: 1 V 2nd gain: 2 V	Gain type indicated by output voltage.		
	n.□□0C	Completion of position reference	Completed: 5 V Not completed: 0 V	Completion indicated by out- put voltage.		
	n.□□0D	External encoder speed	1 V/1000 min <sup>-1</sup>	Value at motor shaft		

# \*1. Refer to 5.8.1 Switching Gain Settings for details.

(3) Setting Monitor Factor

The output voltages on analog monitors 1 and 2 are calculated by the following equations.



<Example> Analog monitor output at n.  $\Box \Box 00$  (motor rotating speed setting)





Output resolution: 16-bit

# (4) Related Parameters

Use the following parameters to change the monitor factor and the offset.

	Analog Monitor 1 Off	set Voltage	Speed	Position Torque	Classification
Pn550	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	0.1 V	0	Immediately	Setup
	Analog Monitor 2 Off	set Voltage	Speed	Position Torque	Classification
Pn551	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	0.1 V	0	Immediately	Setup
	Analog Monitor Magn	ification ( $\times$ 1)	Speed	Position Torque	Classification
Pn552	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	× 0.01	100	Immediately	Setup
Pn553	Analog Monitor Magn	ification ( $\times$ 2)	Speed	Position Torque	Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	× 0.01	100	Immediately	Setup

#### 5.1.4 Safety Precautions on Adjustment of Servo Gains

If adjusting the servo gains, observe the following precautions.
Do not touch the rotating section of the servomotor while power is being supplied to the motor.
Before starting the servomotor, make sure that the DRIVER can come to an emergency stop at any time.
Make sure that a trial operation has been performed without any trouble. Install a safety brake on the machine.

Set the following protective functions of the DRIVER to the correct settings before starting to adjust the servo gains.

(1) Overtravel Function

Set the overtravel function. For details on how to set the overtravel function, refer to 4.3.2 *Overtravel*.

(2) Torque Limit

The torque limit calculates the torque required to operate the machine and sets the torque limits so that the out- put torque will not be greater than required. Setting torque limits can reduce the amount of shock applied to the machine when troubles occur, such as collisions or interference. If a torque limit is set lower than the value that is needed for operation, overshooting or vibration can be occurred. For details, refer to *4.6 Limiting Torque*.

(3) Excessive Position Error Alarm Level

The excessive position error alarm is a protective function that will be enabled when the DRIVER is used in position control.

If this alarm level is set to a suitable value, the DRIVER will detect an excessive position error and will stop the servomotor if the servomotor does not operate according to the reference. The position error indicates the difference between the position reference value and the actual motor position.

The position error can be calculated from the position loop gain (Pn102) and the motor speed with the follow- ing equation.

Position Error [reference unit] = 
$$\frac{\text{Motor Speed [min^{-1}]}}{60} \times \frac{\text{Encoder Resolution}^{+1}}{\text{Pn102 [0.1/s]/10}^{+2}} \times \frac{\text{Pn210}}{\text{Pn20E}}$$

Excessive Position Error Alarm Level (Pn520 [1 reference unit])

 $Pn520 > \frac{Max. Motor Speed [min<sup>-1</sup>]}{60} \times \frac{Pncoder Resolution^{*1}}{Pn102 [0.1/s]/10^{*2}} \times \frac{Pn210}{Pn20E} \times (1.2 \text{ to } 2)$ 

- \*1. Refer to 4.4.3 Electronic Gear.
- \*2. To check the Pn102 setting, change the parameter display setting to display all parameters (Pn00B.0 = 1).

At the end of the equation, a coefficient is shown as " $\times$  (1.2 to 2)." This coefficient is used to add a margin that prevents a position error overflow alarm (A.d00) from occurring in actual operation of the servomotor.

Set the level to a value that satisfies these equations, and no position error overflow alarm (A.d00) will be generated during normal operation. The servomotor will be stopped, however, if it does not operate according to the reference and the DRIVER detects an excessive position error.

The following example outlines how the maximum limit for position deviation is calculated. These conditions apply.

- Maximum speed = 6000
- Encoder resolution = 1048576 (20 bits)
- Pn102 = 400
- Pn210/Pn20E = 1/1

Under these conditions, the following equation is used to calculate the maximum limit (Pn520).

$$Pn520 = \frac{6000}{60} \times \frac{1048576}{400/10} \times \frac{1}{1} \times 2$$
  
= 2621440 × 2  
= 5242880 (The factory setting of Pn520)

If the acceleration/deceleration of the position reference exceeds the capacity of the servomotor, the servomo- tor cannot perform at the requested speed, and the allowable level for position error will be increased as not to satisfy these equations. If so, lower the level of the acceleration/deceleration for the position reference so that the servomotor can perform at the requested speed or increase the excessive position error alarm level (Pn520).

-	Re	lated	Para	amet	er
---	----	-------	------	------	----

	Excessive Position Error Alarm Level		Position		Classification
Pn520	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 1073741823	1 reference unit	5242880	Immediately	Setup

- Related Alarm

Alarm Display	Alarm Name	Meaning
A.d00	Position Error Overflow	Position errors exceeded parameter Pn520.

(4) Vibration Detection Function

Set the vibration detection function to an appropriate value with the vibration detection level initialization (Fn01B). For details on how to set the vibration detection function, refer to *6.15 Vibration Detection Level Initialization (Fn01B)*.

#### (5) Excessive Position Error Alarm Level at Servo ON

If position errors remain in the error counter when turning ON the servomotor power, the servomotor will move and this movement will clear the counter of all position errors. Because the servomotor will move suddenly and unexpectedly, safety precautions are required. To prevent the servomotor from moving suddenly, select the appropriate level for the excessive position error alarm level at servo ON (Pn526) to restrict opera- tion of the servomotor.



# - Related Parameters

D 500	Excessive Position Erro	or Alarm Level at Servo	ON Position		Classification
Ph526	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 1073741823	1 reference unit	5242880	Immediately	Setup

	Excessive	Position Error Warning Le	evel at Servo ON	Position	Classification
Pn528	Setting Range	Setting Unit	Factory Setting	When Enabled	Classification
	10 to 100	1%	100	Immediately	Setup

	Speed Limit Level at Se	ervo ON	Position		Classification
Pn529	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 10000	1 min <sup>-1</sup>	10000	Immediately	Setup

# - Related Alarms

Alarm Dis- play	Alarm Name	Meaning
A.d01	Position Error Overflow Alarm at Servo ON	This alarm occurs if the servomotor power is turned ON when the position error is greater than the set value of Pn526 while the servomotor power is OFF.
A.d02	Position Error Overflow Alarm by Speed Limit at Servo ON	When the position errors remain in the error counter, Pn529 limits the speed if the servomotor power is turned ON. If Pn529 limits the speed in such a state, this alarm occurs when position references are input and the number of position errors exceeds the value set for the excessive position error alarm level (Pn520).

When an alarm occurs, refer to 9 Troubleshooting and take the corrective actions.

#### 5.2 Tuning-less Function

The tuning-less function is enabled in the factory settings. If resonance is generated or excessive vibration occurs, refer to *5.2.2 Tuning-less Levels Setting (Fn200) Procedure* and change the set value of Pn170.2 for the rigidity level and the set value in Pn170.3 for the load level.



# 5.2.1 Tuning-less Function

The tuning-less function obtains a stable response without manual adjustment regardless of the type of machine or changes in the load.

(1) Enabling/Disabling Tuning-less Function

The following parameter is used to enable or disable the tuning-less function.

Parameter		Meaning	When Enabled	Classification
	n.口口口0	Disables tuning-less function.		
	n.□□□1 [Factory setting]	Enables tuning-less function.		
Pn170	n.□□0□ [Factory setting]	Used as speed control.	After restart	Setup
	n.□□1□	Used as speed control and PC or PLCetc. used as position control.		

# (2) Application Restrictions

The tuning-less function can be used in position control or speed control. This function is not available in torque control. The following application restrictions apply to the tuning-less function.

Function	Availability	Remarks
Vibration detection level initialization (Fn01B)	Available	-
Advanced autotuning (Fn201)	Available (Some conditions apply)	<ul> <li>This function can be used when the moment of inertia is calculated.</li> <li>While this function is being used, the tuning-less function cannot be used. After completion of the autotuning, it can be used again.</li> </ul>
Advanced autotuning by reference (Fn202)	Not available	-
One-parameter tuning (Fn203)	Not available	-
Anti-resonance control adjustment func- tion (Fn204)	Not available	_
Vibration suppression function (Fn205)	Not available	_
EasyFFT (Fn206)	Available	While this function is being used, the tuning- less function cannot be used. After completion of the EasyFFT, it can be used again.
Friction compensation	Not available	-
Gain switching	Not available	-
Offline moment of inertia calculation *	Not available	Disable the tuning-less function by setting Pn170.0 to 0 before executing this function.
Mechanical analysis*	Available	While this function is being used, the tuning- less function cannot be used. After completion of the analysis, it can be used again.

\* Operate using SigmaWin+.

(3) Automatically Setting the Notch Filter

Usually, set this function to Auto Setting. (The notch filter is factory-set to Auto Setting.) If this function is set to Auto Setting, vibration will be detected automatically and the notch filter will be set when the tuning-less function is enabled.

Set this function to Not Auto Setting only if you do not change the notch filter setting before executing tuning- less function.

Parameter		Meaning	When Enabled	Classification
Pn460	n.□0□□	Does not set the 2nd notch filter automatically with utility function.	Immediately	Tuning
Pn460	n.□1□□ [Factory setting]	Set the 2nd notch filter automatically with utility function.	minediatery	Tuning

#### (4) Tuning-less Level Settings

Two tuning-less levels are available: the rigidity level and load level. Both levels can be set in the Fn200 util- ity function or in the Pn170 parameter.

- Rigidity Level

Parameter		Meaning	When Enabled	Classification
	n.口0口口	Rigidity level 0 (Level 0)		
	n.□1□□	Rigidity level 1 (Level 1)		Setup
Pn170	n.□2□□	Rigidity level 2 (Level 2)	Immediately	
	n.□3□□	Rigidity level 3 (Level 3)	5	1
	n.□4□□ [Factory setting]	Rigidity level 4 (Level 4)		

# - Load Level

Parameter		Meaning	When Enabled	Classification
	n.0口口口	Load level : Low (Mode 0)		
Pn170	n.1□□□ [Factory setting]	Load level : Medium (Mode 1)	Immediately	Setup
	n.2□□□	Low level : High (Mode 2)		

5.2.2 Tuning-less Levels Setting (Fn200) Procedure



The procedure to use the tuning-less function is given below.

Operate the tuning-less function from the SigmaWin+.

(1) Preparation

Check the following settings before performing the tuning-less function. If the settings are not correct, "NO- OP" will be displayed during the tuning-less function.

- The tuning-less function must be enabled (Pn170.0 = 1).
- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The test without a motor function must be disabled. (Pn00C.0 = 0).
- (2) Operating Procedure with Sigma Win+
  - 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Setup** and then **Response Level Setting**.

Response Level Setting-Adj AXI5#01
Response Level Setting Set the response level. Lower the level until the vibration stops.
3- 2- 1-
Completed. Cancel

- 2. Click the setting arrows to adjust the response level so that the machine does not vibrate.
  - The factory setting is 4, the maximum level.
- 3. Click **Completed** to save the setting in the DRIVER.



(3) Alarm and Corrective Actions

The autotuning alarm (A.521) will occur if resonance sound is generated or excessive vibration occurs during position control. In such case, take the following actions.

- Resonance Sound In the SigmaWin+, reduce the setting of the Response level.
- Excessive Vibration during Position Control Take one of the following actions to correct the problem.

In the SigmaWin+, reduce the setting of the Response level. Increase the setting of Pn170.3 (Load level) or reduce the setting of Pn170.2.

(4) Parameters Disabled by Tuning-less Function

When the tuning-less function is enabled in the factory settings, the settings of these parameters are not avail- able: Pn100, Pn101, Pn102, Pn103, Pn104, Pn105, Pn106, Pn160, Pn139, and Pn408. These gain-related parameters, however, may become effective depending on the executing conditions of the functions specified in the following table. For example, if EasyFFT is executed when the tuning-less function is enabled, the set- tings in Pn100, Pn104, Pn101, Pn105, Pn102, Pn106, and Pn103, as well as the manual gain switch setting, will be enabled, but the settings in Pn408.3, Pn160.0, and Pn139.0 will be not enabled.

Parameters Disabled by Tuning-less Function		Related Functions and Parameters*			
Item	Name	Pn Number	Torque Con- trol	Easy FFT	Mechanical Analysis (Ver- tical Axis Mode)
	Speed Loop Gain 2nd Speed Loop Gain	Pn100 Pn104	0	0	0
Gain	Speed Loop Integral Time Constant 2nd Speed Loop Integral Time Constant	Pn101 Pn105	×	0	0
	Position Loop Gain 2nd Position Loop Gain	Pn102 Pn106	×	0	0
	Moment of Inertia Ratio	Pn103	0	0	0
Advanced Control	Friction Compensation Function Selec- tion	Pn408.3	×	×	×
	Anti-resonance Control Adjustment Selection	Pn160.0	×	×	×
Gain Switch-ing	Gain Switching Selection Switch	Pn139.0	×	×	×

\* O: Parameter enabled

 $\times$ : Parameter disabled

#### (5) Tuning-less Function Type

The following table shows the types of tuning-less functions for the version of DRIVER software.

Software Version*	Tuning-less Type	Meaning
000A or earlier	Tuning-less type 1	-
000B or later	Tuning-less type 2	The level of noise produced is lower than that of Type 1.

\*Refer to "6.13 Product Information Display" for the confirm method of the software version. The software version number of your DRIVER can be checked with Fn012.

Parameter		Meaning	When Enabled	Classification
	n.口口0口	Tuning-less type 1		
Pn14F	n.□□1□ [Factory setting]	Tuning-less type 2	After restart	Tuning



#### 5.2.3 Related Parameters

The following table lists parameters related to this function and their possibility of being changed while exe- cuting this function or of being changed automatically after executing this function.

- Parameters related to this function
  - These are parameters that are used or referenced when executing this function.
- Allowed changes during execution of this function
  - Yes : Parameters can be changed using SigmaWin+ while this function is being executed. No : Parameters cannot be changed using SigmaWin+ while this function is being executed.
- Automatic changes after execution of this function
  - Yes : Parameter set values are automatically set or adjusted after execution of this function.
    - No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes
Pn170	Tuning-less Function Related Switch	No	Yes
Pn401	Torque Reference Filter Time Constant	No	Yes
Pn40C	2nd Notch Filter Frequency	No	Yes
Pn40D	2nd Notch Filter Q Value	No	Yes

# 5.3 Advanced Autotuning (Fn201)

This section describes the adjustment using advanced autotuning.

r	
<b>P</b> IMPORTANT	<ul> <li>Advanced autotuning starts adjustments based on the set speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when starting adjustments. In this case, make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.</li> <li>Before performing advanced autotuning with the tuning-less function enabled (Pn170.0 = 1: Factory setting), always set calculate the load moment of inertia. The tuning-less function will automatically be disabled, and the gain will be set by advanced autotuning.</li> <li>With the load moment of inertia is not calculated, "Error" will be displayed on the panel operator, and advanced autotuning will not be performed.</li> <li>If the operating conditions, such as the machine-load or drive system, are changed after advanced autotuning, then change the following related parameters to disable any values that were adjusted before performing advanced autotun- ing is performed without changing the parameters, machine vibration may occur, resulting in damage to the machine.</li> <li>Pn00B.0=1 (Displays all parameters.)</li> <li>Pn140.0=0 (Does not use model following control.)</li> <li>Pn408=n.00□0 (Does not use friction compensation, 1st notch filter, or 2nd notch filter.)</li> </ul>

5.3.1 Advanced Autotuning

Advanced autotuning automatically operates the servo system (in reciprocating movement in the forward and reverse directions) within set limits and adjust the DRIVER automatically according to the mechanical characteristics while the servo system is operating.

Advanced autotuning can be performed without connecting the PC or PLC...etc. The following automatic operation specifications apply.

- Maximum speed: Rated motor speed × 2/3
- Acceleration torque: Approximately 100% of rated motor torque
  - The acceleration torque varies with the influence of the moment of inertia ratio
  - (Pn103), machine friction, and external disturbance.
- Travel distance: The travel distance can be set freely. The distance is factory-set to a value equivalent to 3 motor rotations.



Advanced autotuning performs the following adjustments.

- Moment of inertia ratio
- Gains (e.g., position loop gain and speed loop gain)
- Filters (torque reference filter and notch filter)
- Friction compensation
- Anti-resonance control
- Vibration suppression (Mode = 2 or 3)

Refer to 5.3.3 *Related Parameters* for parameters used for adjustments.

# 

• Because advanced autotuning adjusts the DRIVER during automatic operation, vibration or over- shooting may occur. To ensure safety, perform advanced autotuning in a state where the DRIVER can come to an emergency stop at any time.

(1) Preparation

Check the following settings before performing advanced autotuning. The message "NO-OP" indicating that the settings are not appropriate will be displayed, if all of the following conditions are not met.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servomotor power must be OFF.
- The control method must not be set to torque control.
- The gain selection switch must be in manual switching mode (Pn139.0 = 0).
- Gain setting 1 must be selected.
- The test without a motor function must be disabled (Pn00C.0 = 0).
- All alarms and warning must be cleared.
- The hardwire baseblock (HWBB) must be disabled.
- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- Jcalc must be set to ON to calculate the load moment of inertia when the tuning-less function is enabled (Pn170.0 = 1: factory setting) or the tuning-less function must be disabled (Pn170.0 = 0).
- Note: If advanced autotuning is started while the DRIVER is in speed control, the mode will change to position control automatically to perform advanced autotuning. The mode will return to speed control after completing the adjustment. To perform advanced autotuning in speed control, set the mode to 1 (Mode = 1).

(2) When Advanced Autotuning Cannot Be Performed

Advanced autotuning cannot be performed normally under the following conditions. Refer to *5.4 Advanced Autotuning by Reference (Fn202)* and *5.5 One-parameter Tuning (Fn203)* for details.

• The machine system can work only in a single direction.

(3) When Advanced Autotuning Cannot Be Performed Successfully

Advanced autotuning cannot be performed successfully under the following conditions. Refer to *5.4 Advanced Autotuning by Reference (Fn202)* and *5.5 One-parameter Tuning (Fn203)* for details.

- The operating range is not applicable.
- The moment of inertia changes within the set operating range.
- The machine has high friction.
- The rigidity of the machine is low and vibration occurs when positioning is performed.
- The position integration function is used.
- P control operation (proportional control) is used.
  - Note: If a setting is made for calculating the moment of inertia, an error will result when P control operation is selected using /V\_PPI of the servo command output signals (SVCMD\_IO) while the moment of inertia is being calculated.
- The mode switch is used.
- Note: If a setting is made for calculating the moment of inertia, the mode switch function will be disabled while the moment of inertia is being calculated. At that time, PI control will be used. The mode switch function will be enabled after calculating the moment of inertia.
- Speed feedforward or torque feedforward is input.
- The positioning completed width (Pn522) is too small.



Change only the overshoot detection level (Pn561) to finely adjust the amount of overshooting without chang- ing the positioning completed width (Pn522). Because Pn561 is set by default to 100%, the allowable amount of overshooting is the same amount as that for the positioning completed width.

When Pn561 is set to 0%, the amount of overshooting can be adjusted to prevent overshooting the positioning completed width. If the setting of Pn561 is changed, however, the positioning time may be extended.

	Overshoot Detection Level		Speed Position Torque		Classification
Pn561	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 100	1%	100	Immediately	Setup
#### 5.3.2 Advanced Autotuning Procedure

The following procedure is used for advanced autotuning. Advanced autotuning is performed from the SigmaWin+. The operating procedure from the SigmaWin+ is described here.



This function executes tuning for sure to carefully read the SigmaV taken for the following.	the Servopack. Using this function while the motor is running is dangerous. Be vin+ Operation Manual before executing this function. Special care must be
Safety Precautions>	
<ol> <li>Before executing this function, m</li> </ol>	ake sure that the emergency stop (power off) can be activated when needed.
The response speed may change of	onsiderably during tuning.
Before executing this function, mak	e sure that the emergency stop (power off) can be activated when needed.
2. Confirm the safety of the area ad	joining the drive unit.
Before executing this function, all	vays confirm that the area within the motor motion range
and direction is clear for safe ope	ration. Provide protective devices to ensure safety in
the event of overtraveling or othe	r unexpected movement.
3. Always confirm that there is no p	osition error before running the motor.
Be sure to return to the origin and	reset the position prior to normal operation.
Running the motor without resetting	g the origin can lead to an overrun and is extremely dangerous.
4. When the moment of inertia (mas:	s) identification function is used for a vertical axis,
check the safety of the system.	
When the moment of inertia (mass	) identification function is used for a vertical axis,
confirm that the axis level does no	t drop when the servo is turned off.
<tuning precautions=""></tuning>	
5. Set the moment of inertia (mass)	ratio first.
The moment of intertia (mass) ration	o must be set to achieve correct tuning.
Be sure to set the ratio. The settin	g can be performed from the Tuning window.
<ol> <li>If vibration is generated, execute</li> </ol>	custom tunina.
Lower the gain until there is no vit	pration by executing custom tuning.
Note: Mithile turning, you oon yood the	wrong tipps related to the process
Click the Precentions button prov	vided in each tuning window

Click Execute. The Tuning main window appears.

Tuning		×
Set the moment of inertia (mass) ratio before executing autotuning.	Precautions	
Moment of inertia (mass) ratio identification		
Pn103 : Moment of Inertia Ratio		
Execute.	_	
100 % Edit		
Autotuning Reference input from host controller Position reference input Autotuning No reference input		
Advanced adjustment	Finish	

# - Moment of Inertia (Mass) Identification

Click Execute in the Tuning main window. The Condition Setting box will appear.

#### 1. Setting the Conditions

Set the conditions for identifying moment of inertia (mass) in the Condition Setting box.

Condition IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	nt 🖙 Write Results
Flease set the following conditions for Moment of Inertia Ide	stification.
Speed Loop Setting Pn100 Speed Loop Sain F000 [0.1Hz] Edit	Reference Selection           ±1000min-1(2:50 turns MAX)
Pn101:Speed Loop Integral Time Constant [2000 [0.01ms]	Detailed Setting(limitation in operation)
Identification start level           300         [%]	Acceleration ±[20000.00   5000.00 - 45836.62 ) [min-1/s]
	Speed ± 1000.00
The Moment of Inertia Riatio can not be identified correctly under the following cases:	(9.16 - 1100.00) [min-1]
<ol> <li>When the torque limit is active Please see the Setting Help in detail.</li> </ol>	Moving distance
Execute the software reset function, or turn the power off and then on after completion of execution.	(001-2.75) [iotation]
	<back next=""> Cancel</back>

Speed Loop Setting: Set the speed loop gain and integral time constant. [Edit]

Click Edit to view the Speed Loop-Related Setting Change box.

Identification Start Level: Set the moment of inertia (mass) identification start level. [Help]

Click **Help** to open the window for guidelines on the reference condition settings. Reference Selection: Select the reference pattern for identifying the moment of inertia (mass). (Recommended method.)

Detailed Setting: Create the reference pattern for setting the moment of inertia (mass) by changing the values with the slider or by directly entering the values.



#### [Next>]

Click Next to view the Reference Transmission box.

## [Cancel]

Click **Cancel** to return to the main window without changing the conditions. **[Confirm]** 

Click Confirm to view the reference wave.

Reference confirmation		X
Moving distance 2.50	(rota)	
Driving pattern		
V:Speed	1000.00	(min-1]
T1:Acceleration Time	50	[me]
T2:Constant-speed time	100	[me]
Total moving time	400	[ms]
	ок	

# 2. Reference Transmission

Transfer the reference conditions to the DRIVER. Click **Start** in the Reference Transmission box to begin the transfer.



#### [Start]

Click to **Start** to transfer the reference conditions to the DRIVER. A progress bar displays the progress status of the transfer.

#### [Cancel]

The **Cancel** button is available only during the transfer to the DRIVER. After the transmission is finished, it is unavailable and cannot be selected.

#### [Next>]

The Next button is available if the data is transferred successfully. If an error occurs or if the transmission is interrupted, it is unavailable and cannot be selected.



Click Next to view the Operation/Measurement box.

# [<Back]

Click **Back** to return to the Condition Setting box. The **Back** button is unavailable during a data transfer.

#### [Cancel]

Click Cancel to stop processing and return to the main window.

After the data has been successfully transferred, click Next, and the Operation/ Measurement box appears.

#### 3. Operation/Measurement

In the Operation/Measurement box, run and measure the actual motor. Measurements are taken two to seven times and then verified. Run the motor and take measurements using the following procedure.

1. Click Servo ON to turn on the servo power.



2. Click **Forward** to take measurements by turning (moving) the motor forward. After the measurements and the data transmission are finished, the following window appears.



3. Click **Reverse** to take measurements by turning (moving) the motor in reverse. After the measurements and the data transmission are finished, the following window appears.



- 4. Repeat steps 2 through 3 until all the measurements have been taken. The actual number of times the measurements have been taken is displayed in the upper left part on the screen.
  - The progress bar displays the percentage of data that has been transferred.1
- 5. After the measurement has been successfully completed, click Servo ON to turn to the servo OFF status.
- 6. Click Next, and the Write Results box appears.
  - When Next is clicked without turning to the servo OFF status, the following message appears.





Click OK to turn to the servo OFF status.

#### 4. Writing Results

In the Write Results box, set the moment of inertia (mass) ratio calculated in the operation/ measurement to the parameters.

Write	Results AX	<is#0< th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th></is#0<>							
Co Se	ondition etting	••	Reference Transmission	••	Operation / Measurement	••	Write Results		
	Writ	es th	ie Identifie	d Mo	ment of In	ertia F	Ratio.		
					- <b></b>	5			
			Identified Mom	ent of Ir	nertia Hatio [%] ►	•	Pn103 : Momei	nt of Inertia Hatio [%]	
						Results			
							< <u>B</u> ack	Einish	Cancel

#### [Writing Results]

Click **Writing Results** to assign the value displayed in the identified moment of inertia (mass) ratio to DRIVER parameter Pn103.

Pn103: Moment of Inertia (Mass) Ratio

Displays the value assigned to the parameter.

Click Write Results, and the new ratio calculated from the operation/measurement will be displayed.

#### [<Back]

The Back button is unavailable.

# [Cancel]

Click Cancel to return to the main window.

#### [Finish]

Click **Finish**, and a warning message appears reminding you to reset the origin position. (No warning message appears when the Write Results box has been opened from the Tuning main window.)

Moment of Inertia Identification	×
Be sure to reset the position before normal operation. Because the motor is driven by an internal reference, be sure to perform home return and reset the position prior to normal operation. Performing servomotor operation without reset is extremely dangerous a may lead to runaway, etc.	n asit
ок	

Click **OK** to return to the SigmaWin+ ©-V component Main window. If Pn103 (Moment of Inertia (Mass) Ratio) has been changed, that new value will remain.

- Autotuning without Reference Input
  - To execute autotuning without using a reference input, use the following procedure.
  - 1. Select the No reference input option under Reference input from host controller in the Tuning main window, and then click Autotuning. The Autotuning-Setting Conditions box will appear.

Autotuning - Settin	g Conditions A	XIS#1	
Set conditions.			
Switching the load mor	ment of intertia (	load mass) identifica	tion ———
1:A moment of inerti	a is not presum	ed.	•
Mode selection			
2:For positioning			•
A gain adjustment sp following automatic a notch filter, anti-reso	ecialized for po adjustments can nance control, a	sitioning will be exec be executed: Model and vibration suppres	uted. In addition, the following control, ssion.
Mechanism selection -			
D.Dell correct marchs	pism or linear m	otor	<b>_</b>
2.Dali screw necha	nishi of incur m	0.01	
2.Bail screw niecha Executes adjustment ball screw or linear r	: suitable for rela notor. Select thi	atively high-rigidity m s type if there is no a	echanism, such as a applicable mechanism.
Executes adjustment ball screw or linear r	: suitable for rek notor. Select thi	atively high-rigidity m s type if there is no a	echanism, such as a ppplicable mechanism.
Executes adjustment ball screw or linear r Distance	: suitable for rela notor. Select this	atively high-rigidity m s type if there is no a alue is specified.	echanism, such as a pplicable mechanism.
Executes adjustment ball screw or linear r Distance The moving range fro	suitable for rek notor. Select thi om the current v X 1000 =	atively high-rigidity m s type if there is no a alue is specified. 98000	echanism, such as a ppplicable mechanism. [reference units]
Executes adjustment ball screw or linear r Distance The moving range fro 98 (-99990 - 99990) (Setting invalid range	suitable for rek notor. Select thi om the current v X 1000 = e: -31 - 31)	atively high-rigidity m s type if there is no a alue is specified. 98000 2.9	echanism, such as a applicable mechanism. [reference units] [Rotation]
Z.Bail screw necha     Executes adjustment     ball screw or linear r     Distance     The moving range fro     [98     (-99990 - 99990)     (Setting invalid range     Tuning parameters	suitable for relation notor. Select thi com the current v X 1000 = e: -31 - 31)	atively high-rigidity m s type if there is no a alue is specified. 98000 2.9	echanism, such as a applicable mechanism. [reference units] [Rotation]
Z.Bail Screw necha         Executes adjustment         ball screw or linear r         Distance         The moving range from         98         (-99990 - 99990)         (Setting invalid range         Tuning parameters         Start tuning using	is suitable for relation notor. Select this om the current v X 1000 = e: -31 - 31) the default setti	atively high-rigidity m s type if there is no a alue is specified. 98000 2.9	echanism, such as a applicable mechanism. [reference units] [Rotation]

- 2. Select whether or not to use the load moment of inertia (load mass) identification from the Switching the load moment of inertia (load mass) identification box, the mode from the Mode selection box, the mechanism from the Mechanism selection box, and enter the moving distance. Then, click Next.
- · Calculating Moment of Inertia

Select the mode to be used. Usually, set to the Moment of inertia calculated.



## · Mode Selection

Select the mode.

Mode = 1: Makes adjustments considering response characteristics and stability (Standard level).

Mode = 2: Makes adjustments for positioning [Factory setting].

Mode = 3: Makes adjustments for positioning, giving priority to overshooting suppression.

#### ·Mechanism Selection

Select the mechanism according to the machine element to be driven. If there is noise or the gain does not increase, bet- ter results may be obtained by changing the rigidity type.

Type = 1: For belt drive mechanisms (LEFB, LEJB)

Type = 2: For ball screw drive mechanisms [Factory setting] (LEY, LEFS, LEJS)

# ·STROKE (Travel Distance) Setting

Travel distance setting range:

The travel distance setting range is from -99990000 to +99990000 [reference unit].

Specify the STROKE (travel distance) in increments of 1000 reference units.

The negative (-) direction is for reverse rotation, and the positive (+) direction is for forward rotation.

Initial value: About 3 rotations

Notes:

- •Set the number of motor rotations to at least 0.5; otherwise, "Error" will be displayed and the travel distance cannot be set.
- •To calculate the moment of inertia and ensure precise tuning, it is recommended to set the number of motor rotations to around 3.

x

When the **Start tuning using the default settings.** check box is selected in the Autotuning-Setting Conditions box, tuning will be executed using the tuning parameters set to the default values.

Autotuning - Automatic setting AXIS#1

Waiting for execution	Servo ON/OFF operation           Servo ON/OFF           Servo OFF
Oscillation level measurement	
Gain search behaviour evaluation	
Tuning completed	Mode selection 2:For positioning
	Mechanism selection
	2:Ball screw mechanism or linear motor
ONotch filter	98000 [reference units]
Anti-res Adj Vib Suppress	2.9 [Rotation]
Precautions	< Back Finish Cancel

3. Click Servo ON. The following box will appear.

Autotuning - Automatic se	etting AXIS#1	x
Waiting for execution	Servo ON/OFF operation Servo OFF Servo ON	
Oscillation level measurement		
Gain search behaviour evaluation		
Tuning completed	Mode selection 2:For positioning	
	Mechanism selection	
	2:Ball screw mechanism or linear motor	
ONotch filter	98000 [reference units]	
OAnti-res Adj OVib Suppress	2.9 [Rotation]	
Precautions	< Back Finish Cancel	

4. Click Start tuning. The motor will start rotating and tuning will commence.

acocaring Hacomatic	
Waiting for execution	Servo ON/OFF operation
-	Servo ON
Oscillation level measurement	
	Tuning
Gain search behaviour evaluation	Cancel
Tuning completed	Mode selection
]	2:For positioning
	Mechanism selection
	2:Ball screw mechanism or linear motor
	Distance
Notch filter	98000 [reference units]
Anti-res Adj Vib Suppress	2.9 [Rotation]
Precautions	< Back Finish Cancel

Vibration generated during tuning is automatically detected, and the optimum setting for the detected vibration will be made. When the setting is complete, the LED indicator lamps (bottom left of the box) of the functions used for the setting will light up.

5. When tuning is completed, click **Finish**. The results of tuning will be written in the parameters.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.6.3 Autotuning without Reference Input.

# (2) Failure in Operation When "NO-OP" Flashes on the Display

Probable Cause	Corrective Actions
The main circuit power supply was OFF.	Turn ON the main circuit power supply.
An alarm or warning occurred.	Remove the cause of the alarm or the warning.
Overtraveling occurred.	Remove the cause of the overtravel.
Gain setting 2 was selected by gain switching.	Disable the automatic gain switching.
The HWBB function operated.	Disable the HWBB function.

# When "Error" Flashes on the Display

\_

Error	Probable Cause	Corrective Actions
The gain adjustment was not successfully completed.	Machine vibration is occurring or the posi- tioning completed signal (/COIN) is turning ON and OFF when the servomotor is stopped.	<ul> <li>Increase the set value for Pn522.</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control adjustment function and the vibration suppression function.</li> </ul>
An error occurred during the calculation of the mo- ment of inertia.	Refer to the following table • When an Error Inertia.	Occurs during Calculation of Moment of
Travel distance setting er- ror	The travel distance is set to approximately 0.5 rotation or less, which is less than the min- imum adjustable travel distance.	Increase the travel distance. It is recom- mended to set the number of motor rota- tions to around 3.
The positioning complet- ed signal (/COIN) did not turn ON within approxi- mately 10 seconds after positioning adjustment was completed.	The positioning completed width is too nar- row or proportional control (P control) is being used.	<ul> <li>Increase the set value for Pn522.</li> <li>Set 0 to V_PPI in the servo command output signals (SVCMD_IO).</li> </ul>
The moment of inertia cannot be calculated when the tuning-less function was activated.	When the tuning-less function was activat- ed, Jcalc was set to the Moment of inertia not calculated so the moment of inertia was not calculated.	<ul> <li>Turn OFF the tuning-less function.</li> <li>Set to the Moment of inertia calculated, so the moment of inertia will be calculated.</li> </ul>

# When an Error Occurs during Calculation of Moment of Inertia

The following table shows the probable causes of errors that may occur during the calculation of the moment of inertia with the Moment of inertia calculated, along with corrective actions for the errors.

Error Dis- play	Probable Cause	Corrective Actions
Err1	The DRIVER started calculating the moment of inertia, but the calculation was not completed.	<ul><li>Increase the speed loop gain (Pn100).</li><li>Increase the STROKE (travel distance).</li></ul>
Err2	The moment of inertia fluctuated greatly and did not converge within 10 tries.	Set the calculation value based on the machine specifi- cations in Pn103 and execute the calculation with the Jcalc set to OFF.
Err3	Low-frequency vibration was detected.	Double the set value of the moment of inertia calculat- ing start level (Pn324).
Err4	The torque limit was reached.	<ul><li>When using the torque limit, increase the torque limit.</li><li>Double the set value of the moment of inertia calculating start level (Pn324).</li></ul>
Err5	While calculating the moment of inertia, the speed control was set to proportional control by setting 1 to V_PPI in the servo command output signals (SVCMD_IO).	Operate the DRIVER with PI control while calcu- lating the moment of inertia.

#### (3) Related Functions on Advanced Autotuning

This section describes functions related to advanced tuning.

-Notch Filter

Usually, set this function to Auto Setting. (The notch filter is factory-set to Auto Setting.) If this function is set to Auto Setting, vibration will be detected automatically during advanced autotuning and the notch filter will be set.

Set this function to Not Auto Setting only if you do not change the notch filter setting before executing advanced autotuning.

Parameter		Function	When Enabled	Classification
Pn460	n. 🗆 🗆 🗆 0	Does not set the 1st notch filter automatically with the utility function.		Tuning
	n.□□□1 [Factory setting]	Sets the 1st notch filter automatically with the utility function.	Immediately	
	n.□0□□	Does not set the 2nd notch filter automatically with the utility function.	minediatery	
	n.□1□□ [Factory setting]	Sets the 2nd notch filter automatically with the utility function.		

#### -Anti-Resonance Control Adjustment

This function reduces low vibration frequency, which the notch filter does not detect.

Usually, set this function to Auto Setting. (The anti-resonance control is factory-set to Auto Setting.)

When this function is set to Auto Setting, vibration will be automatically detected during advanced autotuning and anti-resonance control will be automatically adjusted and set.

Parameter		Function	When Enabled	Classification
Pn160	n.口口0口	Does not use the anti-resonance control automatically with the utility function.	Immediately	Tuning
Ph160	n.□□1□ [Factory setting]	Uses the anti-resonance control automatically with the utility function.	minediatery	Tuning

-Vibration Suppression

The vibration suppression function suppresses transitional vibration at frequency as low as 1 to 100 Hz that is generated mainly when positioning if the machine stand vibrates.

Usually, set this function to Auto Setting. (The vibration suppression function is factory-set to Auto Setting.) When this function is set to Auto Setting, vibration will be automatically detected during advanced autotuning and vibration suppression will be automatically adjusted and set.

Set this function to Not Auto Setting only if you do not change the setting for vibration suppression before executing advanced autotuning.

Note: This function uses model following control. Therefore, the function can be executed only if the mode is set to 2 or 3.

Parameter		Function	When Enabled	Classification
Pn140	n.□0□□	Does not use the vibration suppression function auto- matically with the utility function.	Immediately	Tuning
	n.□1□□ [Factory setting]	Uses the vibration suppression function automatically with the utility function.	minediatery	Tuning

#### -Related Parameter



# -Friction Compensation

This function compensates for changes in the following conditions.

- Changes in the viscous resistance of the lubricant, such as the grease, on the sliding parts of the machine
- Changes in the friction resistance resulting from variations in the machine assembly
- Changes in the friction resistance due to aging

The conditions for applying friction compensation depend on the mode. The friction compensation setting in Pn408.3 applies when the Mode is 1. The friction compensation function is always enabled regardless of the friction compensation setting in Pn408.3 when the Mode is 2 or 3.

Mode Friction Compensation Selecting		Mode = 1	Mode = 2	Mode = 3	
Pn408	n.0□□□ [Factory setting]	Adjusted without the friction compensation function	Adjusted with the friction	Adjusted with the friction	
	n.1□□□	Adjusted with the friction compensation function	compensation function	compensation function	

# - Feedforward

If Pn140 is set to the factory setting and the mode setting is changed to 2 or 3, the feedforward gain (Pn109), speed feedforward (VFF) input, and torque feedforward (TFF) input will be disabled.

Set Pn140.3 to 1 if model following control is used together with the speed feedforward (VFF) input and torque feedforward (TFF) input from the PC or PLC...etc.

Parameter		Function	When Enabled	Classification
n.0□□□ [Factory setting]		Model following control is not used together with the speed/torque feedforward input.	Immediately	Tuning
Pn140	n.1口口口	Model following control is used together with the speed/torque feedforward input.	minounatory	Tuning

Refer to 8 MECHATROLINK-III Commands for details.

 Model following control is used to make optimum feedforward settings in the DRIVER when model following control is used with the feedforward function. Therefore, model following control is not normally used together with either the speed feedforward (VFF) input or torque feedforward (TFF) input from the PC or PLC...etc. However, model following control can be used with the speed feedforward (VFF) input or torque feedforward (TFF) input if required. An improper feedforward input may result in over- shooting.

# 5.3.3 Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

- Parameters related to this function These are parameters that are used or referenced when executing this function.
- Allowed changes during execution of this function
  - Yes : Parameters can be changed using SigmaWin+ while this function is being executed.
  - No : Parameters cannot be changed using SigmaWin+ while this function is being executed.
- Automatic changes after execution of this function
  - Yes : Parameter set values are automatically set or adjusted after execution of this function.
  - No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes
Pn100	Speed Loop Gain	No	Yes
Pn101	Speed Loop Integral Time Constant	No	Yes
Pn102	Position Loop Gain	No	Yes
Pn103	Moment of Inertia Ratio	No	No
Pn121	Friction Compensation Gain	No	Yes
Pn123	Friction Compensation Coefficient	No	Yes
Pn124	Friction Compensation Frequency Correction	No	No
Pn125	Friction Compensation Gain Correction	No	Yes
Pn401	Torque Reference Filter Time Constant	No	Yes
Pn408	Torque Related Function Switch	Yes	Yes
Pn409	1st Notch Filter Frequency	No	Yes
Pn40A	1st Notch Filter Q Value	No	Yes
Pn40C	2nd Notch Filter Frequency	No	Yes
Pn40D	2nd Notch Filter Q Value	No	Yes
Pn140	Model Following Control Related Switch	Yes	Yes
Pn141	Model Following Control Gain	No	Yes
Pn142	Model Following Control Gain Compensation	No	Yes
Pn143	Model Following Control Bias (Forward Direction)	No	Yes
Pn144	Model Following Control Bias (Reverse Direction)	No	Yes
Pn145	Vibration Suppression 1 Frequency A	No	Yes
Pn146	Vibration Suppression 1 Frequency B	No	Yes
Pn147	Model Following Control Speed Feedforward Compensation	No	Yes
Pn160	Anti-Resonance Control Related Switch	Yes	Yes
Pn161	Anti-Resonance Frequency	No	Yes
Pn163	Anti-Resonance Damping Gain	No	Yes
Pn531	Program JOG Movement Distance	No	No
Pn533	Program JOG Movement Speed	No	No
Pn534	Program JOG Acceleration/Deceleration Time	No	No
Pn535	Program JOG Waiting Time	No	No
Pn536	Number of Times of Program JOG Movement	No	No



# 5.4 Advanced Autotuning by Reference (Fn202)

Adjustments with advanced autotuning by reference are described below.



Advanced autotuning by reference starts adjustments based on the set speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when starting adjustments. In this case, make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.

# 5.4.1 Advanced Autotuning by Reference

Advanced autotuning by reference is used to automatically achieve optimum tuning of the DRIVER in response to the user reference inputs from the PC or PLC...etc.

Advanced autotuning by reference is performed generally to fine-tune the DRIVER after advanced autotuning of the DRIVER has been performed.

If the moment of inertia ratio is correctly set to Pn103, advanced autotuning by reference can be performed without performing advanced autotuning.



DRIVER

Advanced autotuning by reference performs the following adjustments.

- Gains (e.g., position loop gain and speed loop gain)
- Filters (torque reference filter and notch filter)
- Friction compensation
- Anti-resonance control
- Vibration suppression

Refer to 5.4.3 Related Parameters for parameters used for adjustments.

# 

Because advanced autotuning by reference adjusts the DRIVER during automatic operation, vibra- tion or overshooting may occur. To ensure safety, perform advanced autotuning by reference in a state where the DRIVER can come to an emergency stop at any time.

(1) Preparation

Check the following settings before performing advanced autotuning by reference. The message "NO-OP" indicating that the settings are not appropriate will be displayed, if all of the following conditions are not met.

- The DRIVER must be in Servo Ready status (Refer to 4.8.4).
- There must be no overtravel.
- The servomotor power must be OFF.
- The position control must be selected when the servomotor power is ON.
- The gain selection switch must be in manual switching mode (Pn139.0 = 0).
- Gain setting 1 must be selected.
- The test without a motor function must be disabled. (Pn00C.0 = 0).
- All warnings must be cleared.
- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The tuning-less function must be disabled (Pn170.0 = 0).
- (2) When Advanced Autotuning by Reference Cannot Be Performed Successfully

Advanced autotuning by reference cannot be performed successfully under the following conditions. If the result of autotuning is not satisfactory, perform one-parameter tuning (Fn203). Refer to *5.5 One-parameter Tuning (Fn203)* for details.

- The travel distance in response to references from the PC or PLC...etc. is smaller than the set positioning com- pleted width (Pn522).
- The motor speed in response to references from the PC or PLC...etc. is smaller than the set rotation detection level (Pn502).
- The stopping time, i.e., the period while the positioning completed /COIN signal is OFF, is 10 ms or less.
- The rigidity of the machine is low and vibration occurs when positioning is performed.
- The position integration function is used.
- P control operation (proportional control) is performed.
- The mode switch is used.
- The positioning completed width (Pn522) is too small.



Change only the overshoot detection level (Pn561) to finely adjust the amount of overshooting without chang- ing the positioning completed width (Pn522). Because Pn561 is set by default to 100%, the allowable amount of overshooting is the same amount as that for the positioning completed width.

When Pn561 is set to 0%, the amount of overshooting can be adjusted without any overshooting in the posi- tioning completed width. If the setting of Pn561 is changed, however, the positioning time may be extended.

	Overshoot Detection	Level	Speed Position	Torque	Classification
Pn561	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 100	1%	100	Immediately	Setup

## 5.4.2 Advanced Autotuning by Reference Procedure

The following procedure is used for advanced autotuning by reference. Advanced autotuning by reference is performed from the SigmaWin+.

• When using the MP2000 Series with phase control, select the mode = 1 (standard level). If 2 or 3 is selected, phase control of the MP2000 Series may not be possible.
(1) Operating Procedure
Set the correct moment of inertia ratio in Pn103 by using the advanced autotuning before performing this pro- cedure.
In the SigmaWin+ $\Sigma$ -V component main window, click <b>Tuning</b> and then click <b>Tuning</b> .
- Moment of Inertia (Mass) Identification It is the same as 5.3.2 Advanced Autotuning Procedure.
<ul> <li>Autotuning with Reference Input</li> <li>1. Select the Position reference input option under Reference input from host controller in the Tuning main window, and then click Autotuning. The Autotuning-Setting Conditions box will appear.</li> </ul>
Autotuning - Setting Conditions AXIS#1
Set conditions.
Mode selection
2:For positioning
A gain adjustment specialized for positioning will be executed. In addition, the following automatic adjustments can be executed: Model following control, notch filter, anti-resonance control, and vibration suppression.
Mechanism selection
2:Ball screw mechanism or linear motor
Executes adjustment suitable for relatively high-rigidity mechanism, such as a ball screw or linear motor. Select this type if there is no applicable mechanism.
Tuning parameters
Start tuning using the default settings.

2. Select the mode from the **Mode selection** combo box and the mechanism from **Mechanism selection** combo box, and then click **Next**. The Autotuning-Moment of Inertia Ratio Setting box will appear. When the **Start tuning using the default settings.** check box is selected in the Autotuning-Setting Conditions box, tuning will be executed using tuning parameters set to the default value.

Cancel

 $\cdot$  Mode Selection

Select the mode.

- Mode = 1: Makes adjustments considering response characteristics and stability (Standard level).
- Mode = 2: Makes adjustments for positioning [Factory setting].
- Mode = 3: Makes adjustments for positioning, giving priority to overshooting suppression.



Next ≻

#### •Type Selection

Select the type according to the machine element to be driven.

If there is noise or the gain does not increase, better results may be obtained by changing the rigidity type.

Type = 1: For belt drive mechanisms (LEFB, LEJB)

Type = 2: For ball screw drive mechanisms [Factory setting] (LEY, LEFS, LEJS)

Autotuning - Moment of Inertia RatioSet		
If Moment of Inertia Ratio is not correctly set, vibration may be generated.		
Is Moment of Inertia Ratio correctly set?		
Pn103 : Moment of Inertia Ratio (0 - 20000)		
[%]		
< Back Next > Cance		

3. Enter the correct moment of inertia ratio and then click Next. The following window will appear.

Autotuning - Automatic	setting AXIS#1	×
Waiting for execution	Tuning Turn the servo on, input the reference from the host controller, and then click the Start button.	
Oscillation level measurement Gain search behaviour evaluation	Start tuning	
Tuning completed	Mode selection 2:For positioning	
Notch filter Anti-res Adj Vib Suppress	Mechanism selection 2:Ball screw mechanism or linear motor	
Precautions	< Back Finish Cancel	

4. Turn the servo on and then input the reference from the host controller. Click Start tuning to start tuning.

Autotuning - Automatic sel	tting AXIS#1	×
Waiting for execution	Tuning Executing tuning (Input the reference.)	]
Oscillation level measurement	Cancel	
Gain search behaviour evaluation		
Tuning completed		
	Mode selection	
	2:For positioning	
Notch filter	Mechanism selection	
ŽAnti-res Adj	2:Ball screw mechanism or linear motor	
♥Vib Suppress		
Precautions	< Back Finish Cancel	

Vibration generated during tuning is automatically detected and the optimum setting for the detected vibration will be made. When setting is completed, the LED indicator lamps (bottom left of the box) of the functions used for the setting will light up.

5. When tuning is complete, click **Finish**. The results of tuning will be written in the parameters.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.6.2 Autotuning with Reference Input.

#### (2) Failure in Operation

-When "NO-OP" Flashes on the Display

Probable Cause	Corrective Actions
The main circuit power supply was OFF.	Turn ON the main circuit power supply.
An alarm or warning occurred.	Remove the cause of the alarm or the warning.
Overtraveling occurred.	Remove the cause of the overtravel.
Gain setting 2 was selected by gain switching.	Disable the automatic gain switching.
HWBB operated.	Disable the HWBB function.

-When "Error" Flashes on the Display

Error	Probable Cause	Corrective Actions
The gain adjustment was not successfully completed.	Machine vibration is occurring or the posi- tioning completed signal (/COIN) is turning ON and OFF when the servomotor is stopped.	<ul> <li>Increase the set value for Pn522.</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control adjustment function and the vibration suppression function.</li> </ul>
The positioning complet- ed signal (/COIN) did not turn ON within approximately 10 seconds after position- ing adjustment was com- pleted.	The positioning completed width is too nar- row or proportional control (P control) is being used.	<ul> <li>Increase the set value for Pn522.</li> <li>Set 0 to V_PPI of the servo command output signals (SVCMD_IO).</li> </ul>

(3) Related Functions on Advanced Autotuning by Reference

This section describes functions related to advanced autotuning by reference.

- Notch Filter

Usually, set this function to Auto Setting. (The notch filter is factory-set to Auto Setting.) If this function is set to Auto Setting, vibration will be detected automatically during advanced autotuning by reference, and the notch filter will be set.

Set this function to Not Auto Setting only if you do not change the notch filter setting before executing advanced autotuning by reference.

Parameter		Function	When Enabled	Classification
n.□□□0           n.□□□1           [Factory setting]           n.□□□□	n.□□□0	Does not set the 1st notch filter automatically with the utility function.	Immediately	Tuning
	n.□□□1 [Factory setting]	Sets the 1st notch filter automatically with the utility function.		
	n.□0□□	Does not set the 2nd notch filter automatically with the utility function.		
	n.□1□□ [Factory setting]	Sets the 2nd notch filter automatically with the utility function.		

- Anti-Resonance Control Adjustment

This function reduces low vibration frequency, which the notch filter does not detect.

Usually, set this function to Auto Setting. (The anti-resonance control is factory-set to Auto Setting.)

When this function is set to Auto Setting, vibration will be automatically detected during advanced autotuning by reference and anti-resonance control will be automatically adjusted and set.

Parameter		Function	When Enabled	Classification
Pn160	n.口口0口	Does not use the anti-resonance control automatically with the utility function.	Immediately	Tuning
Pn160	n.□□1□ [Factory setting]	Uses the anti-resonance control automatically with the utility function.	minediatery	Tuning

- Vibration Suppression

The vibration suppression function suppresses transitional vibration at frequency as low as 1 to 100 Hz that is generated mainly when positioning if the machine stand vibrates.

Usually, set this function to Auto Setting. (The vibration suppression function is factory-set to Auto Setting.) When this function is set to Auto Setting, vibration will be automatically detected during advanced autotuning by reference and vibration suppression will be automatically adjusted and set.

Set this function to Not Auto Setting only if you do not change the setting for vibration suppression before executing advanced autotuning by reference.

Note: This function uses model following control. Therefore, the function can be executed only if the mode is set to 2 or 3.

#### -Related Parameters

Parameter		Function	When Enabled	Classification
Pn140	n.口0口口	Does not use the vibration suppression function auto- matically.	Immediately	Tuning
Pn140	n.□1□□ [Factory setting]	Uses the vibration suppression function automati- cally.	minediatery	Tuning



- Friction Compensation

This function compensates for changes in the following conditions.

- Changes in the viscous resistance of the lubricant, such as the grease, on the sliding parts of the machine
- Changes in the friction resistance resulting from variations in the machine assembly
- Changes in the friction resistance due to aging

Conditions to which friction compensation is applicable depend on the mode. The friction compensation set- ting in Pn408.3 applies when the mode is 1. Mode = 2 and Mode = 3 are adjusted with the friction compensa- tion function regardless of the friction compensation setting in P408.3.

Mode Friction Compensation Selecting		Mode = 1	Mode = 2	Mode = 3	
Pn408	n.0□□□ [Factory setting]	Adjusted without the friction compensation function	Adjusted with the friction	Adjusted with the friction	
	n.1口口口	Adjusted with the friction compensation function		compensation function	

# - Feedforward

If Pn140 is set to the factory setting and the mode setting is changed to 2 or 3, the feedforward gain (Pn109), speed feedforward (VFF) input, and torque feedforward (TFF) input will be disabled.

Set Pn140.3 to 1 if model following control is used together with the speed feedforward (VFF) input and torque feedforward (TFF) input from the PC or PLC...etc.

Parameter		Function	When Enabled	Classification
Pn140	n.0□□□ [Factory setting]	Model following control is not used together with the speed/torque feedforward input.	Immediately	Tuning
Pn140	n.1□□□	Model following control is used together with the speed/torque feedforward input.	minoutatory	Tuning

# Refer to 8 MECHATROLINK-III Commands for details.

<ul> <li>Model following control is used to make optimum feedforward settings in the DRIVER when model following control is used with the feedforward function. Therefore, model following control is not normally used together with either the speed feedfor- ward (VFF) input or torque feedforward (TFF) input from the PC or PLCetc However, model following control can be used with the speed feedforward (VFF) input or torque feedforward (TFF) input if required. An improper feedforward input may result in over- shooting.</li> </ul>		
	<b>D</b> IMPORTANT	<ul> <li>Model following control is used to make optimum feedforward settings in the DRIVER when model following control is used with the feedforward function. Therefore, model following control is not normally used together with either the speed feedfor- ward (VFF) input or torque feedforward (TFF) input from the PC or PLCetc However, model following control can be used with the speed feedforward (VFF) input or torque feedforward (TFF) input if required. An improper feedforward input may result in over- shooting.</li> </ul>

# 5.4.3 Related Parameters

The following table lists parameters related to this function and their possibility of being changed while exe- cuting this function or of being changed automatically after executing this function.

- Parameters related to this function These are parameters that are used or referenced when executing this function.
- Allowed changes during execution of this function
  - Yes : Parameters can be changed using SigmaWin+ while this function is being executed.
  - No : Parameters cannot be changed using SigmaWin+ while this function is being executed.
- Automatic changes after execution of this function

Yes : Parameter set values are automatically set or adjusted after execution of this function. No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes
Pn100	Speed Loop Gain	No	Yes
Pn101	Speed Loop Integral Time Constant	No	Yes
Pn102	Position Loop Gain	No	Yes
Pn103	Moment of Inertia Ratio	No	No
Pn121	Friction Compensation Gain	No	Yes
Pn123	Friction Compensation Coefficient	No	Yes
Pn124	Friction Compensation Frequency Correction	No	No
Pn125	Friction Compensation Gain Correction	No	Yes
Pn401	Torque Reference Filter Time Constant	No	Yes
Pn408	Torque Related Function Switch	Yes	Yes
Pn409	1st Notch Filter Frequency	No	Yes
Pn40A	1st Notch Filter Q Value		Yes
Pn40C	Pn40C 2nd Notch Filter Frequency		Yes
Pn40D	Pn40D 2nd Notch Filter Q Value		Yes
Pn140	Pn140 Model Following Control Related Switch		Yes
Pn141	Pn141 Model Following Control Gain		Yes
Pn142	Model Following Control Gain Compensation	No	Yes
Pn143	Model Following Control Bias (Forward Direction)	No	Yes
Pn144	Model Following Control Bias (Reverse Direction)	No	Yes
Pn145	Vibration Suppression 1 Frequency A	No	Yes
Pn146	Pn146 Vibration Suppression 1 Frequency B		Yes
Pn147	Model Following Control Speed Feedforward Compensation	No	Yes
Pn160	Anti-Resonance Control Related Switch	Yes	Yes
Pn161	Anti-Resonance Frequency	No	Yes
Pn163	Anti-Resonance Damping Gain	No	Yes

#### 5.5 One-parameter Tuning (Fn203)

Adjustments with one-parameter tuning are described below.

5.5.1 One-parameter Tuning

One-parameter tuning is used to manually make tuning level adjustments during operation with a position ref- erence or speed reference input from the PC or PLC...etc.

One-parameter tuning enables automatically setting related servo gain settings to balanced conditions by adjusting one or two tuning levels.

One-parameter tuning performs the following adjustments.

- Gains (e.g., position loop gain and speed loop gain)
- Filters (torque reference filter and notch filter)
- Friction compensation
- Anti-resonance control

Refer to 5.5.4 Related Parameters for parameters used for adjustments.

Perform one-parameter tuning if satisfactory response characteristics is not obtained with advanced autotun- ing or advanced autotuning by reference.

To fine-tune each servo gain after one-parameter tuning, refer to 5.8 Additional Adjustment Function.



(1) Preparation

Check the following settings before performing one-parameter tuning. The message "NO-OP" indicating that the settings are not appropriate will be displayed, if all of the following conditions are not met.

- The test without a motor function must be disabled (Pn00C.0 = 0).
- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The tuning-less function must be disabled (Pn170.0 = 0).
- The tuning mode must be set to 0 or 1 when performing speed control.

5.5.2 One-parameter Tuning Procedure

The following procedure is used for one-parameter tuning.

There are the following two operation procedures depending on the tuning mode being used.

- When the tuning mode is set to 0 or 1, the model following control will be disabled and one-parameter tun- ing will be used as the tuning method for applications other than positioning.
- When the tuning mode is set to 2 or 3, the model following control will be enabled and it can be used for tuning for positioning.

One-parameter tuning is performed from the SigmaWin+.

Make sure that the moment of inertia ratio (Pn103) is set correctly using advance autotuning before beginning operation.

The following section provides the operating procedure from the SigmaWin+.

When using the MP2000 Series with phase control, select the tuning mode = 0 or 1. If 2 or 3 is selected, phase control of the MP2000 Series may not be possible.	

(1)SigmaWin+ Operating Procedure

In the SigmaWin+  $\Sigma$ -V component main window, click **Tuning** and then click **Tuning**. Click **Advanced adjustment** in the Tuning main window, and then click **Custom tuning** in the Tuning box that will appear. The Custom Tuning - Mode selection box will appear.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.6.4 Custom Tuning.

- Setting the Tuning Mode 0 or 1

• Tuning Mode Select the tuning mode. Select the tuning mode 0 or 1. Tuning Mode = 0: Makes adjustments giving priority to stability. Tuning Mode = 1: Makes adjustments giving priority to responsiveness.

· Type Selection

Select the type according to the machine element to be driven. If there is noise or the gain does not increase, better results may be obtained by changing the rigidity type.

Type = 1: For belt drive mechanisms (LEFB, LEJB)

Type = 2: For ball screw drive mechanisms [Factory setting] (LEY, LEFS, LEJS)

·Tuning Lebel Change the tuning level.

Note: The higher the lebel, the greater the responsiveness will be. If the value is too large, however, vibration will occur.

- Setting the Tuning Mode 2 or 3

·Tuning Mode

Select the tuning mode. Select the tuning mode 2 or 3.

Tuning Mode = 2: Enables model following control and makes adjustments for positioning.

Tuning Mode = 3: Enables model following control, makes adjustments for positioning, and suppresses over- shooting.

· Type Selection

Select the type according to the machine element to be driven.

If there is noise or the gain does not increase, better results may be obtained by changing the rigidity type.

Type = 1: For belt drive mechanisms (LEFB, LEJB)

Type = 2: For ball screw drive mechanisms [Factory setting] (LEY, LEFS, LEJS)

·FF Lebel, FB Lebel Change the FF level and FB level.

- Note: The higher the FF lebel, the positioning time will be shorter and the response will be better. If the level is too high, however, overshooting or vibration may occur. Overshooting will be reduced if the FB level is increased.
- (2) Related Functions on One-parameter Tuning

This section describes functions related to one-parameter tuning.

- Notch Filter

Usually, set this function to Auto Setting. (The notch filter is factory-set to Auto Setting.) If this function is set to Auto Setting, vibration will be detected automatically during one-parameter tuning and the notch filter will be set.

Set this function to Not Auto Setting only if you do not change the notch filter setting before executing one- parameter tuning.

Parameter		Function	When Enabled	Classification
Pn460	n. 🗆 🗆 🗆 0	Does not set the 1st notch filter automatically with the utility function.		
	n.□□□1 [Factory setting]	Sets the 1st notch filter automatically with the utility function.	Immediately	Tuning
	n.□0□□	Does not set the 2nd notch filter automatically with the utility function.	minodiatory	Tuning
	n.□1□□ [Factory setting]	Sets the 2nd notch filter automatically with the utility function.		

- Anti-Resonance Control Adjustment

This function reduces low vibration frequency, which the notch filter does not detect.

Usually, set this function to Auto Setting. (The anti-resonance control is factory-set to Auto Setting.)

When this function is set to Auto Setting, vibration will be automatically detected during one-parameter tuning and anti-resonance control will be automatically adjusted and set.

Parameter		Function	When Enabled	Classification
Pn160	n.口口0口	Does not use the anti-resonance control automatically with the utility function.	Immediately	Tuning
Pn160	n.□□1□ [Factory setting]	Uses the anti-resonance control automatically with the utility function.		



- Friction Compensation
  - This function compensates for changes in the following conditions.
  - Changes in the viscous resistance of the lubricant, such as the grease, on the sliding parts of the machine
  - Changes in the friction resistance resulting from variations in the machine assembly
  - Changes in the friction resistance due to aging

Conditions to which friction compensation is applicable depend on the tuning mode. The friction compensa- tion setting in F408.3 applies when the mode is 0 or 1. Tuning Mode = 2 and Tuning Mode = 3 are adjusted with the friction compensation function regardless of the friction compensation setting in P408.3.

Friction Compen Selecting	Mode sation	Tuning Mode = 0	Tuning Mode = 1	Tuning Mode = 2	Tuning Mode = 3
Pn408	n.0□□□ [Factory setting]	Adjusted without the friction compensation function	Adjusted without the friction compensation function	Adjusted with the	Adjusted with the
	n.1□□□	Adjusted with the friction compensation function	Adjusted with the friction compensation function	function	function

# - Feedforward

If Pn140 is set to the factory setting and the tuning mode setting is changed to 2 or 3, the feedforward gain (Pn109), speed feedforward (VFF) input, and torque feedforward (TFF) input will be disabled.

Set Pn140.3 to 1 if model following control is used together with the speed feedforward (VFF) input and torque feedforward (TFF) input from the PC or PLC...etc.

Parameter		Function	When Enabled	Classification
Pn140	n.0□□□ [Factory setting]	Model following control is not used together with the speed/torque feedforward input.	Immediately	Tuning
	n.1□□□	Model following control is used together with the speed/torque feedforward input.		

# Refer to 8 MECHATROLINK-III Commands for details.

Model following control is used to make optimum feedforward settings in the DRIVER when model following control is used with the feedforward function. Therefore, model following control is not normally used together with either the speed feedfor- ward (VFF) input or torque feedforward (TFF) input from the PC or PLC...etc. However, model following control can be used with the speed feedforward (VFF) input or torque feedforward (TFF) input if required. An improper feedforward input may result in over- shooting.



5.5.3 One-parameter Tuning Example The following procedure is used for one-parameter tuning on the condition that the tuning mode is set to 2 or 3. This mode is used to reduce positioning time.

Step	Measuring Instrument Display Example	Operation
1	Position error Reference speed Positioning completed signal	Measure the positioning time after setting the moment of iner- tia ratio (Pn103) correctly. Tuning will be completed if the specifications are met here. The tuning results will be saved in the DRIVER.
2		The positioning time will become shorter if the FF level is increased. The tuning will be completed if the specifications are met. The tuning results will be saved in the DRIVER. If overshooting occurs before the specifications are met, go to step 3.
3		Overshooting will be reduced if the FB level is increased. If the overshooting is eliminated, go to step 4.
4		The graph shows overshooting generated with the FF level increased after step 3. In this state, the overshooting occurs, but the positioning settling time is shorter. The tuning will be com- pleted if the specifications are met. The adjustment results are saved in the DRIVER. If overshooting occurs before the specifications are met, repeat steps 3 and 4. If vibration occurs before the overshooting is eliminated, the vibration will be suppressed by the automatic notch filter and anti-resonance control. Note: The vibration frequencies may not be detected if the vibration is too small. If that occurs, forcibly detect the vibration frequencies.
5		The adjustment results are saved in the DRIVER.

# 5.5.4 Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

- Parameters related to this function These are parameters that are used or referenced when executing this function.
- Allowed changes during execution of this function
  - Yes : Parameters can be changed using SigmaWin+ while this function is being executed.
  - No : Parameters cannot be changed using SigmaWin+ while this function is being executed.
- Automatic changes after execution of this function
  - Yes : Parameter set values are automatically set or adjusted after execution of this function.
  - No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes
Pn100	Speed Loop Gain	No	Yes
Pn101	Speed Loop Integral Time Constant	No	Yes
Pn102	Position Loop Gain	No	Yes
Pn103	Moment of Inertia Ratio	No	No
Pn121	Friction Compensation Gain	No	Yes
Pn123	Friction Compensation Coefficient	No	Yes
Pn124	Friction Compensation Frequency Correction	No	No
Pn125	Friction Compensation Gain Correction	No	Yes
Pn401	Torque Reference Filter Time Constant	No	Yes
Pn408	Torque Related Function Switch	Yes	Yes
Pn409	1st Notch Filter Frequency	No	Yes
Pn40A	1st Notch Filter Q Value	No	Yes
Pn40C	2nd Notch Filter Frequency	No	Yes
Pn40D	2nd Notch Filter Q Value	No	Yes
Pn140	Model Following Control Related Switch	Yes	Yes
Pn141	Model Following Control Gain	No	Yes
Pn142	Model Following Control Gain Compensation	No	Yes
Pn143	Model Following Control Bias (Forward Direction)	No	Yes
Pn144	Model Following Control Bias (Reverse Direction)	No	Yes
Pn145	Vibration Suppression 1 Frequency A	No	No
Pn146	Vibration Suppression 1 Frequency B	No	No
Pn147	Model Following Control Speed Feedforward Compensation	No	Yes
Pn160	Anti-Resonance Control Related Switch	Yes	Yes
Pn161	Anti-Resonance Frequency	No	Yes
Pn163	Anti-Resonance Damping Gain	No	Yes

# 5.6 Anti-Resonance Control Adjustment Function (Fn204)

This section describes the anti-resonance control adjustment function.

5.6.1 Anti-Resonance Control Adjustment Function

The anti-resonance control adjustment function increases the effectiveness of the vibration suppression after one-parameter tuning. This function is effective in supporting anti-resonance control adjustment if the vibra- tion frequencies are from 100 to 1000 Hz.

This function rarely needs to be used because it is automatically set by the advanced autotuning or advanced autotuning by reference input. Use this function only if fine-tuning is required, or vibration detection is failed and readjustment is required.

Perform one-parameter tuning (Fn203) or use another method to improve the response characteristics after performing this function. If the anti-resonance gain is increased with one-parameter tuning performed, vibra- tion may result again. If that occurs, perform this function again to fine-tune the settings.



(1) Before Performing Anti-Resonance Control Adjustment Function

Check the following settings before performing anti-resonance control adjustment function. The message "NO-OP" indicating that the settings are not appropriate will be displayed, if all of the following conditions are not met.

- The tuning-less function must be disabled (Pn170.0 = 0).
- The test without a motor function must be disabled (Pn00C.0 = 0).
- The control must not be set to torque control.
- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).

5.6.2 Anti-Resonance Control Adjustment Function Operating Procedure With this function, an operation reference is sent, and the function is executed while vibration is occurring.

Anti-resonance control adjustment function is performed from the SigmaWin+. The following methods can be used for the anti-resonance control adjustment function.

- Using anti-resonance control for the first time
- With undetermined vibration frequency
- With determined vibration frequency
- For fine-tuning after adjusting the anti-resonance control

The following describes the operating procedure from the digital operator.

In the SigmaWin+  $\Sigma$ -V component main window, click **Tuning** and then click **Tuning**. In the Tuning main window, click Advanced adjustment, Custom tuning, and then Anti-resonance control.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.6.6 Anti-resonance Control Adjustment Function.

Note:

If vibration is not detected even when vibration is occurring, lower the vibration detection sensitivity (Pn311). When this parameter is lowered, the detection sensitivity will be increased. Vibration may not be detected accurately if too small value is set.

Increase the damping gain from about 0% to 200% in 10% increments while checking the effect of vibration reduction. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the control gain by using a different method, such as one-parameter tuning.

#### 5.6.3 Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

- Parameters related to this function

These are parameters that are used or referenced when executing this function.

- Allowed changes during execution of this function
  - Yes : Parameters can be changed using SigmaWin+ while this function is being executed.
  - No : Parameters cannot be changed using SigmaWin+ while this function is being executed.

# - Automatic changes after execution of this function

- Yes : Parameter set values are automatically set or adjusted after execution of this function.
- No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes
Pn160	Anti-Resonance Control Related Switch	Yes	Yes
Pn161	Anti-Resonance Frequency	No	Yes
Pn162	Anti-Resonance Gain Compensation	Yes	No
Pn163	Anti-Resonance Damping Gain	No	Yes
Pn164	Anti-Resonance Filter Time Constant 1 Compensation	Yes	No
Pn165	Anti-Resonance Filter Time Constant 2 Compensation	Yes	No



5.7 Vibration Suppression Function (Fn205)

The vibration suppression function is described in this section.

5.7.1 Vibration Suppression Function

The vibration suppression function suppresses transitional vibration at frequency as low as 1 to 100 Hz that is generated mainly when positioning if the machine stand vibrates.

This function is set automatically when advanced autotuning or advanced autotuning by reference is executed. In most cases, this function is not necessary. Use this function only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration.

Perform one-parameter tuning (Fn203) if required to improve the response characteristics after performing this function.

(1) Preparation

Check the following settings before performing the vibration suppression function. The message "NO-OP" indicating that the settings are not appropriate will be displayed, if all of the following conditions are not met.

- The control must be set to position control.
- The tuning-less function must be disabled (Pn170.0 = 0).
- The test without a motor function must be disabled (Pn00C.0 = 0).
- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).

#### (2) Items Influencing Performance

If continuous vibration occurs when the servomotor is not rotating, the vibration suppression function cannot be used to suppress the vibration effectively. If the result is not satisfactory, perform anti-resonance control adjustment function (Fn204) or one-parameter tuning (Fn203).



(3) Detection of Vibration Frequencies

No frequency detection may be possible if the vibration does not appear as a position error or the vibration resulting from the position error is too small.

The detection sensitivity can be adjusted by changing the setting for the remained vibration detection width (Pn560) which is set as a percentage of the positioning completed width (Pn522). Perform the detection of vibration frequencies again after adjusting the remained vibration detection width (Pn560).

	Remained Vibration I	Detection Width	Position	Classification	
Pn560	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 3000	0.1%	400	Immediately	Setup

Note: As a guideline, change the setting 10% at a time. The smaller the set value is, the higher the detection sensitivity will be. If the value is too small, however, the vibration may not be detected accurately.

The vibration frequencies that are automatically detected may vary somewhat with each positioning operation. Perform positioning several times and make adjustments while checking the effect of vibration suppression.

5.7.2 Vibration Suppression Function Operating Procedure

The following procedure is used for vibration suppression function.

Vibration suppression function is performed from the SigmaWin+. The operating procedure from the SigmaWin+ is described here.

(1) Operating Procedure

In the SigmaWin+  $\Sigma$ -V component main window, click **Tuning** and then click **Tuning**. In the Tuning main window, click **Custom tuning**, and then **Vibration suppression**.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.6.7 Vibration Suppression Function.

Note:

Frequency detection will not be performed if there is no vibration or the vibration frequency is outside the range of detectable frequencies. If the vibration frequencies are not detected, prepare a means of detecting and measuring the vibration. When the vibration frequencies are measured, manually set the measured vibration frequency.



No settings related to the vibration suppression function will be changed during operation.

If the servomotor does not stop approximately 10 seconds after the setting changes, a timeout error will result and the previous setting will be automatically enabled again. The vibration suppression function will be enabled in sets the displayed frequency. The motor response, however, will change when the servomotor comes to a stop with no reference input.

(2) Related Function on Vibration Suppression Function

This section describes functions related to vibration suppression function.

-Feedforward

The feedforward gain (Pn109), speed feedforward (VFF) input, and torque feedforward (TFF) input will be disabled in the factory setting.

Set Pn140.3 to 1 if model following control is used together with the speed feedforward (VFF) input and torque feedforward (TFF) input from the PC or PLC...etc.



Pa	arameter	Function	When Enabled	Classification
Pn140	n.0□□□ [Factory setting]	Model following control is not used together with the speed/torque feedforward input.	Immediately	Tuning
	n.1□□□	Model following control is used together with the speed/torque feedforward input.	initiation	Tuning

Refer to 8. MECHATROLINK-III Commands for details.

**IMPORTANT** 

Model following control is used to make optimum feedforward settings in the DRIVER when model following control is used with the feedforward function. Therefore, model following control is not normally used together with either the speed feedfor- ward (VFF) input or torque feedforward (TFF) input from the PC or PLC...etc. However, model following control can be used with the speed feedforward (VFF) input or torque feedforward (TFF) input if required. An improper feedforward input may result in overshooting.



#### 5.7.3 Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

- Parameters related to this function

These are parameters that are used or referenced when executing this function.

- Allowed changes during execution of this function
  - Yes : Parameters can be changed using SigmaWin+ while this function is being executed. No : Parameters cannot be changed using SigmaWin+ while this function is being executed.
- Automatic changes after execution of this function
  - Yes : Parameter set values are automatically set or adjusted after execution of this function.
  - No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes
Pn140	Model Following Control Related Switch	Yes	Yes
Pn141	Model Following Control Gain	No	Yes
Pn142	Model Following Control Gain Compensation	No	No
Pn143	Model Following Control Bias (Forward Direction)	No	No
Pn144	Model Following Control Bias (Reverse Direction)	No	No
Pn145	Vibration Suppression 1 Frequency A	No	Yes
Pn146	Vibration Suppression 1 Frequency B	No	Yes
Pn147	Model Following Control Speed Feedforward Compen- sation	No	No
Pn14A	Vibration Suppression 2 Frequency	No	No
Pn14B	Vibration Suppression 2 Compensation	No	No



## 5.8 Additional Adjustment Function

This section describes the functions that can be used for additional fine tuning after making adjustments with advanced autotuning, advanced autotuning by reference, or one-parameter tuning.

- Switching gain settings
- Friction compensation
- Current control mode selection
- Current gain level setting
- Speed detection method selection

#### 5.8.1 Switching Gain Settings

Two gain switching functions are available, manual switching and automatic switching. The manual switching function uses an external input signal to switch gains, and the automatic switching function switches gains automatically.

By using the gain switching function, the positioning time can be shortened by increasing the gain during positioning and vibration can be suppressed by decreasing the gain while it is stopped.

Parameter		Function	When Enabled	Classification
Pn139	n.□□□0 [Factory setting]	Manual gain switching	Immediately	Tuning
	n.□□□2	Automatic gain switching		

Note: n.  $\Box \Box \Box 1$  is reserved. Do not use.

For the gain combinations for switching, refer to (1) Gain Combinations for Switching. For the manual gain switching, refer to (2) Manual Gain Switching. For the automatic gain switching, refer to (3) Automatic Gain Switching.

(1) Gain Combinations for Switching

Setting	Speed Loop Gain	Speed Loop Integral Time Constant	Position Loop Gain	Torque Refer- ence Filter	Model Follow- ing Control Gain	Model Follow- ing Control Gain Compen- sation	Friction Com- pensation Gain
Gain Setting 1	Pn100 Speed Loop Gain	Pn101 Speed Loop Integral Time Constant	Pn102 Position Loop Gain	Pn401 Torque Refer- ence Filter Time Constant	Pn141 <sup>*</sup> Model Follow- ing Control Gain	Pn142 <sup>*</sup> Model Follow- ing Control Gain Compen- sation	Pn121 Friction Com- pensation Gain
Gain Setting 2	Pn104 2nd Speed Loop Gain	Pn105 2nd Speed Loop Integral Time Constant	Pn106 2nd Position Loop Gain	Pn412 1st Step 2nd Torque Refer- ence Filter Time Constant	Pn148 <sup>*</sup> 2nd Model Fol- lowing Control Gain	Pn149 <sup>*</sup> 2nd Model Fol- lowing Control Gain Compen- sation	Pn122 2nd Gain for Friction Compensation

\* The switching gain settings for the model following control gain and the model following control gain compensation are available only for manual gain switching. To enable the gain switching of these parameters, a gain switching input signal must be sent, and the following conditions must be met.

- No command being executed.

- Motor having been completely stopped.

If these conditions are not satisfied, the applicable parameters will not be switched although the other parameters shown in this table will be switched.



### (2) Manual Gain Switching

Manual gain switching uses G-SEL of the servo command output signals (SVCMD\_IO) to switch between gain setting 1 and gain setting 2.

Туре	Command Name	Setting	Meaning
Input	G-SEL of the servo	0	Switches to gain setting 1.
	(SVCMD IO)	1	Switches to gain setting 2.

# (3) Automatic Gain Switching

Automatic gain switching is enabled only in position control. The switching conditions are specified using the following settings.

Parameter Setting		Switching Condition	Setting	Switching Wait Time	Switching Time
Pn139	n. 🗆 🗆 🗆 2	Condition A satisfied.	Gain setting 1 to gain setting 2	Pn135 Gain Switching Waiting Time 1	Pn131 Gain Switching Time 1
		Condition A not satis- fied.	Gain setting 2 to gain setting 1	Pn136 Gain Switching Waiting Time 2	Pn132 Gain Switching Time 2

Select one of the following settings for switching condition A.

Parameter		Switching Condition A for Position Control	For Other than Posi- tion Control (No Switching)	When Enabled	Classification
Pn139	n.□□0□ [Factory setting]	Positioning completed signal (/COIN) ON	Fixed in gain setting 1		Tuning
	n.□□1□	Positioning completed signal (/COIN) OFF	Fixed in gain setting 2		
	n.□□2□	Positioning near signal (/NEAR) ON	Fixed in gain setting 1		
	n.□□3□	Positioning near signal (/NEAR) OFF	Fixed in gain setting 2	Immediately	
	n.口口4口	No output for position reference filter and posi- tion reference input OFF	Fixed in gain setting 1		
	n.口口5口	Position reference input ON	Fixed in gain setting 2		

# Automatic switching pattern 1 (Pn139.0 = 2)




Relationship between the Waiting and Switching Times for Gain Switching
 In this example, the "positioning completed signal (/COIN) ON" condition is set as
 condition A for automatic gain switching. The position loop gain is switched from the
 value in Pn102 (position loop gain) to the value in Pn106 (2nd position loop gain). When
 the /COIN signal goes ON, the switching operation begins after the waiting time set in
 Pn135. The switching operation changes the position loop gain linearly from Pn102 to
 Pn106 within the switching time set in Pn131.



Note: Automatic gain switching is available in the PI and I-P controls (Pn10B).

(4) Rela	aleu Falameleis					
	Speed Loop Gain		Speed	Position	Classification	
Pn100	Setting Range	Setting Unit	Factory Setting	When Enabled		
	10 to 20000	0.1 Hz	400	Immediately	Tuning	
	Speed Loop Integral Ti	me Constant	Speed	Position	Classification	
Pn101	Setting Range	Setting Unit	Factory Setting	When Enabled		
	15 to 51200	0.01 ms	2000	Immediately	Tuning	
	Position Loop Gain			Position	Classification	
Pn102	Setting Range	Setting Unit	Factory Setting	When Enabled		
	10 to 20000	0.1/s	400	Immediately	Tuning	
	Torque Reference Filte	r Time Constant	Speed Position	Torque	Classification	
Pn401	Setting Range	Setting Unit	Factory Setting	When Enabled		
	0 to 65535	0.01 ms	100	Immediately	Tuning	
	Model Following Contr	ol Gain		Position	Classification	
Pn141	Setting Range	Setting Unit	Factory Setting	When Enabled		
	10 to 20000	0.1/s	500	Immediately	Tuning	
	Model Following Contr	ol Gain Compensation		Position	Classification	
Pn142	Setting Range	Setting Unit	Factory Setting	When Enabled		
	500 to 2000	0.1%	1000	Immediately	Tuning	
	Friction Compensation	n Gain	Speed	Position	Classification	
Pn121	Setting Range	Setting Unit	Factory Setting	When Enabled		
	10 to 1000	1%	100	Immediately	Tuning	
	2nd Speed Loop Gain		Speed	Position	Classification	
Pn104	Setting Range	Setting Unit	Factory Setting	When Enabled		
	10 to 20000	0.1 Hz	400	Immediately	Tuning	

# (4) Related Parameters



(cont'd)	
· /	

	2nd Speed Loop Integ	ral Time Constant	Speed	Position	Classification
Pn105	Setting Range	Setting Unit	Factory Setting	When Enabled	Classification
Ī	15 to 51200	0.01 ms	2000	Immediately	Tuning
	2nd Position Loop Gai	ו		Position	Classification
Pn106	Setting Range	Setting Unit	Factory Setting	When Enabled	
	10 to 20000	0.1/s	400	Immediately	Tuning
D. (10	1st Step 2nd Torque Reference Filter Time         Speed         Position         Torque           Constant         Constant				Classification
Pn412	Setting Range	Setting Unit	Factory Setting	When Enabled	
Ī	0 to 65535	0.01 ms	100	Immediately	Tuning
	2nd Model Following C	Position	Classification		
Pn148	Setting Range	Setting Unit	Factory Setting	When Enabled	
Ī	10 to 20000	0.1/s	500	Immediately	Tuning
	2nd Model Following C	ontrol Gain Compensa	tion	Position	Classification
Pn149	Setting Range	Setting Unit	Factory Setting	When Enabled	
	500 to 2000	0.1%	1000	Immediately	Tuning
_	2nd Gain for Friction 0	Compensation	Speed	Position	Classification
Pn122	Setting Range	Setting Unit	Factory Setting	When Enabled	
	10 to 1000	1%	100	Immediately	Tuning

(5) Parameters for Automatic Gain Switching

	Gain Switching Time 1	l		Position		
Pn131	Setting Range	Setting Unit	Factory Setting	When Enabled		
	0 to 65535	1 ms	0	Immediately	Tuning	
	Gain Switching Time 2			Position	Classification	
Pn132	Setting Range	Setting Unit	Factory Setting	When Enabled		
	0 to 65535	1 ms	0	Immediately	Tuning	
_	Gain Switching Waiting	Position	Classification			
Pn135	Setting Range	Setting Unit	Factory Setting	When Enabled		
	0 to 65535	1 ms	0	Immediately	Tuning	
	Gain Switching Waiting	Time 2		Position	Classification	
Pn136	Setting Range	Setting Unit	Factory Setting	When Enabled		
	0 to 65535	1 ms	0	Immediately	Tuning	

# (6) Related Monitor

Monitor No. (Un) Name		Э	Value		Remarks
Un014	Effective gain	Effective gain monitor		For gain setting	ng 1
011014	Effective gain	Encetive gain monitor		For gain setting	ng 2
Note: When using the tuning-less function, gain setting 1 is enabled.					
Parameter No.	Analog Moni- tor	Ν	lame	Output Value	Remarks
-				4	a ·

	tor	Hame	output value	
Pn006	n.□□0B	Effective gain moni-	1 V	Gain setting 1 is enabled.
Pn007		tor	2 V	Gain setting 2 is enabled.



# 5.8.2 Manual Adjustment of Friction Compensation

Friction compensation rectifies the viscous friction change and regular load change.

The friction compensation function can be automatically adjusted with advanced autotuning (Fn201), advanced autotuning by reference input (Fn202), or one-parameter tuning (Fn203). This section describes the steps to follow if manual adjustment is required.

# (1) Required Parameter Settings

The following parameter settings are required to use friction compensation.

Pa	arameter	Function	When Enabled	Classification
Pn408	n.0□□□ [Factory setting]	Does not use friction compensation.	Immediately	Setup
	n.1□□□	Uses friction compensation.		

	Friction Compensation Gain		Speed	Classification	
Pn121	Setting Range	Setting Unit	Factory Setting	When Enabled	
	10 to 1000	1%	100	Immediately	Tuning
	Friction Compensation	n Coefficient	Speed	Position	Classification
Pn123	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 100	1%	0	Immediately	Tuning
	Friction Compensation	n Frequency Correction	Speed	Position	Classification
Pn124	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-10000 to 10000	0.1 Hz	0	Immediately	Tuning
	Friction Compensation	n Gain Correction	Speed	Position	Classification
Pn125	Setting Range	Setting Unit	Factory Setting	When Enabled	
	1 to 1000	1%	100	Immediately	Tuning

# (2) Operating Procedure for Friction Compensation

The following procedure is used for friction compensation.

 CAUTION

 Before using friction compensation, set the moment of inertia ratio (Pn103) as accurately as possible. If the wrong moment of inertia ratio is set, vibration may result.

Step	Operation				
1	Set the following parameters for friction compensation to the factory setting as follows. Friction compensation gain (Pn121): 100 Friction compensation coefficient (Pn123): 0 Friction compensation frequency correction (Pn124): 0 Friction compensation gain correction (Pn125): 100 Note: Always use the factory-set values for friction compensation frequency correction (Pn124) and friction compensation gain correction (Pn125).				
2	<ul> <li>To check the effect of friction compensation, gradually increase the friction compensation coefficient (Pn123).</li> <li>Note: Usually, set the friction compensation coefficient value to 95% or less. If the effect is insufficient, increase the friction compensation gain (Pn121) by 10% increments until it stops vibrating.</li> <li>Effect of Parameters for Adjustment</li> <li>Pn121: Friction Compensation Gain</li> <li>This parameter sets the responsiveness for external disturbance. The higher the set value is, the better the responsiveness will be. If the equipment has a resonance frequency, however, vibration may result if the set value is excessively high.</li> <li>Pn123: Friction Compensation Coefficient</li> <li>This parameter sets the effect of friction compensation. The higher the set value is, the more effective friction compensation will be. If the set value is excessively high, however, the vibration will occur easily. Usually, set the value to 95% or less.</li> </ul>				
3	Effect of Adjustment The following graph shows the responsiveness with and without proper adjustment. Insufficient responsiveness because of friction Small friction Positon error Large friction Referencespeed Without friction compensation With friction compensation				

# 5.8.3 Current Control Mode Selection Function

This function reduces high-frequency noises while the servomotor is being stopped. This function is enabled by default and set to be effective under different application conditions. Set Pn009.1 = 1 to use this function.

\*This function can not be used with LECYU2-V ...

Parameter		Meaning	When Enabled	Classification
	n. 🗆 🗆 O 🗆	Selects the current control mode 1.		
Pn009	n. □□1□ [Factory setting]	Selects the current control mode 2 (low noise).	After restart	Tuning

#### 5.8.4 Current Gain Level Setting

This function reduces noises by adjusting the parameter value for current control inside the DRIVER according to the speed loop gain (Pn100). The noise level can be reduced by reducing the current gain level (Pn13D) from its factory setting of 2000% (disabled). If the set value of Pn13D is decreased, the level of noise will be lowered, but the response characteristics of the DRIVER will also be degraded. Adjust the current gain level within the allowable range at which DRIVER response characteristics can be secured.

	Current Gain Level Speed Position Clas		Classification		
Pn13D	Setting Range	Setting Unit	Factory Setting	When Enabled	
	100 to 2000	1%	2000	Immediately	Tuning
IM	PORTANT · If th resp DRIV	e parameter setting onses character- istic /ER must, therefore, t	of the current gain is of the speed loop be read-justed again.	level is changed, th will also change. Th	ie ie

# 5.8.5 Speed Detection Method Selection

This function can ensure smooth movement of the servomotor while the servomotor is running. Set the value of Pn009.2 to 1 and select speed detection 2 to smooth the movement of the servomotor while the servomotor is running.

Parameter		Meaning	When Enabled	Classification
Pn009	n. □0□□ [Factory setting]	Selects speed detection 1.	After restart	Tuning
	n. 🗆 1 🗆 🗆	Selects speed detection 2.		

Characteristics of the speed loop will change and the DRIVER must be readjusted again.
---

- 5.8.6 Backlash Compensation Function
  - (1) Overview

When driving a machine with backlash, there will be a deviation between the travel distance in the position reference that is managed by the PC or PLC...etc. and the travel distance of the actual machine. Use backlash compensation function to add the backlash compensation value to the position reference and use the result to drive the servomotor. This means that the travel distance of the actual machine will be the same as the travel distance in the PC or PLC...etc.

- Note 1. This function is supported only for position control.
  - 2. Software version 0023 or higher is required to use this function. For details, refer to 6.13 Product Information Display.



(2) Related Parameter

Set the following parameter to use backlash compensation.

- Backlash Compensation Direction

Set the direction in which to apply backlash compensation.

Parameter		Function	When Enabled	Classification
Pn230	n. □□□0 [Factory setting]	Compensates with a reference in the forward direc- tion.	After restart	Setup
	n. 🗆 🗆 🗆 1	Compensates with a reference in the reverse direc- tion.		

- Backlash Compensation Value

Set the amount of backlash compensation to add to the position reference. The amount is set in increments of 0.1 reference unit. However, when the amount is converted to encoder pulses, it is rounded off at the decimal point.

Example: If Pn231 is set to 6,553.6 [reference unit] and the electronic gear ratio (Pn20E/Pn210) is set to 4/1, then the pulse equivalent is 6,553.6  $\times$  4 = 26,214.4 [pulses].  $\Rightarrow$ The backlash compensation value will be 26,214 encoder pulses.

Pn231	Backlash compensation	value	Position	Classification	
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	-500000 to 500000	0.1 reference unit	0	Immediately	Setup



IMPORTANT	• The backlash compensation value is restricted by the following formula. The specified compensation is not performed if this condition is not met. $Pn231 \le \frac{Pn210}{Pn20E} \times \frac{Maximum motor speed [min-1]}{60} \times Encoder resolution* \times 0.00025$
	* For details on encoder resolution, refer to 8.3.5 <i>Electronic Gear</i> .
	Example 1:
	Assuming Pn20E = 4, Pn210 = 1, maximum motor speed = 6000
	[min <sup>-1</sup> ], encoder resolution = 1048576 (20 bits):
	1/4 $\times$ 6000/60 $\times$ 1048576 $\times$ 0.00025 = 6553.6 [reference units]
	$\Rightarrow$ The upper limit for the backlash compensation is 6553.6 [reference units].
	Example 2:
	When using the conditions $Pn20E = 4$ , $Pn210 = 1$ , maximum motor speed = 6000 [min <sup>-1</sup> ], external encoder pitch count ( $Pn20A$ ) = 500, signal resolution: 1/256:
	$1/4 \times 6000/60 \times (500 \times 256) \times 0.00025$ = 800.0 [reference units] $\Rightarrow$ The upper limit for the backlash compensation is 800.0 [reference units].
	<ul> <li>Do not exceed the upper limit of the backlash compensation value. The upper limit of the backlash compensation value can be confirmed in Un031.</li> </ul>

# - Backlash Compensation Time Constant

Set a time constant for a first order lag filter to use when adding the backlash compensation value (Pn231) to the position reference. If you set Pn233 to 0, the first order lag filter is disabled.

	Backlash compensation	time constant		Position	Classification
Pn233	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 65535	0.01 ms	0	Immediately	Setup

Note: Changes to the set value are applied when there is no position reference input and the servomotor is stopped. The current operation is not affected if the set value is changed during servomotor operation.

# (3) Related Monitor

The following monitoring parameters provide information on backlash compensation.

Displayed Information	Unit
The current backlash compensation value	0.1 reference unit
Backlash compensation setting limit value	0.1 reference unit

(4) Compensation Operation

This section describes the operation that is performed for backlash compensation.

Note: The following figures are for when backlash compensation is applied for references in the forward direction (Pn230.0 = 0). The following monitoring information is provided in the figures: TPOS (target position in the reference coordinate system), POS (reference position in the reference coordinate system), and APOS (feedback position in the machine coordinate system). The monitoring information includes the feedback position in machine coordinate system (APOS) and other feedback information. The backlash compensation value is subtracted from the feed- back positions in the monitoring information, so it is not necessary for the PC or PLC...etc. to consider the backlash compensation value.



- When Servo is ON

The backlash compensation value (Pn231) is added in the compensation direction when the servo is ON (i.e., the servomotor is powered) and a reference is input in the same direction as the backlash compensation direc- tion (Pn230.0). If there is a reference input in the direction opposite to the backlash compensation direction, the backlash compensation value is not added (i.e., backlash compensation is not performed).

The relationship between APOS and the servomotor shaft position is as follows:

If a reference is input in the compensation direction: APOS = Motor shaft position - Pn231

If a reference is input in the direction opposite to the compensation direction: APOS = Motor shaft position

The following figure shows driving the servomotor in the forward direction from target position TPOS0 to TPOS1 and then to TPOS2, and then returning from TPOS2 to TPOS1 and then to TPOS0.

Backlash compensation is applied when moving from TPOS0 to TPOS1, but not when moving from TPOS2 to TPOS1.



- When Servo is OFF

Backlash compensation is not applied when the servo is OFF (i.e., when the servomotor is not powered). Therefore, the reference position POS moves by only the backlash compensation value.

The relationship between APOS and the servomotor shaft position is as follows:

- When servo is OFF: APOS = Servomotor shaft position

The following figure shows what happens when the servo is turned OFF after driving the servomotor in the forward direction from target position TPOS0 to TPOS1. Backlash compensation is not applied when the servo is OFF (i.e., the DRIVER manages the position data so that APOS and POS are the same).



- When There is Overtravel

When there is overtravel (i.e., when driving is prohibited due to an overtravel signal or software limit), the operation is the same as for • *When Servo is OFF*, i.e., backlash compensation is not applied.

- When Control is Changed

Backlash compensation is performed only for position control.

Backlash compensation is not applied if changing from position control to any other type of control. Backlash compensation is applied in the same way as • *When Servo is ON* if changing from any other type of control to position control.

# (5) Monitor Functions (Un Monitoring)

Displayed Information	Unit	Specification
Input reference speed	min <sup>-1</sup>	Indicates the input reference speed before backlash compensation.
Position error amount	Reference unit	Displays the position error with respect to the position reference after backlash compensation.
Input reference counter	Reference unit	Displays the input reference counter before backlash compensation.
Feedback pulse counter	Encoder pulse	Displays the pulse count of the actually driven motor encoder.
Fully-closed feedback pulse counter	External encoder resolution	Displays the pulse count of the actually driven external encoder.
Feedback pulse counter	Reference unit	Displays the pulse count of the actually driven encoder in reference units.

# (6) MECHATROLINK Monitor Information

This section describes the information that is set for the MECHATROLINK monitoring information (Monitor 1, Monitor 2, Monitor 3, and Monitor 4) and the backlash compensation operation.

Monitor Code	Designation	Meaning	Unit	Remarks
0	POS	Reference position in the reference coordinate system (after the position reference filter)	Reference unit	-
1	MPOS	Reference position	Reference unit	-
2	PERR	Position error	Reference unit	-
3	APOS	Feedback position in the machine coordinate system	Reference unit	Feedback position with the backlash compensation subtracted
4	LPOS	Feedback latch position in the machine coordinate system	Reference unit	Feedback position with the backlash compensation subtracted
5	IPOS	Reference position in the reference coordinate system (before the position reference filter)	Reference unit	-
6	TPOS	Target position in the reference coor- dinate system	Reference unit	-
Е	OMN1	Option monitor 1 (selected with Pn824)	_	-
F	OMN2	Option monitor 2 (selected with Pn825)	-	-

Paran	neters	Monitor Information	Output Unit	Remarks
	0003H	Position error (lower 32 bits)	Reference unit	-
	0004H	Position error (upper 32 bits)	Reference unit	-
	000AH	Encoder count (lower 32 bits)	Reference unit	Count value of the actually driven
Pn824	000BH	Encoder count (upper 32 bits)	Reference unit	motor encoder
	000CH	FPG count (lower 32 bits)	Reference unit	Count value of the actually driven
	000DH	FPG count (upper 32 bits)	Reference unit	external encoder
Pn825	0017H	Input reference speed	min <sup>-1</sup>	Same as monitor display Un007
	0018H	Position error amount	Reference unit	Same as monitor display Un008
	001CH	Input reference counter	Reference unit	Same as monitor display Un00C
	001DH	Feedback pulse counter	Encoder pulse	Same as monitor display Un00D
	001EH	Fully-closed feedback pulse counter	External encoder resolution	Same as monitor display Un00E
	0080H	Previous value of latched feedback position (LPOS)	Encoder pulse	Feedback position with the backlash compensation subtracted

- Related Monitoring Diagrams





# 5.8.7 Torque Reference Filter

As shown in the following diagram, the torque reference filter contains first order lag filter and notch filters arrayed in series, and each filter operates independently. The notch filters can be enabled and disabled with the Pn408.



# (1)Torque Reference Filter

If you suspect that machine vibration is being caused by the servo drive, try adjusting the filter time constants with Pn401. This may stop the vibration. The lower the value, the better the response will be, but there may be a limit that depends on the machine conditions.

Pn401	Torque Reference Filter Time Constant		Speed Position Torque		Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 65535	0.01 ms	100	Immediately	Tuning

0

- Trque Reference Filter Setting Guide

Use the speed loop gain (Pn100 [Hz]) and the torque filter time constant (Pn401 [ms]) to set the torque refer- ence filter.

Adjusted value for stable control: Pn401 [ms]  $\leq$  1000/ (2 $\pi$  × Pn100 [Hz] × 4) Critical gains: Pn401 [ms] < 1000/ (2 $\pi$  × Pn100 [Hz] × 1)

Pn40F	2nd Step 2nd Torque Reference Filter Frequency		Speed Position Torque		Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	100 to 5000	1 Hz	5000*	Immediately	Tuning
Pn410	2nd Step 2nd Torque Q Value	e Reference Filter	Speed Position	Torque	Classification
	Setting Range	Setting Unit	Factory Setting	When Enabled	
	50 to 100	0.01	50	Immediately	Tuning

5-68

\* The filter is disabled if 5000 is set.

6.	Utility Functions (Fn $\Box \Box$ )	2
	6.1 List of Utility Functions	2
	6.2 Alarm History Display (Fn000)	3
	6.3 JOG Operation (Fn002)	4
	6.4 Origin Search (Fn003)	5
	6.5 Program JOG Operation (Fn004)	6
	6.6 Initializing Parameter Settings (Fn005)	10
	6.7 Clearing Alarm History (Fn006)	11
	6.8 Offset Adjustment of Analog Monitor Output (Fn00C)	12
	6.9 Gain Adjustment of Analog Monitor Output (Fn00D)	14
	6.10 Automatic Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00E)	.16
	6.11 Manual Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00F)	17
	6.12 Write Prohibited Setting (Fn010)	18
	6.13 Product Information Display (Fn011)	20
	6.14 Resetting Configuration Errors in Option Modules (Fn014)	21
	6.15 Vibration Detection Level Initialization (Fn01B)	22
	6.16 Origin Setting (Fn020)	24
	6.17 Software Reset (Fn030)	25
	6.18 EasyFFT (Fn206)	26
	6.19 Online Vibration Monitor (Fn207)	28

# 6. Utility Functions (Fn

# 6.1 List of Utility Functions

Utility functions are used to execute the functions related to servomotor operation and adjustment. The following table lists the utility functions and reference section.

Function No.	Function	Reference Section
Fn000	Alarm history display	6.2
Fn002	JOG operation	6.3
Fn003	Origin search	6.4
Fn004	Program JOG operation	6.5
Fn005	Initializing parameter settings	6.6
Fn006	Clearing alarm history	6.7
Fn008	Absolute encoder multiturn reset and encoder alarm reset	4.7.4
Fn00C	Offset adjustment of analog monitor output	6.8
Fn00D	Gain adjustment of analog monitor output	6.9
Fn00E	Automatic offset-signal adjustment of the motor current detection signal	6.10
Fn00F	Manual offset-signal adjustment of the motor current detection signal	6.11
Fn010	Write prohibited setting	6.12
Fn011	Product Information display	6.13
Fn013	Multiturn limit value setting change when a multiturn limit disagreement alarm occurs	4.7.6
Fn014	Resetting configuration error in option modules	6.14
Fn01B	Vibration detection level initialization	6.15
Fn020	Origin setting	6.16
Fn030	Software reset	6.17
Fn200	Tuning-less levels setting	5.2.2
Fn201	Advanced autotuning	5.3.2
Fn202	Advanced autotuning by reference	5.4.2
Fn203	One-parameter tuning	5.5.2
Fn204	Anti-resonance control adjustment function	5.6.2
Fn205	Vibration suppression function	5.7.2
Fn206	EasyFFT	6.18
Fn207	Online vibration monitor	6.19

Note: Execute the utility function with SigmaWin+.

### 6.2 Alarm History Display (Fn000)

This function displays the last ten alarms that have occurred in the DRIVER. The latest ten alarm numbers and time stamps\* can be checked.

\* Time Stamps

A function that measures the ON times of the control power supply and main circuit power supply in 100-ms units and displays the total operating time when an alarm occurs. The time stamp operates around the clock for approximately 13 years.

<Example of Time Stamps> If 36000 is displayed, 3600000 [ms] = 3600 [s] = 60 [min] = 1 [h] Therefore, the total number of operating hours is 1 hour.

#### (1) Preparation

There are no tasks that must be performed before displaying the alarm history.

(2) Operating Procedure

In the SigmaWin+  $\Sigma$ -V component main window, click **Alarm** and then click **Display Alarm**. Click Alarm Traceback tab page, and are shown in order of occurrence with alarm codes and details about the type of alarm, such as name.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.2 Alarm Display.

Note:

- If the same alarm occurs after more than one hour, the alarm will be saved. If it occurs in less than one hour, it will not be saved.
- Click **Clear** to delete or clear the alarm history. The alarm history is not cleared on alarm reset or when the DRIVER main circuit power is turned OFF.



# 6.3 JOG Operation (Fn002)

JOG operation is used to check the operation of the servomotor under speed control without connecting the DRIVER to the host controller.



(1) Preparation

The following conditions must be met to perform a jog operation.

The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000). The main circuit power supply must be ON. All alarms must be cleared. The hardwire baseblock (HWBB) must be disabled. The servomotor power must be OFF.

The JOG speed must be set considering the operating range of the machine. Set the jog speed in Pn304.

	Jog Speed		Speed	Position Torque	Classification
Pn304	Setting Range	Setting Unit	Factory Setting	When Enabled	
	0 to 10000	1 min <sup>-1*</sup>	500	Immediately	Setup

(2) Operating Procedure

Use the following procedure. The following example is given when the rotating direction of servomotor is set as Pn000.0=0 (Forward rotation by forward reference).

1. In the SigmaWin+  $\Sigma$ -V component main window, click **Test Run**, and then click **Jog**.

2. Set up the JOG speed. To change the JOG speed, click Edit.

3. Click Servo ON.

4. Press Forward or Reverse. A JOG operation is performed only while one of these buttons is pressed.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.7.1 JOG Operation.

#### 6.4 Origin Search (Fn003)

The origin search is designed to position the origin pulse position of the incremental encoder (phase C) and to clamp at the position.



This function is used when the motor shaft needs to be aligned to the machine.

Motor speed at the time of execution: 60 min<sup>-1</sup>

(For SGMCS direct drive motors, the speed at the time of execution is  $6 \text{ min}^{-1}$ .)



For aligning the motor shaft to the machine

(1) Preparation

The following conditions must be met to perform the origin search.

The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000). The main circuit power supply must be ON. All alarms must be cleared. The hardwire baseblock (HWBB) must be disabled. The servomotor power must be OFF.

## (2) Operating Procedure

Use the following procedure.

1. In the SigmaWin+  $\Sigma$ -V component main window, click **Setup**, and then click **Search Origin**.

2. Click Servo ON.

3. Press **Forward** or **Reverse**. The search is performed while one of these buttons is pressed. The axis stops when the search is complete.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL Σ-V Component 4.4.4 Origin Search.



#### 6.5 Program JOG Operation (Fn004)

The program JOG operation is a utility function, that allows continuous operation determined by the preset operation pattern, movement distance, movement speed, acceleration/deceleration time, waiting time, and number of times of movement.

This function can be used to move the servomotor without it having to be connected to a host controller for the machine as a trial operation in JOG operation mode. Program JOG operation can be used to confirm the operation and for simple positioning operations.

#### (1) Preparation

The following conditions must be met to perform the program JOG operation.

The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000). The main circuit power supply must be ON. All alarms must be cleared. The hardwire baseblock (HWBB) must be disabled. The servomotor power must be OFF. The travel distance and speed must be set correctly considering the machine operation range and safe operation speed. There must be no overtravel.

(2) Additional Information

The functions that are applicable for position control, such as position reference filter, can be used. The overtravel function is enabled in this function.

(3) Program JOG Operation Patterns

The following describes an example of program JOG operation pattern. The following example is given when the rotating direction of the servomotor is set as Pn000.0 = 0 (Forward rotation by forward reference).



Note: When Pn536 (number of times of program JOG movement) is set to 0, infinite time operation is enabled.



Note: When Pn530.0 is set to 3, infinite time operation is disabled.





Note: When Pn536 (number of times of program JOG movement) is set to 0, infinite time operation is enabled.



Note: When Pn536 (number of times of program JOG movement) is set to 0, infinite time operation is enabled.

# (4) Related Parameters

The following parameters set the program JOG operation pattern. Operation pattern can change setting at Running Condition Setting box of program JOG operation.

Do not change the settings while the program JOG operation is being executed.

	Program JOG Opera	tion Related Switch	Speed	Position	Torque	Classification
Pn530	Setting Range	Setting Unit	Factory Setting	When E	nabled	
	0000 to 0005	_	0000	Immed	liately	Setup
B 504	Program JOG Move	ment Distance	Speed	Position	Torque	Classification
Ph531	Setting Range	Setting Unit	Factory Setting	When E	nabled	
	1 to 1073741824	1 reference unit	32768	Immed	liately	Setup
	Program JOG Move	ment Speed	Speed	Position	Torque	Classification
Pn533	Setting Range	Setting Unit	Factory Setting	When E	nabled	
	1 to 10000	1 min <sup>-1*</sup>	500	Immed	liately	Setup
	Program JOG Accel	eration/Deceleration 1	Time Speed	Position	Torque	Classification
Pn534	Program JOG Accel Setting Range	eration/Deceleration T Setting Unit	Time Speed Factory Setting	Position When E	Torque	Classification
Pn534	Program JOG Accel Setting Range 2 to 10000	eration/Deceleration T Setting Unit 1 ms	Fine Speed Factory Setting	Position When E Immed	Torque Enabled liately	Classification
Pn534	Program JOG Accel Setting Range 2 to 10000 Program JOG Waitin	eration/Deceleration T Setting Unit 1 ms ng Time	Fime Speed Factory Setting 100 Speed	Position When E Immed	Torque Enabled liately Torque	Classification Setup Classification
Pn534 Pn535	Program JOG Accel Setting Range 2 to 10000 Program JOG Waitin Setting Range	eration/Deceleration T Setting Unit 1 ms ng Time Setting Unit	Time Speed Factory Setting 100 Speed Factory Setting	Position When E Immed Position When E	Torque Enabled liately Torque Enabled	Classification Setup Classification
Pn534 Pn535	Program JOG Accel Setting Range 2 to 10000 Program JOG Waitin Setting Range 0 to 10000	eration/Deceleration T Setting Unit 1 ms ng Time Setting Unit 1 ms	Speed       Factory Setting       100       Speed       Factory Setting       100	Position When E Immed Position When E Immed	Torque inabled liately Torque inabled liately	Classification Setup Classification Setup
Pn534 Pn535	Program JOG Accel Setting Range 2 to 10000 Program JOG Waitin Setting Range 0 to 10000 Number of Times of	eration/Deceleration T Setting Unit 1 ms ng Time Setting Unit 1 ms Program JOG Moven	Speed       Factory Setting       100       Speed       Factory Setting       100	Position When E Immed Position When E Immed	Torque inabled liately Torque inabled liately Torque	Classification Setup Classification Setup Classification
Pn534 Pn535 Pn536	Program JOG Accel Setting Range 2 to 10000 Program JOG Waitin Setting Range 0 to 10000 Number of Times of Setting Range	eration/Deceleration T Setting Unit 1 ms ng Time Setting Unit 1 ms Program JOG Moven Setting Unit	Speed       Factory Setting       100       Speed       Factory Setting       100       nent       Speed       Factory Setting       100	Position When E Immed Position When E Position When E	Torque inabled liately Torque inabled liately Torque nabled	Classification Setup Classification Setup Classification

(5) Operating Procedure

Use the following procedure.

1. In the SigmaWin+  $\Sigma$ -V component main window, click **Test Run** and then click **Program JOG Operation**.

- 2. Set the running conditions and click Apply. The graph for the operation pattern is displayed.
- 3. Click **Run** and the Program JOG Operation box appears.
- 4. Click Servo ON and Execute. The program JOG operation starts.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL Σ-V Component 4.7.2 *Program JOG Operation*.

#### 6.6 Initializing Parameter Settings (Fn005)

This function is used when returning to the factory settings after changing parameter settings.



Be sure to initialize the parameter settings while the servomotor power is OFF. After initialization, turn OFF the power supply and then turn ON again to validate the settings.

Note: Any value adjusted with Fn00C, Fn00D, Fn00E, and Fn00F cannot be initialized by Fn005.

#### (1) Preparation

The following conditions must be met to initialize the parameter values.

The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000). The servomotor power must be OFF.

(2) Operating Procedure

Use the following procedure.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Parameters** and then click **Edit Parameters**. The Parameter Editing window for the online mode appears.
- 2. Click Initialize.
- 3. To enable the change in the setting, turn the power OFF and ON again.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.1.1 Editing Parameter.



# 6.7 Clearing Alarm History (Fn006)

The clear alarm history function deletes all of the alarm history recorded in the DRIVER.

Note: The alarm history is not deleted when the alarm reset is executed or the main circuit power supply of the DRIVER is turned OFF.

## (1) Preparation

The follow conditions must be met to clear the alarm history. The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).

# (2) Operating Procedure

Use the following procedure.

1. In the SigmaWin+  $\Sigma$ -V component main window, click **Alarm** and then click **Display Alarm**. 2. To clear an alarm, click **Reset** after removing the cause of the alarm.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.2 Alarm Display.

#### 6.8 Offset Adjustment of Analog Monitor Output (Fn00C)

This function is used to manually adjust the offsets for the analog monitor outputs (torque reference monitor output and motor speed monitor output). The offset values are factory-set before shipping. Therefore, the user need not usually use this function.

(1) Adjustment Example

An example of offset adjustment to the motor speed monitor is shown below.



Offset Adjustment Range	-2.4 V to + 2.4 V
Adjustment Unit	18.9 mV/LSB

Note:

-The adjustment value will not be initialized when parameter settings are initialized using Fn005.

-Make offset adjustment with a measuring instrument connected, so that the analog monitor output is zero. An example of settings for a zero analog monitor output is shown below.

- While the servomotor is not turned ON, set the monitor signal to the torque reference.
- In speed control, set the monitor signal to the position error.

(2) Preparation

The following condition must be met to adjust the offsets of the analog monitor output.

-The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).

(3) Operating Procedure

Use the following procedure to perform the offset adjustment of analog monitor output.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click Setup, point to Adjust Offset and click **Adjust the Analog Monitor Output**.
- 2. Click the Zero Adjustment tab.
- 3. While watching the analog monitor, use the +1 and -1 buttons to adjust the offset.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.3 Offset Adjustment.

#### 6.9 Gain Adjustment of Analog Monitor Output (Fn00D)

This function is used to manually adjust the gains for the analog monitor outputs (torque reference monitor output and motor rotating speed monitor output). The gain values are factory-set before shipping. Therefore, the user need not usually use this function.

(1) Adjustment Example

An example of gain adjustment to the motor rotating speed monitor is shown below.



Item	Specifications
Gain-adjustment Range	100±50%
Adjustment Unit	0.4%/LSB

The gain adjustment range is made with a 100% output set as a center value (adjustment range: 50% to 150%). The following is a setting example.

<Setting the Set Value to -125> 100% + ( $-125 \times 0.4$ ) = 50% Therefore, the monitor output voltage is 0.5 time as high.

<Setting the Set Value to 125>  $100\% + (125 \times 0.4) = 150\%$ Therefore, the monitor output voltage is 1.5 times as high.

Note: The adjustment value will not be initialized when parameter settings are initialized using Fn005.

#### (2) Preparation

The following condition must be met to adjust the gain of the analog monitor output.

- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).



# (3) Operating Procedure

Use the following procedure to perform the gain adjustment of analog monitor output.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Setup**, point to **Adjust Offset** and click **Adjust the Analog Monitor Output**.
- 2. Click the Gain Adjustment tab.
- 3. While watching the analog monitor, use the +1 and -1 buttons to adjust the gain.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL Σ-V Component *4.4.3 Offset Adjustment*.



## 6.10 Automatic Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00E)

Perform this adjustment only if highly accurate adjustment is required for reducing torque ripple caused by current offset. The user need not usually use this function.



Note: The adjusted value is not initialized by executing the Fn005 function (Initializing Parameter Settings).

(1) Preparation

The following conditions must be met to automatically adjust the offset of the motor current detection signal.

- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The DRIVER must be in Servo Ready status (Refer to 4.8.4).
- The servomotor power must be OFF.

(2) Operating Procedure

Use the following procedure.

- 1. In the SigmaWin+ $\Sigma$ -V component main window, click **Setup**, point to **Adjust Offset** and click **Adjust the Motor Current Detection Offset**.
- 2. Click Continue, and then click the Automatic Adjustment tab.
- 3. Click Adjust. The automatically adjusted values are displayed in the New box.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.3 Offset Adjustment.

# 6.11 Manual Offset-Signal Adjustment of the Motor Current Detection Signal (Fn00F)

Use this function only if the torque ripple is still high after the automatic offset-signal adjustment of the motor current detection signal (Fn00E).

	If this function is adjusted incorrectly and then executed, characteristics of the servomo- tor performance could be affected.
	Observe the following precautions when performing manual servo tuning.
IMPORTANT	<ul> <li>Run the servomotor at a speed of approximately 100 min<sup>-1</sup>.</li> <li>Adjust the offset while monitoring the torque reference with the analog monitor until the ripple of torque reference monitor's waveform is minimized.</li> <li>Adjust the phase-U and phase-V offset amounts alternately several times until these offsets are well balanced.</li> </ul>

Note: The adjusted value is not initialized by executing the Fn005 function (Initializing Parameter Settings).

#### (1) Preparation

The following condition must be met to manually adjust the offset of the motor current detection signal. - The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).

#### (2) Operating Procedure

Use the following procedure.

- 1. Turn the motor at 100 min-1.
- 2. In the SigmaWin+ $\Sigma$ -V component main window, click **Setup**, point to **Adjust Offset** and click **Adjust the Motor Current Detection Offset**.
- 3. Click Continue, and then click the Manual Adjustment tab.
- 4. While watching the analog monitor, use the +1 and -1 buttons to adjust the offset to minimize the ripple on the torque reference monitor. The U-phase and V-phase currents must be adjusted so that they balance. Repeat the adjustment alternately between them several times.

Repeat the operations of steps 4 to 6 (phase-U and-V alternately) until adjusting the offset amounts both for phase-U and -V in both directions cannot reduce the torque ripple any more. Then, perform the same operation by adjusting by smaller amount.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.3 Offset Adjustment.

#### 6.12 Write Prohibited Setting (Fn010)

This function prevents changing parameters by mistake and sets restrictions on the execution of the utility function.

Parameter changes and execution of the utility function become restricted in the following manner when Write prohibited (P.0001) is assigned to the write prohibited setting parameter (Fn010).

- Parameters: Cannot be changed. If you attempt to change it, "NO-OP" will flash on the display and the screen will return to the main menu.

- Utility Function: Some functions cannot be executed. (Refer to the following table.) If you attempt to exe- cute these utility functions, "NO-OP" will flash on the display and the screen will return to the main menu.

Parameter No.	Function	Write Prohibited Setting	Reference Section
Fn000	Alarm history display	Executable	6.2
Fn002	JOG operation	Cannot be executed	6.3
Fn003	Origin search	Cannot be executed	6.4
Fn004	Program JOG operation	Cannot be executed	6.5
Fn005	Initializing parameter settings	Cannot be executed	6.6
Fn006	Clearing alarm history	Cannot be executed	6.7
Fn008	Absolute encoder multiturn reset and encoder alarm reset	Cannot be executed	4.7.4
Fn00C	Offset adjustment of analog monitor output	Cannot be executed	6.8
Fn00D	Gain adjustment of analog monitor output	Cannot be executed	6.9
Fn00E	Automatic offset-signal adjustment of the motor current detection signal	Cannot be executed	6.10
Fn00F	Manual offset-signal adjustment of the motor current detection signal	Cannot be executed	6.11
Fn010	Write prohibited setting	_	6.12
Fn011	Product Information display	Executable	6.13
Fn013	Multiturn limit value setting change when a multiturn limit dis- agreement alarm occurs	Cannot be executed	4.7.6
Fn014	Resetting configuration error in option modules	Cannot be executed	6.14
Fn01B	Vibration detection level initialization	Cannot be executed	6.15
Fn020	Origin setting	Cannot be executed	6.16
Fn030	Software reset	Executable	6.17
Fn200	Tuning-less levels setting	Cannot be executed	5.2.2
Fn201	Advanced autotuning	Cannot be executed	5.3.2
Fn202	Advanced autotuning by reference	Cannot be executed	5.4.2
Fn203	One-parameter tuning	Cannot be executed	5.5.2
Fn204	Anti-resonance control adjustment function	Cannot be executed	5.6.2
Fn205	Vibration suppression function	Cannot be executed	5.7.2
Fn206	EasyFFT	Cannot be executed	6.18
Fn207	Online vibration monitor	Cannot be executed	6.19

#### (2) Operating Procedure

- Follow the steps to set enable or disable writing. Setting values are as follows:
- "P.0000": Write permitted (Releases write prohibited mode.) [Factory setting]
- "P.0001": Write prohibited (Parameters become write prohibited from the next power ON.)
- 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Setup**, and then click **Write Prohibited Setting.**

<If the Write Prohibited Setting is ON>

2. Click the ▼ button to change the value to "0000" and click **Setting**. The write prohibited setting is off.

<If the Write Prohibited Setting is OFF>

- 2. Click the  $\blacktriangle$  button to change the value to "0001" and click Setting. The write prohibited setting is on.
- 3. Click **OK** and restart the SERVOPACK.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.5 Write Prohibited Setting.



## 6.13 Product Information Display (Fn011)

This function is used to check the servomotor model, voltage, capacity, encoder type, encoder resolution, software version, and ID. If the DRIVER has been custom-made, you can also check the specification codes of DRIVERs.

## (1) Preparation

There are no tasks that must be performed before the execution.

(2) Operating Procedure

In the SigmaWin+  $\Sigma$ -V component main window, click **Monitor** and then click **Product Information**. Information about the DRIVER, the motor, and the option modules will be displayed.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.3.1 Product Information.

#### 6.14 Resetting Configuration Errors in Option Modules (Fn014)

The DRIVER with option module recognizes installation status and types of option modules that are connected to DRIVER. If an error is detected, the DRIVER issues an alarm. This function clears these alarms.

- Note 1. Alarms related to option module can be cleared only by this function. These alarms cannot be cleared by alarm reset or turning OFF the main circuit power supply.
  - 2. Before clearing the alarm, perform corrective action for the alarm.
- (1) Preparation

The following condition must be met to clear detection alarms of the option module.

-The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).

(2) Operating Procedure

Use the following procedure.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click Setup and then Reset Configuration Error of Option Card.
- 2. Check to see if the **Clear** check box of the option module whose detection result to be cleared is selected, and then click **Execute**.
- 3. To enable the change in the setting, turn the power OFF and ON again.



The detection result **Error detected** cannot be cleared. Remove the option module, or check to see if the option module is correctly mounted.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.9 Resetting the Configuration Error of Option Module.

### 6.15 Vibration Detection Level Initialization (Fn01B)

This function detects vibration when servomotor is connected to a machine in operation and automatically adjusts the vibration detection level (Pn312) to output more exactly the vibration alarm (A.520) and the vibration warning (A.911).

The vibration detection function detects vibration elements according to the motor speed.

Parameter		Meaning	When Enabled	Classification
	n.□□□0 [Factory setting]	Does not detect vibration.		
Pn310	n.□□□1	Outputs the warning (A.911) when vibration is detected.	Immediately	Setup
	n.□□□2	Outputs the alarm (A.520) when vibration is detected.		

If the vibration exceeds the detection level calculated by the following formula, the alarm or warning will be output according to the setting of vibration detection switch (Pn310).

Detection level =  $\frac{\text{Vibration detection level (Pn312 [min^{-1}]) \times \text{Vibration detection sensitivity (Pn311 [%])}}{100}$ 

Use this function if the vibration alarm (A.520) or the vibration warning (A.911) is not output correctly when a vibration at the factory setting of the vibration detection level (Pn312) is detected. In other cases, it is not necessary to use this function.

The vibration alarm or warning detection sensibility differs depending on the machine conditions. In this case, fine-tune the setting of the vibration detection sensitivity (Pn311) using the above detection level formula as a guide.

	Vibration Detection S	oration Detection Sensitivity Speed Position Torque		n Torque	Classification
Pn311	Setting Range	Setting Unit	Factory Setting	When Enabled	
	50 to 500	1%	100	Immediately	Tuning

<b>D</b> IMPORTANT	<ul> <li>The vibration may not be detected because of improper servo gains. Also, not all kinds of vibrations can be detected. Use the detection result as a guideline.</li> <li>Set a proper moment of inertia ratio (Pn103). Improper setting may result in the vibration alarm, warning misdetection, or non-detection.</li> </ul>
	<ul> <li>The references that are used to operate your system must be input to execute this function.</li> </ul>
	<ul> <li>Execute this function under the operating condition for which the vibration detection level should be set.</li> </ul>
	• Execute this function while the motor speed reaches at least 10% of its maximum.

#### (1) Preparation

The following conditions must be met to initialize the vibration detection level.

- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The test without a motor function must be disabled (Pn00C.0 = 0).


#### (2) Operating Procedure

Use the following procedure.

1. In the SigmaWin+  $\Sigma$ -V component main window, click **Setup**, and then click **Initialize Vibration Detection Level**.

2. Select a percentage as the degree of vibration detection sensitivity and the vibration detection switch, and then click **Detection Start**.

3. Click **Execute**. The level at which the vibrations are detected is automatically adjusted, and the setting is displayed in the box on the right and saved in the DRIVER.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.7 *Initializing Vibration Detection Level.* 

(3) Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

- Parameters related to this function

These are parameters that are used or referenced when executing this function.

- Allowed changes during execution of this function

Yes : Parameters can be changed using SigmaWin+ while this function is being executed. No : Parameters cannot be changed using SigmaWin+ while this function is being executed.

- Automatic changes after execution of this function

Yes : Parameter set values are automatically set or adjusted after execution of this function. No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes
Pn311	Vibration Detection Sensitivity	Yes	No
Pn312	Vibration Detection Level	No	Yes

## 6.16 Origin Setting (Fn020)

When using an external absolute encoder for fully-closed loop control, this function is used to set the current position of the external absolute encoder as the origin (zero point position). (Do not use origin setting in LECY series.)

This function can be used with the following products. Mitutoyo Corporation ABS ST780A series Model: ABS ST78DA/ST78DAL



• After execution of origin setting, the servo ready (/S-RDY) signal will become inactive because the system position data will have been changed. Always turn the power supply OFF and then ON again after execution of origin setting.

#### (1) Preparation

The following conditions must be met to set the origin.

- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The servomotor power must be OFF.

#### (2) Operating Procedure

Use the following procedure.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click Setup and then Zero Point Position Setting.
- 2. Click Execute.
- 3. Click Continue to execute the zero point position setting.
- 4. To enable the change in the setting, turn the power OFF and ON again.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.14 Setting the Zero Point Position.



## 6.17 Software Reset (Fn030)

This function enables resetting the DRIVER internally from software. This function is used when reset- ting alarms and changing the settings of parameters that normally require restarting the DRIVER. This function can be used to change those parameters without restarting the DRIVER.



## (1) Preparation

- The following condition must be met to perform a software reset.
  - The servomotor power must be OFF.

#### (2) Operating Procedure

Use the following procedure.

- 1. In the SigmaWin+ $\Sigma$ -V component main window, click Setup and then click Software Reset.
- 2. Click Execute. The Software Reset window will appear.

3. Click Execute. When execution of the software reset function is complete, a warning message will appear, asking you to reconnect the SigmaWin+ to the DRIVER.

4. Click OK to close the Software Reset window. All settings including parameters have been re-calculated. Disconnect the SigmaWin+ from the DRIVER, and then reconnect.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.14 Setting the Zero Point Position.



## 6.18 EasyFFT (Fn206)

EasyFFT sends a frequency waveform reference from the DRIVER to the servomotor and slightly rotates the servomotor several times over a certain period, thus causing machine vibration. The DRIVER detects the resonance frequency from the generated vibration and makes notch filter settings according to the resonance frequency detection. The notch filter is effective for the elimination of high-frequency vibration and noise.

Execute this function after the servomotor power is turned OFF if operation of the DRIVER results in high-frequency noise and vibration.



The servomotor rotates slightly when EasyFFT is executed. Do not touch the servomotor or machine dur- ing execution of EasyFFT, otherwise injury may result.



Use the EasyFFT when the servo gain is low, such as in the initial stage of servo adjustment. If EasyFFT is executed after increasing the gain, the servo system may vibrate depending on the machine character- istics or gain balance.



In addition to this function, online vibration monitor (Fn207) can be used to detect machine vibration and automatically make notch filter settings.

If a LECYU2-V $\square$  Series is used to make adjustments, it is recommended to use advanced autotuning. EasyFFT is normally no need to use it.

## (1) Preparation

The following conditions must be met to perform EasyFFT.

- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The main circuit power supply must be ON.
- All alarms must be cleared.
- The hardwire baseblock (HWBB) must be disabled.
- The servomotor power must be OFF.
- There must be no overtravel.
- The test without a motor function must be disabled (Pn00C.0 = 0).
- An external reference must not be input.



## (2) Operating Procedure

Use the following procedure.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Setup** and then click **EasyFFT**.
- 2. Click **OK**, and the EasyFFT box appears.
- 3. Click Servo ON.
- 4. Select the instruction amplitude and the rotation direction, and click **Start**. The motor begins to rotate, and the measurement of the frequency starts. After the measurements have been taken, the results are displayed in the lower section of the box.
  - Note: When making the initial settings for EasyFFT, do not change the setting for the reference amplitude. Start with the original value of 15. Increasing reference amplitude increases the detection accuracy, but the vibration and noise from the machine will increase. Increase the amplitude value little by little.

#### 5. Click Measurement complete.

- 6. Click **Result Writing** to assign the results as parameter settings.
- 7. To enable the change in the setting, turn the power OFF and ON again.

< Important >

If two seconds or more are required for the operation although detection was successfully completed, the detection accuracy might be insufficient. Increasing reference amplitude more than 15 increases the detection accuracy, but the vibration and noise from the machine will increase. Increase the amplitude value little by little.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.4.8 EasyFFT.

#### (3) Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

#### - Parameters related to this function

These are parameters that are used or referenced when executing this function.

- Allowed changes during execution of this function

Yes : Parameters can be changed using SigmaWin+ while this function is being executed. No : Parameters cannot be changed using SigmaWin+ while this function is being executed.

- Automatic changes after execution of this function Yes : Parameter set values are automatically set or adjusted after execution of this function.
  - No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes	
Pn408	Torque Related Function Switch	Yes	Yes	
Pn409	1st Notch Filter Frequency	No	Yes	
Pn40A	1st Notch Filter Q Value	No	No	
Pn40C	2nd Notch Filter Frequency	No	Yes	
Pn40D	2nd Notch Filter Q Value	No	No	
Pn456	Sweep Torque Reference Amplitude	No	No	

#### 6.19 Online Vibration Monitor (Fn207)

If vibration is generated during operation and this function is executed while the servomotor power is still ON, the machine vibration can sometimes be suppressed by setting a notch filter or torque reference filter for the vibration frequencies.

When online, vibration frequency caused by machine resonance will be detected and the frequency that has the highest peak will be displayed on the panel operator. The effective torque reference filter or notch filter frequency for the vibration frequencies will be automatically selected and the related parameters will be automatically set.

In addition to this function, EasyFFT (Fn206) can be used to detect machine vibration and automatically make notch filter settings. Use the following flowchart to determine how these functions should be used.

If a LECYU2-V $\square$  Series DRIVER is used to make adjustments, it is recommended that you use advanced autotuning. This function is normally no need to use it.



How to use EasyFFT (Fn206) and online vibration monitor (Fn207), when they are mainly used for servo gain adjustment.

#### (1) Preparation

The following conditions must be met to perform online vibration monitoring.

- The write prohibited setting parameter (Fn010) must be set to Write permitted (P.0000).
- The servomotor power must be ON.
- There must be no overtravel.
- The correct moment of inertia (Pn103) must be set.
- The test without a motor function must be disabled (Pn00C.0 = 0).



## (2) Operating Procedure

Use the following procedure.

1. In the SigmaWin+  $\Sigma$ -V component main window, click **Monitor**, and then click **Online Vibration Monitor**.

- 2. Click **OK**, and the Online Vibration Monitor box appears.
- 3. Click **Execute** to activate the vibration sensor. The peak frequencies of the vibrations are displayed.
- 4. Click Auto Setting. In the "Previous" column, the current settings are displayed.

5. Click **Write result**. The adjusted values for detected frequencies are displayed in the "Current" column, and the values are stored in the SERVOPACK.

For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.3.4 Online Vibration Monitor.

## (3) Related Parameters

The following table lists parameters related to this function and their possibility of being changed while executing this function or of being changed automatically after executing this function.

- Parameters related to this function

These are parameters that are used or referenced when executing this function.

Allowed changes during execution of this function
 Yes : Parameters can be changed using SigmaWin+ while this function is being executed.
 No : Parameters cannot be changed using SigmaWin+ while this function is being executed.

# Automatic changes after execution of this function Yes : Parameter set values are automatically set or adjusted after execution of this function. No : Parameter set values are not automatically set or adjusted after execution of this function.

Parameter	Name	Mid-execution changes	Automatic changes	
Pn401	Torque Reference Filter Time Constant	No	Yes	
Pn408	Torque Related Function Switch	Yes	Yes	
Pn409	1st Notch Filter Frequency	No	Yes	
Pn40A	1st Notch Filter Q Value	No	No	
Pn40C	2nd Notch Filter Frequency	No	No	
Pn40D	2nd Notch Filter Q Value	No	No	

7. Monitor Displeys	2
7.1 Monitor Displays	2
7.1.1 System Monitor	2
7.1.2Status Monitor	2
7.1.3 Motion Monitor	2
7.1.4 Input Signal Monitor	2
7.1.5 Output Signal Monitor	3

# 7. Monitor Displeys

#### 7.1 Monitor Displays

The monitor displays can be used for monitoring the I/O signal status, and DRIVER internal status. There are five types of monitor windows: System Monitor, Status Monitor, Motion Monitor, Input Signal Monitor, and the Output Signal Monitor.

The monitor windows are independent of each other, but several windows can be displayed at the same time. Select the items to be monitored in the Monitor Item Setting Window (For System Monitor, the items to be monitored are fixed and cannot be selected.)

The monitor display can be checked or viewed in the SigmaWin+. For more information on the usage of the SigmaWin+, refer to AC Servo Drives Engineering Tool Sigma Win+ ONLINE MANUAL  $\Sigma$ -V Component 4.3.2 *Monitor*.

## 7.1.1 System Monitor

The System Monitor window will automatically open when the SigmaWin+ starts. Or, in the SigmaWin+  $\Sigma$ -V component window, click **Monitor**, point to **Monitor**, and then click **System Monitor**. The display is as follows.

- DRIVER current status
  - Same as the status displayed on the panel operator on the front of DRIVER.
- DRIVER signal current status
  - Same as the signal status displayed in bit data on the panel operator on the front of DRIVER.
- Starts the main functions directly from the System Monitor window.

#### 7.1.2 Status Monitor

The status monitor function monitors the DRIVER status.

To monitor the status of the DRIVER, use the following procedure.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click Monitor, point to Monitor and click Status Monitor. The items which can be monitored are listed.
- 2. Select the items to be monitored. The current status of a selected item is displayed in "Value" column.

#### 7.1.3 Motion Monitor

The motion monitor function monitors the DRIVER motion.

To monitor the motions of the DRIVER.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Monitor**, point to **Monitor** and click **Motion Monitor**. The items which can be monitored are listed.
- 2. Select the items to be monitored. The current status of a selected item is displayed in the "Value" column.

## 7.1.4 Input Signal Monitor

The input signal monitor function monitors the DRIVER input signals. To monitor the input signals of the DRIVER.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Monitor**, point to **Monitor** and click **Input Signal Monitor**. The items which can be monitored are listed.
- 2. Select the items to be monitored. The current status of a selected item is displayed in the "Value" column.

Note: Input signals use the following circuit configuration. OFF: Open ON: Short-circuited Example



#### 7.1.5 Output Signal Monitor

The output signal monitor function monitors the DRIVER output signals. To monitor the output signals of the DRIVER, use the following procedure.

- 1. In the SigmaWin+  $\Sigma$ -V component main window, click **Monitor**, point to **Monitor** and click **Output Signal Monitor**. The items which can be monitored are listed.
- 2. Select the items to be monitored. The current status of a selected item is displayed in the "Value" column.

Note: Input signals use the following circuit configuration. OFF: Transistor OFF ON: Transistor ON Example

**ON: Transistor ON** 

8.	MECHATROLINK-III Commands	4
	3.1 Layers	4
	3.2 Frame Structure	4
	8.3 State Transition Diagram	5
	3.4 Command and Response Timing	6
	8.4.1 Command Data Execution Timing	6
	8.4.2 Monitored Data Input Timing.	6
	8.4.3 Supporting the Transmission Cycle of 125 us	7
	8.4.5 Supporting the Transmission Cycle of 125 μs	/ Q
	8.5.1 Command Types	0 0 Q
	8.5.1 Commands	0 Q
	8.5.2 Main Commands	10
	8.5.4 Combinations of Main Commands and Subcommands	. 10
	8.5.4 Combinations of Main Commands and Subcommands	. 11
	8.0 Common Command Format	. 12
	8.7 Command Header Section of Main Command Area	. 14
	8.7.1 Command Code (CMD/RCMD)	. 14
	8.7.2 Watchdog Data (WD1/KWD1)	. 15
	8.7.3 Command Control (CMD_CTRL)	. 13
	8.7.4 Command Status (CMD_STAT)	. 16
	3.8 Command Header Section of Subcommand Area	. 20
	8.8.1 Subcommand Codes (SUB_CMD/SUB_RCMD)	. 20
	8.8.2 Subcommand Control (SUB_CTRL)	. 20
	8.8.3 Subcommand Status (SUB_STAT)	. 21
	3.9 Servo Command Format.	. 22
	3.10 Command Header Section	. 23
	8.10.1 Servo Command Control (SVCMD_CTRL)	. 23
	8.10.2 Servo Command Status (SVCMD_STAT)	. 25
	8.10.3 Supplementary Information on CMD_PAUSE and CMD_CANCEL	. 27
	8.10.4 Supplementary Information on Latching Operation	. 30
	3.11 Servo Command I/O Signal (SVCMD_IO)	. 31
	8.11.1 Bit Allocation of Servo Command Output Signals	. 31
	8.11.2 Bit Allocation of Servo Command I/O Signal Monitoring	. 33
	8.12 Command Data	. 36
	8.12.1 Data Order	. 36
	8.12.2 Specifying Units	. 36
	8.12.3 Specifying Monitor Data	. 37
	8.12.4 Position Data	. 37
	8.13 Common Commands	. 38
	8.13.1 Common Commands	. 38
	8.13.2 No Operation Command (NOP: 00H)	. 39
	8.13.3 Read ID Command (ID_RD: 03H)	. 40
	8.13.4 Setup Device Command (CONFIG: 04H)	. 47
	8.13.5 Read Alarm or Warning Command (ALM_RD: 05H)	. 49
	8.13.6 Clear Alarm or Warning Command (ALM_CLR: 06H)	. 51
	8.13.7 Start Synchronous Communication Command (SYNC_SET: 0DH)	. 52
	8.13.8 Establish Connection Command (CONNECT: 0EH)	. 53
	8.13.9 Disconnection Command (DISCONNECT: 0FH)	. 55
	8.13.10 Read Memory Command (MEM_RD: 1DH)	. 56
	8.13.11 Write Memory Command (MEM_WR: 1EH)	. 58



8.14 Servo Commands	61
8.14.1 Table of Servo Commands	61
8.14.2 Set Coordinates Command (POS_SET: 20H)	62
8.14.3 Apply Lock Command (BRK_ON: 21H)	64
8.14.4 Release Lock Command (BRK_OFF: 22H)	65
8.14.5 Turn Sensor ON Command (SENS_ON: 23H)	67
8.14.6 Turn Sensor OFF Command (SENS_OFF: 24H)	68
8.14.7 Servo Status Monitor Command (SMON: 30H)	69
8.14.8 Servo ON Command (SV_ON: 31H)	70
8.14.9 Servo OFF Command (SV_OFF: 32H)	71
8.14.10 Interpolation Command (INTERPOLATE: 34H)	73
8.14.11 Positioning Command (POSING: 35H)	74
8.14.12 Feed Command (FEED: 36H)	76
8.14.13 External Input Feed Command (EX_FEED: 37H)	
8.14.14 External Input Positioning Command (EX_POSING: 39H)	80
8.14.15 Zero Point Return Command (ZRET: 3AH)	82
8.14.16 Velocity Control Command (VELCTRL: 3CH)	85
8.14.17 Torque (Force) Control Command (TRQCTRL: 3DH)	86
8.14.18 Read Servo Parameter Command (SVPRM_RD: 40H)	87
8.14.19 Write Servo Parameter Command (SVPRM_WR: 41H)	88
8.14.20 Motion Command Data Setting Method	89
8.15 Subcommands	
8.15.1 No Operation Subcommand (NOP: 00H)	
8.15.2 Read Alarm or Warning Subcommand (ALM_RD: 05H)	
8.15.3 Clear Alarm or Warning Subcommand (ALM_CLR: 06H)	94
8.15.4 Read Memory Subcommand (MEM_RD: 1DH)	
8.15.5 Write Memory Subcommand (MEM_WR: 1EH)	
8.15.6 Servo Status Monitor Subcommand (SMON: 30H)	
8.15.7 Read Servo Parameter Subcommand (SVPRM_RD: 40H)	
8.15.8 Write Servo Parameter Subcommand (SVPRM_WR: 41H)	
8.16 Preparing for Operation	100
8.16.1 Setting MECHAIROLINK-III Communications	100
8.16.2 Checking the Communications Status	100
8.1 / Parameter Management and Operation Sequence.	101
8.17.1 Operation Sequence for Managing Parameters Using a PC or PLCetc	101
8.17.2 Operation Sequence for Managing Parameters Using a DRIVER	102
8.18 Setting the Zero Point before Starting Operation	103
8.19 Operation Sequence when Turning the Servo ON	104
8.20 Operation Sequence when OT (Overtravel Limit Switch) Signal is input	104
8.21 Operation Sequence at Emergency Stop (Main Circuit OFF)	104
8.22 Operation Sequence when a Safety Signal is input	105
8.25 Operation Sequence at Occurrence of Alarm	10/
3.24 Notes when the rostioning Completed State ( $rSET - T$ ) is Established while Called Motion Command	107
9 25 Function/Command Dalated Decemeters	109
8 25 1 Interpolation Command	100
8 25 2 Positioning Command	100
8 25 3 Torque (Force) Limiting Function	109
6.25.4 Torque (Force) Feedforward Function	111
8 25 5 Software Limit Function	11/
	114



8.25.6 Latch Function	116
8.25.7 Acceleration/Deceleration Parameter High-speed Switching Function	121
8.26 Detecting Alarms/Warnings Related to Communications or Commands	125
8.26.1 Communication Related Alarms	125
8.26.2 Warnings Related to Communication and Commands	127
8.27 Common Parameters	128
8.27.1 Overview	128
8.27.2 List of Common Parameters	129
8.27.3 Common Parameters and Corresponding Device Parameters	138
8.28 Virtual Memory Space	140
8.29 Information Allocated to Virtual Memory	141
8.29.1 ID Information Area	141
8.29.2 Common Parameter Area	142
8.29.3 Adjustment Operation Area	143

# 8. MECHATROLINK-III Commands

## 8.1 Layers

The MECHATROLINK-III communications layers have functions equivalent to layers 1, 2, and 7 in the OSI (Open System Interconnection) reference model.

Hierarchical Organization in the OSI Reference Model

OSI	MECHATROLINK-III Protocol
Layer 7: Application layer	MECHATROLINK-III application layer
Layers 3 to 6	None
Layer 2: Data link layer	ASIC dedicated to MECHATROLINK-III
Layer 1: Physical layer	Standard Ethernet PHY IEEE 802.3u

This chapter describes standard servo profile commands for the application layer.

## 8.2 Frame Structure

A standard servo profile command is composed of the combination of a main command and a subcommand as shown below. It is also possible to use a main command alone.

Byte	0		31 32			46 47
		Main command area		Subcommand area	I	
	<del>&lt;</del>		Information field —			

Classification	Byte	Command	Response	
Information Field	0 to 31	Jsed by main commands.		
	32 to 47	Used by subcommands. The subcommands for servo commands use byte 33 to byte 48. Note: In some main commands, subcommand cannot be used.		

The application layer interfaces with only the information field.

#### 8.3 State Transition Diagram

The master and slave station state transitions are shown in the following diagrams.



#### Slave Station State Transition

Phase	Abbreviation	Description
1	P1	Waiting for establishment of connection.
2	P2	Asynchronous communications enabled. Only asynchronous commands can be used.
3	Р3	Synchronous communications enabled. Both synchronous and asynchronous commands can be used.



## 8.4 Command and Response Timing

This section describes command execution timing at the DRIVER and monitored data input timing at the master station.

These timings are constant, regardless of the transmission cycle and communication cycle.

## 8.4.1 Command Data Execution Timing

Motion commands (such as POSING and INTERPOLATE), and the servo command control and servo command I/O signals (SVCMD\_CTRL and SVCMD\_IO) are executed 312.5 µs after their reception.



#### 8.4.2 Monitored Data Input Timing

The monitor, I/O, and status data are the data of 312.5 µs before the response is sent.



## 8.4.3 Supporting the Transmission Cycle of 125 $\mu s$

By adopting a shorter transmission cycle, the command throughput of the host PC or PLC...etc is improved by eliminating transmission delays.





# 8.5 List of Commands

# 8.5.1 Command Types

Standard servo profile commands are classified into common commands and servo commands.

Common commands: Commands that are common for MECHATROLINK-III communications, independent of profiles Servo commands: Commands that are defined in the standard servo profile and specific to DRIVERs

## 8.5.2 Main Commands

The standard servo profile main commands used for LECY series DRIVERs are listed below.

Category	Command Code (Hex.)	Command	Command Name	Function	Reference
	00	NOP	No operation command	Nothing is performed.	8.13.2
	03	ID_RD	Read ID command	Reads the device ID.	8.13.3
	04	CONFIG	Device setup request command	Enables the current parameter settings.	8.13.4
	05	ALM_RD	Read alarm/ warning command	Reads the current alarm or warning status, and the alarm history.	8.13.5
Common	06	ALM_CLR	Clear alarm/ warning state command	Clears the current alarm or warning status, and the alarm history.	8.13.6
Commands	0D	SYNC_SET	Request for establishing synchronization command	Starts synchronous communications.	8.13.7
	0E	CONNECT	Request for establishing connection command	Requests the establishment of a connection and setting of the communication mode.	8.13.8
	0F	DISCONNECT	Request for releasing con- nection command	Requests disconnection.	8.13.9
	1D	MEM_RD	Read memory command	Reads data from virtual memory.	8.13.10
	1E	MEM_WR	Write memory command	Writes data to virtual memory.	8.13.11
	20	POS_SET	Set coordinates command	Sets the coordinate system.	8.14.2
	21	BRK_ON	Request for applying lock command	Turns the lock signal OFF and applies the holding lock.	8.14.3
	22	BRK_OFF	Release lock command	Turns the lock signal ON and releases the holding lock.	8.14.4
	23	SENS_ON	Request for turning sensor ON command	Turns the encoder power supply ON, and gets the position data.	8.14.5
Servo	24	SENS_OFF	Request for turning sensor OFF command	Turns the encoder power supply OFF.	8.14.6
Commands	30	SMON	Monitor servo status command	Monitors the DRIVER status.	8.14.7
	31	SV_ON	Servo ON command	Turns the servo of the motor ON.	8.14.8
	32	SV_OFF	Servo OFF command	Turns the servo of the motor OFF.	8.14.9
	34	INTERPO- LATE	Interpolation command	Starts interpolation feeding.	8.14.10
	35	POSING	Positioning command	Starts positioning to the target position (TPOS) at the target speed (TSPD).	8.14.11

Category	Command Code (Hex.)	Command	Command Name	Function	Reference
	36	FEED	Constant speed feed command	Starts constant speed feeding at the target speed (TSPD).	8.14.12
Servo Commands	37	EX_FEED	Positioning at constant speed by external input command	Starts constant speed feeding at the target speed (TSPD). When an external signal is input part way through, positioning to the specified position is performed from the external signal input position.	8.14.13
	39	EX_POSING	Positioning by external input command	Starts positioning to the target position (TPOS) at the target speed (TSPD). When an external signal is input part way through, positioning to the speci- fied position is performed from the external signal input position.	8.14.14
	3A	ZRET	Zero point return command	Performs zero point return.	8.14.15
	3C	VELCTRL	Velocity control command	Controls speed.	8.14.16
	3D	TRQCTRL	Torque control command	Controls torque.	8.14.17
	40	SVPRM_RD	Read servo parameter command	Reads the specified servo parameter.	8.14.18
	41	SVPRM_WR	Write servo parameter command	Writes the specified servo parameter.	8.14.19

# 8.5.3 Subcommands

The standard servo profile subcommands used for LECY series DRIVERs are listed below.

Category	Command Code (Hex.)	Command	Command Name	Function	Reference	
	00	NOP	No operation command	Nothing is performed.	8.15.1	
	05	ALM_RD	Read alarm/ warning command	Reads the current alarm or warning status, and the alarm history.	8.15.2	
	06	ALM_CLR	Clear alarm/ warning state command	Clears the current alarm or warning status, and the alarm history.	Reference           8.15.1           e           8.15.2           e           8.15.3           8.15.4           8.15.5           8.15.6           8.15.7           8.15.8	
Servo	1D	MEM_RD	Read memory command	Reads data from virtual memory.	8.15.4	
Commands	1E	MEM_WR	Write memory command	Writes data to virtual memory.	8.15.5	
	30	SMON	Monitor servo status command	Monitors the DRIVER status.	8.15.6	
	40	SVPRM_RD	Read servo parameter command	Reads the specified servo parameter.	8.15.7	
	41	SVPRM_WR	Write servo parameter command	Writes the specified servo parameter.	8.15.8	

## 8.5.4 Combinations of Main Commands and Subcommands

The combinations of main commands and subcommands are listed below. When an invalid combination is specified, an alarm (SUBCMD\_ALM = BM (A.95E)) occurs.

			Subcommands							
			NOP (00H)	ALM_ RD (05H)	ALM_ CLR (06H)	MEM_ RD (1DH)	MEM_ WR (1EH)	SMON (30H)	SVPRM _RD (40H)	SVPRM _WR (41H)
		NOP (00H)	0	0	0	0	0	0	0	0
		ID_RD (03H)	0	0	0	0	0	0	0	0
		CONFIG (04H)	0	Х	Х	Х	Х	0	Х	Х
		ALM_RD (05H)	0	Х	Х	Х	Х	0	Х	Х
	Common	ALM_CLR (06H)	0	Х	Х	Х	Х	0	Х	Х
	Commands	SYNC_SET (0DH)	0	Х	Х	Х	Х	0	Х	Х
		CONNECT (0EH)	0	Х	Х	Х	Х	Х	Х	Х
		DISCONNECT (0FH)	0	Х	Х	Х	Х	Х	Х	Х
		MEM_RD (1DH)	0	Х	Х	Х	Х	0	Х	Х
		MEM_WR (1EH)	0	Х	Х	Х	Х	0	Х	Х
		POS_SET (20H)	0	Х	Х	Х	Х	0	Х	Х
		BRK_ON (21H)	0	Х	Х	Х	Х	0	Х	Х
		BRK_OFF (22H)	0	Х	Х	Х	Х	0	Х	Х
Main		SENS_ON (23H)	0	Х	Х	Х	Х	0	Х	Х
Command		SENS_OFF (24H)	0	Х	Х	Х	Х	0	Х	Х
3		SMON (30H)	0	0	0	0	0	0	0	0
		SV_ON (31H)	0	0	0	0	0	0	0	0
		SV_OFF (32H)	0	0	0	0	0	0	0	0
	Servo	INTERPOLATE (34H)	0	0	0	0	0	0	0	0
	Commands	POSING (35H)	0	0	0	0	0	0	0	0
		FEED (36H)	0	0	0	0	0	0	0	0
		EX_FEED (37H)	0	0	0	0	0	0	0	0
		EX_POSING (39H)	0	0	0	0	0	0	0	0
		ZRET (3AH)	0	0	0	0	0	0	0	0
		VELCTRL (3CH)	0	0	0	0	0	0	0	0
		TRQCTRL (3DH)	0	0	0	0	0	0	0	0
		SVPRM_RD (40H)	0	Х	Х	Х	×	0	×	Х
		SVPRM_WR (41H)	0	Х	Х	Х	×	0	Х	Х

 $_{\circ}~$  : Can be combined

 $\times$  : Cannot be combined

Note: Even for a valid combination, a command error (A.95A) occurs if the execution conditions of the commands are not satisfied.

Example: If initialization of a parameter is attempted by the MEM\_WR command while sending the SV\_ON command (during the servo ON state), a command error (A.95A) occurs instead of a command interference error (A.95E).

## 8.6 Common Command Format

This section describes the specifications that are common for all commands.

The format that is common for the commands sent from the master station and the responses returned from slave stations is shown below.

The format of a command can be divided into the main command area (32 bytes) and the subcommand area (16 bytes). The subcommand area is used to supplement the main command with another command. Whether the subcommand area is used or not is determined by the setting of the number of transmission bytes. When the number of transmission bytes is 32, the subcommand area is not used.

Both the main command area and subcommand area are divided into the command header section and the command data section.

Fields in the command header section of the main command area

Command: CMD, WDT, CMD\_CTRL Response: RCMD, RWDT, CMD\_STAT Fields in the command header section of the subcommand area Command: SUBCMD, SUB\_CTRL Response: RSUBCMD, SUB\_STAT

	Byte	Command	Response	Description
	0	CMD	RCMD	CMD/RCMD:
	1	WDT	RWDT	Command code specified for individual commands.
	2	CMD CTRI	CMD STAT	• WDT/RWDT
	3	end_end	Response       Description         RCMD       • CMD/RCMD: Command code specified for individual commands. Refer to 8.7.1 Command Code (CMD/RCMD).         CMD_STAT       • WDT/RWDT: Refer to 8.7.2 Watchdog Data (WDT/RWDT).         • CMD_CTRL: Refer to 8.7.3 Command Control (CMD_CTRL).         • CMD_STAT         • CMD_STAT: Refer to 8.7.4 Command Status (CMD_STAT).         • CMD_DATA/RSP_DATA: Specified for individual commands.	
	4			• CMD_CTRL:
	5			Refer to 8.7.3 Command Control (CMD_CTRL).
	6			Refer to 8.7.4 Command Status (CMD STAT).
	7			• CMD_DATA/RSP_DATA:
	8			Specified for individual commands.
	9			
Main Command	10			
	11			
	12			
	13			
	14			
	15			
Area	16		RSP DATA	
	17	CMD DATA		
	18	_	_	
	19			
	20			
	21			
	22			
	23			
	24			
	25			
	20			
	27			
	28			
	29			
	21			
	51			



	Byte	Command	Response	Description	
	32	Command SUBCMD SUB_CTRL	RSUBCMD	SUBCMD/RSUBCMD:	
	33	SUB_CTRL		Command code specified for individual commands.	
Sub-	34		SUB_STAT	<ul> <li>SUB_CTRL: Refer to 8.8.2 Subcommand Control (SUB_CTRL).</li> <li>SUB_STAT: Refer to 8.8.3 Subcommand Status (SUB_STAT).</li> <li>SUB_CMD_DATA/SUB_RSP_DATA: Specified for individual commands. Refer to 8.15</li> </ul>	
	35				
	36				
	37				
Area	38				
	:	SUB CMD DATA	SUB RSP DATA	Subcommands.	
	:	SOD_CNID_DAIN			
	45				
	46				
	47				

## 8.7 Command Header Section of Main Command Area

This section describes the command header section of the main command area.

#### 8.7.1 Command Code (CMD/RCMD)

This is the command code that defines the meaning of the messaging. Byte 0 of the command format is defined as the CMD/RCMD field. The data set in this field of the response data is a copy of that of the command data. The following table shows the command codes.

Profile	Command Code	Command	Operation	Compliance <sup>*1</sup>	Com P	munic hases	ation *3
	(Hex.)				1	2	3
	00	NOP	No operation	0	-	0	0
	01	PRM_RD	Read parameter	×*2	-	Х	Х
	02	PRM_WR	Write parameter	×*2	-	Х	Х
	03	ID_RD	Read ID	0	-	0	0
	04	CONFIG	Device setup request	Δ	-	0	0
	05	ALM_RD	Read alarm/warning	Δ	-	0	0
	06	ALM_CLR	Clear alarm/warning state	0	-	0	0
Common Commands	0D	SYNC_SET	Request for establishing synchronization	0	Ι	0	Δ
	0E	CONNECT	Request for establishing connection	0	0	Δ	Δ
	0F	DISCONNECT	Request for releasing connection	0	0	0	0
	1B	PPRM_RD	Read stored parameter	×*2	-	Х	Х
	1C	PPRM_WR	Write stored parameter	×*2 -		Х	Х
-	1D	MEM_RD	Read memory	Δ	-	0	0
	1E	MEM_WR	Write memory	Δ	-	0	0
	20	POS_SET	Set coordinates	0	-	0	0
	21	BRK_ON	Request for applying lock	0	-	0	0
	22	BRK_OFF	Release lock	0	-	0	0
	23	SENS_ON	Request for turning sensor ON	0	-	0	0
	24	SENS_OFF	Request for turning sensor OFF	0	-	0	0
	30	SMON	Monitor servo status	0	-	0	0
	31	SV_ON	Servo ON	0	-	0	0
	32	SV_OFF	Servo OFF	0	-	0	0
Servo	34	INTERPOLATE	Interpolation	0	-	Х	0
Commands	35	POSING	Positioning	0	-	0	0
	36	FEED	Constant speed feed	0	-	0	0
	37	EX_FEED	Servo OFF				0
	39	EX_POSING	Positioning by external input	0	-	0	0
	3A	ZRET	Zero point return	0	-	0	0
	3C	VELCTRL	Velocity control	0	-	0	0
	3D	TRQCTRL	Torque (force) control	0	-	0	0
	40	SVPRM_RD	Read servo parameter	Δ	-	0	0
	41	SVPRM_WR	Write servo parameter	0	-	0	0

\*1. Indicates the compliance status.

 $_{\circ}$ : Possible,  $\Delta$ : Possible with specification restrictions (Refer to the subsection describing each command for the details of the restrictions.),  $\times$ : Not possible

\*2. The standard servo command profile does not use PRM\_RD, PRM\_WR, PPRM\_RD and PPRM\_WR, but uses SVPRM\_RD and SVPRM\_WR instead.

\*3.  $_{\circ}$ : Can be executed,  $\Delta$ : Ignored,  $\times$ : Command error, –: Indefinite response data



## 8.7.2 Watchdog Data (WDT/RWDT)

The details of the watchdog timer (WDT) data in commands and responses are described below. Byte 1 of the command/response format is specified as the WDT/RWDT field.



The watchdog data (WDT) is checked after establishing synchronous communications (phase 3). The watchdog data (RWDT) at the DRIVER will be refreshed regardless of the establishment of synchronous communications.

## 8.7.3 Command Control (CMD\_CTRL)

The following describes the command control data.

Byte 2 and byte 3 of the command format are specified as the CMD\_CTRL field.

The designation in the CMD\_CTRL field is valid even when an alarm specified by CMD\_ALM has occurred. The CMD\_CTRL field is specified as shown below by the communication specification.

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
CMD_ID		Reserved	Reserved	ALM_CLR	Reserved	Reserved	Reserved

bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8
Reserved							

(1) ALM\_CLR: Clear Alarm/Warning State

- Definition

Clears the alarms and warnings that have occurred in the DRIVER.

0: Clear alarm/warning disabled

1: Clear alarm/warning triggered

- Description

Clears the alarm/warning state at the leading edge.

The same processing as when ALM\_CLR\_MODE = 0 for the ALM\_CLR command (the current alarm/warning state is cleared) is performed.

#### (2) CMD\_ID: Command ID

- Definition

The master station uses the command ID to have a slave station acknowledge that the command is a new command when the master station sends the same command repeatedly to the slave station.

Applicable commands: EX\_FEED, EX\_POSING, ZRET A value in the range 0 to 3 is used.

#### - Description

Since the slave station returns the CMD\_ID of the command being executed, the master station can decisively judge the command to which the slave station sent the response.

While  $CMD_RDY = 0$  (while the execution process of the command is incomplete), the slave station disregards commands that have a different CMD\_ID and continues the execution of the command being executed.



#### 8.7.4 Command Status (CMD\_STAT)

The following describes the status of responses.

Byte 2 and byte 3 of the response format are specified as the CMD\_STAT field.

The CMD\_STAT field is specified as shown below by the communication specification.

bit 7	bit 7 bit 6		bit 4	bit 3	bit 2	bit 1	bit 0
RCMD_ID		Reserved	Reserved	ALM_CLR_ CMP	CMDRDY	D_WAR	D_ALM
bit 15 bit 14 bit 13 bit 1		bit 12	bit 11	bit 10	bit 9	bit 8	
	COMM	I_ALM			CMD	ALM	

#### (1) D\_ALM

- Definition

This bit indicates the device alarm state of the slave station.

- 1: A device-specific alarm has occurred.
- 0: Other state (normal state, or the alarm specified by COMM\_ALM or CMD\_ALM has occurred.)

#### - Description

When a device-specific alarm other than the alarm state specified by COMM\_ALM and CMD\_ALM has occurred, the D ALM status bit is set to "1."

D\_ALM is independent of COMM\_ALM and CMD\_ALM.

When a device-specific alarm has occurred and D\_ALM is set to "1" in the servo ON state, the servo OFF state is established.

When the slave station shifts from the alarm state to the normal state as a result of the execution of the ALM\_CLR command or CMD\_CTRL.ALM\_CLR, this bit is set to "0."

[Example] Device alarm: Excessive position error (A.D00)  $\rightarrow$  D ALM = 1

#### (2) D\_WAR

#### - Definition

This bit indicates the device warning state of the slave station.

1: A device-specific warning has occurred.

0: Other state (normal state, or the alarm specified by COMM\_ALM or CMD\_ALM has occurred.)

#### - Description

When a device-specific warning other than the warning state specified by COMM\_ALM or CMD\_ALM has occurred, the D\_WAR status bit is set to "1."

D\_WAR is independent of COMM\_ALM and CMD\_ALM.

When a device-specific warning has occurred and the D\_WAR status bit is set to "1" in the servo ON state, the servo ON state is retained.

When the slave station shifts from the device warning state to the normal state as a result of the execution of the ALM\_CLR command or CMD\_CTRL.ALM\_CLR, this bit is set to "0."

[Example] Device warning: Overload warning  $(A.910) \rightarrow D_WAR = 1$ 



#### (3) CMDRDY

- Definition

This bit indicates whether the slave station is ready to receive commands.

1: Command reception enabled

0: Command reception disabled

#### - Description

CMDRDY = 0 means that command processing is in progress. While CMDRDY = 0, the slave station con-tinues to process the current command, but the slave station will discard new commands received while CMDRDY = 0. Only the DISCONNECT command is executed immediately regardless of the CMDRDY value.

Completion of command execution is confirmed in accordance with the completion confirmation method of each command.

The hold time for CMDRDY = 0 is specified for each command.

If command execution is possible despite an alarm or warning state, CMDRDY is set to "1."

#### (4) ALM\_CLR\_CMP

- Definition

This bit indicates the execution state of the ALM\_CLR command.

1: Execution of the ALM\_CLR command (CMD\_CTRL.ALM\_CLR) completed 0: Other

#### - Description

ALM\_CLR\_CMP is set to "1" in the following cases.

When the alarm clear processing executed by the ALM\_CLR command has been completed ALM\_CLR\_CMP is set to "1" when the alarm cannot be cleared as well.

When the alarm clear processing time (approx. 200 ms) has elapsed after receiving the ALM\_CLR command. ALM CLR CMP is set to "1" when the alarm cannot be cleared as well.

ALM CLR CMP can be cancelled by setting "0" for CMD CTRL.ALM CLR.

## (5) RCMD\_ID

- Definition

This is the echo-back of the CMD\_ID in the CMD\_CTRL field of the command data.

#### - Description

This is the identification code of the same commands that the slave station has received contiguously. Returns the CMD\_ID of the command format.

## (6) CMD\_ALM

- Definition

This bit indicates the validation result of the command.

- Description

CMD\_ALM indicates whether the command is valid or not. The results of validations of the command codes, and the combinations of commands and the data in the command frame are notified.

CMD\_ALM is independent of COMM\_ALM, D\_ALM and D\_WAR.

If a normal command is received after the occurrence of a command error, CMD\_ALM is automatically cleared. The phase doesn't change even if the status of CMD\_ALM is not "0." The servo ON/OFF state doesn't change either.

Code		Description	Remark					
	0	Normal						
	1	Invalid data						
	2							
	3		The slave station notifies the warning state, but operates at					
Warning	4		the specified value or the value on clamping at the maximum					
	5		or minimum value.					
	6							
	7							
	8	Unsupported command received						
	9	Invalid data						
	А	Command execution condition error						
Alarm	В	Subcommand combination error	The slave station notifies the alarm state and the command is					
	С	Phase error	not executed.					
	D							
	Е							
	F							

[Example] Command error: Invalid data (A.94B)  $\rightarrow$  CMD\_ALM = 9H



Check the status of CMD\_ALM with the host PC or PLC...etc for every communication cycle and perform appropriate processing because CMD\_ALM will be automatically cleared.

## (7) COMM\_ALM

- Definition

This bit indicates the MECHATROLINK communications error status.

- Description

 $COMM\_ALM \ shows \ if the \ data \ transmission \ in \ the \ physical \ or \ application \ layer \ has \ completed \ normally \ or \ not. \\ COMM\_ALM \ is \ independent \ of \ CMD\_ALM, \ D\_ALM \ and \ D\_WAR.$ 

Code		Description	Remark					
	0	Normal						
	1	FCS error	Occurs when an error is detected once.					
	2	Command data not received	The servo ON state is retained when an error is detected in the servo ON state					
	3	Synchronous frame not received	Error detection method					
	4		1: FCS error					
Warning	5		2: Command data not received					
	6		The DRIVER detects that command data has not been					
	7		<ul> <li>received.</li> <li>3: Synchronous frame not received The DRIVER detects that the synchronous frame has not been received.</li> </ul>					
	8	FCS error	Occurs when an error is detected in the following detection					
	9	Command data not received	methods.					
	А	Synchronous frame not received	• If the system is in communication phase 3, it will shift to communication phase 2.					
Alarm	В	Synchronization interval error	• Establishes the servo OFF state.					
Alalin	С	WDT error	Error detection method					
	D		the error detection method for warnings 1, 2 and 3					
	E		described above. B. C. Set immediately upon occurrence of a single error					
	F		b, c. Set minedialery upon occurrence of a single error.					

COMM\_ALM is cleared by the ALM\_CLR command or CMD\_CTRL.ALM\_CLR.

[Example]

Communications error (warning): Reception error warning (A.960)  $\rightarrow$  COMM\_ALM = 2H Communications error (alarm): Reception error alarm (A.E60)  $\rightarrow$  COMM\_ALM = 9H

#### 8.8 Command Header Section of Subcommand Area

Subcommands use byte 32 to byte 47 of the data field and function as a supplementary command to the main command. This subsection describes the command header section of the subcommand area.

## 8.8.1 Subcommand Codes (SUB\_CMD/SUB\_RCMD)

This is the subcommand code that specifies the meaning of the subcommand messaging. Byte 32 of the command format is defined as the SUB\_CMD/SUB\_RCMD field. The data set in this field of the response data is a copy of that of the command data.

The following table shows the subcommand codes.

Profile	Command Code	Command	Operation	Cor	mmunica Phases <sup>*2</sup>	ation <sup>*2</sup>	
	(Hex.)			1	2	3	
	00	NOP	No operation	-	0	0	
	05	ALM_RD <sup>*1</sup>	andOperationCom PandOperation $-$ No operation $-$ IRead alarm/warning $-$ IRead alarm/warning state $-$ IRead memory command $-$ IRead memory command $-$ IWrite memory command $ \mathbb{P}^{*1}$ Write memory status $ \mathbb{D}^{*1}$ Read servo parameter $-$ I/RWrite servo parameter $-$			0	
	06	ALM_CLR	Clear alarm/warning state	-	0	0	
Servo Commands	1D	MEM_RD <sup>*1</sup>	Read memory command	-	0	0	
Serve Communes	1E	MEM_WR <sup>*1</sup>	Write memory command	-	0	0	
	30	SMON	Monitor servo status	-	0	0	
	40	SVPRM_RD <sup>*1</sup>	Read servo parameter	-	0	0	
	41	SVPRM_WR	Write servo parameter	_	0	0	

\*1. Specification restrictions apply (Refer to the subsection describing each command for the details of the restrictions.)

\* 2.  $_{\circ}$ : Can be executed,  $\Delta$ : Ignored,  $\times$ : Command error, -: Indefinite response data

#### 8.8.2 Subcommand Control (SUB\_CTRL)

The following describes the subcommand control data.

Byte 33 to byte 35 of the command format are specified as the SUB\_CTRL field.

The SUB\_CTRL field is specified as shown below by the communication specification.

(1) SUB\_CTRL Field

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Reserved Reserved			Rese	erved			
bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8
	SEL_I	MON4			Rese	erved	
bit 23	bit 22	bit 21	bit 20	bit 19	bit 18	bit 17	bit 16
	SEL_I	MON6			SEL_N	MON5	

(2) Details of Control Bits

The following table shows the details of the control bits.

Bit	Name	Description	Value	Setting
12 to 15	SEL_MON4	Monitor selection 4	0 to 15	Selects the monitor information with the setting value.
16 to 19	SEL_MON5	Monitor selection 5	0 to 15	Selects the monitor information with the setting value.
20 to 23	SEL_MON6	Monitor selection 6	0 to 15	Selects the monitor information with the setting value.



## 8.8.3 Subcommand Status (SUB\_STAT)

The following describes the subcommand status of responses. Byte 33 to byte 35 of the response format are specified as the SUB\_STAT field. The SUB\_STAT field is specified as shown below by the communication specification.

(1) SUB\_STAT Field

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
Rese	erved	Rese	rved	Reserved	SUBCMDRDY	Reserved	Reserved
bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8
	SEL_	MON4			SUBCMI	D_ALM	
hit 23	hit 22	hit 21	hit 20	hit 19	bit 18	hit 17	hit 16

bit 23	bit 22	bit 21	bit 20	bit 19	bit 18	bit 17	bit 16
	SEL_1	MON6			SEL_1	MON5	

## (2) Details of Status Bits

The following table shows the details of the status bits.

Bit	Name	Description	Value	Setting
2	SUBCMDRDY*	Subcommand ready	1	Subcommand reception enabled
_	Sebenibitb I	Subcommuna roudy	0	Other
8 to 11	SUBCMD_ALM	Subcommand alarm	0 to 15	Refer to 8.7.4 Command Status (CMD_STAT) (6).
12 to 15	SEL_MON4	Monitor selection 4	0 to 15	Indicates the selected monitor information. (Copy of the command)
16 to 19	SEL_MON5	Monitor selection 5	0 to 15	Indicates the selected monitor information. (Copy of the command)
20 to 23	SEL_MON6	Monitor selection 6	0 to 15	Indicates the selected monitor information. (Copy of the command)

\* When no subcommand is used, the SUBCMDRDY status bit is set to "1."

## 8.9 Servo Command Format

This section describes the specifications of the servo commands.

The servo commands are specified by the 32-byte command and response data in the communication specifications as shown in the table below.

The command/response data area can be expanded to 48 bytes by using subcommands. For the subcommands, refer to 8.15 *Subcommands*.

The following table shows the format of the servo command and response data.

Byte	Command	Response	Description
0	CMD	RCMD	• CMD_CTRL:
1	WDT	RWDT	Keter to 8.7.5 Command Control (CMD_CTRL).     CMD STAT:
2	CMD CTRL	CMD STAT	Refer to 8.7.4 Command Status (CMD_STAT).
3	emb_erne	cmp_bm	SVCMD_CTRL: Refer to 8 10 1_Servo Command Control (SVCMD_CTRL)
4			• SVCMD_STAT:
5	SVCMD CTRL	SVCMD STAT	Refer to 8.10.2 Servo Command Status (SVCMD_STAT).
6	STONE_CITE	STORE_STRE	Refer to 8.11 Servo Command I/O Signal (SVCMD_IO).
7			CMD_DATA/RSP_DATA:     Specified for individual commonds
8			specified for individual commands.
9	SVCMD IO	SVCMD IO	
10			
11			
12			
13			
14			
15			
16			
17			
18			
20			
21	CMD_DATA	RSP_DATA	
22			
23			
25			
25			
27			
28			
29			
30			
31			
-			



## 8.10 Command Header Section

Refer to 8.7 *Command Header Section of Main Command Area* for the details of the command header section (command code, watchdog data and command control fields).

## 8.10.1 Servo Command Control (SVCMD\_CTRL)

Byte 4 to byte 7 of the command format are specified as the SVCMD\_CTRL field. The control bit specifies a motion command for a slave station.

The SVCMD\_CTRL field contains auxiliary data for the specified command and the control bits have no meaning with commands other than the command that specified the data.

Note that the designation in this field is valid even when a CMD\_ALM has occurred.

The SVCMD\_CTRL field is specified as shown below by the communication specification.

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0		
Reserv	ved (0)	ACCFIL		STOP_MODE		STOP_MODE		CMD_ CANCEL	CMD_ PAUSE
bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8		
Reserv	ved (0)	LT_S	SEL2	LT_SEL1		LT_REQ2	LT_REQ1		
				•					
bit 23	bit 22	bit 21	bit 20	bit 19	bit 18	bit 17	bit 16		
	SEL_N	MON2		SEL_MON1					
bit 31	bit 30	bit 29	bit 28	bit 27	bit 26	bit 25	bit 24		
Reserved (0)				SEL_	MON3	·			

#### (1) SVCMD\_CTRL Field

(2) Details of Control Bits

The following table shows the details of the control bits.

Bit	Name	Description	Value	Setting	Enabled Timing			
		Pause of Move	0	None				
0	CMD_PAUSE	Command	1	Move command pause command	Level			
	ne POSING, FEED, EX <u>.</u> 10DE.	_FEED, E	EX_POSING, ZRET and VELCT	RL commands				
		Cancellation of	0	None				
1	CMD_CANCEL	Move Command	1	Cancellation of move command	Level			
	Cancels execution of according to STOP_M	the POSING, FEED, EX 10DE.	_FEED,	EX_POSING, ZRET and VELCT	[RL commands			
			0	Stop after deceleration				
	STOP MODE	Selection of Stop	1	Immediate stop	Laval			
2, 3	STOL_WODE	Mode	2	Reserved	Level			
			3	Reserved				
	Selects the stop mode for CMD_PAUSE and CMD_CANCEL.							

Bit	Name	Description	Value	Setting	Enabled Timing				
			0	No position reference filter					
	ACCEII	Selection of Position Reference	1	Exponential function position reference filter	Level				
4, 5	ACCFIL	Filter	2	Movement average position reference filter	Level				
			3	Reserved					
	To be set when specif	To be set when specifying the position reference filter.							
	IT PEO1	Latch Request 1	0	None	Leading adga				
8	LI_KEQI	Laten Request 1	1	Request for latch	Leading edge				
	Requests latch by the	C phase or an external i	nput sign	al.					
	LT REO2	Latch Request 2	0	None	Leading edge				
9	LI_KLQ2	Laten Request 2	1	Request for latch	Leading edge				
	Requests latch by the This can be used as the	C phase or an external i e continuous latch mod	nput sign e as well.	al.					
			0	C phase					
	IT CEL 1	Latah Gianal Calast 1	1	External input signal 1	Leading edge of				
10 11	LI_SELI	Laten Signal Select I	2	External input signal 2	LT_REQ1				
10, 11			3	External input signal 3					
	Selects the C phase or the external input signal for LT_REQ1. Make a setting different from LT_SEL2.								
			0	C phase					
	LT_SEL2	Latch Signal Select 2	1	External input signal 1	Leading edge of LT_REQ2				
			2	External input signal 2					
12, 13			3	External input signal 3					
	Selects the C phase of Make a setting differe When the continuous parameter is used.	the external input signa nt from LT_SEL1. latch mode is selected,	al for LT_ this settin	REQ2. g will be ignored since the signa	l set with the				
16 to 18	SEL_MON1	Monitor Selection 1	0 to 15	Monitor selection	Level				
	Sets the monitor infor	mation.							
19 to 22	SEL_MON2	Monitor Selection 2	0 to 15	Monitor selection	Level				
	Sets the monitor infor	mation.							
23 to 26	SEL_MON3	Monitor Selection 3	0 to 15	Monitor selection	Level				
	Sets the monitor infor	mation.							

# 8.10.2 Servo Command Status (SVCMD\_STAT)

Byte 4 to byte 7 of the response format are specified as the SVCMD\_STAT field. The status bit indicates the status of the slave station.

Note that the designation in this field is valid even when a CMD\_ALM has occurred.

The SVCMD\_STAT field is specified as shown below by the communication specification.

(1)	SVCMD	STAT	Field
· ·			

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0		
Reserv	Reserved (0) ACCFIL Reserved (0)		CMD _CANCEL _CMP	CMD _PAUSE _CMP					
bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8		
Reserv	ved (0)	SV_ON	M_RDY	PON	POS_RDY	L_CMP2	L_CMP1		
bit 23	bit 22	bit 21	bit 20	bit 19	bit 18	bit 17	bit 16		
	SEL_N	MON2			SEL_MON1				
bit 31	bit 30	bit 29	bit 28	bit 27	bit 26	bit 25	bit 24		
Reserved (0)				SEL_N	MON3				

#### (2) Details of Status Bits

The following table shows the details of the status bits.

bit	Name	Description	Value	Setting			
	CMD DALISE CMD	Completion of Pause of Move	0	Incomplete (when pausing commanded)			
0	CWD_IAUSE_CWI	Command	1	Pausing of move command completed			
	The status used to judg ZRET and VELCTRL	ge the completion of pausing of the commands	e POSIN	NG, FEED, EX_FEED, EX_POSING,			
	CMD_CANCEL_	Completion of Cancellation of	0	Incomplete (when cancellation commanded)			
1	СМР	Move Command	1	Cancellation of move command completed			
	The status used to judg ZRET and VELCTRL	ge the completion of cancellation commands	of the PC	DSING, FEED, EX_FEED, EX_POSING,			
			0	No position reference filter			
	ACCFIL	Current Position Reference	1	Exponential function position reference filter			
4, 5		Filter	2	Movement average position reference filter			
			3	Reserved			
	The status used to judg	ge the position reference filter cur	rently be	ing applied			
	L CMP1	Latch Completion 1	0	Latch not completed			
8			1	Latch completed			
	The status used to judg Up until "0" is set for	ge the completion of latching requ LT_REQ1, L_CMP1 is maintaine	ested by d at "1."	LT_REQ1			
	L CMP2	Latch Completion 2	0	Latch not completed			
	L_CIVII 2	Laten Completion 2	1	Latch completed			
9	9 The status used to judge the completion of latching requested by LT_REQ2 Up until "0" is set for LT_REQ2, L_CMP2 is maintained at "1." In the continuous latch mode, L_CMP2 is returned to "0" after one communication cycle after collatching.						



bit	Name	Description	Value	Setting
10	POS_RDY	Position Data Enabled	0	Disabled
			1	Enabled
	The status used to judge if the position data currently being monitored as the monitor information of the response data is valid When an incremental encoder is used: "1" is set on completion of the CONNECT command. When an absolute encoder is used: "1" is set on completion of the SENS_ON command and "0" is set on completion of the SENS_OFF and CONFIG commands. When position data cannot be obtained properly due to an encoder error, "0" is set.			
11	PON	Power ON	0	Power OFF
			1	Power ON
	The status used to judge if the power is turned ON or not			
12	M_RDY	Motor Energization Ready	0	Not ready
			1	Ready
	The status used to judge if the servo can be turned ON or not			
13	SV_ON	Servo ON	0	Servo OFF
			1	Servo ON
	The status used to judge if the motor is energized or not			
16 to 19	SEL_MON1	Monitor Selection 1: Returns what data is being monitored.	0 to 15	Monitor selection
	The status used to judge the data currently being monitored as the monitor information of the response data (Copy of the command) For details, refer to <i>8.12.3 Specifying Monitor Data</i> .			
20 to 23	SEL_MON2	Monitor Selection 2: Returns what data is being monitored.	0 to 15	Monitor selection
	The status used to judge the data currently being monitored as the monitor information of the response data (Copy of the command) For details, refer to 8.12.3 Specifying Monitor Data.			
24 to 27	SEL_MON3	Monitor Selection 3: Returns what data is being monitored.	0 to 15	Monitor selection
	The status used to judge the data currently being monitored as the monitor information of the response data (Copy of the command) For details, refer to 8.12.3 Specifying Monitor Data.			


#### 8.10.3 Supplementary Information on CMD\_PAUSE and CMD\_CANCEL

(1) CMD\_PAUSE (Pausing a Command Operation)

CMD\_PAUSE is used to pause motion command operation. (Motion command processing continues. Motion command operation can be resumed by clearing CMD\_PAUSE.)

CMD\_PAUSE is valid only when the POSING, FEED, EX\_FEED, EX\_POSING, ZRET or VELCTRL command is specified.

[Pausing Procedure]

- 1. The master station sets "1" for STOP\_MODE and CMD\_PAUSE and transmits one of the motion commands given above.
- 2. The slave station stops in accordance with STOP\_MODE. When deceleration to a stop is specified, the slave station decelerates its motion at the deceleration specified in DECR of the command.
- 3. "1" is set for CMD\_PAUSE\_CMP at the slave station when CMD\_PAUSE and ZSPD become "1." Even after stopping, the slave station maintains the previous control mode and DEN remains at "0" (in the position control mode).

[Precautions]

CMD\_PAUSE is disregarded for commands for which CMD\_PAUSE is not valid, and CMD\_PAUSE\_CMP remains OFF.

When using CMD\_PAUSE, execute the relevant motion command continuously until CMD\_PAUSE\_CMP becomes "1."

By setting "0" for CMD\_PAUSE, the pausing operation is canceled and the motion command operation is resumed.





#### (2) CMD\_CANCEL (Canceling a Command Operation)

CMD\_CANCEL is used to interrupt motion command operation. (Motion command processing is cleared.) CMD\_CANCEL is valid only when the POSING, FEED, EX\_FEED, EX\_POSING, ZRET or VELCTRL command is specified.

[Canceling Procedure]

- 1. The master station sets "1" for STOP\_MODE and CMD\_PAUSE and transmits one of the motion commands given above.
- 2. The slave station stops in accordance with STOP\_MODE. When deceleration to a stop is specified, the slave station decelerates its motion at the deceleration specified in DECR of the command.
- 3. "1" is set for CMD\_CANCEL\_CMP at the slave station in the following circumstances. In the position control mode: When CMD\_PAUSE and DEN become "1" In the speed control mode: When CMD\_CANCEL and ZSPD become "1" Even after stopping, the slave station maintains the previous control mode.

[Precautions]

CMD\_CANCEL is disregarded for commands for which CMD\_CANCEL is not valid, and CMD\_CANCEL\_CMP remains OFF.

When CMD\_PAUSE and CMD\_CANCEL are simultaneously turned ON or when CMD\_CANCEL is turned ON after CMD\_PAUSE, CMD\_CANCEL takes priority.

When using CMD\_CANCEL, execute the relevant motion command continuously until CMD\_CANCEL\_CMP becomes "1."

By setting "0" for CMD\_CANCEL, the cancellation operation is canceled and the motion command is processed as a new motion command.







#### 8.10.4 Supplementary Information on Latching Operation

The latch operation is enabled at the leading edge of LT\_REQ1 and LT\_REQ2. The operations to be per- formed when commands are changed after enabling the latch operation are specified in the table below. (The value of LT\_SEL is an example.)

Command before Switching	Command after Switching	Latch Operation
Command without a latch function LT_SEL = 1 LT_REQ = 1	Common commands	Continues the latch request before switching.
Command with a latch function LT_SEL = 1 LT_REQ = 1	Common commands	Interrupts operation as a command with a latch function.
Command without a latch function LT_SEL = 1 LT_REQ = 1	Command without a latch function LT_SEL = 1 LT_REQ = 1	Continues the latch request before switching.
Command without a latch function LT_SEL = 1 LT_REQ = 1	Command without a latch function LT_SEL = 2 LT_REQ = 1	Continues the latch request before switching.
Command without a latch function LT_SEL = 1 LT_REQ = 1	Command with a latch function LT_SEL = 1 LT_REQ = 1	Switches to a latch request for the command after switching. The servo drive executes another latch request. (Internal processing) If the status "L_CMP = 1" is established before command switching, then the status is set to "L_CMP = 0" at command switching.
Command with a latch function LT_SEL = 1 LT_REQ = 1	Command without a latch function LT_SEL = 1 LT_REQ = 1	Switches to a latch request for the command after switching. The servo drive executes another latch request. (Internal processing) If the status "L_CMP = 1" is established before command switching, then the status is set to "L_CMP = 0" at command switching.
Command with a latch function LT_SEL = 1 LT_REQ = 1	Command with a latch function LT_SEL = 1 LT_REQ = 1	Switches to a latch request for the command after switching. The servo drive executes another latch request. (Internal processing) If the status "L_CMP = 1" is established before command switching, then the status is set to "L_CMP = 0" at command switching.

Note 1. Commands with a latch function: EX\_FEED, EX\_POSING, ZRET

### Commands without a latch function: POS\_SET, BRK\_ON, BRK\_OFF, SENS\_ON, SENS\_OFF, SMON, SV\_ON, SV\_OFF, INTERPOLATE, POSING, FEED, VELCTRL, TRQC-TRL, SVPRM\_RD, SVPRM\_WR

 $Common \ commands: \ NOP, ID\_RD, \ CONFIG, \ ALM\_RD, \ ALM\_CLR, \ SYNC\_SET, \ CONNECT, \ and \$ 

DISCONNECT, MEM\_RD, MEM\_WR

2. LT\_SEL: LT\_SEL1 or LT\_SEL2 LT\_REQ: LT\_REQ1 or LT\_REQ2

#### 8.11 Servo Command I/O Signal (SVCMD\_IO)

This section describes the servo command I/O signal monitoring.

#### 8.11.1 Bit Allocation of Servo Command Output Signals

Byte 8 to byte 11 of the command format are specified as the SVCMD\_IO (output) field. The servo command output signals are signals output to the slave station.

Note that the designation in this field is valid even when a CMD\_ALM has occurred.

(1) SVCMD\_IO (Output) Field

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
N_CL	P_CL	P_PPI	V_PPI	Reserved (0)			
bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8
Reserved (0)					G-S	SEL	
bit 23	bit 22	bit 21	bit 20	bit 19	bit 18	bit 17	bit 16
Reserved	SO3	SO2	SO1	BANK_SEL			
bit 31	bit 30	bit 29	bit 28	bit 27	bit 26	bit 25	bit 24
			Reserved (0	))			

(2) Details of Output Signal Bits The following table shows the details of the output signal bits.

bit	Name	Description	Value	Setting	Enabled Timing	
	V PPI	Speed Loop P/PI Control	0	PI control	Level	
4	v_111	Speed Loop 1711 Condon	1	P control	Level	
·	Switches the speed co Used for adjusting the	ntrol from PI control to P control. settling time by suppressing over	ing acceleration.			
	D DDI	Position Loop P/PL Control	0	PI control	Laval	
5	r_rri		1	P control	Level	
5	Switches the position Used for shortening th	control automatically from PI con e settling time by suppressing over	ntrol to P c ershoot du	control. ring positioning mover	nent.	
	P CL	Forward Torque Limit	0	Torque not clamped	Level	
6	I_CL	Torward Torque Emili	1	Torque clamped	Level	
	Used to select whether (common parameter 8	r the forward torque is clamped or C).	r not accor	rding to the forward tor	que limit	
	N CI	Reverse Torque Limit	0	Torque not clamped	Level	
7	N_CL		1	Torque clamped		
	Used to select whether the reverse torque is clamped or not according to the reverse torque limit (common parameter 8D).					
	G_SEL	Gain Select	0	First gain		
			1	Second gain	Level	
			2 to 15	Reserved (Do not set.)		
8 10 11	Used to select the position loop gain, speed loop gain and other settings as desired according to the G_SEL value. 0: First gain 1: Second gain 2 to 15: Reserved (Do not set.)					
			0	Bank 0		
	RANK SEI		1	Bank 1	- Level	
16 to 19	DAINK_SEL	Dalik Sciector	:	:		
			F	Bank F		
	High-speed acceleration	on/deceleration parameter (bank s	witching)	function	<u>.                                    </u>	
	SO1 (+ SO2		0	Signal OFF	T1	
	SOI to SO3	1/O Signal Output Command	1	Signal ON	Level	
20 to 22	Turns ON/OFF the signal output for I/O signal outputs (SO1 to SO3).         [Important]         The OUT_SIGNAL operation is disabled when other output signals are allocated at the same time to parameters Pn50E, Pn50F and Pn510. To use OUT_SIGNAL, set all of parameters Pn50E, Pn50F an Pn510 to "0."				ame time to E, Pn50F and	

#### 8.11.2 Bit Allocation of Servo Command I/O Signal Monitoring

Byte 8 to byte 11 of the response format are specified as the SVCMD\_IO (I/O signal) field. Note that the designation in this field is valid even when a CMD\_ALM has occurred.

bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
ESTP	EXT3	EXT2	EXT1	N-OT	P-OT	DEC	Reserved (0)
bit 15	bit 14	bit 13	bit 12	bit 11	bit 10	bit 9	bit 8
ZPOINT	PSET	NEAR	DEN	N-SOT	P-SOT	BRK_ON	Reserved (0)
bit 23	bit 22	bit 21	bit 20	bit 19	bit 18	bit 17	bit 16
	Reserv	ved (0)		ZSPD	V_CMP	V_LIM	T_LIM
bit 31	bit 30	bit 29	bit 28	bit 27	bit 26	bit 25	bit 24
IO_STS8	IO_STS7	IO_STS6	IO_STS5	IO_STS4	IO_STS3	IO_STS2	IO_STS1

(1) SVCMD\_IO (I/O Signal) Field

#### (2) Details of I/O Signal Bits

The following table shows the details of the I/O signal bits.

Bit	Name	Description	Value	Setting		
	DFC	Zero Return Deceleration	0	OFF		
1	DLC	Limit Switch Input	1	ON		
	The status used to judg	ge the state of the deceleration	limit swit	ch used for zero point return operation		
	РОТ	Forward Drive Prohibition	0	OFF		
	1_01	Input	1	ON		
2	Overtravel (OT) is a fu	nction that forcibly stops a mo	vable mac	chine unit if it moves beyond its range		
	P_OT is the status used The OT stop judgment	d to judge if the movable mach is made based on ZSPD.	ine unit is	in the forward drive prohibited state.		
	N OT	Reverse Drive Prohibition	0	OFF		
	N_01	Input	1	ON		
3	<ul> <li>Overtravel (OT) is a function that forcibly stops a movable machine unit if it moves beyond its range of movement.</li> <li>N_OT is the status used to judge if the movable machine unit is in the reverse drive prohibited state. The OT stop judgment is made based on ZSPD.</li> </ul>					
	EXT1	External Latch 1 Input	0	OFF		
4			1	ON		
	The status used to judge the state of the external latch 1 input signal					
	EVT2	External Latah 2 Input	0	OFF		
5	EATZ	External Laten 2 mput	1	ON		
	The status used to judge the state of the external latch 2 input signal					
	EXT3	External Latch 3 Input	0	OFF		
6	LAIS	External Eaten 5 mput	1	ON		
	The status used to judg	ge the state of the external later	n 3 input s	ignal		
	ESTP	Emergency Stop	0	OFF		
7	(HWBB)	Emergency stop	1	ON		
	When the HWBB1 or HWBB2 signal is input, the power to the motor is shut down forcibly and the motor stops according to the setting of the 1st digit of parameter Pn001.					

Bit	Name	Description	Value	Setting	
	BRK ON	Lock Application Output	0	Lock released	
0	BICK_ON	Lock Application Output	1	Lock applied	
9	The holding lock is used in applications where the servo driver controls the vertical axis. This is the status used to judge the state of the holding lock control signal (/BK). Note that the logi the inverse of that of the hardware output (/BK).				
			0	Range of motion	
	P_SOT	Forward Software Limit	1	Drive prohibited due to forward soft- ware limit	
10	The software limit for in the same manner a signals). This is the status used (common parameter 24	cibly stops a movable machine s the overtravel function, with to judge if the movable machin 6).	e unit if it h or witho he unit is i	moves beyond the software limit range out using P_OT and N_OT (overtravel n the Forward Software Limit state	
			0	Range of motion	
	N_SOT	Reverse Software Limit	1	Drive prohibited due to reverse soft- ware limit	
11	The software limit for in the same manner a signals). This is the status used (common parameter 2)	cibly stops a movable machine s the overtravel function, with to judge if the movable machine 8).	e unit if it h or with he unit is i	moves beyond the software limit range out using P_OT and N_OT (overtravel n the Reverse Software Limit state	
	(	Distribution Completed	0	During distribution	
12	DEN	(Position Control Mode)	1	Distribution completed	
12	12 The status used to judge if the position reference from the servo drive has been completed This bit is valid only in the position control mode.				
	NEAR	Near Position (Position Control Mode)	0	Outside the near-position range	
12			1	Within the near-position range	
13	The status used to judge if the current position is within the range of the NEAR Signal Width (common parameter: 67) This bit is valid only in modes other than the position control mode.				
	PSET	Positioning Completed (Position Control Mode)	0	Outside the positioning completion range	
			1	Within the positioning completion range	
14	The status used to judge if the current position is within the range of the Positioning Completed Width (common parameter: 66) This bit is valid only in the position control mode. Refer to 8.24 Notes when the Positioning Completed State (PSET = 1) is Established while Canceling a Motion Command.				
	<b>ZPOINT</b>	Zero Point	0	Outside the zero point position range	
15			1	Within the zero point position range	
	The status used to judg (common parameter: 8	ge if the current position is with (B)	in the ran	ge of the Origin Detection Range	
	T LIM	Torque Limit	0	Not in the torque limited state	
16			1	In the torque limited state	
	The status to judge if t	he torque is clamped at the For	ward Toq	ue Limit or the Reverse Toque Limit	
	V_LIM	Speed Limit	0	Speed limit not detected	
17		(Torque Control Mode)	1	Speed limit detected	
	The state to judge if the speed is clamped at the limit value specified in the command or parameter This bit is valid only in the torque control mode.				

Bit	Name	Description	Value	Setting	
	V CMP	Speed Match	0	Speed not matched	
10	v_civii	(Speed Control Mode)	1	Speed match	
18	The status used to judge if the speed is within the Speed Match Signal Detection Range (comm parameter: 8F) This bit is valid only in the speed control mode.				
19	ZSPD	Zero Speed	0	Zero speed not detected	
			1	Zero speed detected	
	The status used to judge if the current speed is within the Zero Speed Detection Range (common parameter: 8E)				
24 to 31	IO_STS1 to	I/O Signal Monitor	0	Signal OFF	
	IO_STS8	i o bighur Wollitor	1	Signal ON	
	The status used to indicate the I/O signal state of CN1 Allocate the input signals using parameters Pn860 to Pn866, Pn868, and Pn869.				

#### 8.12 Command Data

This section describes the servo-specific data used with servo commands.

#### 8.12.1 Data Order

Data in commands and responses is stored in little endian byte order.

For example, 4-byte data "0x1234ABCD" in hexadecimal is stored from the least significant byte as shown below.

Byte	Data
1	CD
2	AB
3	34
4	12

#### 8.12.2 Specifying Units

The units for the user command and parameter data can be selected.

The system of units is set in the common parameters. For the details on the common parameters, refer to 8.27 *Common Parameters*.

#### (1) Speed

The following units can be selected.

Settings are made with common parameters 41 and 42.

Unit	Remark
Reference unit/s (default)	$\times 10^{n}$ [reference unit/s] can be set.
Reference unit/min	$\times 10^{n}$ [reference unit/min] can be set.
"%" of rated speed	$\times 10^{n}$ [%] can be set.
min <sup>-1</sup> (rpm)	$\times 10^{n}  [min^{-1}]$ can be set.
Max. motor speed/40000000 (Hex.)	Set "0" for common parameter 42.

#### (2) Position

The following units can be selected.

Settings are made with common parameters 43 and 44.

Unit	Remark
Reference unit (default)	[Reference unit] Fixed Set "0" for common parameter 44.

#### (3) Acceleration

The following units can be selected.

Settings are made with common parameters 45 and 46.

Unit	Remark
Reference unit/s <sup>2</sup> (default)	$\times 10^{n}$ [reference unit/s <sup>2</sup> ] can be set.

(4) Torque

The following units can be selected. Settings are made with common parameters 47 and 48.

Unit	Remark
% of rated torque (default)	$\times 10^{n}$ [%] can be set.
Max. torque/40000000 (Hex.)	Set "0" for common parameter 48.



#### 8.12.3 Specifying Monitor Data

The master station sets the selection code of the monitor data to be read from a slave station at monitor selection bits SEL\_MON1 to 3 in the servo command control field (SVCMD\_CTRL) and at monitor selection bits SEL\_MON4 to 6 in the subcommand control field (SUB\_CTRL). The slave station sets the specified monitor selection code and the monitor data in the response.

Selection Code	Monitor Name	Description	Remark
0	APOS	Feedback Position	
1	CPOS	Command Position	
2	PERR	Position Error	
3	LPOS1	Latched Position 1	
4	LPOS2	Latched Position 2	
5	FSPD	Feedback Speed	
6	CSPD	Reference Speed	
7	TRQ	Reference Torque (Force)	
8	ALARM	Detailed Information on the Current Alarm	When an alarm has occurred after the occurrence of a warning, the information on the alarm is displayed.
9	MPOS	Command Position	Input reference position in a position control loop MPOS = APOS + PERR
А	-	Reserved	
В	-	Reserved	
С	CMN1	Common Monitor 1	Selects the monitor data specified at common parameter 89.
D	CMN2	Common Monitor 2	Selects the monitor data specified at common parameter 8A.
Е	OMN1	Optional Monitor 1	Selects the monitor data specified at parameter Pn824.
F	OMN2	Optional Monitor 2	Selects the monitor data specified at parameter Pn825.

The following table lists the monitor data.

#### 8.12.4 Position Data

Servo commands use 4-byte data as position data. For infinite length operation, position data beyond this limit are expressed as shown in the diagram below.



#### 8.13 Common Commands

#### 8.13.1 Common Commands

The table below shows the common commands.

Profile	Command Code (Hex.)	Command	Operation	Compliance <sup>*1</sup>
	00	NOP	No operation	0
	01	PRM_RD	Read parameter	×*2
	02	PRM_WR	Write parameter	×*2
	03	ID_RD	Read ID	0
	04	CONFIG	Device setup request	Δ
	05	ALM_RD	Read alarm/warning	0
Common	06	ALM_CLR	Clear alarm/warning state	0
Commands	0D	SYNC_SET	Request for establishing synchronization	0
	0E	CONNECT	Request for establishing connection	0
	0F	DISCONNECT	Request for releasing connection	0
	1B	PPRM_RD	Read retentive parameter	×*2
	1C	PPRM_WR	Write retentive parameter	×*2
-	1D	MEM_RD	Read memory	Δ
	1E	MEM_WR	Write memory	Δ

\*1. Indicates the compliance status.

o: Possible

 $\Delta$ : Possible with specification restrictions (Refer to the subsection describing each command for the details of the restrictions.)

 $\times$  : Not possible

\*2. The standard servo profile does not use PRM\_RD, PRM\_WR, PPRM\_RD and PPRM\_WR, but uses SVPRM\_RD and SVPRM\_WR instead.

# 8.13.2 No Operation Command (NOP: 00H)

#### Data Format

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command				
Pro	cessing Time	Within communication cycle	Subcommand	Can b	e used				
Puto	NC	OP		Description					
Буге	Command	Response	Description						
0	00H	00H	The NOP command	l is used for network c	ontrol.				
1	WDT	RWDT	• The current state is	returned as a response $D = NOP (-00H)$ and	<b>.</b>				
2	CMD CTRI	CMD STAT	CMD_STAT.CMD	RDY = 1.					
3	CMD_CIKL	CMD_STAT							
4									
5									
6									
7									
8									
9									
10									
11									
12									
13									
14									
15									
16									
17	Pasarvad	Pasarvad							
18	Reserved	Reserved							
19									
20									
21									
22									
23									
24									
25									
26									
27									
28									
29									
30									
31									

Phases in which the Command can be Executed		2, 3	Command Classification	Common command	Asynchronous command			
Pro	cessing Time	Within communication cycle	Subcommand Can be used					
Buto	ID_	RD		Description				
Byte	Command	Response		Description				
0	03H	03H	• The ID_RD comma	and reads the ID of a de	evice. This command			
1	WDT	RWDT	<ul> <li>reads the product if</li> <li>The ID data is selected.</li> </ul>	itormation as ID data.	ving ID CODE			
2	CMD CTPI	CMD STAT	Confirm the complete	etion of the command	execution by			
3	CMD_CIKL	CMD_STAT	checking that RCM	$ID = ID_RD (= 03H) a$	ind solving the setting for			
4	ID_CODE	ID_CODE	ID_CODE, OFFSE	CT and SIZE.	seeking the setting for			
5	OFFSET	OFFSET		1 11 1				
6	SIZE	SIZE	In the following cases response in those cases	s, an alarm will occur. I	e will be indefinite.			
7	SIZE	SIZE	• When the ID_COD	E data is invalid:				
8			• When the OFFSET	(A.94A) data is invalid or the 9	SIZE data do not			
9			match: CMD_ALM	1 = 9H (A.94D)				
10			If the OFFSET or SIZE data is invalid for the specified ID_CODE, an alarm occurs. Example: Setting OFFSET = 3 and SIZE = 4 for reading t device version (4-byte data) specifies reading o data outside the device version data (4 bytes) an generates an alarm.					
11								
12								
13								
14								
15								
16								
17								
18								
19	Pasarvad	ID						
20	Reserved	ID						
21								
22								
23								
24								
25								
26								
27								
28								
29								
30								
31								

# 8.13.3 Read ID Command (ID\_RD: 03H) (1) Data Format

ID\_CODE: ID data selection code OFFSET: ID read offset SIZE: Read data size [bytes]

The following tables describe details of the ID\_CODE.

ID_CODE	De	scription		Data Siz	e	Data Type		Compliance	
	Vendor ID Cod	e		4 bytes		Binar	y Data		0
01H	00000000H An ID code u Members As	used to spec sociation.	ify the ven	dor. Vendor I	D coo	des are	managed by	the MECH	IATROLINK
	Device Code			4 bytes		Binar	y Data		o
02H	02200000H (LE This is a code	02200000H (LECY series DRIVERs). This is a code specific to each device.							
	Device Version			4 bytes		Binar	y Data		o
03H	Returns the firm Version infor	Returns the firmware version of this product. Example: 00160000H Version information of device							
	Device Informa	ation File Ve	ersion	4 bytes		Binar	y Data		0
04H	This is the ve	ersion inform	nation of th	ne device info	ormat	ion (M	DI) file supp	oorted by th	is product.
	bit7	bit6	bit5	bit4	b	oit3	bit2	bit1	bit0
			•	Revisi	on N	0.			
	bit15	bit14	bit13	bit12	bi	it11	bit10	bit9	bit8
		Major	version				Minor	version	
	Revision No. Bit 16 to 31: Extended Addr	Function Normally Reserved (	changes. y returns "( 0)	)."		D.			
	(for Future Use	e)		4 bytes		Binary Data			o
05H	1 This is the number of extended addresses used. The value is always "1" because this product comprises a single axis.								
06H	Serial No.			32 bytes		ASCI (Delin	I Code miter: 00)		o
	Serial numbe	er specific to	o each devi	ce					
	Profile Type 1 (	(Primary)		4 bytes		Binar	y Data		0
10H	<ul> <li>00000010H (Standard servo profile)</li> <li>Profile type (primary) that the device supports</li> <li>This product supports the following two profile types.</li> <li>(1) Profile type 1: Servo profile (this ID_CODE)</li> <li>(2) Profile type 2: MECHATROLINK-II compatible profile (12H)</li> <li>(3) Profile type 3: None (14H)</li> </ul>								
	Profile Version	1 (Primary	)	4 bytes		Binar	y Data		0
11H	00000030H Profile versio	on (primary)	) that the de	evice supports	5.	1			1
1011	Profile Type 2			4 bytes		Binar	y Data		0
1211	0000000H (M	ECHATRO	LINK-II c	ompatible pro	ofile)				



ID_CODE	De	escription		Data Siz	ze		Data Ty	ре	Compliance
1211	Profile Version	2		4 bytes		Binar	y Data		0
1311	00000021H								
144	Profile Type 3			4 bytes		Binar	y Data		0
1411	000000FFH (N	ot supporte	d code)						
15H	Profile Version	3		4 bytes		Binar	y Data		0
1511	00000000H								
	Minimum Valu Cycle	e of Transm	ission	4 bytes		Binar	y Data		o
16H	12500 [0.01 µs The minimum transmission	unit] (0.12: n transmiss cycle incre	5 ms) ion cycle th ment (18H)	at the device	e can s	upport	in the gran	ularity level	of the
	Maximum Value of Transı Cycle			4 bytes		Binar	y Data		o
17H	400000 [0.01 µs unit] (4 ms) The maximum transmission cycle that the device can support in the granularity level of transmission cycle increment (18H)						l of the		
	Transmission Cycle Increment (Granularity)4 bytesBinary Data						Q		
18H	00000003H There are the following four levels of transmission cycle increment that the device supports. This product supports level 03H. 00H: 31.25, 62.5, 125, 250, 500 (µsec), 2 to 64 (msec) (2 msec increment) 01H: 31.25, 62.5, 125, 250, 500 (µsec), 1 to 64 (msec) (1 msec increment) 02H: 31.25, 62.5, 125, 250, 500 (µsec), 1 to 64 (msec) (0.5 msec increment) 03H: 31.25, 62.5, 125, 250, 500, 750 (µsec), 1 to 64 (msec) (0.5 msec increment)							upports.	
19H	Minimum Value of Communication Cycle     4 bytes     Binary Data       25000 [0 01 us unit] (0 25 ms)					o			
	The minimu	m communi	cation cycle	e that the dev	vice su	pports	ł		
1 <b>4</b> H	Maximum Valu Cycle	e of Comm	unication	4 bytes		Binar	y Data		o
IAII	3200000 [0.01 The maximu	µs unit] (32 m commun	ms) ication cycl	e that the de	vice su	apports	5		
	Number of Tra	nsmission E	Bytes	4 bytes		Binar	y Data		0
1511	0000000EH The number The numbers supported: 0	of transmiss s of bytes to )	sion bytes t be transmit	hat the devic ted are alloc	e supp ated to	oorts o the fo	ollowing bit	s. (Supporte	ed: 1, Not
IBH	bit7	bit6	bit5	bit4	bi	it3	bit2	bit1	bit0
	Reserved	Reserved	Reserved	64 bytes	481	oytes	32 bytes	16 bytes	8 bytes
	0	0	0	0		1	1	1	0
	bit 5 to 63: R	Reserved (0)							
	Number of Tran (Current Setting	nsmission B g)	ytes	4 bytes		Binar	y Data		o
1CH	0000000xH The number indicated by The numbers	of transmiss "–" will be s of bytes to	sion bytes t set to "1." be transmi	hat is curren	tly set	with I o the fe	DIP switch (	S3). One of	the bits
	bit7	bit6	bit5	bit4	bi	it3	bit2	bit1	bit0
	Reserved	Reserved	Reserved	64 bytes	481	oytes	32 bytes	16 bytes	8 bytes
	0	0	0	0		-	-	-	0
	bit 5 to 63: R	eserved (0)		•	•		•	•	+



ID_CODE		Description		Data Si	ze	Data Type			Compliance
1DH	Profile Type	(Current Sel	ection)	4 bytes	B	inary	y Data		o
IDII	This is the	e profile selec	cted with the	CONNECT	comman	d.			
	Supported Communication Mode         4 bytes         Binary Data								0
20H	00000002H The comm The comm bit 1: Cyc	(Cyclic compunication monication monicati monication monication monication monication mo	munication) ode that the o odes are allo cation	levice suppo cated to the f	rts following	g bits	s. (Supported	: 1, Not sup	ported: 0)
21H	MAC Addre	SS							
	Not supporte	ed		-					
	List of Supp	orted Main C	Commands	32 bytes	A	rray			0
	The commands are allocated as shown below. bit 0 to 255: 0: Command not supported 1: Command supported								
	bit7	bit6	bit5	bit4	bit3		bit2	bit1	bit0
	Reserved (0)	ALM_ CLR	ALM_ RD	CONFIG	ID_R	D	PRM_ WR	PRM_RD	NOP
	0	1	1	1	1		0	0	1
	bit15	bit14	bit13	bit12	bit11		bit10	bit9	bit8
	DISCON-	CON-	SYNC	Reserved	Reserv	red	Reserved	Reserved	Reserved
	NECT	NECT	SET	(0)	(0)		(0)	(0)	(0)
	1	1	1	0	0		0	0	0
	bit 16 to 2	3: Reserved	(0)	1.000	1.00	7	1:00	1:05	1:04
	bit31	bit30	bit29	bit28	bit2	/	bit20	bit25	bit24
	(0)	WR	RD	WR	RD	<u>a</u>	(0)	(0)	(0)
	0	1	1	0	0		0	0	0
30H	bit39	bit38	bit37	bit36	bit3	5	bit34	bit33	bit32
	Reserved (0)	Reserved (0)	Reserved (0)	SENS_ OFF	SENS ON	S_ I	BRK_ OFF	BRK_ON	POS_ SET
	0	0	0	1	1		1	1	1
	bit 40 to 4	7: Reserved	(0)	•				•	
	bit55	bit54	bit53	bit52	bit51	L	bit50	bit49	bit48
	EX_ FEED	FEED	POSING	INTER- POLATE	Reserv (0)	red	SV_OFF	SV_ON	SMON
	1	1	1	1	0		1	1	1
	bit63	bit62	bit61	bit60	bit50	)	bit58	bit57	bit56
	Reserved	Reserved	TROCTRL	VELCTRL	Reserv	red	ZRET	EX_	Reserved
	(0)	(0)	1	1	(0)		1	POSING	(0)
	0	U	1	1	U		1	1	U
	bit71	bit70	bit69	bit68	bit67	7	bit66	bit65	bit64
	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserv (0)	ed	Reserved (0)	SVPRM_ WR	SVPRM_ RD
	0	0	0	0	0		0	1	1
	bit 72 to 2	55: Reserved	d (0)						



ID_CODE	D	escription		Data S	Size	Data Type			Compliance		
	List of Suppor	ted Subcom	mands	32 bytes		Arra	у		0		
	The list of the The comma	The list of the subcommands that the device supports The commands are allocated as shown below.									
	bit 0 to 255:	bit 0 to 255: 0: Command not supported 1: Command supported									
	bit7	bit6	bit5	bit4	bit3		bit2	bit1	bit0		
	Reserved (0)	ALM_ CLR	ALM_ RD	Reserved (0)	Reserv (0)	red	PRM_ WR	PRM_RD	NOP		
	0	1	1	0	0		0	0	1		
	bit 8 to 23: 1	Reserved (0	)								
	bit31	bit30	bit29	bit28	bit.	27	bit26	bit25	bit24		
2911	Reserved (0)	MEM_ WR	MEM_ RD	PPRM_ WR	PPR RI	M_ D	Reserved (0)	Reserve (0)	d Reserved (0)		
361	0	1	1	0	0	)	0	0	0		
	bit 32 to 47: Reserved (0)										
	bit55	bit54	bit53	bit52	bit	51	bit50	bit49	bit48		
	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Rese (0	rved ))	Reserved (0)	Reserve (0)	d SMON		
	0	0	0	0	0	)	0	0	1		
	bit 56 to 63: Reserved (0)										
	bit71	bit70	bit69	bit68	bit	67	bit66	bit65	bit64		
	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0	rved ))	Reserved (0)	SVPRM WR	_ SVPRM_ RD		
	0	0	0	0	0	)	0	1	1		
	bit 72 to 255	5: Reserved	(0)								
	List of Suppor Parameters	ted Commo	n	32 bytes		Arra	у		0		
	The list of the	ne common n parameter	parameter i	numbers that	t the dev	vice s	upports				
		n parameter			in below						
	bit 0 to 255:	0: Comm 1: Comm	ion parame	ter not supp ter supporte	orted d						
4011	bit7	bit6	bit5	bit4	bit3		bit2	bit1	bit0		
40H	07	06	05	04	03		02	01	Reserved (0)		
	1	1	1	1	1		1	1	0		
	bit15	bit14	bit13	bit12	bit11	1	bit10	bit9	bit8		
	Reserved (0)	Reserved (0)	Reserved (0)	0C	0B		0A	09	08		
	0	0	0	1	1		1	1	1		

ID_CODE		Des	cription		Data Siz	ze Data Type			Compliance
	bit 16	to 31: R	eserved (0)	-					
	1	bit39	bit38	bit37	bit36	bit35	bit34	bit33	bit32
		27	26	25	24	23	22	21	Reserved (0)
		1	1	1	1	1	1	1	0
	1	bit47	bit46	bit45	bit44	bit43	bit42	bit41	bit40
	Re	eserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	29	28
		0	0	0	0	0	0	1	1
	bit 48	to 63: R	eserved (0)						
	1	bit71	bit70	bit69	bit68	bit67	bit66	bit65	bit64
		47	46	45	44	43	42	41	Reserved (0)
		1	1	1	1	1	1	1	0
	1	bit79	bit78	bit77	bit76	bit75	bit74	bit73	bit72
	Re	eserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	Reserved (0)	49	48
		0	0	0	0	0	0	1	1
	bit 80	to 95: R	eserved (0)		1				
	b	oit103	bit102	bit101	bit100	bit99	bit98	bit97	bit96
40H (Continued)		67	66	65	64	63	62	61	Reserved (0)
		1	1	1	1	1	1	1	0
	b	oit111	bit110	bit109	bit108	bit107	bit106	bit105	bit104
	Re	eserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved
		(0)	(0)	(0)	(0)	(0)	(0)	(0)	(0)
	bit 11	2 to 127	Decorrect	<u>v</u>	V	0	v	0	V
	bit 11.	2 to 127.	hit134	0) bit133	bit132	bit131	bit130	hit120	bit128
		87	86	85	84	83	82	81	Reserved
		1	1	1	1	1	1	1	0
	h	nit143	bit142	bit141	bit140	bit130	bit138	bit137	bit136
		8F	8E	8D	8C	8B	8A	89	88
		1	1	1	1	1	1	1	1
	b	oit151	bit150	bit149	bit148	bit147	bit146	bit145	bit144
	Re	eserved	Reserved	Reserved (0)	Reserved (0)	93	92	91	90
		0	0	0	0	1	1	1	1
	bit 152	2 to 255	Reserved	(0)					
	Main De	evice Na	me		32 bytes	ASC (Deli	II Code miter: 00)		0
80H	Product The m <noti To juc Refer</noti 	model nain devi ce> lge the d to <i>before</i>	Example: ce name (A evice with <i>e</i> for the co	SGDV-1R SCII code the host de rresponden	6A21A ) vice, use the ice of device	device cod name and I	e (02H) inst LECY's mo	ead of this I del.	ID_CODE.

ID_CODE	Description	Data Size	Data Type	Compliance				
00H	Sub Device 1 Name	32 bytes	ASCII Code (Delimiter: 00)	0				
9011	Motor model Example: SGMJV-01 The name of sub device 1 (ASCII c Refer to <i>before</i> for the correspondence	ADA21 ode) e of device name a	and LECY's model.					
	Sub Device 1 Version	4 bytes	Binary Data	0				
98H	Firmware version of the motor encode The version number of sub device 1	Er Example: 00	000001H					
A0H	Sub Device 2 Name	32 bytes	ASCII Code (Delimiter: 00)	0				
11011	External encoder model Example: The name of sub device 2 (ASCII c	ode)						
	Sub Device 2 Version	4 bytes	Binary Data	0				
A8H	The software version of the external e The version number of sub device 2	encoder Examp	le: 0000001H					
B0H	Sub Device 3 Name	32 bytes	ASCII Code (Delimiter: 00)	0				
Don	Not supported: NULL The name of sub device 3 (ASCII code)							
	Sub Device 3 Version	4 bytes	Binary Data	0				
B8H	Not supported: 0000000H The version number of sub device 3							
BCH to BFH	Reserved		r					
С0Н	Sub Device 4 Name	32 bytes	ASCII Code (Delimiter: 00)	0				
	The safety option module model The name of sub device 4 (ASCII code)							
	Sub Device 4 Version	4 bytes	Binary Data	0				
С8Н	The software version of the safety opt The version number of sub device 4	ion module Ex 1	ample: 00000001H					
D0H	Sub Device 5 Name	32 bytes	ASCII Code (Delimiter: 00)	0				
Don	The feedback option module model The name of sub device 5 (ASCII code)							
	Sub Device 5 Version	4 bytes	Binary Data	0				
D8H	The software version of the feedback The version number of sub device 5	option module	Example: 00000001H					
F0H	Sub Device 6 Name	32 bytes	ASCII Code (Delimiter: 00)	0				
2011	Reserved The name of sub device 6 (ASCII c	ode)						
	Sub Device 6 Version	4 bytes	Binary Data	0				
E8H	Reserved The version number of sub device 6	5						

Note: The ID\_CODE values of C0H and above are the vendor-specific area.

# 8.13.4 Setup Device Command (CONFIG: 04H)

#### (1) Data Format

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command					
Pro	cessing Time	Refer to the specifications of CONFIG_MOD.	Subcommand	Cannot	be used					
Duta	CON	NFIG	Description							
Вује	Command	Response		Description						
0	04H	04H	The CONFIG comm	and sets up devices.						
1	WDT	RWDT	Confirm the comple checking that RCMI	tion of the command $c = CONFIG (= 0.4H)$	execution by					
2	CMD CTDI	CMD STAT	CMD_STAT.CMDR	DY = 1, and also che	cking the setting for					
3	CMD_CTKL	CMD_STAT	CONFIG_MOD.							
4	CONFIG_MOD	CONFIG_MOD	Indefinite until the c	ompletion of the com	mand					
5				1	1.4 1					
6			will not be executed.	an alarm will occur a	ind the command					
7			• When the CONFIG	MOD data is invalid:						
8			• While in the servo C	A.94B) N state:						
9			$CMD_ALM = AH($	$CMD_ALM = AH (A.95A) (In MECHATROLINK-II)$						
10			communications, the	stablished and the						
11			While editing using	ALM = AH (A.95A)						
12										
13										
14										
15										
16										
17										
18	Reserved	Reserved								
19										
20										
21										
22										
23										
24										
25										
26										
27										
28										
29										
30										
31										

- CONFIG\_MOD: Configuration mode
- 0: Parameter re-calculation and setup, processing time: 5 seconds or less
- 1: Not supported (CMD\_ALM = 9H(A.94B))
- 2: Initialization to the factory-set parameter setting values, processing time: 20 seconds or less Turn the power OFF after completion of the process and turn it back ON.
- (3) State of Each Status during CONFIG Command Execution

The following tables show the state of each status before, during and after CONFIG command processing.

- When Re-calculating and Setting up the Parameters

Status and Output Signal	Before CONFIG Processing	During CONFIG Processing	After CONFIG Processing
ALM	Current state	Current state	Current state
CMDRDY	1	0	1
M_RDY	Current state	Indefinite	Current state
Other Statuses	Current state	Indefinite	Current state
ALM (CN1 Output Signal)	Current state	Current state	Current state
/S-RDY (CN1 Output Signal)	Current state	OFF	Current state
Other Output Signals	Current state	Indefinite	Current state

- When Initializing to the Factory-set Parameter Settings

Status and Output Signal	Before CONFIG Processing	During CONFIG Processing	After CONFIG Processing
ALM	Current state	Current state	Current state
CMDRDY	1	0	1
M_RDY	Current state	0	0
Other Statuses	Current state	Indefinite	Current state
ALM (CN1 Output Signal)	Current state	Current state	Current state
/S-RDY (CN1 Output Signal)	Current state	OFF	OFF
Other Output Signals	Current state	Indefinite	Current state

# 8.13.5 Read Alarm or Warning Command (ALM\_RD: 05H)

(1) Data Format

Dhee	os in which the		Command	Common	Agunahranaua		
Command can be Executed		2, 3	Classification	command	command		
Pro	cessing Time	Refer to the specifications of ALM_RD_MOD	Subcommand Cannot be used				
ALM_		_RD	Description				
Byte	Command	Response	Description				
0	05H	05H	• The ALM_RD com	nmand reads the alarm	or warning state.		
1	WDT	RWDT	The current alarm of the complexity of the	or warning state is read	to ALM_DATA.		
2	CMD CTPI	CMD STAT	checking that RCM	$ID = ALM_RD (= 05H)$	H) and		
3	CMD_CTRL	CMD_STAT	CMD_STAT.CMD	RDY = 1, and also che nd ALM_INDEX	ecking the setting for		
4	ALM PD MOD	ALM PD MOD					
5	ALM_KD_MOD	ALM_KD_MOD	In the following cases, an alarm will occur. Do not read				
6	ALM INDEX	ALM INDEX	ALM_DATA in the response in these cases because the ALM_DATA value will be indefinite.				
7	ALM_INDEX	ALM_INDEX	• When the ALM_RD_MOD data is invalid:				
8			• When the ALM IN	(A.94B) IDEX data is invalid:			
9			$CMD_ALM = \overline{9H}$	(A.94B)			
10							
11							
12	]						
13							
14							
15							
16							
17							
18							
19	Reserved	AIM DATA					
20	i coor vou						
21							
22							
23							
24							
25							
26							
27							
28							
29							
30							
31							

Note 1. ALM\_DATA specifies an alarm using 2 bytes.

2. The alarm history arranges alarms in the order of occurrence starting from the latest alarm.

3. 0000H is set in the normal state.



#### The details of ALM\_RD\_MOD are described below.

ALM_RD_MOD	Description	Processing Time
0	Current alarm/warning state Max. 10 items (byte 8 to 27) (00H is set for the remaining bytes (byte 28 to 31).)	Within communication cycle
1	Alarm occurrence status history (Warnings are not retained in the history.) Max. 10 items (byte 8 to 27) (00H is set for the remaining bytes (byte 28 to 31).)	Within 60 ms

For LECY series DRIVERs, alarm codes are defined as 2-byte data with the following configuration.

	Bit 15 to 12	Bit 11 to 0
	0	Alarm code
Example: A.94B	0H	94BH



Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command		
Processing Time Refi		Refer to the specifications of ALM_CLR_MOD.	Subcommand Cannot be used				
Byte	ALM	CLR	Description				
Dyte	Command	Response		Description			
0	06H	06H	• The ALM_CLR command clears the alarm or warning state. I				
1	WDT	RWDT	cause of the alarm	or warning. ALM CL	R should be used to		
2	CMD CTRL	CMD STAT	clear the state after	the cause of the $a\overline{larm}$	or warning has been		
3	ewib_erike	CNID_51/M	<ul><li>When a communica</li></ul>	ation error (reception e	rror) or synchronous		
4	ALM CLR MOD	ALM CLR MOD	communication err	or (watchdog data erro	or) occurs during		
5	MEM_CER_MOD	MEM_CER_WOD	must be recovered	by using the SYNC S	ET communication		
6			the ALM_CLR cor	nmand has been execu	ted.		
7			• Confirm the completion of the command execution by checking that RCMD = ALM_CLR (= 06H) and				
8			$CMD_STAT.CMDRDY = 1$ , and also checking the se				
9			ALM_CLK_MOD				
10			In the following cases	s, an alarm will occur a	and the command		
11			• When the AI M C	R MOD data is inva	lid		
12			$CMD_ALM = 9H (A.94B)$				
13			While editing using	g SigmaWin+: CMD_A	ALM = AH (A.95A)		
14			Use this command wi	th CMD CTRL.ALM	CLR set to "0."		
15				_	-		
16							
17							
18	Reserved	Reserved					
20							
21							
22							
23							
24							
25							
26							
27							
28							
29							
30							
31							

# 8.13.6 Clear Alarm or Warning Command (ALM\_CLR: 06H)

(1) Data Format

(2) Command Parameters

The details of ALM\_CLR\_MOD are described below.

ALM_CLR_MOD	Description	Processing Time
0	Clearance of the current alarm or warning state	Within 200 ms
1	Clearance of the alarm history	Within 2 s



#### Data Format Phases in which the Command Common Asynchronous 2 Command can be Executed Classification command command Communication Processing Time Subcommand cycle or greater, and Cannot be used 5 seconds or less SYNC SET Description Byte Command Response 0DH 0DH • The SYNC SET command starts synchronous 0 communication. The system will be in the synchronous WDT RWDT 1 communication mode (phase 3) when the execution of this 2 command is completed and watchdog data error detection CMD CTRL CMD STAT starts. 3 It can be used to return to synchronous communication (phase 4 3), for example, when a shift has been made to asynchronous communication (phase 2) as a result of a communication error. 5 Synchronous communication is established by taking the 6 transition of the watchdog data (WDT) during the execution of this command as the reference. 7 Maintains this command at the master station until processing 8 has been completed. · Confirm the completion of the command execution by check-9 ing that RCMD = SYNC SET (= 0DH) and 10 CMD STAT.CMDRDY = 1.• If the system is in communication phase 2, it will establish the 11 servo OFF state and shift to communication phase 3. 12 • If the system is in communication phase 3, this command will 13 be ignored and a normal response will be returned. • If 8 or a higher COMM\_ALM has occurred, the system shifts 14 to communication phase 2. In such a case, restart synchronous 15 communication by sending this command. 16 In the following case, an alarm will occur and the command will 17 not be executed. Reserved Reserved • When editing using SigmaWin+: CMD ALM = AH (A.95A)18 19 20 21 22 23 24 25 26 27 28 29 30 31

#### 8.13.7 Start Synchronous Communication Command (SYNC\_SET: 0DH)



## 8.13.8 Establish Connection Command (CONNECT: 0EH) (1) Data Format

Phase Comman	es in which the d can be Executed	1	Command Classification	Common command	Asynchronous command		
Pro	cessing Time	Communication cycle or greater, and 5 seconds or less	Subcommand	Subcommand Cannot be used			
Puto	CONI	NECT	Description				
Dyte	Command	Response		Description			
0	0EH	0EH	• The CONNECT co	mmand establishs a M	IECHATROLINK		
1	WDT	RWDT	connection. When the completed, the completed	the execution of this control of slave stations is	started by means of		
2	CMD CTPI	CMD STAT	MECHATROLINK	communication.			
3	CMID_CTRL	CMD_STAT	Confirm the compl checking that RCN	etion of the command $ID = CONNECT (= 0)$	execution by FH) and		
4	VER	VER	CMD_STAT.CMD	RDY = 1, and also that	t the settings of VER,		
5	COM_MOD	COM_MOD	COM_MODE, CO	M_TIME, and PROF	ILE_TYPE of the		
6	COM_TIM	COM_TIM	response agree with	i the set data.			
7	PROFILE_TYPE	PROFILE_TYPE	In the following cases	s, an alarm will occur a	and the system will		
8			• When the VER dat	a is invalid:			
9			$CMD_ALM = 9H$	(A.94B)			
10			• When the COM_T CMD_ALM = $9H$	IM data is invalid:			
11			• When the PROFIL	E_TYPE data is invali	d:		
12			$CMD\_ALM = 9H (A.94B)$				
13			• when the number of and SUBCMD = 1;	:	8 32		
14			CMD_ALM=9H (A	A.94B)			
15			While editing using	g SigmaWin+: CMD_A	ALM = AH (A.95A)		
16							
17							
18							
19							
20	Reserved	Reserved					
21							
22							
23							
24							
25							
26							
27							
28							
29							
30							
31							

VER: MECHATROLINK application layer version For servo profile: VER = 30H

COM MOD: Communication mode

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
SUBCMD	0	0	0	DTM	IODE	SYNCMODE	0

- SYNCMODE: Synchronization setting

1: Performs synchronous communication.

(Watchdog data error detection enabled. Synchronous communication commands can be used.) 0: Performs asynchronous communication.

(Watchdog data error detection disabled. Synchronous communication commands cannot be used.)

- DTMODE: Data transfer method

00: Single transmission

01: Consecutive transmission

- 10: Reserved
- 11: Reserved

- SUBCMD: Subcommand setting

0: Subcommand disabled

1: Subcommand enabled

COM TIM: Communication cycle setting

Sets the number by which the transmission cycle is multiplied. This result is the setting for the communi- cation cycle.

Setting range: 1 to 32 for software version 0020 or earlier

1 to 255 for software version

0021 or later The set value must satisfy the

following conditions.

 $0.25 \text{ [ms]} \leq \text{Transmission cycle [ms]} \times \text{COM}_\text{TIME} \leq 32 \text{ [ms]}$  Transmission cycle: for 0.125 ms, set a multiple of 2.

Example: When the transmission cycle is 0.5 [ms] and the communication cycle is 2  $[ms] COM_TIME = 2/0.5 = 4$ 

PROFILE\_TYPE: Profile type setting Sets the profile type to be used. PROFILE\_TYPE = 10H (Standard servo profile)



# 8.13.9 Disconnection Command (DISCONNECT: 0FH)

#### Data Format

Phase Comman	es in which the d can be Executed	All phases	Command Classification	Common command	Asynchronous command		
Pro	cessing Time	Communication cycle or greater, and 5 seconds or less	Subcommand Cannot be used				
Puto	DISCO	NNECT	Description				
Dyte	Command	Response		Description			
0	0FH	0FH	• When releasing a c	onnection, the master	station transmits the		
1			cycles. At this time	the slave station inte	rrupts current		
2			processing and the	n performs the initializ	ation required to		
3			establishment requ	est from the master sta	tion.		
4			• The DISCONNEC	F command can be ser	it regardless of the		
5			command is sent w	hen the CMD_STAT.C	CMDRDY state bit is		
6			0, processing is inte	errupted and this comm	hand is processed.		
7			as two or more con	munication cycles.	51 the master station		
8			<ul> <li>Upon receipt of thin performed</li> </ul>	s command, the follow	ving operation is		
9			- Shifts the commu	e 1.			
10			<ul> <li>Establishes the se</li> <li>Disables reference</li> </ul>	rvo OFF state.			
11			- Initializes the pos	ition data.			
12			When the control p     DISCONNECT co	ower is turned OFF at mmand is sent the res	the same time the		
13			indefinite.		ponoe data io		
15							
16	Reserved	Reserved					
17							
18							
19							
20							
21							
22							
23							
24							
25							
26							
27							
28							
29							
30							
31							

8.13.10 Read Memory Command (MEM	RD: 1DH)

(1) Data Format

Phase Comman	Phases in which the 2, 3		Command Classification	Common command	Asynchronous command		
Pro	cessing Time	Within 200 ms	Subcommand	Canno	t be used		
Buto	MEM	I_RD		Description			
Dyte	Command	Response		Description			
0	1DH	1DH	• The MEM_RD con	mmand reads the d	ata stored in virtual		
1	WDT	RWDT	memory by specify reading	ng the initial address	s and the data size for		
2	CMD CTPI	CMD STAT	Confirm the comple	tion of the command	execution by		
3	CMD_CTKL	CMD_STAT	checking that RCMI	D = MEM_RD (= 1D 2DY = 1_ and also che	H) and ecking the setting for		
4	Reserved	Reserved	ADDRESS, SIZE a	nd MODE/DATA_TY	PE.		
5	MODE/ DATA_TYPE	MODE/ DATA_TYPE	In the following cases,	an alarm will occur.	Do not read DATA in		
6	SIZE	SIZE	indefinite.	ases because the DAI	IA value will be		
7	SIZE	SIZE	<ul> <li>When the ADDRESS data is invalid: CMD_ALM = 9H (A.94A)</li> <li>When the MODE/DATA_TYPE data is invalid.</li> </ul>				
8							
9	ADDRESS	ADDRESS	$CMD\_ALM = 9H (A.94B)$				
10	ADDIAL55	ADDILLSS	<ul> <li>When the SIZE data</li> <li>While editing using</li> </ul>	i is invalid: CMD_AI	$mvalid: CMD_ALM = 9H (A.94D)$ $maWin+: CMD_ALM = AH (A.95A)$		
11			thine outling using				
12			For details, refer to 8.1	3.11 - Method to Acc	ess Virtual Memory		
13			Areas.				
14							
15							
16							
17							
18							
19							
20							
21	Reserved	DATA					
22							
23							
24							
25							
26							
27							
28							
29							
30							
51							

The details of MODE/DATA\_TYPE are described below.

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MODE				DATA_TYPE			

MODE = 1: Volatile memory, 2: Not supported DATA\_TYPE = 1: Byte, 2: Short, 3: Long, 4: Not supported

SIZE:Data size for reading (of type specified by DATA\_TYPE)ADDRESS: Initial address for readingDATA:Read data



# 8.13.11 Write Memory Command (MEM\_WR: 1EH)

(1) Data Format

Phases in which the Command can be Executed		2, 3	Command Classification	Common command	Asynchronous command	
Processing Time		Refer to - Executing the Adjustment Operation.	Subcommand Cannot be used			
Byte MEN		_WR	Description			
2910	Command	Response				
0	1EH	1EH	• The MEM_WR con	mmand writes the data	in virtual memory	
1	WDT	RWDT	writing.	intial address, the data	size and the data for	
$\frac{2}{3}$	CMD_CTRL	CMD_STAT	This command provides an adjustment function equivalent that of the ADJ command of the MECHATROLINK			
4	Reserved	Reserved	Confirm the compl	etion of the command	execution by	
5	MODE/ DATA_TYPE	MODE/ DATA_TYPE	checking that RCMD = MEM_WR (= 1EH) and CMD_STAT.CMDRDY = 1, and also checking the setting ADDRESS_SIZE_MODE/DATA_TYPE and DATA			
6	SIZE	SIZE				
7	SHEE	SIEE	In the following cases, an alarm will occur and the commar will not be executed			
8			When the ADDRESS data is invalid:			
9	ADDRESS	ADDRESS	<ul> <li>CMD_ALM = 9H (A.94A)</li> <li>When the MODE/DATA_TYPE data is invalid: CMD_ALM = 9H (A.94B)</li> </ul>			
10						
11			• When the SIZE dat	a is invalid: CMD_AL	M = 9H (A.94D)	
12			<ul> <li>When the DATA data is invalid: CMD_ALM = 9H (A.9)</li> <li>When the conditions for executing the adjustment opera</li> </ul>			
13			the next page are not satisfied: CMD_ALM=AH (A.95A)			
14			• While editing using SigmaWin+: CMD_ALM = A	ALM = AH (A.95A)		
15			For details, refer to - Method to Access Virtual Memory Areas.			
10						
17						
10						
20						
20						
22	DATA	DATA				
23						
24						
25						
26						
27						
28						
29						
30						
31						

The details of MODE/DATA\_TYPE are described below.

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
	MC	DE			DAT	TA_TYPE	

MODE = 1: Volatile memory, 2: Non-volatile memory (Non-volatile memory can be selected only for common parameters)

DATA\_TYPE = 1: Byte, 2: Short, 3: Long, 4: Not supported

SIZE: Data size for writing (type specified by DATA\_TYPE) ADDRESS: Initial address for writing DATA: Data to be written

- Executing the Adjustment Operation

The table below lists the adjustment operations that can be executed.

Adjustment	Request Code	Preparation before Execution	Processing Time	Execution Conditions
Normal mode	0000H	None	200 ms max.	-
Parameter initialization	1005H	None	20 s max.	Initialization impossible while the servo is ON. After initialization, the power supply must be turned OFF and then ON again.
Absolute encoder reset	1008H	Required	5 s max.	When using an incremental encoder, impossible to reset the encoder while the servo is ON. After execution, the power supply must be turned OFF and then ON again.
Automatic offset adjustment of motor current detection signals	100EH	None	5 s max.	<ul> <li>Adjustment is disabled:</li> <li>While the main circuit power supply is OFF</li> <li>While the servo is ON</li> <li>While the servomotor is running</li> </ul>
Multiturn limit setting	1013H	Required	5 s max.	When using an incremental encoder, the setting is disabled unless A.CC0 (Multiturn limit dis agreement) occurs. After execution, the power supply must be turned OFF and then ON again.

- · Details of Command for Adjustment
  - 1. Send the following data and set the request code of the adjustment to be executed.

Command = MEM\_WR ADDRESS = 80004000H MODE/DATA\_TYPE = 12H SIZE = 0001H

DATA = Request code of the adjustment to be executed

To confirm the completion of the execution, check that CMDRDY = 1. If an error occurs, carry out the operation in step 4 to abort execution.

2. For adjustment that requires a preparation process in the table, send the following data.

Command = MEM\_WR ADDRESS = 80004002H MODE/DATA\_TYPE = 12H SIZE = 0001H DATA = 0002H

To confirm the completion of the execution, check that CMDRDY = 1. If an error occurs, carry out the operation in step 4 to abort execution.



3. Send the following data to execute adjustment.

Command = MEM\_WR ADDRESS = 80004002H MODE/DATA\_TYPE = 12H SIZE = 0001H DATA = 0001H To confirm the completion of the execution, check that CMDRDY = 1. If an error occurs, carry out the operation in step 4 to abort execution.

4. Send the following data to abort the execution.

Command = MEM\_WR ADDRESS = 80004000H MODE/DATA\_TYPE = 12H SIZE = 0001H DATA = 0000H To confirm the completion of the execution, check that CMDRDY = 1.

- Method to Access Virtual Memory Areas

For the information on the allocation of virtual memory areas, refer to 8.29 *Virtual Memory Space*. The details of the units (DATA TYPE) for accessing the virtual memory areas are described below.

Area Name	Details	DATA_TYPE	SIZE*	Accessible/inaccessible	
Vendor-specific area	Reserved			Inaccessible	
vendor-speeme area	Register area	Short, long	Number of data	Accessible	
Reserved	Reserved			Inaccessible	
Common parameter area	Common parameters	Long	Number of data	Accessible	
ID area	Reserved	Byte short long	Number of data	Accessible	
	ID	Byte, short, long	Truinder of duta		

\* Set the number of data of the data type specified by DATA\_TYPE.

The details of CMD\_ALM of the MEM\_RD/MEM\_WR command are described below.

CMD_ALM	Displayed Code	Error Details
9Н	A.94A	When an initial address outside the defined areas is specified
		When an address within the reserved ranges of common parameter or vendor-specific areas is specified
		When a value other than a multiple of the data size specified in DATA_TYPE is set for ADDRESS
	A.94B	When the MODE or DATA_TYPE data is invalid
	A.94D	When the initial address is within the defined areas but the specified size goes beyond those areas
		When a data size beyond the specification of the command format is set for SIZE

#### 8.14 Servo Commands

#### 8.14.1 Table of Servo Commands

The following table shows the servo commands.

Profile	Command Code (Hex.)	Command	Operation	Compliance*
	20	POS_SET	Set coordinates	0
	21	BRK_ON	Request for applying lock	0
	22	BRK_OFF	Release lock	0
	23	SENS_ON	Request for turning sensor ON	0
	24	SENS_OFF	Request for turning sensor OFF	0
	30	SMON	Monitor servo status	0
	31	SV_ON	Servo ON	0
	32	SV_OFF	Servo OFF	0
Standard	34	INTERPOLATE	Interpolation	0
Standard	35	POSING	Positioning	0
	36	FEED	Constant speed feed	0
	37	EX_FEED	Positioning at constant speed by external input	0
	39	EX_POSING	Positioning by external input	0
	3A	ZRET	Zero point return	0
	3C	VELCTRL	Velocity control	0
	3D	TRQCTRL	Torque (force) control	0
	40	SVPRM_RD	Read servo parameter	Δ
	41	SVPRM_WR	Write servo parameter	0

\* Indicates the compliance status.

 $\circ$  : Possible

\_

- $\Delta$ : Possible with specification restrictions (Refer to the subsection describing each command for the details of the restrictions.)
- $\times$  : Not possible

# 8.14.2 Set Coordinates Command (POS\_SET: 20H)

(1) Data Format

Processing Time         Within communication cycle         Subcommand         Cannot be used           Byte         POS_SET         Description           0         20H         20H         -           1         WDT         RwDT         -         -           2         CMD_CTRL         CMD_STAT         -         -         -           3         CMD_CTRL         CMD_STAT         -         -         -         -         -           4         -	Phases in which the Command can be Executed		2, 3	Command Classification	Common motion command	Asynchronous command		
Byte         POS_SET         Description           0         20H         20H         20H           1         WDT         RWDT         slave station. Specify the type of coordinate system for the slave station. Specifying this command after setting REFE = 1 sets the machine zero point according to the coordinate setting values and enables the stroke check (software limit) function.           5         SVCMD_CTRL         SVCMD_STAT         - This command after setting values and enables the stroke check (software limit) function.           6         SVCMD_CTRL         SVCMD_STAT         - Confirm the completion of the command execution by checking that RCMD = POS_SET (= 20H) and CMD_STAT.CMDRDY = 1, and also checking the setting for POS_SET (= 20H) and CMD_STAT.CMDRDY = 1, and also checking the setting for POS_SET_MOD POS_SET_MOD           10         SVCMD_10         SVCMD_10           11         SVCMD_10         SVCMD_10           12             13         POS_SET_MOD         POS_DATA           14         POS_DATA         POS_DATA           19             20             21             22             23             24	Processing Time		Within communication cycle	Subcommand Cannot be used		be used		
Dyte         Command         Response         Description           0         20H         20H         The POS_SET command sets the coordinate system for the side stion code using POS_SEL.           1         WDT         RWDT         Side station. Specify the type of coordinate system for the selection code using POS_SEL.           2         CMD_CTRL         CMD_STAT         This command also provides a function to set the reference point. Specifying this command after setting RFFE = 1 sets the machine zero point according to the coordinate setting or values and enables the stroke check (software limit) function.           4	POS		SET	Description				
0     20H     20H       1     WDT     RWDT       2     CMD_CTRL     RWDT       3     CMD_CTRL     CMD_STAT       4	Byte	Command	Response	Description				
1     WDT     RWDT       2     CMD_CTRL     RWDT       3     CMD_CTRL     CMD_STAT       4	0	20H	20H	• The POS_SET con	nmand sets the coordin	nate system for the		
2       CMD_CTRL       CMD_STAT         3       CMD_CTRL       CMD_STAT         4	1	WDT	RWDT	slave station. Specify the type of coordinates with the monito selection code using POS_SEL				
3     CMD_CTRL     CMD_DTA       4	2	CMD CTRI	CMD STAT	This command also	provides a function t	o set the reference		
4     values and enables the stroke check (software limit) function.       5     SVCMD_CTRL     SVCMD_STAT       6     SVCMD_CTRL     SVCMD_STAT       7     Confirm the completion of the command execution by checking that RCMD = POS_SET_GDI and CMD_STAT.CMDRDY = 1, and also checking the setting for POS_SEL and POS_DATA.       8     9     SVCMD_IO       9     SVCMD_IO     SVCMD_IO       10     SVCMD_IO     SVCMD_IO       11     In the following case, an alarm will occur and the command will not be executed.       11     0     When the POS_SET_MOD data is invalid:       13     POS_SET_MOD     POS_SET_MOD       14     POS_DATA     POS_DATA       19     POS_DATA     POS_DATA       19     MONITOR1     MONITOR2       20     MONITOR2     MONITOR2       21     MONITOR3     MONITOR3	3	CWD_CTKL	CMD_STAT	the machine zero p	his command after sett oint according to the c	oordinate setting		
5     SVCMD_CTRL     SVCMD_STAT       6     SVCMD_CTRL     SVCMD_STAT       7	4			values and enables	the stroke check (software)	ware limit) function.		
6     57 CMD_CIAL     57 CMD_DIA       7     CMD_STAT_CMDRDY = 1, and also checking the setting for POS_SEL and POS_DATA.       9     SVCMD_IO       10     SVCMD_IO       10     SVCMD_IO       11     SVCMD_IO       12     When the POS_SET_MOD       13     POS_SET_MOD       14     POS_SET_MOD       15     POS_DATA       16     POS_DATA       19     POS_DATA       20     MONITOR1       21     MONITOR2       22     MONITOR3       30     MONITOR3	5	SVCMD CTRI	SVCMD STAT	<ul> <li>Confirm the compl checking that RCN</li> </ul>	etion of the command $1D = POS SET (= 20)$	execution by H) and		
7       POS_SEL and POS_DATA.         8	6	SVEIND_CINE	Svenib_Sini	$CMD_STAT.CMDRDY = 1$ , and also checking the setting for				
8         9         SVCMD_IO         SVCMD_IO         In the following case, an alarm will occur and the command will not be executed.           10         10         SVCMD_IO         SVCMD_IO         • When the POS_SET_MOD data is invalid: CMD_ALM = 9H (A.94B)           11         12	7			POS_SEL and POS	S_DAIA.			
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	8			In the following case, an alarm will occur and the command will				
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	9	SVCMD 10	SVCMD 10	<ul> <li>not be executed.</li> <li>When the POS_SET_MOD data is invalid: CMD ALM = 9H (A.94B)</li> </ul>				
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	10	5, 6, 12, 10	Stening_10					
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	11							
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	12		POS_SET_MOD					
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	13	POS SET MOD						
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	14							
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	15							
17     POS_DATA     POS_DATA       18     POS_DATA     POS_DATA       19	16							
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	17	POS DATA	POS DATA					
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	18	_	100_2					
20     MONITOR1       21     MONITOR1       22     23       23     MONITOR1       24     MONITOR2       25     Reserved       26     MONITOR2       27     MONITOR3       30     MONITOR3	19							
21     MONITOR1       22     MONITOR1       23     MONITOR1       24     MONITOR2       25     MONITOR2       26     MONITOR2       27     MONITOR3       30     MONITOR3	20							
22       23       24       25       26       27       28       29       30       31	21		MONITOR1					
23     4       24     1       25     Reserved       26     MONITOR2       27     1       28     1       29     MONITOR3	22							
25     Reserved     MONITOR2       26     27	23							
26     Reserved     MONITOR2       27     28	24							
27       28       29       30       31	25	Reserved	MONITOR2					
28         29           30         31	20							
29 30 31 MONITOR3	28							
30 31 MONITOR3	29							
31	30		MONITOR3					
	31							
#### (2) Command Parameters

#### POS\_SET\_MOD: Coordinates Setting Mode

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0		
REFE	0	0	0		POS	SEL			
bit15	bit14	bit13	bit12	bit11	bit10	bit9	bit8		
	Reserved								
bit23	bit22	bit21	bit20	bit19	bit18	bit17	bit16		
			Rese	erved					
bit31	bit30	bit29	bit28	bit27	bit26	bit25	bit24		
			Rese	erved					

- POS\_SEL: Select coordinates system (specify using the monitor selection code).

When APOS (feedback position of the machine coordinates system) = 0 is selected, the command/ machine coordinates system is set at POS\_DATA.

- REFE: Enable/Disable setting of reference point

- 0: Disables setting of a reference point.
- 1: Enables setting of a reference point. The coordinate reference point setting is confirmed and the ZPOINT (zero point position) and software limit become effective.

- POS\_DATA: Coordinates set value

- Set the reserved bits to "0."



# 8.14.3 Apply Lock Command (BRK\_ON: 21H)

Data Fo	rmat						
Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Servo standard command	Asynchronous command		
Pro	cessing Time	Within communication cycle	Subcommand	Cannot be used			
Byte	BRK	_ON		Description			
Dyte	Command	Response		Becomption			
0	21H	21H	• The BRK_ON com	mand outputs a lock	operation signal.		
1	WDT	RWDT	Confirm the compl checking that RCM	etion of the command $D = BRK ON (= 21)$	d execution by H) and		
2	CMD CTRI	CMD STAT	CMD_STAT.CMD	RDY = 1.			
3	CMD_CIRL	CMD_51AI	Valid only in the se     This commond is as	rvo OFF state.	is set to a value other		
4			than "0" (allocation	of /BK).	is set to a value other		
5	SVCMD CTRI	SVCMD STAT					
6	SVEWID_CIKL	SVCWD_STAT					
7							
8							
9	SVCMD IO	SVCMD IO					
10	SVCMD_IO	SVCWID_IO					
11							
12							
13		CPRM_SEL_					
14		MON1	MON1				
15							
16							
17		CPRM_SEL_					
18		MON2					
19							
20							
21	Reserved	MONITOR 1					
22	ixesei veu						
23							
24							
25		MONITOR?					
26		1101110112					
27							
28							
29		MONITOR3					
30							
31							

# 8.14.4 Release Lock Command (BRK\_OFF: 22H)

Phase Comman	es in which the d can be Executed	2, 3	Command Classification	Servo standard command	Asynchronous command		
Pro	cessing Time	Within communication cycle	Subcommand	Cannot	be used		
Byte	BRK_	_OFF	Description				
Dyte	Command	Response	]	Description			
0	22H	22H	• The BRK_OFF cor	nmand releases the lo	ck.		
1	WDT	RWDT	Confirm the complete checking that RCM	etion of the command $ID = BRK OFF (= 22)$	execution by H) and		
2	CMD CTDI	CMD STAT	CMD_STAT.CMD	RDY = 1.	ii) und		
3	CMD_CTRL	CMD_STAT	• This command is en	habled when Pn50F.2	is set to a value other		
4			than "0" (allocation	OI/BK).			
5							
6	SVCMD_CTRL	SVCMD_STAT					
7							
8			-				
9							
10	SVCMD_IO	SVCMD_IO					
11							
12			-				
13		CPRM_SEL					
14		MON1					
15							
16							
17		CPRM SFL					
18		MON2					
19							
20			-				
21							
22	Reserved	MONITOR1					
23							
24			1				
25							
26		MONITOR2					
27							
28			1				
29							
30		MONITOR3					
31							



- Lock signal Output Timing



# 8.14.5 Turn Sensor ON Command (SENS\_ON: 23H)

Phase Comman	es in which the d can be Executed	2, 3	CommandCommonAsynchrClassificationcommandcomm		Asynchronous command		
Pro	cessing Time	Within 2 s	Subcommand	Subcommand Cannot be used			
Byte	SENS	S_ON		Description			
Dyte	Command	Response		Description			
0	23H	23H	The SENS_ON cor	nmand is the sensor in	formation		
1	WDT	RWDT	<ul> <li>Initialization reques</li> <li>Confirm the completion</li> </ul>	st command. It initiality etion of the command	zes the sensor. execution by		
2	CMD CTPI	CMD STAT	checking that RCM	$ID = SENS_ON (= 23)$	H) and		
3	CMD_CTRL	CMD_51AI	• CPRM_STAT.CMD	RDY = 1.	12.		
4			Monitor data can be	e selected by changing	the common		
5	SVCMD CTRI	SVCMD STAT	parameter setting. I	For details, refer to 8.2	27 Common		
6	SVCMD_CIKL	SVCWD_STAT	• When an absolute e	encoder is used, the ini	itial position is		
7			acquired from the e	encoder.	red encoder position +		
8			zero point position	offset (common paran	neter 23).		
9	SVCMD IO	SVCMD IO	The coordinate reference point setting is confirmed and <b>ZPOINT</b> (zero point position) and software limit become				
10			effective.	effective.			
11							
12							
13		CPRM_SEL_ MON1					
14							
15							
16							
17		CPRM_SEL_					
18		MON2					
19							
20							
21	Reserved	MONITOR 1					
22	Reserved	MONTORI					
23							
24							
25		MONITOR?					
26		1010111012					
27							
28							
29		MONITOR3					
30		MONTORS					
31							

# 8.14.6 Turn Sensor OFF Command (SENS\_OFF: 24H)

Data Fo	rmat						
Phas Comman	es in which the d can be Executed	2, 3	Command Classification	nd Common Asynchro tion command comma			
Pro	cessing Time	Within 2 s	Subcommand	Cannot	be used		
Dute	SENS	_OFF		Description			
Вуте	Command	Response		Description			
0	24H	24H	• The SENS_OFF co	mmand is the sensor	power OFF request		
1	WDT	RWDT	<ul> <li>command. It is used</li> <li>Confirm the completion</li> </ul>	to turn OFF the pow tion of the command	execution by		
2	CMD CTRI	CMD STAT	checking that RCM	$D = SENS_OFF (= 24)$	4H) and		
3	CNID_CIKE	CMD_51AI	• CPRM_STAT.CMD	RDY = 1. [1/CPRM_SEL_MON	12.		
4			Monitor data can be	e selected by changing	the common		
5	SVCMD CTRL	SVCMD STAT	parameter setting. F	For details, refer to 8.2	27 Common		
6	SVCMD_CIAL	SVCMD_SIM	• When an absolute e	ncoder is used the pos	sition data is		
7			indefinite. "0" is set	t for POS_RDY. rence point setting be	comes invalid and		
8			the ZPOINT (zero p	point position) and sof	tware limit also		
9	SVCMD 10	SVCMD 10	become invalid.				
10	5, 6, 12, 10	5, 6, 12, 10	In the following case, an alarm will occur and the command will				
11			not be executed.	te: CMD AIM - AH	(( 05 ))		
12			• In the serve on sta	te. CMD_ALM – AII	(A.95A)		
13		CPRM_SEL_					
14		MONI					
15							
16							
17		CPRM_SEL_					
18		MON2					
19							
20							
21	Reserved	MONITOR1					
22							
23							
24							
25		MONITOR2					
26							
28			-				
29							
30		MONITOR3					
31							
	1	1	1				



# 8.14.7 Servo Status Monitor Command (SMON: 30H)

Phase Comman	es in which the d can be Executed	2, 3	Command Classification	CommandServo standardAsynchroClassificationcommandcommand			
Processing Time		Within communication cycle	Subcommand Can be used				
Byte	SM	ON	Description				
Dyte	Command	Response		Description			
0	30H	30H	The SMON comma	and reads the alarms, s	tatus, and monitor		
1	WDT	RWDT	information (position monitor setting and	on, speed, output, torq d the state of the I/O s	ue, etc.) specified in		
2	CMD CTDI	CMD STAT	drive.				
3	CMD_CTRL	CMD_STAT	Confirm the complete checking that RCM	etion of the command $ID = SMON (= 30H)$	execution by		
4			CMD_STAT.CMD	RDY = 1.	ind		
5	QUOND OTDI	OVCMD OTAT	CPRM_SEL_MON Monitor data can be	11/CPRM_SEL_MON	12:		
6	SVCMD_CIKL	SVCMD_STAT	parameter setting. I	For details, refer to 8.2	27 Common		
7			Parameters.				
8							
9	SVCMD 10	SVCMD IO					
10	SVCMD_IO	SVCMD_IO					
11							
12			•				
13		CPRM SEL					
14		MON1					
15							
16							
17		CPRM SEL					
18		MON2					
19							
20							
21	Dana 1	MONUTOD 1					
22	Keserved	MUNITORI					
23							
24							
25		MONUTODA					
26		MONITOR2					
27							
28							
29							
30		MONITOR3					
31							
			I				

# 8.14.8 Servo ON Command (SV\_ON: 31H)

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Servo standard command	Asynchronous command	
Pro	cessing Time	Normally 50 ms (10 s max.)	Subcommand	Subcommand Can be used		
Bvte	SV_	ON		Description		
	Command	Response				
0	31H	31H	• The SV_ON comm	and supplies the powe	er to the servomotor	
1	WDT	RWDT	<ul> <li>and makes it ready</li> <li>Confirm the completion</li> </ul>	for operation.	execution by	
2	CMD_CTRL	CMD_STAT	checking that RCM CMD_STAT.CMD	$ID = SV_ON (= 31H)$ RDY = 1.	and	
			CPRM_SEL_MON	1/CPRM_SEL_MON	2:	
			parameter setting. I	For details, refer to 8.2	7 Common	
6	SVCMD_CTRL	SVCMD_STAT	Parameters.			
7			• To establish the ser send a command ot	vo ON state after a wa her than SV ON, such	rning has occurred, as the SV OFF	
8			command, and then	send the $SVON$ con	nmand.	
9			<ul> <li>Upon completion o position (CPOS) mi</li> </ul>	pon completion of execution of this con osition (CPOS) must be read and the PO		
10	SVCMD_IO	SVCMD_IO	coordinate system must be set up.			
11			• Confirm that M_RI	JY = 1 before sending	this command.	
12			In the following cases	s, AH (A.95A) will be	set for CMD_ALM	
13		CPRM SEL	<ul> <li>and the command will not be executed.</li> <li>When an alarm (COM_ALM = 8H or greater or D_ALM = 1)</li> </ul>			
14		MON1	has occurred			
15			<ul> <li>When PON = 0</li> <li>When the execution</li> </ul>	of the SENS ON co	nmand has not	
16			completed with an	absolute encoder used	innund nus not	
17		CPRM_SEL_	When ESTP (HWE     When parameters h	BB signal off) = $1$		
18		MON2	• when parameters in	ave been mitialized		
19						
20						
21	Reserved	MONITOR1				
22						
23						
24						
25		MONITOR2				
26						
27						
28						
29		MONITOR3				
30						
51						

# 8.14.9 Servo OFF Command (SV\_OFF: 32H)

Phase Comman	es in which the d can be Executed	2, 3	Command Classification	Servo standard Asynchrono command command			
Pro	cessing Time	Time set with Pn506 500 ms max.	Subcommand Can be used		e used		
Byte	SV_	OFF	Description				
Dyte	Command	Response		Description			
0	32H	32H	The SV_OFF com	nand shuts the power	to the servomotor.		
1	WDT	RWDT	• Confirm the comple checking that RCM	etion of the command $D = SV OFF (= 32H)$	execution by and		
2	CMD CTRI	CMD STAT	CMD_STAT.CMD	$RDY = \overline{1}.$	, unu		
3	CMD_CTRL	CMD_STAT	CPRM_SEL_MON     Monitor data can be	11/CPRM_SEL_MON	12: It the common		
4			parameter setting. I	For details, refer to 8.2	27 Common		
5	SVCMD CTRI	SVCMD STAT	Parameters.	FF waiting time at da	coloration to a stan)		
6	SVCMD_CIKL	SVCMD_STAT	is set to a value oth	er than "0", the servo	will be turned OFF		
7			after the servomoto	r decelerates to a stop	according to the		
8			servomotor deceler	deceleration constant for stopping set by the parameter. (The servomotor decelerates to a stop in position control mode.) When Pn829 (SVOFF waiting time at deceleration to a stop) is set to "0", the servo will be turned OFF immediately after reception of this command (default setting).			
9	SVCMD IO	SVCMD IO	• When Pn829 (SVO				
10			reception of this co				
11			(The control mode	before receiving the S	V_OFF command		
12			• Executing the SV	.) ′ OFF command wi	ll cancel the speed		
13		CPRM_SEL_	reference, speed fe	edforward, torque fee	dforward, and torque		
14		MON1	limits set by a posit	limits set by a position/speed control command.			
15							
16							
17		CPRM SEL					
18		MON2					
19							
20							
21	Pasarvad	MONITOP 1					
22	Keserved	WONTORI					
23							
24							
25		MONITOP2					
26		WOMTOK2					
27							
28			1				
29		MONUTOD2					
30		WONITOK3					
31							

#### - Related Parameters

Parameter No.	Description
Pn829	SVOFF waiting time at deceleration to a stop
Pn827 (Pn840)	Linear deceleration constant for stopping

Parameter numbers in parentheses are those when Pn833 = 1.



# 8.14.10 Interpolation Command (INTERPOLATE: 34H)

Phase Comman	es in which the d can be Executed	3	Command Classification	Servo standard command	Synchronous command		
Processing Time		Within communication cycle	Subcommand Can be used				
Byte	INTERF	POLATE	Description				
Dyte	Command	Response	1	Description			
0	34H	34H	• The INTERPOLATE command performs interpolation				
1	WDT	RWDT	communication cvo	tying the interpolati	on positions every CT command.		
2	CMD CTPI	CMD STAT	Confirm the compl	etion of the command	execution by		
3	CMD_CTKL	CMD_STAT	checking that RCM	ID = INTERPOLATE RDY = 1	(= 34H) and		
4			Confirm motion ref	ference output complet	tion by checking that		
5	SVCMD CTRI	SVCMD STAT	SVCMD_IO.DEN checking that SVC	= 1, and the completic $MD IO PSFT = 1$	on of positioning by		
6	SVCMD_CIKL	SVCMD_STAT	CPRM_SEL_MON	VI/CPRM_SEL_MON	12:		
7			Monitor data can be	e selected by changing	the common		
8			Parameters.	rol details, lefer to 8.2	./ Common		
9	SVCMD IO	SVCMD IO	<notes command="" on="" the="" using=""> • TPOS (target position): Set the target position with a signed value.</notes>				
10		SVENID_10					
11							
12			• VFF (velocity feedforward):				
13	TROS	CPRM_SEL_	Use it as a speed feedforward function.				
14	1105	MON1	• TFF (torque feedforward):				
15			Use it as a torque (1	force) feedforward fun	ction.		
16			• TLIM (torque limit	i):			
17	VEE	CPRM SEL	For the information	on the settings of the	ie. above reference		
18	۷ГГ	MON2	data, refer to 8.14.20 Motion Command Data Setting				
19			Method. • For the units of command values set in the command area				
20			refer to 8.12.2 Spec	cifying Units.	ie command area,		
21	TEE	MONITOD 1	In the fellowing error	1			
22	ТГГ	MONITORI	will not be executed.	s, an alarm will occur a	and the command		
23			• When used in com	nunication phase 2:			
24			• In the servo OFF st	(A.9/A) ate: CMD ALM = AI	H (A.95A)		
25	Pasarvad	MONITOP2	• When the difference	e relative to the previo	ous TPOS exceeds		
26	- Reserved MONITOR2		the limit value: CM	ID_ALM = 9H (A.94]	B) and the relevant		
27			value will be clamped	at the limit value.	and the relevant		
28			• When the VFF data	a is invalid: CMD_AL	M = 1H (A.94B)		
29	TI IM		• when the IFF data	i is invalid: CMD_AL	м – 1п (А.94В)		
30	1 1.1111						
31							

# 8.14.11 Positioning Command (POSING: 35H)

Data Format

Phase Commane	es in which the d can be Executed	2, 3	Command Classification	Servo standard command	Asynchronous command		
Proc	cessing Time	Within communication cycle	Subcommand	Can be used			
Buto	POS	SING		Description			
Byte	Command	Response		Description			
0	35H	35H	The POSING comr     position	nand executes positioni	ng to the specified		
1	WDT	RWDT	<ul> <li>Positioning is exec</li> </ul>	uted to the target position	on (P1) at the		
2	CMD CTRL	CMD STAT	<ul> <li>Confirm the compl</li> </ul>	etion of the command e	execution by checking		
3	enin_enin		that RCMD = POS $1.$	ING (= 35H) and CMI	D_STAT.CMDRDY =		
4			Confirm motion ret SVCMD IO.DEN	ference output completi $= 1$ , and the completion	on by checking that of positioning by		
5	SVCMD CTRL	SVCMD STAT	checking that SVC	$MD_IO.PSET = 1.$	of the command by		
6	_	_	checking that RCM	ID = POSING (= 35H), PDV = 1 and	for the command by		
7			SVCMD_STAT.CMD	$MD_{CANCEL}CMP =$	1.		
8			Confirm the compl checking that RCM	etion of pausing of the of ID = POSING (= 35H),	command by		
9	SVCMD IO	SVCMD IO	CMD_STAT.CMDRDY = 1 and SVCMD_STAT.CMD_PAUSE_CMP = 1.				
10	_	_	CPRM_SEL_MON Monitor data can be	V1/CPRM_SEL_MON2	): The common parameter		
11			setting. For details, refer to 8.27 Common Parameters.				
12			• TPOS (target position):				
13	TPOS	CPRM_SEL_	<ul> <li>Set the target position with a signed value.</li> <li>TSPD (target speed): Set the target speed with an unsigned value.</li> <li>ACCR (acceleration):</li> </ul>				
14		MONT					
15			Set the acceleration	with an unsigned value	e.		
16			• DECR (deceleration Set the deceleration	n): 1 with an unsigned valu	e.		
17	TSPD	CPRM_SEL_	When both ACCR a is performed accord	and DECR are "0", acce ding to the parameter se	eleration/deceleration		
18		MON2	To perform two-ste and DECR to "0."	p acceleration/decelerat For details, refer to 8.25	tion, set both ACCR 5.2 <i>Positioning</i>		
19			Command.	).			
20			Set the torque limit	with an unsigned value	2. 		
21	ACCR	MONITOR1	For the information	n on the settings of the a	bove reference data,		
22			<ul><li>refer to 8.14.20 Mo</li><li>For the units of corr</li></ul>	tion Command Data Se nmand values set in the	<i>tting Method.</i> command area, refer		
23			to 8.12.2 Specifyin In the following cases	g Units. 5. an alarm will occur a	nd the command will		
24			not be executed.	a = CMD A I M = A H	(1 954)		
25	DECR	MONITOR2	When the TSPD da	ta is invalid: (4.04D)	(11.7511)		
20			• When the ACCR of	(A.94B) r DECR data is invalid:			
21			<ul><li>CMD_ALM = 9H</li><li>When either of the</li></ul>	(A.94B) ACCR or DECR data is	s set to "0":		
20			$CMD\_ALM = 9H$ In the following case	(A.94B) an alarm will occur and	d the relevant value		
30	TLIM	MONITOR3	will be clamped at the	e limit value.	M = 111 (A 0.4D)		
31			• when the TLIM da	I data is invalid: CMD_ALM = 1H (A.94B)			







### 8.14.12 Feed Command (FEED: 36H)

Phase Commane	es in which the d can be Executed	2, 3	Command Classification	Servo standard command	Asynchronous command		
Pro	cessing Time	Within communication cycle	Subcommand Can be used				
Byte	FE	ED		Description			
Dyte	Command	Response	1	Description			
0	36Н	36H	• The FEED comman	nd performs constant sp	beed feed control at		
1	WDT	RWDT	To change the spee	peed. d and direction of feed.	change the feed		
2	CMD_CTRL	CMD_STAT	<ul><li>speed setting.</li><li>To cancel constant</li></ul>	speed feed, set			
			SVCMD_CTRL.C.     To pause constant s	MD_CANCEL to "1."			
4	-		SVCMD_CTRL.C	MD_PAUSE to "1."			
<u> </u>	SVCMD_CTRL	SVCMD_STAT	Confirm the compl checking that RCM	etion of the cancellation $D = FEED (= 36H) CN$	n of the command by AD STAT CMDRDY		
6			= 1 and SVCMD_S	TAT.CMD_CANCEL	CMP = 1.		
7			- SVCMD IO.DEN	= 1, and the completion	on by checking that n of positioning by		
8			checking that SVC	$MD_IO.PSET = 1.$	f the command hy		
9	SVCMD IO	SVCMD 10	• Confirm the completion of pausing of the command by checking that RCMD = FEED (= 36H).				
10	Stening_re		$CMD_STAT.CMDRDY = 1 $ and SVCMD_STAT.CMD_PAUSE_CMP = 1 and				
11			• CPRM_SEL_MON1/CPRM_SEL_MON2:				
12			Monitor data can be parameter setting. I	e selected by changing t For details, refer to 8.27	the common 7 <i>Common</i>		
13		CPRM SEL	Parameters.				
14	Reserved	MON1	<notes command="" on="" the="" using=""></notes>				
15			• TSPD (target speed	):			
16			ACCR (acceleration	n):			
17	-	CDDM SEI	Set the acceleration	with an unsigned valu	e.		
18	TSPD	MON2	• DECK (deceleration Set the deceleration	n with an unsigned valu	e.		
19			When both ACCR a     is performed accord	and DECR are "0", acce	eleration/deceleration		
20			To perform two-ste	p acceleration/decelera	tion, set both ACCR		
21	1		and DECR to "0." I <i>Command</i> .	or details, refer to 8.2.	5.2 Positioning		
	ACCR	MONITOR1	• TLIM (torque limit	): with an unsigned web-	2		
			For the information	on the settings of the a	bove reference data,		
23			• For the units of corr	otion Command Data S	etting Method.		
	4		to 8.12.2 Specifyin	g Units.	כסווווומוע מודמ, ודוכו		
25	DECR	MONITOR2	In the following cases	an alarm will occur a	nd the command will		
26			not be executed.	, un aiaini will occul à	na the command will		
27			<ul> <li>In the servo OFF st</li> <li>When the TSPD data</li> </ul>	ate: CMD_ALM = AH	I(A.95A) IM = 9H(A.94B)		
28			When the ACCR of	r DECR data is invalid:			
29	TLIM	MONITOR3	• When either of the	(A.94B) ACCR or DECR data i	s set to "0"·		
30			$CMD_ALM = 9H$	(A.94B)			
31			In the following case, will be clamped at the	an alarm will occur an limit value.	d the relevant value		
			• When the TLIM da	ta is invalid: CMD AI	M = 1H (A 94B)		







# 8.14.13 External Input Feed Command (EX\_FEED: 37H)

(1) Da	ita Format					
Phases in which the Command can be Executed		2, 3	Command Classification	Servo standard command	Asynchronous command	
Processing Time		Within communication cycle	Subcommand Can be used			
Byte EX_FE		ED		Description		
	Command	Response	• The EX_EEED comm	and performs position	ing in response to the	
0	37H	37H	The EX_FEED command performs positioning in response to input of the external positioning signal during constant speed feed at the specified feed speed			
	WDI	RWDI	<ul> <li>To change the speed at</li> </ul>	nd direction of feed, cl	nange the feed speed	
2	CMD_CTRL	CMD_STAT	<ul> <li>To pause external inpute to "1 "</li> </ul>	it feed, set SVCMD_C	CTRL.CMD_PAUSE	
4			Confirm the completion     that RCMD = EX_FEI	on of the command exe ED (= 37H) and CMD	ecution by checking STAT.CMDRDY =	
5			1. • To cancel the constant	speed feed set	_	
6	SVCMD_CTRL	SVCMD_STAT	SVCMD_CTRL.CME	• Speed feed, set • CANCEL to "1."	tah signal by	
7			checking that SVCME	$D_CTRL.L_CMP1 = 1$		
8			Confirm motion refere SVCMD_CTRL.DEN checking that SVCME	= 1, and the completion CTRL PSFT = 1	on of positioning by	
9			Confirm the completion     absolving that BCMD:	on of the cancellation $(-27H)$	of the command by	
10	SVCMD_IO	SVCMD_IO	checking that RCMD = $EX_FEED$ (= 37H), CMD_STAT.CMDRDY = 1 and SVCMD_STAT.CMD_CANCEL_CMD = 1			
11	Confirm the completion of pausing of the target of target				mmand by checking $\Gamma AT CMDRDY = 1$	
12			and SVCMD_STAT.C	$MD_PAUSE_CMP = CMP = C$	1.	
13		CPRM SEL	Monitor data can be selected by changing the common parameter setting. For details, refer to 8 27 Common Parameters			
14	Reserved	MON1	Netes on using the sour		arameters.	
15			<notes command="" on="" the="" using=""> • To send this command, select the latch signal with LT_SEL1 of</notes>			
16			$LT_REQ1 = 1.$	butput the latch reques	t by setting	
17	TODD	CPRM SEL	• TSPD (target speed): Set the target speed with a signed value.			
18	15PD	MON2	• ACCR (acceleration): Set the acceleration w	ith an unsigned value.		
19			• DECR (deceleration): Set the deceleration w	ith an unsigned value.		
20			When both ACCR and is performed according	DECR are "0", accele to the parameter sett	eration/deceleration ings.	
21	ACCD	MONITOR 1	To perform two-step a and DECR to "0." For	cceleration/dece	on, set both ACCR	
22	ACCK	MONITORI	Command.			
23			Set the torque limit wi	th an unsigned value.		
24			• For the information on the settings of the above reference data refer to 8.14.20 Motion Command Data Setting Method			
25	DECR MONITOR2		• For the units of comm to 8.12.2 Specifying U	and values set in the c Inits.	ommand area, refer	
26			In the following cases, as	n alarm will occur and	the command will	
27			not be executed. • In the serve OFF state	CMD ALM = AH(	A 95A)	
28			• When the ACCB or D	is invalid: CMD_ALM	M = 9H (A.94B)	
29	TLIM	MONITOR3	$CMD\_ALM = 9H (A.$	94B)	the veloce of the	
30			will be clamped at the lin	nit value.	the relevant value	
51			• When the TLIM data is invalid: CMD_ALM = 1H (A.94B)			



#### (2) Operating Sequence

The following describes the operating sequence for external input positioning operation using the EX\_FEED command.

- 1. The master station sends the EX\_FEED command. It selects the latch signal with LT\_SEL1 of SVCMD\_CTRL and outputs the latch request by setting LT\_REQ1 = 1.
- 2. The slave station starts feeding at the specified speed when it receives the EX\_FEED command. At the same time, it enters the external signal positioning mode.
- 3. When the external positioning signal is input, the slave station sets latch completion status L\_CMP1 to "1" to notify the master station that current position latching by the external positioning signal is completed.
- 4. The slave station calculates "(External input positioning target P3) = (Position P2 latched by the external positioning signal) + (Travel distance for external input positioning (common parameter 83))" and performs positioning to external input positioning target P3.
- 5. After the completion of motion reference output to move the device to target position P3, the slave station sets the motion reference output completed flag (DEN) to "1" to notify the master station of the completion of motion reference output to move the device to target position P3.





Note:

- To cancel the external input feed, set SVCMD CTRL.CMD CANCEL to "1."
- The motion direction after latching is determined by the sign of the value set for the external positioning final travel distance.
- If the final travel distance for external positioning is a positive value:
  - After latching during motion in the positive direction, the motor rotates in the positive direction (the same direction) for positioning.
  - After latching during motion in the negative direction, the motor rotates in the positive direction (the reverse direction) for positioning.

If the final travel distance for external positioning is a negative value:

- After latching during motion in the positive direction, the motor rotates in the negative direction (the reverse direction) for positioning.
- After latching during motion in the negative direction, the motor rotates in the negative direction (the same direction) for positioning.



# 8.14.14 External Input Positioning Command (EX\_POSING: 39H)

(1) Data Format

Phases in which the Command can be Executed		2, 3	Command Classification	Servo standard command	Asynchronous command	
Processing Time com		Within communication cycle	Subcommand Can be used			
Byte	EX_PC	DSING		Description		
	Command	Response	The FY DOODIC	1		
0	39H	39H	• The EX_POSING command performs positioning in response to the input of the external positioning signal.			
1	WDT	RWDT	• To pause the extern SVCMD_CTRL_C	al input positioning, so MD_PAUSE to "1."	et	
3	CMD_CTRL	CMD_STAT	Confirm the compl checking that RCM	etion of the command $D = EX_POSING (= PDV = 1)$	execution by 39H) and	
4			CMD_STAT.CMD     Confirm the compl	KDY = 1. etion of latching by th	e latch signal by	
5	SVCMD CTRL	SVCMD STAT	<ul> <li>checking that SVC</li> <li>Confirm motion ret</li> </ul>	MD_CTRL.L_CMP1 ference output comple	= 1. tion by checking that	
6	SVEIND_CIRL	bvennb_bran	SVCMD_CTRL.D	EN = 1, and the complete $CMD$ $CTPL$ $DSET$	pletion of positioning	
7			Confirm the complete the c	etion of the cancellation	= 1. on of the command	
8			by checking that R CMD STAT.CMD	$CMD = EX_POSING$ RDY = 1 and	(= 39H),	
9	- SVCMD_IO SVCMD_IO		SVCMD_STAT.CN	ID_CANCEL_CMP =	= 1.	
10			checking that RCM CMD_STAT.CMD	$D = EX_POSING (= RDY = 1 and$	39H),	
11			SVCMD_STAT.CMD_PAUSE_CMP = 1.			
12			Monitor data can be selected by changing the common			
13		CDDM SEI	Parameters.		., common	
14	TPOS	MON1	<notes c<="" on="" td="" the="" using=""><td>ommand&gt;</td><td></td></notes>	ommand>		
15			• To send this comma of SVCMD_CTRL	and, select the latch sig and output the latch r	gnal with LT_SEL1 equest by setting	
16			• TPOS (target positi	on):		
17		CPRM SEL	<ul> <li>Set the target positi</li> <li>TSPD (target speed</li> </ul>	on with a signed value ):	2.	
18	TSPD	MON2	Set the target speed • ACCR (acceleration	with an unsigned value.	ue.	
19			Set the acceleration	with an unsigned value	ue.	
20			• DECR (deceleration): Set the deceleration with an unsigned value.			
21			When both ACCR     acceleration/decele	and DECR are "0", ration is performed ac	cording to the	
22	ACCR	MONITOR1	To perform two-ste	pacceleration/de	ation, set both ACCR	
23			and DECR to "0." I	For details, refer to 8.2	25.2 Positioning	
24			TLIM (torque limit Set the torque limit	): with an unsigned valu	16.	
25			• For the information	on the settings of the a	bove reference data,	
26	DECR MONITOR2		• For the units of cor	nmand values set in th	e command area,	
27			refer to 8.12.2 Spec In the following cases	<i>cifying Units</i> . s, an alarm will occur a	and the command	
28			<ul> <li>will not be executed.</li> <li>In the serve OFF st</li> </ul>	ate: CMD $AIM = AI$	H (A 95A)	
29	TI INA	MONUTOD?	• When the TSPD da	ta is invalid: CMD_A	LM = 9H (A.94B)	
30	I LIIVI	MONITORS	• when the ACCR of $CMD\_ALM = 9H$	(A.94B)	1.	
31			In the following case, an alarm will occur and the relevant value will be clamped at the limit value.			



#### (2) Operating Sequence

The following describes the operating sequence for external input positioning operation using the EX\_POSING command.

- 1. The master station sends the EX\_POSING command. Target position P1 is set in the "target position" field to be used as the positioning target if the external signal is not input. It selects the latch signal with LT\_SEL1 of SVCMD\_CTRL and outputs the latch request by setting LT\_REQ1 = 1.
- 2. The slave station starts feeding toward the positioning target position P1 at the specified speed when it receives the EX\_POSING command. At the same time, it enters the external input positioning mode.
- 3. When the external positioning signal is input, the slave station sets latch completion status L\_CMP1 to "1" to notify the master station that current position latching by the external positioning signal is completed.
- 4. The slave station calculates "(External input positioning target P3) = (Position P2 latched by the external positioning signal) + (Travel distance for external input positioning (common parameter 83))" and performs positioning to external input positioning target P3.
- 5. After the completion of motion reference output to move the device to target position P3, the slave station sets the motion reference output completed flag (DEN) to "1" to notify the master station of the completion of motion reference output to move the device to target position P3.



Note:

- To cancel the external input positioning, set SVCMD CTRL.CMD CANCEL to "1."
- The motion direction after latching is determined by the sign of the value set for the external positioning final travel distance.

If the final travel distance for external positioning is a positive value:

- After latching during motion in the positive direction, the motor rotates in the positive direction (the same direction) for positioning.
- After latching during motion in the negative direction, the motor rotates in the positive direction (the reverse direction) for positioning.

If the final travel distance for external positioning is a negative value:

- After latching during motion in the positive direction, the motor rotates in the negative direction (the reverse direction) for positioning.
- After latching during motion in the negative direction, the motor rotates in the negative direction (the same direction) for positioning.



# 8.14.15 Zero Point Return Command (ZRET: 3AH)

Denses in which the Command on the Executed         2.3         Command Classification         Servo standard Servo standard Command Castification         Asynchronous command           Processing Time         Within communication cycle         Subcommand         Can be used           0         3AH         3AH         Castification         Can be used           0         3AH         3AH         -         -           1         WDT         RWDT         -         -           2         CMD_CTRL         CMD_STAT         -         The ZRET command specifies the type of zero point return operation and performs the operation using the zero point imit switch and the position is specified by "latch signal selection".         -         -           2         CMD_CTRL         CMD_STAT         -         To gause the zero point return operation set system and execution by checking that SVCMD or proton reference output by checking that SVCMD or DIO DESCHET (SAL)         -	<u>(1)</u> Da	ta Format				1	
Processing Time         Within communication cycle         Subcommand         Can be used           Byte         ZRET         Description           0         3AH         3AH           1         WDT         RRyDT           2         CMD_CTRL         CMD_STAT           3         CMD_CTRL         CMD_STAT           4	Phases in which the Command can be Executed 2,		2, 3	Command Classification	Servo standard command	Asynchronous command	
Byte         ZRET         Description           0         3AH         3AH         *         The ZRET command specifies the type of zero point return operation and performs the operation using the zero point in the signal used to latch the position latch signal.         *           2         CMD_CTRL         CMD_STAT         *         The signal used to latch the position latch signal.         *           3         CMD_CTRL         CMD_STAT         *         To pause the zero point return operation, set         *           4         * </td <td colspan="2">Processing Time c</td> <td>Within communication cycle</td> <td colspan="2">Subcommand Can be used</td> <td>e used</td>	Processing Time c		Within communication cycle	Subcommand Can be used		e used	
0         3AH         3AH         The ZRET command specifies the type of zero point return imit switch and the position latch signal.           2         CMD_CTRL         CMD_STAT         The signal selection.         The signal selection.           3         CMD_CTRL         CMD_STAT         To pause the zero point return operation, set signal selection.         To pause the zero point return operation, set SVCMD_CTRL.         SVCMD_CTRL         To pause the zero point return operation by checking that SVCMD_PAUSE to "1."           6         SVCMD_CTRL         SVCMD_STAT         Confirm the completion of the command sectifies the type of zero point by the checking that SVCMD_PAUSE to "1."         To ause the zero point return operation, set SVCMD_PAUSE to "1."           7         SVCMD_IO         SVCMD_CTRL         Confirm the completion of more forence output by checking that SVCMD_IO_IENT = 1.         To ause the zero point system of the command SVCMD_OTENT = 1.         Confirm the completion of the command by checking that SVCMD_IO_IENT = 1.         Confirm the completion of the command by checking that SVCMD_CANCEL_CMP = 1.         Confirm the completion of the command by checking that SVCMD_CANCEL_CMP = 1.         Confirm the sompletion of the command by checking that SVCMD_CANCEL_CMP = 1.         Confirm the sompletion of the command by checking that SVCMD_CANCEL_CMP = 1.         Confirm the sompletion of the command by checking that SVCMD_CANCEL_CMP = 1.         Confirm the sompletion of the command by checking that some set to the command set to the common parameter setting. For details, refer to 8.27 Common Parameter setting. For	Byte	ZR Command	ET Response	]	Description		
I         WDT         RWDT           1         WDT         RWDT           2         CMD_CTRL         CMD_STAT           3         CMD_CTRL         CMD_STAT           4         -         -           5         SVCMD_CTRL         SVCMD_STAT           6         -         -           7         -         -           6         -         -           7         -         -           6         -         -           7         -         -           6         -         -           7         -         -           6         -         -           7         -         -           7         -         -           8         -         -           9         SVCMD_IO         SVCMD_IO         -           10         -         -         -           11         -         -         -           12         -         -         -           13         MODE         CPRM_SEL         -           14         MODE         CPRM_SEL         -	0	ЗАН	3AH	The ZRET comman	nd specifies the type of	f zero point return	
2       CMD_CTRL       CMD_STAT         3       CMD_CTRL       CMD_STAT         4	1	WDT	RWDT	limit switch and the	position latch signal.	ng the zero point	
3       CMD_CTRL       CMD_STAT         4	2	CMD CTDI	CMD STAT	• The signal used to 1 signal selection."	atch the position is sp	ecified by "latch	
4       5       SVCMD_CTRL       SVCMD_STAT         6       SVCMD_CTRL       SVCMD_STAT         7       Confirm the completion of motion reference output by checking that SVCMD [O.DRDY=1.         7       Confirm the completion of the cancellation of the command execution by checking that SVCMD [O.DRDY=1.         8       Confirm the completion of the cancellation of the command by checking that SVCMD [O.DRDY] = 1 and the completion of the cancellation of the command by checking that SVCMD [O.DRDY] = 1 and SVCMD STAT.CMD CANCEL_CMP = 1.         10       Onfirm the completion of the cancellation of the command by checking that SVCMD [O.DRDY] = 1 and SVCMD STAT.CMD [O.ANCEL_CMP = 1.         11       Confirm the completion of parameter setting. For details, refer to 8.27 Common parameter setting.         16       CPRM SEL_MON1CORM SEL_MON2         18       MON2         19       CPRM SEL_MON1COR         20       .         21       ACCR         22       ACCR         23       .         24       .         25       DECR         26       .         27       .         28       .         29 </td <td>3</td> <td>CMD_CTRL</td> <td>CMD_STAT</td> <td>• To pause the zero p</td> <td>oint return operation,</td> <td>set</td>	3	CMD_CTRL	CMD_STAT	• To pause the zero p	oint return operation,	set	
3       SVCMD_CTRL       SVCMD_STAT         6       SVCMD_CTRL       SVCMD_STAT         7       Confirm the completion of motion reference output by checking that SVCMD_1OPNET = 1, and the completion of positioning at the zero point by checking that SVCMD_1OPNET = 1.         9       SVCMD_1O       SVCMD_1O         10       SVCMD_1OPSET = 1.         11       Confirm the completion of the cancellation of the command by checking that RCMD = ZRET (= 3AH). (CMD STATCMD PARET (= 3AH). (CMD	4			Confirm the comple checking that RCM	etion of the command D = ZRET (= 3AH) at	execution by	
6       - Continu the completion of motion reference output by checking that SVCMD_IO.DEN = 1, and the completion of positioning at the zero point by checking that SVCMD_IO.PERT = 1.         9       SVCMD_IO       SVCMD_IO         10       0       SVCMD_IO.PERT = 1.         11       - Confirm the completion of the cancellation of the command by checking that RCMD = ZRET (= 3AH).         11       - Confirm the completion of pausing of the command by checking that RCMD = ZRET (= 3AH).         12       - Confirm the completion of pausing of the command by checking that RCMD = ZRET (= 3AH).         14       MODE       CPRM_SEL_MONI.CMD_STAT.CMD_PAUSE_CMP = 1.         15       - Confirm the completion of the common parameter setting. For details, refer to 8.27 Common Parameters.         16       - CPRM_SEL_MON2         17       TSPD       CPRM_SEL_MON2         18       TSPD       CPRM_SEL_MON2         19       - Costs on using the command-         20       - TSPD (target speed):       Set the acceleration with an unsigned value.         21       ACCR       MONITORI         22       ACCR       MONITORI       Set the acceleration with an unsigned value.         23       - DECR (deceleration is command value. Set the command value.       - For the information on the settings of the above reference data, refer to 8.14.20 Motino Command value.         2		SVCMD_CTRL	SVCMD_STAT	CMD_STAT.CMD	RDY=1.	iu	
7       positioning at the zero point by checking that         8       SVCMD_IO         9       SVCMD_IO_SVCMD_IO         10       SVCMD_IO_SVCMD_IO         11       Confirm the completion of the cancellation of the command by checking that RCMD = ZRET (= 3AH), CMD_ETALCMDRDY = 1 and SVCMD_STATCMD_RATEL_ONCEL_CMP = 1.         12       Confirm the completion of pausing of the command by checking that RCMD = ZRET (= 3AH), CMD_ETALCMDRDY = 1 and SVCMD_STATCMD_RATEL_MON1.         14       MODE       CPRM_SEL_MON1/CPRM_SEL_MON2:         15       SVCMD_IO       SVCMD_STATCMD_PAUSE_CMP = 1.         16       CPRM_SEL_MON1/CPRM_SEL_MON2:       Notes on using the command>         16       SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch request by setting LT_REQ1 = 1.         12       ACCR       MONITOR1         23       St the target speed with an unsigned value.         24       St the target speed with an unsigned value.	6			Confirm the comple checking that SVCI	MD_IO.DEN = 1, and	nce output by I the completion of	
8       9       SVCMD_IO       SVCMD_IO       SVCMD_IO         9       SVCMD_IO       SVCMD_IO       SVCMD_IO       SVCMD_IO         10       10       SVCMD_IO       SVCMD_IO       SVCMD_IO         11       11       Confirm the completion of the cancellation of the command by checking that RCMD = ZRET (= 3AH), CMD STAICMD_RANEL (= ATT CMD STAICMD_	7			- SVCMD_IO.ZPOI	ero point by checking NT (zero point positio	that $(n) = 1$ and	
9       SVCMD_IO       SVCMD_IO         10       SVCMD_IO       SVCMD_IO         11       III       by checking that RCMD = ZRET (= 3AH), CMD_STAT.CMDRDY = 1 and SVCMD_STAT.CMDRDY = 1 and SVCMD_STAT.STAT.CMDRDY = 1 and SVCMD_STAT.CMDRDY = 1 and SVCMD_STAT.CMDRDY = 1 and SVCMD_STAT.STAT.CMDRDY = 1 and SVCMD_STAT.STAT.CMDRDY = 1 and SVCMD_STAT.STAT.STAT.STAT.STAT.STAT.STAT.STAT	8			SVCMD_IO.PSET  • Confirm the completion	= 1.	on of the command	
10       -       -       CPRD_STATCMPCATCACC_CMP = 1.         11       SVCMD_STATCMPCATCACC_CMP = 1.       -       Confirm the completion of pausing of the command by checking that RCMD = ZRET (= 3AH).         12       .       CORF       CPRM_SEL_MON1/CPRM_SEL_MON2:         13       MODE       CPRM_SEL_MON1       -       CPRM_SEL_MON1/CPRM_SEL_MON2:         14       MODE       CPRM_SEL_MON1       -       -       CPRM_SEL_MON1/CPRM_SEL_MON2:         16       -       -       -       -       -       -       -         16       -	9	SVCMD IO	SVCMD IO	by checking that R	CMD = ZRET (= 3AE)	I),	
11       Confirm the completion of patising of the command by checking that RCMD = ZRET (= 3AH), CMD, STAT.CMD, PAUSE CMP = 1.         13       MODE       CPRM_SEL_MONI         14       MODE       CPRM_SEL_MONI/CPRM_SEL_MON2:         15       Monitor data can be selected by changing the common parameters setting. For details, refer to 8.27 Common Parameters.         16	10	_	5+0112_10	SVCMD_STAT.CM	1D_CANCEL_CMP =	= 1.	
12       CMD_STATCMDRDY = 1 and SVCMD_STATCMDRDY = 1 and SVCMD_STATCMDPAUSE_CMP = 1.         14       NODE       CPRM_SEL_MON1/CPRM_SEL_MON2: Monitor data can be selected by changing the common <i>parameters</i> .         15       NoT       SVCMD_STATCMDPAUSE_CMP = 1.         16        CPRM_SEL_MON1/CPRM_SEL_MON2: Monitor data can be selected by changing the common <i>parameters</i> .         16           17       TSPD       CPRM_SEL_MON2         18       TSPD       CPRM_SEL_MON2         19           20           21       ACCR       MONITORI         22            23           24           25       DECR       MONITOR2         26       DECR       MONITOR2         27           28           29           30       TLIM       MONITOR3         31       MONITOR3          31           31           31 <t< td=""><td>11</td><td></td><td></td><td colspan="3">• Confirm the completion of pausing of the command by checking that RCMD = ZRET (= 3AH),</td></t<>	11			• Confirm the completion of pausing of the command by checking that RCMD = ZRET (= 3AH),			
13       MODE       CPRM_SEL_MONI/CPRM_SEL_MON2: Monitor data can be selected by changing the common parameters.         15       MON1       PRM_SEL_MON1/CPRM_SEL_MON2: Monitor data can be selected by changing the common parameters.         16       Selected by changing the common parameters.       Provide the latch signal with LT_SEL1 of SVCMD_CTRL and output the latch request by setting LT_REQ1 = 1.         18       TSPD       CPRM_SEL_ MON2       TSPD (target speed): Set the target speed with an unsigned value.         20	12			CMD_STAT.CMDRDY = 1 and SVCMD_STAT.CMD_PAUSE_CMP = 1.			
14       MON1         15       MON1         15       Parameter setting. For details, refer to 8.27 Common Parameters.         16       TSPD         17       TSPD         18       TSPD         19       TSPD         20       Set the target speed): Set the target speed with an unsigned value.         20       Set the target speed): Set the target speed with an unsigned value.         21       ACCR         22       MONITORI         23       Set the deceleration with an unsigned value.         24       When both ACCR and DECR are "0", acceleration/deceleration, set both ACCR and DECR to "0." For details, refer to 8.25.2 Positioning Command.         24       TLIM (torque limit): Set the torque limit with an unsigned value.         25       DECR         26       TLIM (torque limit): Set the torque limit with an unsigned value.         27       TLIM (torque limit): Set the torque limit with an unsigned value.         28       TLIM         29       TLIM         30       TLIM MONITOR3	13	MODE	CPRM_SEL_	CPRM_SEL_MON Monitor data can be	11/CPRM_SEL_MON e selected by changing	V2: g the common	
15	14	WODE	MON1	parameter setting. For details, refer to 8.27 Common Parameters.			
16       Image: Second Se	15			<notes command="" on="" the="" using=""></notes>			
17       TSPD       CPRM_SEL_MON2_       1SPD (target speed): Set the target speed): Set the target speed): Set the target speed): Set the acceleration): Set the acceleration): Set the acceleration): Set the acceleration with an unsigned value.         20        DECR (deceleration): Set the acceleration or with an unsigned value.         21       ACCR       MONITORI         22        When both ACCR and DECR are "0", acceleration/deceleration is performed according to the parameter settings. To perform two-step acceleration/deceleration, set both ACCR and DECR to "0." For details, refer to 8.25.2 Positioning Command.         24           25       DECR       MONITOR2         26           27           28           29       TLIM       MONITOR3         30           30           31 <td< td=""><td>16</td><td></td><td></td><td>• To send this comma of SVCMD_CTRL LT_REO1 = 1</td><td>and, select the latch signand output the latch r</td><td>gnal with LT_SEL1 equest by setting</td></td<>	16			• To send this comma of SVCMD_CTRL LT_REO1 = 1	and, select the latch signand output the latch r	gnal with LT_SEL1 equest by setting	
18       MON2       Set the target speed with an unsigned value.         19       ACCR (acceleration): Set the acceleration with an unsigned value.         20       .       DECR (deceleration): Set the acceleration with an unsigned value.         21       ACCR       MONITOR1         22       ACCR       MONITOR1         23       Set the deceleration with an unsigned value.         24       .       .         24       .       .         25       DECR       MONITOR2         26       MONITOR2       .         27       .       .         28       .       .         29       TLIM       MONITOR3         30       TLIM       MONITOR3	17	TSPD	CPRM_SEL_	• TSPD (target speed):			
19       Set the acceleration with an unsigned value.         20       DECR (deceleration):         20       Set the deceleration with an unsigned value.         21       ACCR         22       MONITORI         23       Set the deceleration with an unsigned value.         23       When both ACCR and DECR are "0", acceleration/deceleration is performed according to the parameter settings. To perform two-step acceleration/deceleration, set both ACCR and DECR to "0." For details, refer to 8.25.2 <i>Positioning Command.</i> 24       TLIM (torque limit): Set the torque limit with an unsigned value.         25       DECR         26       MONITOR2         27       For the information on the settings of the above reference data, refer to 8.14.20 Motion Command Data Setting Method.         28       In the following cases, an alarm will occur and the command will not be executed.         29       In the servo OFF state: CMD_ALM = AH (A.95A)         30       TLIM         31       MONITOR3	18	1012	MON2	ACCR (acceleration	i):	ue.	
20       Set the deceleration with an unsigned value.         21       ACCR       MONITOR1         22       MONITOR1       • When both ACCR and DECR are "0", acceleration/deceleration is performed according to the parameter settings. To perform two-step acceleration/deceleration, set both ACCR and DECR to "0." For details, refer to 8.25.2 <i>Positioning Command.</i> 24       • TLIM (torque limit): Set the torque limit with an unsigned value.         25       DECR       MONITOR2         26       • For the information on the settings of the above reference data, refer to 8.14.20 Motion Command Data Setting Method.         28       • For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         29       TLIM         30       TLIM         31       MONITOR3	19			<ul><li>Set the acceleration with an unsigned value.</li><li>DECR (deceleration):</li></ul>			
21       ACCR       MONITOR1       When the OM in DERCAR OF 0, acceleration is performed according to the parameter settings.         22       is perform two-step acceleration/deceleration, set both ACCR and DECR to "0." For details, refer to 8.25.2 Positioning Command.         24       is perform two-step acceleration/deceleration, set both ACCR and DECR to "0." For details, refer to 8.25.2 Positioning Command.         25       DECR       MONITOR2         26       is the torque limit with an unsigned value.         27       For the information on the settings of the above reference data, refer to 8.12.2 Specifying Units.         28       in the following cases, an alarm will occur and the command will not be executed.         30       TLIM       MONITOR3         31       When the ACCR or DECR data is invalid: CMD_ALM = 9H (A.94B)         in the following case, an alarm will occur and the relevant value will be clamped at the limit value.	20			• When both ACCR	with an unsigned val	ue.	
22       ACCR       MONITORI       parameter settings. To perform two-step acceleration/deceleration, set both ACCR and DECR to "0." For details, refer to 8.25.2 Positioning Command.         24         TLIM (torque limit): Set the torque limit with an unsigned value.         25       DECR       MONITOR2          26         For the information on the settings of the above reference data, refer to 8.14.20 Motion Command Data Setting Method.         27         For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         28         In the following cases, an alarm will occur and the command will not be executed.         30             31       MONITOR3           When the ACCR or DECR data is invalid: CMD_ALM = 9H (A.94B)  .	21	ACCD	MONITOP 1	acceleration/decele	ration is performed ac	cording to the	
23       ACCR and DECR to "0." For details, refer to 8.25.2         24       Positioning Command.         25       DECR         26       MONITOR2         27       For the information on the settings of the above reference data, refer to 8.14.20 Motion Command Data Setting Method.         27       For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         28       In the following cases, an alarm will occur and the command will not be executed.         30       TLIM         30       TLIM         31       MONITOR3	22	ACCK	MONITORI	To perform two-ste	p acceleration/deceler	ation, set both	
24       • TLIM (torque limit):         25       DECR         26       MONITOR2         26       • For the information on the settings of the above reference data, refer to 8.14.20 Motion Command Data Setting Method.         27       • For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         28       • In the following cases, an alarm will occur and the command will not be executed.         30       TLIM         31       MONITOR3	23			ACCR and DECR t Positioning Commo	to "0." For details, refe	er to 8.25.2	
25       DECR       MONITOR2       • For the information on the settings of the above reference data, refer to 8.14.20 Motion Command Data Setting Method.         26        • For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         28           29           30       TLIM       MONITOR3         31       MONITOR3       • When the TSPD data is invalid: CMD_ALM = 9H (A.94B)              31	24			TLIM (torque limit Set the torque limit	): with an unsigned valu	le	
26       MONITOR2       data, refer to 8.14.20 Motion Commana Data Setting Method.         27       For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         28       In the following cases, an alarm will occur and the command will not be executed.         29       TLIM         30       TLIM         31       MONITOR3         When the TSPD data is invalid: CMD_ALM = 9H (A.94B)         In the following case, an alarm will occur and the relevant value will be clamped at the limit value.         When the TLIM data is invalid: CMD_ALM = 9H (A.94B)	25			For the information	on the settings of the	above reference	
27       • For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         28       In the following cases, an alarm will occur and the command will not be executed.         29       • In the servo OFF state: CMD_ALM = AH (A.95A)         30       • When the TSPD data is invalid: CMD_ALM = 9H (A.94B)         31       • When the ACCR or DECR data is invalid: CMD_ALM = 9H (A.94B)         In the following case, an alarm will occur and the relevant value will be clamped at the limit value.	26	DECR MONITOR2		Method.	U Motion Command	Data Setting	
28       In the following cases, an alarm will occur and the command will not be executed.         29       In the servo OFF state: CMD_ALM = AH (A.95A)         30       When the TSPD data is invalid: CMD_ALM = 9H (A.94B)         31       When the ACCR or DECR data is invalid: CMD_ALM = 9H (A.94B)         In the following case, an alarm will occur and the relevant value will be clamped at the limit value.	27			• For the units of com refer to 8.12.2 Spec	nmand values set in th cifying Units.	e command area,	
29       • In the servo OFF state: CMD_ALM = AH (A.95A)         30       • When the TSPD data is invalid: CMD_ALM = 9H (A.94B)         • When the ACCR or DECR data is invalid: CMD_ALM = 9H (A.94B)         • In the following case, an alarm will occur and the relevant value will be clamped at the limit value.	28	<u> </u>	<u> </u>	In the following cases will not be executed	, an alarm will occur	and the command	
30       30         31       MONITOR3         • When the ACCR or DECR data is invalid: CMD_ALM = 9H (A.94B)         In the following case, an alarm will occur and the relevant value will be clamped at the limit value.         • When the ACCR or DECR data is invalid: CMD_ALM = 9H (A.94B)	29		MONTODA	<ul><li>In the servo OFF st</li><li>When the TSPD date</li></ul>	ate: CMD_ALM = Al ta is invalid: CMD_A	H (A.95A) LM = 9H (A.94B)	
31 When the TLIM – JLIM – JLI	30	TLIM	MONITOR3	• When the ACCR of $CMD$ AI M = $0H$	T DECR data is invalid (A 94B)	d:	
	31			CMD_ALM = 9H (A.94B) In the following case, an alarm will occur and the relevant value will be clamped at the limit value.			



#### (2) Command-specific Data

The following describes the data specific to the ZRET command.

Ν	AODE (Lower	l byte)					
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
HOME_DIR	Reserved	Reserved	Reserved		TY	PE	

- MODE.HOME\_DIR (Zero point return direction) Selects the zero point return direction.

MODE.HOME DIR = 0: Positive direction

MODE.HOME DIR = 1: Negative direction

- MODE.TYPE (Zero point return type)

Sets the zero point return type on selection of the type from the patterns below. MODE.TYPE = 0: Latch signal MODE.TYPE = 1: Deceleration limit switch + Latch signal

MODE.11FE = 1. Deceneration limit switch + Late

#### (3) Operating Sequence

The following describes the zero point return operating sequence for each of the zero point return modes.

- 1. MODE = 0 (Latch Signal)
  - The master station sends the ZRET command. It selects the latch signal with LT\_SEL1 of SVCMD\_CTRL and outputs the latch request by setting LT\_REQ1 = 1.
  - (2) The slave station starts feeding in the direction specified by MODE.HOME\_DIR at the speed set for the Homing Approach Speed (common parameter 84).
  - (3) When the current position latch signal, specified by LT\_SEL1 of SVCMD\_CTRL, is input, the slave station executes positioning through the movement of the Final Travel Distance for Homing (common parameter 86) at the Homing Creep Speed (common parameter 85). After the completion of positioning, the slave station sets the zero point of the reference coordinate system.



- 2. MODE = 1 (Deceleration Limit Switch Signal + Latch Signal)
  - The master station sends the ZRET command. It selects the latch signal with LT\_SEL1 of SVCMD\_CTRL and outputs the latch request by setting LT\_REQ1 = 1.
  - (2) The slave station starts feeding in the direction specified by MODE.HOME\_DIR at the speed set in the "TSPD" field.
  - (3) When the "deceleration limit switch" is closed (DEC = 1), the feed speed is switched to the Homing Approach Speed (common parameter 84).
  - (4) When the current position latch signal, specified by LT\_SEL1 of SVCMD\_CTRL, is input after the "deceleration limit switch" is opened (DEC = 0), the slave station executes positioning through the movement of the Final Travel Distance for Homing (common parameter 86) at the Homing Creep Speed (common parameter 85). After the completion of positioning, the slave station sets the zero point of the reference coordinate system.



Note:

The motion direction after latching is determined by the sign of the value set for the Final Travel Distance for Homing.

- If the Final Travel Distance for Homing is a positive value:
  - After latching during motion in the positive direction, the motor rotates in the positive direction (the same direction) for positioning.

- After latching during motion in the negative direction, the motor rotates in the positive direction (the reverse direction) for positioning. (With ZRET in the MECHATROLINK-II compatible profile, the motor rotates in the negative direction (the same direction) for positioning.)

- If the Final Travel Distance for Homing is a negative value:
  - After latching during motion in the positive direction, the motor rotates in the negative direction (the reverse direction) for positioning.
  - After latching during motion in the negative direction, the motor rotates in the negative direction (the same direction) for positioning. (With ZRET in the MECHATROLINK-II compatible profile, the motor rotates in the positive direction (the reverse direction) for positioning.)



# 8.14.16 Velocity Control Command (VELCTRL: 3CH)

Phases in which the Command can be Executed		2, 3	Command Classification	Servo standard command	Asynchronous command	
Processing Time		Within communication cycle	Subcommand Can be used		e used	
Byte	VELO	CTRL		Description		
Dyte	Command	Response		Decomption		
0	ЗСН	3CH	• The VELCTRL con	mmand sends the speed	d reference to a slave	
1	WDT	RWDT	speed control direc	tly without position co	ntrol.	
$\frac{2}{3}$	CMD_CTRL	CMD_STAT	• To cancel the speed 0 or set SVCMD_C	control, set the speed CTRL.CMD_CANCEI	reference as VREF = L to "1."	
4			• To pause the speed SVCMD_CTRL_C	control, set MD_PAUSE to "1."		
5			• Confirm the compl	etion of the command	execution by check-	
6	SVCMD_CTRL	SVCMD_STAT	ing that $RCMD = V$ CMD STAT.CMD	/ELCTRL (= 3CH) an RDY = 1.	d	
7			• To cancel the speed 0 or set SVCMD_C	control, set the speed	reference as VREF =	
8			Confirm the arrival reference (VREF)	of the feedback speed by checking that SVC	l at the speed MD IO.V CMP =	
9	SVCMD IO	SVCMD IO	1.			
10		SVCMD_IO	• Confirm the completion of pausing of the command by checking that RCMD = VELCTRL (= 3CH),			
11			CMD_STAT.CMD	T.CMDRDY = 1 and TAT CMD PAUSE CMP = 1		
12			CPRM_SEL_MON	N1/CPRM_SEL_MON	2:	
13	TEE	CPRM SEL	Monitor data can be selected by changing the common parameter setting. For details, refer to 8.27 <i>Common</i>			
14	lff	MON1	Parameters.			
15			<notes c<="" on="" td="" the="" using=""><td>command&gt;</td><td></td></notes>	command>		
16			<ul> <li>VREF (Velocity ref Set the speed refere</li> </ul>	erence): ence with a signed valu	ie	
17		CPRM SEL	• TFF (torque feedfor	rward):		
18	VREF	MON2	Set the torque feedforward value with a signed Use it as a torque (force) feedforward function		igned value. ction.	
19			• ACCR (acceleration):			
20			DECR (deceleration	n):	ue.	
21			<ul> <li>Set the deceleration</li> <li>TLIM (torque limit)</li> </ul>	n with an unsigned val	ue.	
22	ACCR	MONITOR1	Set the torque limit	with an unsigned valu	le.	
23	-		• For the information refer to 3.2.20 Mot	i on the settings of the a tion Command Data Set	above reference data, etting Method.	
24			<ul> <li>For the units of command values set in the command area, refer to 8.12.2 Specifying Units.</li> <li>If the command is sent in the servo OFF state (SVON = 0), the command is sent in the serve of the serve</li></ul>			
25	DECD					
26	- DECR MONITOR2		(SVON = 1) is esta	blished.	e servo UN state	
27			In the following case, an alarm will occur and the command wil			
28			not be executed.			
29	TT IN #	MONITOP2	• When the ACCR o $CMD_ALM = 9H$	r DECR data is invalic (A.94B)	1:	
30		MONITOK3	In the following cases will be clamped at the	, an alarm will occur a	nd the relevant value	
31			<ul> <li>When the VREF data is invalid: CMD_ALM = 1H (A.94B)</li> <li>When the TLIM data is invalid: CMD_ALM = 1H (A.94D)</li> </ul>			



### 8.14.17 Torque (Force) Control Command (TRQCTRL: 3DH)

Processing Time         Within communication cycle         Subcommand         Can be used           Byte         TROCTRL         Description           0         3DH         3DH           1         WDT         RWDT           2         CMD_CTRL         CMD_STAT           3         CMD_CTRL         CMD_STAT           4	Phases in which the Command can be Executed		2, 3	CommandServo standardAsynclClassificationcommandcom		Asynchronous command		
Byte         TRQCTRL         Description           0         3DII         3DII         3DII           1         WDT         RWDT         to a slave station to performs torque (force) control. The slave station operforms torque control directly without speed control and position control.           2         CMD_CTRL         CMD_STAT         Compare control.         Compare control.           3         CMD_CTRL         CMD_STAT         Compare control.         Compare control.         Compare control.           4         SVCMD_CTRL         CMD_STAT         SVCMD_STAT         Compare control.         Co	Processing Time co		Within communication cycle	Subcommand Can be used				
Description         Description           0         3DH         3DH           1         WDT         RWDT           2         CMD_CTRL         RWDT           3         CMD_CTRL         CMD_STAT           3         CMD_CTRL         CMD_STAT           4         -         -           5         SVCMD_CTRL         CMD_STAT           6         SVCMD_TO         SVCMD_STAT           7         -         -           8         -         -           9         SVCMD_IO         SVCMD_IO           10         SVCMD_IO         SVCMD_IO           11         -         CPRM_SEL_MON1/CPRM_SEL_MON2:           11         -         -           12         -         -           8         -         -           9         SVCMD_IO         SVCMD_IO           10         SVCMD_IO         -           11         -         -           12         -         -           13         VLIM         CPRM_SEL_MON1           15         -         -           16         -         -           17 <t< td=""><td>Byte</td><td>TRQ</td><td>CTRL</td><td></td><td>Description</td><td></td></t<>	Byte	TRQ	CTRL		Description			
0       3DH       3DH         1       WDT       RWDT         2       CMD_CTRL       RWDT         3       CMD_CTRL       CMD_STAT         3       CMD_CTRL       CMD_STAT         4       Confirm the completion of the command execution by check-ing that RCMD = TRQCTRL (= 3DH) and CMD STATCTORDRD = 1.         5       SVCMD_CTRL       SVCMD_STAT         6       SVCMD_CTRL       SVCMD_STAT         7       SVCMD_TO       SVCMD_TO         7       SVCMD_TO       SVCMD_TO         10       SVCMD_TO       SVCMD_TO         11       SVCMD_TO       SVCMD_TO         12       SVCMD_TO       SVCMD_TO         13       VLIM       CPRM_SEL_MON1         14       VLIM       CPRM_SEL_MON1         15       TQREF       CPRM_SEL_MON2         16       TQREF       CPRM_SEL_MON2         19       MONITOR1       If the command is sent in the servo OFF state (SVON = 0), the command back set on the relevant value will be clamped at the limit value.         20       MONITOR1       MONITOR2         21       MONITOR3       MONITOR3	Dyte	Command	Response	Description				
1     WDT     RWDT       2     CMD_CTRL     RWDT       3     CMD_CTRL     CMD_STAT       3     CMD_CTRL     CMD_STAT       4     Confirm the completion of the command execution by checking that RCMD = TRQCTRL (= 3DH) and CMD_STATCMDRDY = 1.       5     SVCMD_CTRL     SVCMD_STAT       6     CPRM_SEL_MONICPRM_SEL_MONIC       7     CPRM_SEL_MONICPRM_SEL_MONIC       8     CPRM_SEL_MONICPRM_SEL_MONIC       9     SVCMD_IO       10     SVCMD_IO       11     SVCMD_IO       12     CPRM_SEL_MONIC       13     VLIM       14     VLIM       15     CPRM_SEL_MONIC       16     CPRM_SEL_MONIC       17     TQREF       18     TQREF       19     MONITOR1       20     MONITOR1       21     MONITOR1       22     MONITOR2       23     MONITOR3	0	3DH	3DH	• The TRQCTRL con	mmand sends the torqu	ue (force) reference		
2       CMD_CTRL       CMD_STAT         3       CMD_CTRL       CMD_STAT         4       Confirm the completion of the command execution by checking that RCMD = TRQCTRL (= 3DH) and CMD_STAT.CMDRDY = 1.         5       SVCMD_CTRL       SVCMD_STAT         6       CPRM_SEL_MON1/CRM SEL_MON2:         7       CPRM_SEL_MON1/CRM SEL_MON2:         9       SVCMD_IO       SVCMD_IO         10       SVCMD_IO       SVCMD_IO         11       CPRM_SEL_MON1/CRM SEL_MON2:         12       VLIM       CPRM_SEL_MON1/CI         13       VLIM       CPRM_SEL_MON1/C         14       VLIM       CPRM_SEL_MON1/C         15       CPRM_SEL_MON1/C       Setting the command >         16       CPRM_SEL_MON1/C       For the units of command values set in the command area, refer to 8.14.20 Motion Command Data Setting Method.         17       TQREF       CPRM_SEL_MON2/C         18       TQREF       MON1/C         20       MON1/C       MON1/C         21       MON1/C       MON1/C         22       MON1/C       MON1/C         23       MON1/C       MON1/C         24       MON1/C       MON1/C         22       MON1/C       MON1/C	1	WDT	RWDT	station performs to	rque control directly w	e) control. The slave vithout speed control		
3       CMD_CTRL       CMD_STAT         4	2	CMD CTRI	CMD STAT	and position contro	1.			
4       CMD_STAT.CMDRDY = 1.         5       SVCMD_CTRL         6       SVCMD_STAT         7       CPRM_SEL_MONI/CPRM_SEL_MON2: Monitor data can be selected by changing the common parameter setting. For details, refer to 8.27 Common Parameters.         8	3	ewib_erike	CNID_51/4	• Confirm the compl ing that RCMD = T	etion of the command ROCTRL (= 3DH) ar	execution by check-		
5       SVCMD_CTRL       SVCMD_STAT       CPRM_SEL_MON1/CPRM_SEL_MON2: Monitor data can be selected by changing the common parameter setting. For details, refer to 8.27 Common Parameters.         8       9       SVCMD_IO       SVCMD_IO         10       SVCMD_IO       SVCMD_IO	4			CMD_STAT.CMD	RDY = 1.			
6       DYCHD_DIN       DYCHD_DIN         7       1       DYCHD_DIN         8       9       SVCMD_IO       SVCMD_IO         10       10       SVCMD_IO       SVCMD_IO         11       11       YLIM       CPRM_SEL_MONI       Set the torque reference with a signed value.         12       YLIM       CPRM_SEL_MONI       Set the speed limit with an unsigned value.         14       YLIM       CPRM_SEL_MONI       Set the speed limit with an unsigned value.         14       YLIM       CPRM_SEL_MONI       Set the speed limit with an unsigned value.         16       SIL2_Specifying Units.       If the command is sen in the servo OFF state (SVON = 0), the command becomes effective next time the servo ON state (SVON = 1) is established.         17       TQREF       CPRM_SEL_MON2         18       TQREF       CPRM_SEL_MON2         19       Wonno       When the TQREF fact as invalid: CMD_ALM = 1H (A.94B)         20       MONITOR1       When the VLIM data is invalid: CMD_ALM = 1H (A.94B)         21       MONITOR2       When the VLIM data is invalid: CMD_ALM = 1H (A.94B)         22       MONITOR3       MONITOR3       State	5	SVCMD CTRI	SVCMD STAT	<ul> <li>CPRM_SEL_MON Monitor data can be</li> </ul>	11/CPRM_SEL_MON e selected by changing	2: The common		
7       Parameters.         8       •         9       SVCMD_IO         10       SVCMD_IO         11       ·         12       ·         13       VLIM         14       ·         15       ·         16       ·         17       TQREF         18       ·         19       ·         20       ·         21       MON1         22       ·         23       ·         24       ·         25       Reserved         MONITOR3       MONITOR3	6	SVEWD_CIKE	SVCND_SIM	parameter setting. I	For details, refer to 8.2	27 Common		
8	7			Parameters.				
9       SVCMD_IO       SVCMD_IO       SVCMD_IO         10       SVCMD_IO       SVCMD_IO       SVCMD_IO         11       11        Structure       Set the torque reference with a signed value.         12              13       VLIM       CPRM_SEL_MONI             14       VLIM       CPRM_SEL_MONI   <	8			<notes c<="" on="" td="" the="" using=""><td>ommand&gt;</td><td></td></notes>	ommand>			
10       OFERE_10       OFERE_10       Set the locide reference with a signed value.         11       11       ····································	9	SVCMD 10	SVCMD IO	• TQREF (Torque reference):				
11       Set the speed limit with an unsigned value.         12	10	5, 6, 10		• VLIM (Velocity lim	inth a signed value.			
12	11			Set the speed limit with an unsigned value.				
13       VLIM       CPRM_SEL_MON1       • For the units of command values set in the command area, refer to 8.12.2 Specifying Units.         15        If the command is sent in the servo OFF state (SVON = 0), the command becomes effective next time the servo ON state (SVON = 1) is established.         17       TQREF       CPRM_SEL_MON2         19        In the following cases, an alarm will occur and the relevant value will be clamped at the limit value.         20           21        MONITOR1         22           23        MONITOR2         24           25       Reserved       MONITOR2         30        MONITOR3	12			• For the information on the settings of the above reference of refer to 8 14 20 Motion Command Data Setting Method				
14     MON1     refer to 8.12.2 Specifying Units.       15     If the command becomes effective next time the servo OF state (SVON = 0), the command becomes effective next time the servo ON state (SVON = 1) is established.       17     TQREF     CPRM_SEL_MON2       18     TQREF     CPRM_SEL_MON2       19	13	VLIM	CPRM_SEL_	<ul> <li>For the units of command values set in the command area, refer to 8.12.2 Specifying Units.</li> <li>If the command is cont is the common OFE state (SVON = 0), the</li> </ul>				
15     In the command becomes effective next time the serve ON state (SVON = 0), the command becomes effective next time the serve ON state (SVON = 1) is established.       17     TQREF       18     CPRM_SEL_MON2       19     In the following cases, an alarm will occur and the relevant value will be clamped at the limit value.       20     In the following cases, an alarm will occur and the relevant value will be clamped at the limit value.       20     When the TQREF data is invalid: CMD_ALM = 1H (A.94B)       21     MONITOR1       22     MONITOR1       23     MONITOR2       24     MONITOR2       27     MONITOR3	14		MON1					
16       IT       TQREF       CPRM_SEL_MON2       In the following cases, an alarm will occur and the relevant value will be clamped at the limit value.         19             20             20             21             22             23             24             25         MONITOR1          28             30             30             30             31	15			command becomes	effective next time th	e servo ON state		
17 18TQREFCPRM_SEL_ MON2In the following cases, an alarm will occur and the relevant value will be clamped at the limit value.19	16			(SVON = 1) is estable	blished.			
$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	17	TOREF	CPRM_SEL_	In the following cases	, an alarm will occur a	nd the relevant value		
19       • when the TQKEP data is invalid: CMD_ALM = TH (A.94B)         20	18		MON2	will be clamped at the	e limit value.	$\mathbf{AIM} = \mathbf{1H} \left( \mathbf{A} 0 4 \mathbf{P} \right)$		
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	19			<ul> <li>When the TQREF data is invalid: CMD_ALM = 1H (A.94B)</li> <li>When the VLIM data is invalid: CMD_ALM = 1H (A.94B)</li> </ul>				
21     MONITOR1       23     24       24     MONITOR2       25     Reserved       26     MONITOR2       27     MONITOR2       28     MONITOR3       30     MONITOR3	20				_			
22	21		MONITOR1					
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	22							
24     MONITOR2       26     MONITOR2       27     MONITOR3       28     MONITOR3	23			-				
2.5     Reserved     MONITOR2       26     27	24							
20       27       28       29       30       31	23	Reserved MONITOR2						
28           29           30           31	20							
29         MONITOR3           30         31	28			4				
30 31 MONITOR3	29							
31	30		MONITOR3					
	31							

### 8.14.18 Read Servo Parameter Command (SVPRM\_RD: 40H)

(1) Data Format

Phases in which the Command can be Executed		2, 3	Command Classification	Servo standard command	Asynchronous command	
Processing Time		Within 200 ms	Subcommand Cannot be used		be used	
SVPR		M_RD	Description			
Dyte	Command	Response		Description		
0	40H	40H	The SVPRM_RD command reads the servo parameters on			
1	WDT	RWDT	specification of the s read mode.	servo parameter numbe	er, data size, and the	
2	CMD CTRL	CMD STAT	Select the parameter	type (common parame	eter or device	
3		e	parameter) in the rea	id mode to read the con	rresponding servo	
4			Confirm the complet	tion of the command ex	ecution by checking	
5	SVCMD CTRL SVCMD STAT		that RCMD = SVPR	$M_RD$ (= 40H) and $DV = 1$ and also check	king the setting for	
6	_	—	NO, SIZE and MOE	DE.	sking the setting for	
7			In the following acces	on alarma uvill a agur T	Do not rood DADAM	
8			ETER in the response	in these cases because	the PARAMETER	
9	SVCMD IO SVCMD IO		value will be indefinite			
10		_	<ul> <li>When the NO data is invalid: CMD_ALM = 9H (A.94A)</li> <li>When the SIZE data is invalid: CMD_ALM = 9H (A.94F)</li> </ul>			
11			• When the MODE data is invalid: CMD_ALM = 9H (A.94B)			
12	NO	NO	• While editing using SigmaWin+: CMD_ALM = AH (A.95			
13	OLZE	017E	_			
14	SIZE	SIZE				
15	MODE	MODE				
16						
17						
10						
20						
20						
22						
23						
24	Reserved	PARAMETER				
25						
26						
27						
28						
29						
30						
31						

### (2) Command Parameters

NO: Servo parameter number

SIZE: Servo parameter data size [byte]

MODE: Servo parameter read mode

Servo Parameter Type	Reading Source	Mode Setting
Common Parameters	RAM area	00H
Device Parameter	RAM area	10H

PARAMETER: Servo parameter data



### 8.14.19 Write Servo Parameter Command (SVPRM\_WR: 41H)

(1) Data Format

Phases in which the Command can be Executed		2, 3	Command Classification	Servo standard command	Asynchronous command	
Processing Time		Within 200 ms	Subcommand Cannot be used			
SVPRI		M_WR	Description			
Буге	Byte Command Response			Description		
0	41H	41H	The SVPRM_WR command writes the servo parameters or specification of the servo parameter number data size and			
1	WDT	RWDT	specification of the s	servo parameter numbe	er, data size, and	
2	CMD CTRI	CMD STAT	Select the parameter	type (common parame	eter or device	
3	CMID_CTRE	CMD_51AI	parameter) and the v	writing destination (RA write mode to write th	M area or retentive	
4			servo parameter.	write mode to write in	e corresponding	
5	SVCMD CTRL	SVCMD STAT	• When specifying off	line parameters, the CO	ONFIG command	
6	STORE_CITE	Svening_Shiri	Confirm the comple	tion of the command ex	Recution by checking	
			that $RCMD = SVPR$	$M_WR (= 41H)$ and $PV = 1$ and also also also	tring the setting for	
8				and PARAMETER.	king the setting for	
9	SVCMD_IO	SVCMD_IO		1.1 1		
10			In the following cases, an alarm will occur and the command will not be executed.			
12			<ul> <li>When the NO data is invalid: CMD_ALM = 9H (A.94A)</li> <li>When the SIZE data is invalid: CMD_ALM = 9H (A.94D)</li> <li>When the SIZE data is invalid: CMD_ALM = 9H (A.94D)</li> </ul>			
12	NO	NO				
14	SIZE	SIZE	When the PARAME	TER data is invalid:	LM – 9П (А.94 <b>Б</b> )	
15	MODE	MODE	$CMD_ALM = 9H(A)$	A.94B)		
16			• While editing using	SigmaWin+: CMD_A	LM = AH (A.95A)	
17						
18						
19						
20						
21						
22						
23						
24	PAKAMETEK	PAKAMETEK				
25						
20						
- 28						
20						
30						

(2) Command Parameters

NO: Servo parameter number

SIZE: Servo parameter data size [byte]

MODE: Servo parameter write mode

Servo Parameter Type	Writing Destination	Mode Setting
Common Parameters	RAM area	00H
	Retentive memory area	01H
Device Parameter	RAM area	10H
	Retentive memory area	11H

PARAMETER: Servo parameter data



### 8.14.20 Motion Command Data Setting Method

This subsection provides information on the settings of the following data fields of the motion commands: TSPD, VREF, VFF, TREF, TFF, TLIM, VLIM, ACCR and DECR.

Name	Description	Setting	CMD_ALM Warning Code	Operation for the Setting			
		FEED, EX_FEED: Set signed 4-b	yte data.				
		-Maximum commandable speed <sup>*1</sup> to + Maximum com- mandable speed	0H Normal	Operates according to the setting.			
		Other than above	9H A.94B	Ignores the command and continues the previous command.			
TSPD	Target speed	POSING, EX_POSING, ZRET: Se	et unsigned 4-b	byte data.			
		0 to Maximum commandable speed and also TSPD ≤ 7FFFFFFFH	0H Normal	Operates according to the setting.			
		Other than above	9H A.94B	Ignores the command and continues the previous command.			
		Set signed 4-byte data.					
VREF VFF	Velocity reference, Velocity feed- forward value	-Maximum output speed <sup>*2</sup> to +Maximum output speed	0H Normal	Operates according to the setting.			
		Other than above	1H A.97B	Operates with the speed clamped at the maximum output speed.			
	-	Set signed 4-byte data.					
TQREF TFF	Torque reference, Torque feed-	-Maximum torque to +Maximum torque	0H Normal	Operates according to the setting.			
	forward value	Other than above	1H A.97B	Operates with the torque clamped at the maximum torque.			
		Set the limit with unsigned 4-byte	data.				
		0 to Maximum torque	0H Normal	Operates according to the setting.			
TLIM	Torque limit	Maximum torque or greater	1H A.97B	Operates with the torque clamped at the maximum torque.			
	*	80000000H to FFFFFFFEH	1H A.97B	DRIVER processes as TLIM = 7FFFFFFFH internally.			
		FFFFFFFH	0H Normal	No torque limit applies. (The torque is clamped at the maximum torque and the alarm CMD_ALM does not occur.)			

Name	Description	Setting	CMD_ALM Warning Code	Operation for the Setting		
		Set the limit with unsigned 4-byte	e data.			
		0 to Maximum output speed <sup>*2</sup>	0H Normal	Operates according to the setting.		
VLIM	Speed limit	Maximum output speed or greater	1H A.97B	Operates with the speed clamped at the maximum output speed.		
	1	80000000H to FFFFFFFEH	1H A.97B	DRIVER processes as VLIM = 7FFFFFFFH internally.		
		FFFFFFFH	0H Normal	No speed limit applies. (The speed is clamped at the maximum output speed and the alarm CMD_ALM does not occur.)		
		Set the acceleration/deceleration v	with unsigned	4-byte data.		
ACCR DECR		1 to Maximum acceleration <sup>*3</sup> Maximum deceleration	0H Normal	Operates according to the setting.		
	Acceleration, Deceleration (position control)	Maximum acceleration or greater Maximum deceleration or greater	9H A.94B	Ignores the command and continues the previous command.		
		0, 80000000H to FFFFFFFEH	9H A.94B	Ignores the command and continues the previous command.		
		FFFFFFFH	0H Normal	Operates at the maximum acceleration/deceleration and the alarm CMD_ALM does not occur.		
		Both ACCR and DECR are set at "0."	0H Normal	Acceleration/deceleration is performed according to the parameter settings.		
		Set the acceleration/deceleration with unsigned 4-byte data.				
		Unit: $\times 10^{n}$ [Reference unit/s <sup>2</sup> ]	1			
		1 to Maximum acceleration Maximum deceleration	0H Normal	Operates according to the setting.		
ACCR DECR	Acceleration, Deceleration (speed control)	Maximum acceleration or greater Maximum deceleration or greater	9H A.94B	Ignores the command and continues the previous command.		
		0, 80000000H to FFFFFFFEH	9H A.94B	Ignores the command and continues the previous command.		
		FFFFFFFFH	0H Normal	Operates at the maximum acceleration/deceleration and the alarm CMD_ALM does not occur.		
		Both ACCR and DECR are set at "0."	9H A.94B	Ignores the command and continues the previous command.		

\*1. Maximum commandable speed = 2097152000 [Reference unit/s]

\*2. Maximum output speed = Common parameter 05

\*3. Maximum acceleration/deceleration = 209715200000 [Reference unit/s<sup>2</sup>]

### 8.15 Subcommands

The following table shows the subcommands.

For information on the combinations of main commands and subcommands, refer to 8.5.4 *Combinations of Main Commands and Subcommands*.

Profile	Command Code	Command	Operation	Communication Phases <sup>*2</sup>			
	(Hex.)			1	2	3	
	00	NOP	No operation	-	0	0	
	05	ALM_RD <sup>*1</sup>	Read alarm/warning	-	0	0	
	06	ALM_CLR	Clear alarm/warning state	_	0	0	
Servo Commands	1D	MEM_RD <sup>*1</sup>	Read memory command	_	0	0	
Serve Communes	1E	MEM_WR <sup>*1</sup>	Write memory command	_	0	0	
	30	SMON	Monitor servo status	_	0	0	
	40	SVPRM_RD <sup>*1</sup>	Read servo parameter	_	0	0	
	41	SVPRM_WR	Write servo parameter	_	0	0	

\*1. Specification restrictions apply (Refer to the subsection describing each command for the details of the restrictions.)

\*2.  $\circ$  : Can be executed,  $\Delta$ : Ignored,  $\times$ : Command error, -: Indefinite response data

# 8.15.1 No Operation Subcommand (NOP: 00H)

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command	
Pro	cessing Time	Within communication cycle				
Byte	NC	)P	Description			
Dyte	Command	Response	]	Description		
32	00H	00H	The NOP subcomm	hand is used for networ	rk control.	
33			Confirm the comple checking that RSU	etion of the subcomma BCMD = NOP (= 00H	nd execution by	
34	SUB_CTRL	SUB_STAT	SUB_STAT.SBCM	DRDY = 1.		
35						
36						
37						
38						
39						
40						
41	Pecerved	Pecerved				
42	ixesei veu	ixesei veu				
43						
44						
45						
46						
47						

# 8.15.2 Read Alarm or Warning Subcommand (ALM\_RD: 05H)

### (1) Data Format

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command	
Pro	cessing Time	Refer to the specifications of ALM_RD_MOD				
Byte	ALM	_RD		Description		
Dyte	Command	Response		Description		
32	05H	05H	• The ALM_RD sub	command reads the cu	rrent alarm or	
33			<ul> <li>warning state as an</li> <li>Confirm the completion</li> </ul>	alarm or warning code	e. and execution by	
34	SUB_CTRL	SUB_STAT	checking that RSUBCMD = ALM_RD (= 05H) and SUB_STAT.SBCMDRDY = 1.			
35						
36	ALM PD MOD	ALM PD MOD	In the following cases, an alarm will occur and the subcomman will not be executed.			
37	ALM_KD_MOD	ALW_KD_WOD				
38	ALM INDEX	ALM INDEX	• when the ALM_RI CMD ALM = 9H	(A.94B)	1.	
39	MEM_INDEX	ALM_NOLA	• When the ALM_IN	DEX data is invalid:		
40			$CMD_ALM = 9H$	(A.94B)		
41						
42						
43	Peserved	ΔΙΜ ΠΑΤΑ				
44	ixesei veu	ALWI_DAIA				
45						
46						
47						

### (2) Command Parameters

The details of ALM\_RD\_MOD are described below.

ALM_RD_MOD	Description	Processing Time
0	Current alarm or warning state Maximum of 4 records (from byte 40 to byte 47)	Within communication cycle
1	Alarm occurrence status history (Warnings are not retained in the history.) Maximum of 4 records (from byte 40 to byte 47)	Within 60 ms

### 8.15.3 Clear Alarm or Warning Subcommand (ALM\_CLR: 06H)

#### (1) Data Format

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command	
Pro	cessing Time	Refer to the specifications of ALM_RD_MOD	Subcommand			
Byte	ALM_	_CLR	Description			
Dyte	Command	Response		Description		
32	06H	06H	• The ALM_CLR sul	bcommand clears the a	larm or warning	
33			eliminate the cause	of the alarm or warnin	g. ALM CLR	
34	SUB_CTRL	SUB_STAT	should be used to c	lear the state after the c	cause of the alarm or	
35			warning has been eliminated.			
36	ALM CLP MOD	ALM CLP MOD	checking that RSUBCMD = ALM_CLR (= 06H) and SUB_STAT.SBCMDRDY = 1.			
37	ALM_CLK_MOD	ALM_CLK_MOD				
38			In the following cases	, an alarm will occur a	nd the subcommand	
39			will not be executed.	D MOD data is invest	: <b>.</b> .	
40			• when the ALM_CI SUBCMD ALM =	<sup>2</sup> 9H (A.94B)	Id.	
41			• While editing using	g SigmaWin+:		
42	Peserved	Pecerved	SUBCMD_ALM =	FAH (A.95A)		
43	Reserved	Reserved				
44						
45						
46						
47						

### (2) Command Parameters

The details of ALM\_CLR\_MOD are described below.

ALM_CLR_MOD	Description	Processing Time
0	Clearance of the current alarm or warning state	Within 200 ms
1	Clearance of the alarm history	Within 2 s

### 8.15.4 Read Memory Subcommand (MEM\_RD: 1DH)

#### (1) Data Format

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command		
Pro	cessing Time	Within 200 ms	Subcommand				
Byte	MEN	I_RD		Description			
Dyte	Command	Response		Decomption			
32	1DH	1DH	• The MEM_RD sub	command reads the da	ata stored in virtual		
33			reading.	ing the initial address	and the data size for		
34	SUB_CTRL	SUB_STAT	• Confirm the compl	etion of the subcomma	and execution by		
35			SUB STAT.SUBC	BCMD = MEM_RD (* MDRDY = 1, and also	= 1DH) and checking the setting		
36	Reserved (0)	Reserved (0)	for ADDRESS and SIZE.				
37	MODE/ DATA_TYPE	MODE/ DATA_TYPE	<ul> <li>In the following cases, an alarm will occur and the subcommanwill not be executed.</li> <li>When the ADDRESS data is invalid: SUBCMD_ALM = 9H (A.94A)</li> <li>When the MODE/DATA_TYPE data is invalid: SUPCMD_ALM = 0H (A.94P)</li> </ul>				
38	SIZE	SIZE					
39	SILL	SIZE					
40			When the SIZE dat	a is invalid:			
41	ADDRESS	ADDRESS	• While editing using	g SigmaWin+:	94D) Win+:		
42	ADDRESS	ADDRESS	SUBCMD_ALM = AH (A.95A) For details, refer to 8.13.11 Write Memory Command (MEM_WR:				
43			1EH) - Method to Acc	ess Virtual Memory A	reas.		
44							
45	Peserved	DATA					
46	Keseiveu	DAIA					
47							

(2) Command Parameters

The details of MODE/DATA\_TYPE are described below.

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MODE					DAT	TA_TYPE	

MODE = 1: Volatile memory, 2: Not supported DATA\_TYPE = 1: Byte, 2: Short, 3: Long, 4: Not supported

SIZE: Data size for reading (of type specified by DATA\_TYPE) ADDRESS: Initial address for reading DATA: Read data

### 8.15.5 Write Memory Subcommand (MEM\_WR: 1EH)

#### (1) Data Format

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command	
Pro	cessing Time	Refer to 8.13.11 (2) Command Parame- ters - Executing the Adjustment Opera- tion.	Subcommand			
Byte	MEN	I_WR		Description		
	Command	Response		Beconption		
32	1EH	1EH	• The MEM_WR	subcommand writes	the data in virtual	
33			data for writing.	ing the initial address,	, the data size and the	
34	SUB_CTRL	SUB_STAT	This subcommand	provides an adjustmen	t function equivalent	
35			compatible profile.	For the operation proc	HAIROLINK-II cedure, refer to the	
36	Reserved (0)	Reserved (0)	<ul> <li>Confirm the completion of the subcommand execution by checking that RSUBCMD = MEM_WR (= 1EH) and SUB_STAT.SUBCMDRDY = 1, and also checking the setting for the subcommand execution by the setting for the settin</li></ul>			
37	MODE/ DATA_TYPE	MODE/ DATA_TYPE				
38			Ior ADDRESS, SL	LE and DAIA.		
39	SIZE	SIZE	In the following cases, an alarm will occur and the subcomman will not be executed.			
40			When the ADDRE     SUBCMD_ALM =	SS data is invalid: = 9H (A.94A)		
41	ADDRESS	ADDRESS	• When the MODE/I SUBCMD_ALM =	DATA_TYPE data is in = 9H (A.94B)	nvalid:	
42	1221200	1221255	• When the SIZE data is invalid: SUBCMD ALM = 9H (A.94D)			
43			• When the condition are not satisfied: S	hs for executing the ad UBCMD $ALM = AH$	justment operation (A.95A)	
44			• While editing using SUBCMD ALM =	g SigmaWin+: = AH (A.95A)		
45	DATA	DATA	For details, refer to 8. (MEM_WR: 1EH) - N	13.11 Write Memory C Iethod to Access Virtud	Command al Memory Areas.	
46	Dimi	Dimi				
47						

(2) Command Parameters

The details of MODE/DATA\_TYPE are described below.

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
MODE					DAT	TA_TYPE	

MODE = 1: Volatile memory, 2: Non-volatile memory (Non-volatile memory can be selected only for common parameters)

DATA\_TYPE = 1: Byte, 2: Short, 3: Long, 4: Not supported

SIZE: Data size for writing (of type specified by DATA TYPE)

ADDRESS: Initial address for writing

DATA: Data to be written

# 8.15.6 Servo Status Monitor Subcommand (SMON: 30H)

Phase Comman	es in which the d can be Executed	2, 3	Command Classification	Common command	Asynchronous command		
Pro	cessing Time	Within communication cycle	Subcommand				
Byte	SM	ON	Description				
Dyte	Command	Response		Becomption			
32	30H	30H	• The SMON subcom	mand reads the alarms,	status, and monitor		
33			monitor setting, and	the state of the I/O sig	nals of the servo		
34	SUB_CTRL	SUB_STAT	<ul> <li>Confirm the completion of the subcommand execution by checking that RSUBCMD = SMON (= 30H) and</li> </ul>				
35							
36			SUB_STAT.SUBCN	ADRDY = 1.	-)		
37		MONITORA					
38		MONTOR					
39							
40							
41	Perenved	MONITOP 5					
42	Reserved	MONTORS					
43							
44							
45		MONITOR					
46		WONTOKO					
47							

### 8.15.7 Read Servo Parameter Subcommand (SVPRM\_RD: 40H)

#### (1) Data Format

Phas Comman	es in which the d can be Executed	2, 3	Command Classification	Command ClassificationServo standard commandAsynchro comma			
Pro	cessing Time	Within 200 ms	Subcommand				
Byte	SVPR	M_RD	Description				
Dyte	Command	Response		Becomption			
32	40H	40H	• The SVPRM_RD s	subcommand reads the	e servo parameters on		
33			read mode.	servo parameter num	bei, data size, and the		
34	SUB_CTRL	SUB_STAT	Confirm the complete sheet PSU	etion of the subcomma	and execution by $(-401)$ and		
35			SUB_STAT.SUBC	MDRDY = 1, and also	checking the setting		
36			for NO, SIZE and N	MODE.			
37	NO	NO	<ul> <li>In the following cases, an alarm will occur. Do not read PARAMETER in the response in these cases because the PARAMETER value will be indefinite.</li> <li>When the NO data is invalid: SUBCMD_ALM = 9H (A.94A)</li> <li>When the SIZE data is invalid: SUBCMD_ALM = 9H (A.94D)</li> </ul>				
38	SIZE	SIZE					
39	MODE	MODE					
40			<ul> <li>When the MODE of SUBCMD_ALM =</li> <li>While editing using</li> </ul>	e 9H (A.94B) SigmaWin+:			
41			SUBCMD_ALM =	AH (A.95A)			
42							
43	Reserved	PARAMETER					
44							
45							
46							
47							

(2) Command Parameters

NO: Servo parameter number

SIZE: Servo parameter data size [byte]

MODE: Servo parameter read mode

Servo Parameter Type	Reading Source	Mode Setting
Common Parameters	RAM area	00H
Device Parameter	RAM area	10H

PARAMETER: Servo parameter data
# 8.15.8 Write Servo Parameter Subcommand (SVPRM\_WR: 41H)

(1) Data Format

Phases in which the Command can be Executed		2, 3	Command Classification	Servo standard command	Asynchronous command		
Pro	Processing Time Within 200 ms		Subcommand				
Byte	SVPRI	M_WR	Description				
	Command	Response					
32	41H	41H	• The SVPRM_WR subcommand writes the servo parameters				
33			write mode.	the servo parameter in	inider, data size, and		
34	SUB_CTRL	SUB_STAT	Confirm the compl     abacking that PSU	etion of the subcomma $PCMD = SVPPM$ W	and execution by $P(-41H)$ and		
35			SUB_STAT.SUBC	MDRDY = 1, and also	checking the setting		
36	NO	NO	for NO, SIZE, MO	DE and PARAMETE	ξ.		
37	NO	NO	<ul> <li>In the following cases, an alarm will occur and the subcom will not be executed.</li> <li>When the NO data is invalid: SUBCMD_ALM = 9H (A.94A)</li> <li>When the SIZE data is invalid: SUBCMD_ALM = 9H (A.94D)</li> <li>When the MODE data is invalid: SUBCMD_ALM = 9H (A.94B)</li> </ul>				
38	SIZE	SIZE					
39	MODE	MODE					
40			• When the PARAM SUBCMD_ALM =	ETER data is invalid: 9H (A.94B)			
41			• While editing using SUBCMD_ALM =	g SigmaWin+: = AH (A.95A)			
42							
43	PARAMETER	PARAMETER					
44							
45							
46							
47							

Note: If the main command and subcommand specifying the same NO are received at the same time as new commands, the main command takes precedence and the alarm specified by SUBCMD\_ALM occurs for the subcommand.

(2) Command Parameters

NO: Servo parameter number SIZE: Servo parameter data size [byte] MODE: Servo parameter write mode

Servo Parameter Type	Reading Source	Mode Setting
Common Parameters	RAM area	00H
common r arameters	Retentive memory area	
Device Parameter	RAM area	10H
	Retentive memory area	11H

## 8.16 Preparing for Operation

This section describes how to set communications specifications before starting communications, and how to confirm the communications status.

## 8.16.1 Setting MECHATROLINK-III Communications

The rotary switches (S1 and S2) and DIP switch (S3), which are located near the top under the front cover of LECY series DRIVER, are used as shown below to set the communications specifications. The station address and the number of transmission bytes are set with these switches.



	Description						
Station Address	03H to EFH Set with the rotary switches (S1 and S2). Example: To set the address 48H, set S1 = 4 and S2 = 8.						
	Set with the DIP switch (S3).						
	Number of Bytes	Switch Setting			)	Remark	
Number of		1	2	3	4	Kentark	
Transmission	16	OFF	OFF	OFF	OFF	Do not use this setting.	
Bytes	32	ON	OFF	OFF	OFF	Make this setting when subcommands are disabled.	
	48	OFF	ON	OFF	OFF	Make this setting when subcommands are enabled.	
	-	ON	ON	OFF	OFF	Do not use this setting.	

# 8.16.2 Checking the Communications Status

To confirm that the DRIVER is in the communication enabled state, check the L1, L2 and CN LEDs.

	Description
L1 LED L2 LED	When communications in the data link layer have started, these LEDs are lit. The L1 LED indicates the status of the communication port at the CN6A connector and the L2 LED that at the CN6B connector. Lit: In normal communication Unlit: Communication not in progress due to disconnected cable, etc.
CN LED	When the connection in the application layer has been established, this LED is lit. Lit: In the CONNECT command completed state Unlit: In the CONNECT command incompleted state
7-segment LED	In normal state: Indicates the status. In alarm/warning state: Indicates the alarm/warning code.

## 8.17 Parameter Management and Operation Sequence

## 8.17.1 Operation Sequence for Managing Parameters Using a PC or PLC...etc

When the parameters are managed by a PC or PLC...etc, the parameters are automatically transmitted from the PC or PLC...etc to the DRIVER when the power is turned ON. Therefore, the settings of DRIVER do not need to be changed when the DRIVER is replaced.

Procedure	Operation	Command to Send
1	Turn ON the control and main circuit power supplies.	-
2	Confirm the completion of the initialization process of the DRIVER.	NOP
3	Reset the previous communications status.	DISCONNECT *
4	Establish communications connection and starts WDT count.	CONNECT
5	Check information such as device ID.	ID_RD
6	Read device setting data such as parameters.	SVPRM_RD
7	Set the parameters required for the device.	SVPRM_WR
8	Enable the parameter settings (Setup).	CONFIG
9	Turn ON the encoder power supply to obtain the position data.	SENS_ON
10	Turn the servo ON.	SV_ON
11	Start operation.	POSING, INTERPOLATE, etc.
12	Turn the servo OFF.	SV_OFF
13	Disconnect the communications connection.	DISCONNECT
14	Turn OFF the control and main circuit power supplies.	-

\* When starting the operation sequence with turning the power ON as the first step, it is not necessary to send the DISCONNECT command.

Note: This example sequence shows the steps to enable starting of communications regardless of the status at that point.

## 8.17.2 Operation Sequence for Managing Parameters Using a DRIVER

To manage the parameters by using DRIVER's non-volatile memory, save the parameters in the non-volatile memory at setup and use an ordinary operation sequence.

Procedure	Operation	Command to Send
1	Turn ON the control and main circuit power supplies.	NOP
2	Reset the previous communications status.	DISCONNECT *
3	Establish communications connection and starts WDT count.	CONNECT
4	Check information such as device ID.	ID_RD
5	Get device setting data such as parameters.	SVPRM_RD
6	Save the parameters required for the device in the non-volatile memory.	SVPRM_WR Note: Do not use RAM.
7	Disconnect the communications connection.	DISCONNECT
8	Turn OFF the control and main circuit power supplies.	-

#### (1) Setup Sequence

\* If the connection cannot be released normally, send a DISCONNECT command for 2 or more communication cycles, and then send a CONNECT command.

Procedure	Operation	Command to Send
1	Turn ON the control and main circuit power supplies.	NOP
2	Reset the previous communications status.	DISCONNECT *
3	Establish communications connection and starts WDT count.	CONNECT
4	Check information such as device ID.	ID_RD
5	Get device setting data such as parameters.	SVPRM_RD
6	Turn ON the encoder power supply to obtain the position data.	SENS_ON
7	Turn the servo ON.	SV_ON
8	Start operation.	POSING, INTERPOLATE, etc.
9	Turn the servo OFF.	SV_OFF
10	Disconnect the communications connection.	DISCONNECT
11	Turn OFF the control and main circuit power supplies.	-

(2) Ordinary Operation Sequence

\* If the connection cannot be released normally, send a DISCONNECT command for 2 or more communication cycles, and then send a CONNECT command.

#### 8.18 Setting the Zero Point before Starting Operation

(1) When Using an Absolute Encoder

When an absolute encoder is used in the slave station, the SENS\_ON command can be used to set the reference coordinate system of the slave station. The reference coordinate system will be set according to the position detected by the absolute encoder and the coordinate system offset of the encoder (i.e., the offset between the encoder's coordinate system and the reference coordinate system (device built-in parameter)). The relationship between the reference coordinate system (CPOS and APOS), the encoder's coordinate system offset of the encoder are shown in the following figure.

CPOS: Reference position APOS: Feedback position



X= x+ Common Parameter 23 (Pn808) Common parameter 23 (Pn808): Absolute encoder origin offset



#### 8.19 Operation Sequence when Turning the Servo ON

Motor control using a PC or PLC...etc is performed using motion commands only in the servo ON state (motor power ON).

In the servo OFF state (when the power to the motor is shut OFF), the DRIVER manages position data so that the reference coordinate system (CPOS, MPOS) and the feedback coordinate system (APOS) are equal. For correct execution of motion commands, therefore, it is necessary to use the SMON (status monitoring) command after the servo ON state has been established, to read the servo reference coordinates (CPOS) and send an appropriate reference position. Set the coordinate system of the DRIVER using the POS\_SET command as necessary.

After completing the setting of the coordinate systems, carry out machine operation using motion commands.

#### 8.20 Operation Sequence when OT (Overtravel Limit Switch) Signal is Input

When an OT signal is input, the DRIVER prohibits the motor from rotating in the way specified in parameter Pn001. The motor continues to be controlled by the DRIVER while its rotation is prohibited.

When an OT signal is input, use the following procedure to process the OT signal.

Procedure	Operation
1	Monitor OT signals. When an OT signal is input, send an appropriate stop command: While an interpolation command (INTERPOLATE) is being executed: Continues execution of the interpolation command while stopping updating of the interpolation position. Or, sends an SMON command. While a move command (such as POSING) other than interpolation commands is being executed: sets CMD_CANCEL = 1.
2	Check the output completion flag DEN. If $DEN = 1$ , the DRIVER completed the OT processing. At the same time, check the flag ZSPD. If $ZSPD = 1$ , the motor is completely stopped. Keep the command used in procedure 1 active until both of the above flags are set to 1.
3	Read out the current reference position (CPOS) and use it as the start position for retraction processing.
4	Use a move command such as POSING or INTERPOLATE for retraction processing. Continue to use this command until the retraction is finished. If the move command ends without finishing the retraction, restart the move command continuously from the last target position.

Note: • When an OT signal is input during execution of a motion command such as ZRET, EX\_FEED or EX\_POSING, the execution of the command will be cancelled.

• During the overtravel state (P-OT = 1 or N-OT = 1), the servomotor is not positioned to the target position specified by the host PC or PLC...etc. Check the feedback position (APOS) to confirm that the axis is stopped at a safe position.



#### 8.21 Operation Sequence at Emergency Stop (Main Circuit OFF)

For circuits incorporating the recommended processing that the control and main circuit power supplies turn OFF on occurrence of an emergency stop, no specific process is required.

For circuits that turn OFF only the main circuit power supply, follow the procedure below.

After confirming that the SV\_ON or PON bit in the STATUS field of the response data is OFF (= 0), send an SV\_OFF command. While in an emergency stop state, always monitor the DRIVER status using a command such as the SMON (status monitoring) command.

For recovery from an emergency stop state, follow the action to be taken on occurrence of an alarm.



#### 8.22 Operation Sequence when a Safety Signal is Input

When an HWBB1 or HWBB2 signal is input while the motor is being operated, current to the motor will be forcibly stopped, and the motor will be stopped according to the setting of the 1st digit of parameter Pn001.

/HWBB1 /HWBB2	ON (The HWBB function is not required.)		OFF (The HWBB function is required.)	ON (The HWBB function is not required.)	
Command	Motion command, etc.	SV_OFF command	SMON	command, etc.	SV_ON command
SVCMD STAT					
SV_ON	1		0		1
SVCMD IO					
ESTP	0		1	0	
DRIVER status	RUN status	(BB status (baseblocked)	HWBB status (hard wire baseblocked)	BB status (baseblocked)	RUN status

[When an HWBB signal is input after the DRIVER stops powering the motor]

[When an HWBB signal is input while the DRIVER is powering the motor]

/HWBB1 /HWBB2	ON (The HWBB function is not required.)	OFF (The HWBB function is required.)	ON (The HWBB function is not required.)		
Command	Motion command, etc.	SMON	I command, etc.	SV_ON command	
SVCMD_STAT. SV_ON	1	0		1	
SVCMD_IO. ESTP	0	1	0		
DRIVER status	RUN status	HWBB status (hard wire baseblocked)	BB status (baseblocked)	RUN status	

- When an HWBB Signal is Input:

Monitor the HWBB input signal and SCM output signal status, or ESTP signal (HWBB) status in the SVCMD\_IO (servo command input signal) field. If a forced stop status is detected, send a command such as SV\_OFF to stop the motor.

- Recovery from Stop Status:

Recover from the stop status by following the procedure below.

- 1. Reset the HWBB1 or HWBB2 signal.
- The HWBB state is still valid at this point.
- 2. Send an SV\_OFF command to shift the DRIVER to the base block state.
- 3. Carry out PC or PLC...etc and system recovery processing.
- 4. Send an SV ON command to establish the servo ON state.
- 5. Complete the preparation for operation after establishing the servo ON state.
- 6. Start operation.



- Note 1. If the DRIVER enters the HWBB status while sending an SV\_ON command, reset the /HWBB1 or /HWBB2 signal and then send a command other than SV\_ON, such as SV\_OFF. Then, send the SV\_ON command again to restore the normal operation status.
  - 2. If the DRIVER enters the HWBB status during execution of an SV\_OFF, INTERPOLATE, POSING, FEED, EX\_FEED, EX\_POSING, or ZRET command, a command warning will occur since the DRIVER status changes to the servo OFF state. Execute the clear alarm or warning (ALM\_CLR) command to restore normal operation.

## 8.23 Operation Sequence at Occurrence of Alarm

When the D\_ALM bit in the CMD\_STAT field of the response is 1 or a COMM\_ALM field of 8 or a greater value is detected, send the SV\_OFF command. Use the ALM\_RD command to check the alarm code.

To clear the alarm status, send the ALM\_CLR command or set the ALM\_CLR bit of the CMD\_CTRL command to "1" after eliminating the cause of the alarm. However, this will not clear the alarm status that require the power supply to be turned OFF and back ON for clearance.

- For Communication Error Alarms

When a communication error alarm (COMM\_ALM  $\ge$  8) occurs, the communication phase shifts to phase 2. To restore communication phase 3, send a SYNC\_SET command after resetting the alarm.

- For Warnings

When the D\_WAR bit is 1 or the COMM\_ALM field of a value from 1 to 7 is detected, a warning occurs but the servo OFF state will not be established. Check the alarm code using the ALM\_RD command and perform appropriate processing. To clear the warning state, send the ALM\_CLR command or set the ALM\_CLR bit of the CMD\_CTRL command to "1."

- For Command Errors

Check the status of CMD\_ALM with the host PC or PLC...etc in every communication cycle and perform appropriate processing because CMD\_ALM will be automatically cleared on reception of the next normal command after detecting CDM  $ALM \neq 0$ .

# 8.24 Notes when the Positioning Completed State (PSET = 1) is Established while Canceling a Motion Command

When the DRIVER enters any of the following states during execution of a motion command, it may cancel the execution of the motion command and establish the positioning completed state (PSET = 1).

- The servo OFF state (SV\_ON of SVCMD\_STAT set to "0") has been established due to an alarm (D\_ALM of CMD\_STAT set to "0" or COMM\_ALM  $\ge$  8).

- The servo OFF state (SV\_ON of SVCMD\_STAT set to "0") has been established because the main power supply was turned OFF (PON of SVCMD\_STAT set to "0").

- The motor has stopped due to overtravel (P-OT or N-OT of SVCMD\_IO set to "1") or a software limit (P\_SOT or N\_SOT of SVCMD\_IO set to "1").

- The servo OFF state (SV\_ON of SVCMD\_STAT set to "0") has been established because the HWBB signal was turned OFF (ESTP of SVCMD\_IO set to "1").

In this case, the motor has not reached the target position specified by the host PC or PLC...etc even though PSET is set to "1." Check the feedback position (APOS) to confirm that the axis is stopped at a safe position.



If the state of an OT signal varies over a short time (in a pulsing manner for example), the host PC or PLC...etc may not be able to monitor the variation of the OT signal properly. Take due care about the selection of limit switches and their mounting and wiring to avoid chattering of OT signals and malfunctioning.



## 8.25 Function/Command Related Parameters

## 8.25.1 Interpolation Command

When sending the INTERPOLATE command, the speed feedforward and torque feedforward values can be specified along with the target position.

The sum of the speed feedforward value specified by the INTERPOLATE command and the (speed) feedforward value set in the parameters (common parameter 64 (Pn109) and Pn10A) will be applied.

Specifying the speed feedforward value using the INTERPOLATE command may lead to overshooting if the settings of the following parameters (common parameter 64 (Pn109) and Pn10A) are inappropriate. When specifying the speed feedforward value using the INTERPOLATE command, set the parameters to "0" (factory setting).

Common Parameters	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
64	Feedforward Compensation	4	0 to 100	%	0
	-	-			
Parameter	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
Pn109	Feedforward Gain	2	0 to 100	1%	0
Pn10A	Feedforward Filter Time Constant	2	0 to 64000	0.01 ms	0

If the speed feedforward and torque feedforward values are specified using the INTERPOLATE command, the values will be cleared when another command is executed.

#### 8.25.2 Positioning Command

There are the following two kinds of acceleration/deceleration method for positioning commands (POSING, FEED, EX\_FEED, EX\_POSING, and ZRET).

- Using the acceleration/deceleration specified by the command
- Using the acceleration/deceleration set in the parameters
- (1) Using the Acceleration/Deceleration (ACCR and DECR) Specified by the Command

When using the acceleration/deceleration (ACCR and DECR) specified by the command, positioning will be performed with 1-step acceleration/deceleration.

When both the acceleration and deceleration (ACCR and DECR) are set to "0" in the command, positioning will be performed with 2-step acceleration/deceleration according to the parameter settings.

(2) Using the Acceleration/Deceleration Set in the Parameters

Set both the acceleration and deceleration (ACCR and DECR) to "0" in the command and select which parameter setting should be used for the acceleration/deceleration with the 1st digit of parameter Pn833.



Note: Make settings so that the distance required for deceleration and the deceleration satisfy the following conditions.

Deceleration [reference unit/s<sup>2</sup>]  $\ge$  Maximum reference speed [reference unit/s]<sup>2</sup>/(Maximum deceleration distance [reference unit]<sup>\*2</sup>)

Parameter		Meaning	Data Size (Byte)	Setting Range	Unit
Pn833	n.□□□0 [Factory setting]	Use parameters Pn80A to Pn80F and Pn827. (Parameters Pn834 to Pn840 are invalid.)	2	0000H to 0001H	_
Pn833	$n. \square \square \square 1$	Use parameters Pn834 to Pn840. (Parameters Pn80A to Pn80F and Pn827 are invalid.)	2		

- Acceleration/Deceleration Constant Switching Setting

Note: The setting will be validated by turning the power supply OFF and then ON again, or by executing the CONFIG command.

Parameter	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
Pn80A	1st Linear Acceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80B	2nd Linear Acceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80C	Acceleration Constant Switching Speed	2	0 to 65535	100 reference units/s	0
Pn80D	1st Linear Deceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80E	2nd Linear Deceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80F	Deceleration Constant Switching Speed	2	0 to 65535	100 reference units/s	0
Pn827	Linear Deceleration Constant for Stopping	2	1 to 65535	10000 reference units/s <sup>2</sup>	100

# - Acceleration/Deceleration Parameters when Pn833=n. $\Box \Box \Box 0$

- Acceleration/Deceleration Parameters when Pn833=n.  $\Box$   $\Box$   $\Box$  1

Parameter	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
Pn834	1st Linear Acceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn836	2nd Linear Acceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn838	Acceleration Constant Switching Speed 2	4	0 to 20971520	100 reference units/s	0
Pn83A	1st Linear Deceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn83C	2nd Linear Deceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn83E	Deceleration Constant Switching Speed 2	4	0 to 20971520	100 reference units/s	0
Pn840	Linear Deceleration Constant 2 for Stopping	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100

## 8.25.3 Torque (Force) Limiting Function

The torque (force) limiting function limits the torque (force) during position/speed control to protect the con-nected machine, etc. There are three ways to limit the output torque (force).

- Internal torque (force) limit according to parameter settings
- External torque (force) limit using the P\_CL and N\_CL bits of the SVCMD\_IO field
- Torque (force) limit by position/speed control command

If all of the above three methods are used, the smallest torque (force) limit will be applied.

(1) Internal Torque (Force) Limit

This method always limits the maximum output torque (force) to the set values of the following parameters.

Parameter	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
Pn402	Forward Torque Limit (For rotational servomotors)	2	0 to 800	%	800
Pn403	Reverse Torque Limit (For rotational servomotors)	2	0 to 800	%	800

(2) External Torque (Force) Limit Using P\_CL/N\_CL Bits of SVCMD\_IO Field

This method uses the P\_CL and N\_CL bits of the SVCMD\_IO field to limit the output torque (force) to the values set for the following parameters. Settings can be made using common parameters.

Common Parameters	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
8C	Forward Torque (Force) Limit	4	0 to 800	%	100
8D	Reverse Torque (Force) Limit	4	0 to 800	%	100
Parameter	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
Pn404	Forward External Torque (Force) Limit	2	0 to 800	%	100
Pn405	Reverse External Torque (Force) Limit	2	0 to 800	%	100

(3) Torque (Force) Limit by Position/Speed Control Command

Torque (force) limits can be specified using the following commands.

INTERPOLATE, POSING, FEED, EX\_FEED, EX\_POSING, ZRET, VELCTRL

This method limits the torque (force) to the value set for TLIM of the position/speed control command.

The torque (force) limit will be applied according to the settings of the parameters (Pn81F.1 and Pn002.0). (Enabled by factory setting)

Parameter		Meaning	Data Size (Byte)	Setting Range	Unit
	$n. \Box \Box \Box 0 \Box$	Reserved			
Pn81F	n. □ □ 1 □ [Factory setting]	The settings of the TFF and TLIM fields of position control commands are enabled. The torque (force) limit will be applied according to the setting of parameter Pn002.0.	2	0000H to 0001H	_
	$n. \Box \Box \Box \Box 0$	Reserved			
Pn002	n.□□□1 [Factory setting]	Forward and reverse torque limits based on the set- ting of the TLIM field of the position/speed control commands are enabled.	2	0000H to 0003H	_
	$n. \Box \Box \Box \Box 2$	Reserved			
n.□□3 Re		Reserved			

Pn002.0	Forward Torque Limit		Reverse Torque Limit		
1 11002.0	When P_CL is set to 0	When P_CL is set to 1	When N_CL is set to 0	When N_CL is set to 1	
1	Pn402 TLIM	Pn402 Common parameter 8C (Pn404) TLIM	Pn403 TLIM	Pn403 Common parameter 8D (Pn405) TLIM	

The following table shows the operation when all of the three methods are used. The smallest torque (force) limit in each group will be applied.

When sending a command other than the commands that can specify torque limit, the last torque limit specified by the TLIM field remains valid. During execution of the SV\_OFF or TRQCTRL command, the torque limit specified by the TLIM field becomes invalid and the maximum torque will be used as the limit.

## 6.25.4 Torque (Force) Feedforward Function

This function is used to apply a torque (force) feedforward (TFF) from a position/speed control command to shorten positioning time. The host PC or PLC...etc differentiates a position reference to generate a torque (force) feedforward reference.

[Torque (Force) Feedforward Reference Settable Commands] INTERPOLATE, VELCTRL

[Setting Parameters]

Set the following parameters to use the torque (force) feedforward reference. (Enabled by factory setting)

Pn81F	Position Control Command TFF/TLIM Function Allocation		
	$n. \square \square 1 \square$	Enables allocation (Set TFF/TLIM operation using Pn002.)	



#### 8.25.5 Software Limit Function

This function forcibly stops the servomotor in the same way as the overtravel function when the moving part of the machine enters the software limit range specified by the parameters (common parameter 26 (Pn804), common parameter 28 (Pn806)).

The method for stopping the servomotor is the same as when an OT signal is input.

(1) Conditions for Enabling the Software Limit Function

The software limit function is enabled when the following operations are completed. In other cases, the function remains disabled.

- Zero point return operation by the ZRET command is completed.

- The coordinate setting is completed after reference point setting (REFE = 1) by executing the POS\_SET command.

- When using an absolute encoder, the sensor is turned on by the SENS\_ON command.

Common Parameters		Name		Setting Range	Unit	Factory Setting
	Limit Se	tting				
25	bit 0	P-OT (0: Enabled, 1: Disabled)				
	bit 1	N-OT (0: Enabled, 1: Disabled)				
	bit 2	Reserved				0000H
	bit 3	Reserved	4	0 to 33H	0 to 33H 0000H	
	bit 4	P-SOT (0: Disabled, 1: Enabled)				
	bit 5	N-SOT (0: Disabled, 1: Enabled)				
	bit 6 to 31	Reserved				
26	Forward Software Limit		4	-1073741823 to 1073741823	Reference unit	1073741823
28	Reverse Software Limit		4	-1073741823 to 1073741823	Reference unit	-1073741823

(2) Parameters Related to Software Limit Functions

Parameter		Meaning	Data Size (Byte)	Setting Range	Unit
	$n.\square \square \square \square 0$	Enables forward and reverse software limit.			
	$n. \square \square \square 1$	Disables forward software limit.			
	$n.\square\square\square2$	Disables reverse software limit.			
n.□□□3 [Factory setting]		Disables software limit in both directions.			
Pn801 n. □ □ 0 □ [Factory setting]	n.□□0□ [Factory setting]	Reserved	2	0000H to 0103H	_
	$n.\square 0 \square$	Disables software limit for reference.			
	$n. \square 1 \square \square$	Enables software limit for reference.			
	n.0□□□ [Factory setting]	Reserved			
Pn804 Forward Software Limit		4	-1073741823 to 1073741823	Reference unit	
Pn806		Reverse Software Limit	4	-1073741823 to 1073741823	Reference unit

#### (3) Software Limit Monitoring

Check servo command input signal monitoring bits P\_SOT and N\_SOT for software limits.

Software limit operations are not performed in directions for which the software limit function is disabled, and the corresponding servo command input signal monitoring bit is always "0."

- Software Limit for Reference (Pn801.2)

If the target position specified by a command such as POSING and INTERPOLATE is in the software limit range, positioning will be performed by using the software limit value as the target position.

#### 8.25.6 Latch Function

Three types of current position latch function using an external signal input are available:

- Latching by using the move command with the latch function (EX\_FEED, EX\_POSING, ZRET)
- Latching based on the latch request set by the LT\_REQ1 and LT\_REQ2 bits
- Continuous latch based on the latch request set by the LT\_REQ2 bit

Type Operation	Move Command with Latch Function	Latching Based on the Latch Request Set by the LT_REQ1 and LT_REQ2 Bits	Continuous Latch Based on the Latch Request Set by the LT_REQ2 Bit	
Latch Operation	The slave station starts latching on reception of the command if $LT_REQ1 = 1$ , and ends latching on input of the specified latch signal.	The slave station starts latching if LT_REQ1 = 1 and LT_REQ2 = 1, and ends latching on input of the specified latch signal.	The slave station starts latching if LT_REQ2 = 1, and repeats latching on input of the specified latch signal.	
Canceling Latching	Cancelled by LT_REQ1 = 0 Cancelled when the slave station receives another command	Cancelled by $LT_REQ1 = 0$ and $LT_REQ2 = 0$	Cancelled by LT_REQ2 = 0	
Checking Completion of Latching	Check L_CMP1.	Check L_CMP1 and L_CMP2.	Check L_CMP2 and EX_STATUS.	
Outputting Latched Position <sup>*</sup>	LPOS1	LPOS1, 2	LPOS2	
Latching Allowable Area	According to the settings of Pn820 and Pn822			

An overview of the latch operation is presented below.

\* The specification differs from that of the MECHATROLINK-II compatible profile. Monitor the latched position by selecting the latched position with monitor selection bits SEL\_MON1 to 3.

The relationship among the signals related to latching is shown in the diagram below.

Even if a request for latching is made, latch signals will not be accepted until the latching conditions are satisfied.

Whether the latching conditions have been satisfied or not can be checked at LT\_RDY1 and LT\_RDY2 selected with common monitor 1 (CMN1) and common monitor 2 (CMN2). These monitors correspond to the 0th and 1st bits of the SV\_STAT field of common parameter 89 (PnB12).

In either of the following cases, latching will not be performed since the latching conditions are not satisfied.

- Outside the latching allowable area set by parameters
- Inside the latching disabled area in the operation sequence for the ZRET command
- Operation when Latching is Completed

LT_REQ	ON Latch condition not established	Ъ
LT_RDY		
L_CMP		
Latch signal		



- Operation w	hen Latching is not Completed
LT_REQ	ON OFF
LT_RDY	ON U
L_CMP	ON )}
Latch signal	

. . . . 0

- Latch Time Lag
  - From reception of the command to latching start: 250 µs max.
  - From completion of latching to transmission of a response: One communication cycle max.
- (1) Continuous Latch by LT\_REQ2 Bit

This function sequentially latches the input positions of sequence signal 1 to sequence signal n (n = 1 to 8) a specified number of times. The continuous latch operation can be aborted by setting the LT REQ2 bit to OFF (LT REQ2 = 0). This function can shorten the time between latch completion and the start of the next latch, and enables sequential latch operations at high speed.



[How to Start and Stop Continuous Latch Operation]

Set the following parameters, and then set LT\_REQ2 to "1" to start continuous latch operation. To abort the operation, set LT REQ2 to "0."

Pn850: Latch Sequence Number n

Pn851: Continuous Latch Count m (When m = 0, the continuous latch operation will be infinitely repeated.)

Pn852: Latch Sequence Signal 1 to 4 Setting

Pn853: Larch Sequence Signal 5 to 8 Setting

Note: If Pn850 is set to "0" and LT REQ2 to "0", normal latching will be performed.

#### [Latch Status]

Latch completion can be confirmed by the following status.

#### [SVCMD STAT]

L\_CMP2: L\_CMP2 is set to "1" for one communication cycle every time the external signal is input. [EX STATUS]

EX STATUS is allocated to OMN1 (Pn824) or OMN2 (Pn825). (Pn824 = 84H or Pn825 = 84H)

L SEQ NO (D8-D11): The latch sequence signal number ( $\leq n$ ) on completion of latching of the current position

(Added on completion of position latching)

- L CMP CNT (D0-D7): The continuous latch count ( $\leq m$ )
  - (Added on completion of position latching when the latch sequence signal n is input.)



[Latched Position Data]

The latest latched position data at completion of latching can be obtained by using the following monitor.

Name	Code	Remark
Feedback Latch Position	LPOS2	The latest latch signal input position

The previously latched position data can be obtained by using the following optional monitors.

Name	Code	Remark
Optional Monitor 1	OMN1	Pn824 = 81H: Previous latch (sequence) signal 2 input position (LPOS2)
Optional Monitor 2	OMN2	Pn825 = 81H: Previous latch (sequence) signal 2 input position (LPOS2)

#### [Operation Example]

An example of a continuous latch operation using two latch sequence signals EXT1 and EXT2 is illustrated below.

(The parameters are set as follows: Pn850 = 2, Pn851 = 2 or more, Pn852 = 0021H, Pn853 = any)



Parameter		Name		Data Size	Setting	Llnit	Factory	
No.	Digit		atch Sequence Number			Range	Onit	Setting
Pn850		Latch Sequence Num	ber		2	0 to 8	-	0
Pn851		Continuous Latch Se	quen	ce Count	2	0 to 255	_	0
		Latch Sequence Sign	al 1 t	o 4 Setting	2	0000H to 3333H	_	0000H
			0	Phase C				
	1	Latch Sequence 1	1	EXT1 signal	_	0 to 3	_	0
	1	Signal Selection	2	EXT2 signal		0 10 5		
Pn852			3	EXT3 signal				
	2	Latch Sequence 2 Signal Selection	Asa	As above				
	3	Latch Sequence 3 Signal Selection	Asa	As above				
	4	Latch Sequence 4 Signal Selection	Asa	above				
		Latch Sequence Signal 5 to 8 Setting			2	0000H to 3333H	_	0000H
			0	Phase C		0.4.2		
	1	Latch Sequence 5	1	EXT1 signal				0
	1	Signal Selection	2	EXT2 signal	_	0 10 5	_	0
Pn853			3	EXT3 signal				
	2	Latch Sequence 6 Signal Selection	Asa	above				
	3	Latch Sequence 7 Signal Selection	Asa	above				
	4	Latch Sequence 8 Signal Selection	Asa	above				

#### [Setting Parameters]

[Application Notes]

- 1. The minimum interval between latch signals is  $500 \ \mu$ s. An interval between latch signals that is longer than the communication cycle is required to continuously obtain latched position data.
- 2. If two latch signals are input without allowing the minimum required interval, only the first latch signal input position will be latched. The second latch signal will be ignored.
- 3. The parameters Pn850 to Pn853 can be changed only while the continuous latch operation is stopped.

#### (2) Setting the Latching Allowable Area

Use the following parameters to set the latching allowable area.

Parameter	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
Pn820	Forward Latching Allowable Area	4	-2147483648 to 2147483647	Reference unit	0
Pn822	Reverse Latching Allowable Area	4	-2147483648 to 2147483647	Reference unit	0

Latch signal input is enabled when the following two conditions are satisfied.

- Within the latching allowable area set by Pn820 and Pn822
- The LT\_REQ1 and LT\_REQ2 bits of the SVCMD\_CTRL field is set to "1" (requesting latching).\* \* For the MECHATROLINK-II compatible profile, the conditions are different.

The above conditions for enabling latch signal input are valid for the latch operation for any command.



## 8.25.7 Acceleration/Deceleration Parameter High-speed Switching Function

This function switches all of the acceleration/deceleration parameters that are used for positioning at the same time.

Register the acceleration/deceleration parameter settings in a bank before starting operation, and specify bank selector BANK\_SEL1 in the data field of the command to switch the acceleration/deceleration parameter set- tings to those of the registered bank.

#### [Specifying a Bank]

Specify a bank with the BANK\_SEL1 bits of the SVCMD\_IO field of the command.

Name	Description	Setting Data
BANK_SEL1 (4 bits)	Bank selector 1 (acceleration/deceleration bank)	Bank 0 to 15

Note: If a bank number larger than the bank number set in Pn900 is specified (BANK\_SEL1  $\ge$  Pn900), the parameter bank will not switch and the currently active bank will be used. The parameters will not switch while DEN = 0 (Distributing) either.

## [Parameter Bank Setting] Set the following parameters.

Parameter No.	Name	Data Size (Byte)	Setting Range	Factory Setting
Pn900	Parameter Bank Number	2	0 to 16	0
Pn901	Parameter Bank Member Number	2	0 to 15	0
Pn902 to Pn910	Parameter Bank Member Definition	2	0000H to 08FFH	0
Pn920 to Pn95F*	Parameter Bank Data	2	0000H to FFFFH Depends on bank member.	0

\* The parameters Pn920 to Pn95F will not be stored in the non-volatile memory. They need to be set every time the power is turned ON.

[Parameters that can be Registered as Bank Members]

The following parameters can be registered as parameter bank members by parameters Pn902 to Pn910.

Parameter	Name	Data Size (Byte)	Setting Range	Unit	Factory Setting
Pn80A	1st Linear Acceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80B	2nd Linear Acceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80C	Acceleration Constant Switching Speed	2	0 to 65535	100 reference units/s	0
Pn80D	1st Linear Deceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80E	2nd Linear Deceleration Constant	2	1 to 65535	10000 reference units/s <sup>2</sup>	100
Pn80F	Deceleration Constant Switching Speed	2	0 to 65535	100 reference units/s	0
Pn834	1st Linear Acceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn836	2nd Linear Acceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn838	Acceleration Constant Switching Speed 2	4	0 to 2097152000	Reference unit/s	0
Pn83A	1st Linear Deceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn83C	2nd Linear Deceleration Constant 2	4	1 to 20971520	10000 reference units/s <sup>2</sup>	100
Pn83E	Deceleration Constant Switching Speed 2	4	0 to 2097152000	Reference unit/s	0
Pn810	Exponential Function Acceleration/ Deceleration Bias	2	0 to 65535	100 reference units/s	0
Pn811	Exponential Function Acceleration/ Deceleration Time Constant	2	0 to 5100	0.1 ms	0
Pn812	Movement Average Time	2	0 to 5100	0.1 ms	0

For 4-byte parameters, one parameter must be registered as two consecutive members. (See Setting Example 2.)

#### [Setting Procedure]

STEP1:

- 1. Set Pn900 (Parameter Bank Number) to m.
- 2. Set Pn901 (Parameter Bank Member Number) to n. Set Pn900 and Pn901 so that Pn900  $\times$  Pn901  $\leq$  64.
- 3. Register bank member parameter numbers using parameters Pn902 to Pn910.
- 4. To enable the bank function, execute the CONFIG command or turn the power supply OFF and then ON again.

#### STEP2:

5. Set the data of each bank in the parameter bank data area from the leading parameter Pn920 in order as shown below. Bank 0: Pn920 to Pn (920 + n - 1)

Bank 0: 1 H 20 to 1 h (920 + h - 1)Bank 1: Pn (920 + n) to Pn (920 + 2n-1)

Sank 1. Pri ( $920 \pm 11$ ) to Pri ( $920 \pm 211$ 

Bank m – 1: Pn  $\{920 + (m - 1) \times n\}$  to Pn  $(920 + m \times n - 1)$ 

- If parameters Pn900 to Pn910 set in STEP 1, 2, and 3 are saved in the non-volatile memory, carry out STEP 5 only after turning the power ON the next and subsequent times. However, if you turn the power supply OFF and then ON again after saving parameters Pn900 to Pn910 in the non-volatile memory (i.e. with the bank function enabled), and start the operation without setting parameters Pn920 to Pn95F, the operation will be carried out under the condition that all bank data is set to 0 (zero) or the minimum setting.
  - 2. If parameters Pn900 to Pn910 set in STEP 1, 2, and 3 are not saved in the non-volatile memory, carry out STEP 1

to 5 each time the power supply is turned ON.

Setting Example 1: Switching three banks of members Pn80B, Pn80E, and Pn80C

Pn900 = 3	Bank number	Pn920 = 80BH value
Pn901 = 3	Member numbe	Pn921 = 80EH value Bank 0
		Pn922 = 80CH value
Pn902 = 80E	H Member 1	Pn923 = 80BH value
Pn903 = 80E	H Member 2	Pn924 = 80EH value Bank 1
Pn904 = 800	H Member 3	Pn925 = 80CH value
		Pn926 = 80BH value
		Pn927 = 80EH value Bank 2
		Pn928 = 80CH value /

Pn900 = 2	Bank number	Pn920 = 836H LS word	] \
Pn901 = 6	Member number	Pn921 = 836H MS word	] \
111001 - 0		Pn922 = 83CH LS word	Dentro
Pn902 = 836H	Member 1	Pn923 = 83CH MS word	Bank U
Pn903 = 836H	Member 2	Pn924 = 838H LS word	1/
Pn904 = 83CH	Member 3	Pn925 = 838H MS word	J
Pn905=83CH	Member 4	Pn926 = 836H LS word	1
Pn906 = 838H	Member 5	Pn927 = 836H MS word	1 \
Pn907 = 838H	Member 6	Pn928 = 83CH LS word	Book 1
	-	Pn929 = 83CH MS word	Darik I
		Pn92A = 838H LS word	1 /
		Pn92B = 838H MS word	1/

Setting Example 2: Switching two banks of members Pn836, Pn83C, and Pn838

[Application Notes]

- 1. If Pn900 (Parameter Bank Number) or Pn901 (Parameter Bank Member Number) is set to 0, the bank function will be disabled.
- 2. If one parameter is registered for more than one bank member definition, the bank data of the biggest bank member definition parameter number will be applied.
- 3. The acceleration/deceleration parameter high-speed switching function is enabled only while DEN = 1 (distribution completed). The parameters will not switch while DEN = 0 (distributing).
- 4. In the following cases, error A.04A (parameter setting error) will occur when the power supply is turned back ON or CONFIG command is executed.
  - One 4-byte parameter is not registered for two consecutive bank members.
  - The total number of bank data entries exceeds 64 (Pn900  $\times$  Pn901 > 64).
- 5. If a parameter that is not allowed to be a bank member is registered, the bank data of the parameter-registered member will become invalid.
- 6. Bank data that exceeds the setting range of the registered bank member parameter will be clamped to a value within the setting range.
- 7. If a bank number larger than the bank number set in Pn900 is specified (BANK SEL1  $\geq$  Pn900), the parameter bank will not switch and the currently active bank will be used.
- 8. The parameters Pn920 to Pn95F will not be stored in the non-volatile memory. They need to be set every time the power is turned ON.

## 8.26 Detecting Alarms/Warnings Related to Communications or Commands

#### 8.26.1 Communication Related Alarms

The table below shows the communication alarms that may occur in MECHATROLINK-III communications.

If an error is found in the command or data that a DRIVER receives, the DRIVER returns the corresponding alarm code (in the COMM\_ALM bit of the CMD\_STAT field of the response).

At the same time, the alarm code is displayed on the DRIVER.

		Alarn	n in Response			DRIVER Side		
Category	COMM _ALM	Name	Meaning	Remedy	Stopping Method	Alarm Code	Alarm Reset	
Communi- cation Setting	0	Communica- tion data size setting error	The received data size does not match the data size set at the local station. The communication data reception status after starting communica- tion is abnormal.	Review the number of trans- mission bytes (S3). Review the communication setting of the PC or PLCetc.	Zero- speed stopping	A.E41	Possi- ble	
Error0Station address setting errorThe station address setting is invalid or a station assigned the same station address exists in the communication network.R R (S0BTransmission cycle setting errorAn unsupported transmission cycle was set on reception of a CONNECT command.R cycle was set on reception of a CONNECT command.Communi- cation Establish- ment ErrorCSynchroniza- tion failureOn reception of the CONNECT command and then the SYNC_SET command, the WDT data is not refreshed in each com- munication timing cannot be synchronized.R ir cData reception errors occurredD	Review the station addresses (S1, S2).	Zero- speed stopping	A.E42	Impos- sible				
	В	Transmission cycle setting error	An unsupported transmission cycle was set on reception of a CONNECT command.	Review the transmission cycle setting of the PC or PLCetc.	Zero- speed stopping	A.E40	Possi- ble	
Communi- cation Establish- ment Error	С	Synchroniza- tion failure	On reception of the CONNECT command and then the SYNC_SET command, the WDT data is not refreshed in each com- munication cycle and the commu- nication timing cannot be synchronized.	Review the WDT process- ing of the PC or PLCetc. Check communication con- nections. Take countermeasures against noise.	Zero- speed stopping	A.E51	Possi- ble	
Communi- cation Error	9	Data reception error	Data reception errors occurred twice consecutively after complet- ing the execution of the CON- NECT command. (Influence of noise, etc.) An error is detected on the com- munication LSI.	Check communication con- nections. Take countermeasures against noise. To recover from the alarm state, send the ALM_CLR command and then the SYNC_SET command. If the alarm continues, replace the DRIVER.	Zero- speed stopping	A.E60	Possi- ble	
	8	FCS error	FCS errors occurred twice consec- utively after completing the execu- tion of the CONNECT command. (Influence of noise, etc.)	Check communication con- nections. Take countermeasures against noise. To recover from the alarm state, send the ALM_CLR command and then the SYNC_SET command.	Zero- speed stopping	A.E62	Possi- ble	
	A	Synchronous frame not received	The synchronous frame not received state was detected twice consecutively after completing the execution of the CONNECT com- mand. (Influence of noise, etc.)	Check communication con- nections. Take countermeasures against noise. To recover from the alarm state, send the ALM_CLR command and then the SYNC_SET command.	Zero- speed stopping	A.E63	Possi- ble	



		Alarr	n in Response		DRIVER Side		
Category	COMM _ALM	Name	Meaning	Remedy	Stopping Method	Alarm Code	Alarm Reset
	С	Synchroniza- tion error	The PC or PLCetc is not refreshing the WDT data in each communication cycle after completing communi- cation synchronization (in commu- nication phase 3).	Review the WDT process- ing of the PC or PLCetc. To recover from the alarm state, send the ALM_CLR command and then the SYNC_SET command.	Zero- speed stopping	A.E50	Possi- ble
Communi- cation	В	Transmission cycle error	The transmission cycle interval varied after completing the execu- tion of the CONNECT command.	Review the transmission cycle interval of the PC or PLCetc. To recover from the alarm state, send the ALM_CLR command and then the SYNC_SET command.	Zero- speed stopping	A.E61	Possi- ble
zation Error	B       Hammission cycle error       varied after completing to tion of the CONNECT c         mi-       Internal o       Internal synchroniza- tion error       The transmission cycle i varied after completing to tion of the CONNECT c         0       Internal synchroniza- tion error       The transmission cycle i varied after completing to varied after completing to of the CONNECT c         0       Internal synchroniza- tion error       The transmission cycle i varied after completing to of the CONNECT c         0       Communica- tion LSI initialization error       The initialization process communication LSI fail- error         0       Communica- tion LSI initialization error       An error is detected on to	The transmission cycle interval varied after completing the execu- tion of the CONNECT command.	Review the transmission cycle interval of the PC or PLCetc. To recover from the alarm state, turn OFF the power and then turn it back ON.	Stop by dynamic brake	A.E02	Impos- sible	
	0	Internal synchroniza- tion error	The transmission cycle interval varied after completing the execu- tion of the CONNECT command.	Review the transmission cycle interval of the PC or PLCetc. To recover from the alarm state, send the ALM_CLR command and then the SYNC_SET command.	Zero- speed stopping	A.EA2	Possi- ble
System Error	0	Communica- tion LSI initialization error	The initialization process of the communication LSI failed.	Replace the DRIVER.	Stop by dynamic brake	A.b6A	Impos- sible
	0	Communica- tion LSI error	An error is detected on the com- munication LSI.	Take countermeasures against noise. Replace the DRIVER.	Stop by dynamic brake	A.b6b	Impos- sible
Parameter Error	0	Parameter setting error	The parameter settings are not cor- rect when turning the power ON or on execution of the CONFIG com- mand. Cause 1: There is an error in the bank parameter set- tings. (Refer to 8.25.7 Acceleration/Decelera- tion Parameter High- speed Switching Func- tion for details.) Cause 2: The settings of the reserved parameters have been changed as follows. Pn200.2≠1 Pn207.1≠1 Pn50A≠*881H Pn50C≠8888H Pn50D≠8888H	Correct invalid parameter settings. Correct the set- tings manually or through communication as appropri- ate.	Stop by dynamic brake	A.04A	Possi- ble
Command Execution Error	0	Command tim- eout error	The execution of the SV_ON or SENS_ON command was not completed within the set period.	Send the command while the motor is stopped.	Zero- speed stopping	A.ED1	Possi- ble

#### 8.26.2 Warnings Related to Communication and Commands

Warnings are divided into two categories, warnings related to data reception and procedures in MECHATROLINK-III communications and warnings related to the validity of commands.

#### (1) Communication Errors (COMM\_ALM)

The table below shows the warnings related to procedures in MECHATROLINK-III communications. When an error of this kind is detected, the warning code is displayed on the DRIVER as well.

If any of these warnings occur, the relevant command will not be executed because the command data is not properly received. The operation of the servomotor continues. Therefore, the response will be the same as that of the previous command.

Category		Alarm in Respons	DRIVER Side			
	COMM_ ALM Meaning		Remedy	Warning Code	Warning Code Reset	
Communi- cations Warning	2	Communication error	Check communication	A.960		
	1	FCS error	connections. Take countermeasures against	A.962	Necessary	
	3	Synchronization frame not received	noise.	A.963		

If a warning A.96  $\square$  occurs during the interpolation operation (INTERPOLATE), the interpolation operation at the current feed speed continues within the communication cycle in which the warning A.96  $\square$  was detected.

#### (2) Command Errors (CMD\_ALM)

The table below shows the warnings related to the validity of commands.

When an error of this kind is detected, the warning code is displayed on the DRIVER as well.

		Alarm in Response	DRIVER	Side			
Category	CMD_ ALM	Meaning	Remedy	Warning Code	Warning Code Reset	Remark	
	9	Parameter numbers or data addresses are incorrect.		A.94A			
	9	The data in the command is invalid.		A.94b		The command received	
	9	The combination of data settings is incorrect.	Review the content of the command data sent	A.94C	Cleared automati-	warning will be ignored. The servomo-	
Data Setting Warnin g	9	The data size specified by the com- mand is incorrect. The data is specified outside the range for the relevant data.	by the PC or PLCetc. (Refer to the setting conditions of each command and	A.94d	carry	tor continues its opera- tion.	
	1	The data in the command is beyond the limit. It will be clamped at the limit value.	parameter.)	A.97b	Cleared automati- cally	The command will be executed with the data clamped at the limit value.	
	А	The command sequence is incorrect.		A.95A			
	8	An unsupported command has been received.		A.95b			
	А	Latch command interferes.	Review the command	A.95d	Cleared		
Command Warning	В	Subcommand and main command interfere.	PC or PLCetc. (Refer to the conditions of	A.95E	automati- cally	-	
	8	An illegal command has been received.	each com- mand.)	A.95F			
	С	A command not allowed in this com- munication phase has been received.		A.97A			

On reception of a normal command after a command error has occurred, CMD\_ALM (A.94 $\square$  and A.95 $\square$ ) is cleared automatically.



## 8.27 Common Parameters

#### 8.27.1 Overview

Common parameters are assigned common parameter numbers that are defined in the standard servo profile and are independent of individual devices. The utilization of common parameters means that parameters can be read or set without using parameter numbers or names specific to individual devices.

To read or set common parameters, select "common parameters" in the MODE field of the SVPRM\_RD or SVPRM\_WR command.

In the common parameters, there are various parameters that have equivalent functions to device parameters (Pn0  $\Box$   $\Box$  to Pn8  $\Box$   $\Box$ ) specific to this DRIVER. As shown in the following example, setting either the common parameter or the device parameter will change the value of the corresponding parameter. (Refer to 8.27.3 *Common Parameters and Corresponding Device Parameters.*)

The units (number of significant digits) differ between common parameters and device parameters (Pn0  $\Box$   $\Box$  to Pn8  $\Box$   $\Box$ ). Therefore, the values are converted between them as shown in the example below so that the device can operate at the accuracy defined with the device parameters.

Example: Changing the position loop gain

Common Parameter		LECY Device Parameter
No. 63 = 40.000		Pn102 = 40.00
Changed $\downarrow$		
No. 63 = <u>50.005</u>	$\rightarrow$ Converted $\rightarrow$	Pn102 = 50.00
		Changed $\downarrow$
No. 63 = 60.010	$\leftarrow \text{Converted} \leftarrow$	Pn102 = <u>60.01</u>

## 8.27.2 List of Common Parameters

The following list shows the common parameters. These common parameters are used to make settings from the host PC or PLC...etc via MECHATROLINK communications. Do not change settings with the SigmaWin+.

Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	Enabled Timing	Category
01 (PnA02)		Encoder	Гуре (read only)	0 to 1	_	_		
	4	0000H	Absolute encoder				-	
		0001H	Incremental encoder					
02		Motor Ty	Motor Type (read only) 0 to 1 – –					
(PnA04)	4	0000H	Rotational servomotor				-	
03	4	Semi-clo (read onl)	sed/Fully-closed Type y)	0 to 1	-	-		
(PnA06)	4	0000H	Semi-closed		_			
		0001H	Fully-closed					
04 (PnA08)	4	Rated Sp	eed (read only)	0 to FFFFFFFFH	$\min^{-1}$	-	_	
05 (PnA0A)	4	Maximur	n Output Speed (read only)	0 to FFFFFFFFH	$\min^{-1}$	_	-	Device Information
06 (PnA0C)	4	Speed M	ultiplier (read only)	_	Ι	_	-	Related Parameters
07 (PnA0E)	4	Rated To	rque (read only)	0 to FFFFFFFFH	Nm	_	_	
08 (PnA10)	4	Maximum (read onl	n Output Torque y)	0 to FFFFFFFFH	Nm	_	Ι	
09 (PnA12)	4	Torque M	Iultiplier (read only)	_	_	-	_	
0A (PnA14)	4	Resolutio	on (read only)	0 to FFFFFFFFH	pulse/rev	_	_	
0B (PnA16)	4	Scale Pite	ch	0 to 65536000	nm [0.01 µm] <sup>*1</sup>	0	After restart	
0C (PnA18)	4	Pulses pe	r Scale Pitch (read only)	0 to FFFFFFFFH	pulse/pitch	-	_	

Note: When using parameters that are enabled after restarting the DRIVER, a CONFIG command must be input or the power must be turned OFF and then ON again.

\*1. Set the units to multiples of 10.

Parameter No.	Size	Name		Setting Range	Units [Resolution]	Factory Setting	Enabled Timing	Category
21 (PnA42)	4	Electroni	c Gear Ratio (Numerator)	1 to 1073741824	_	1	After restart	
22 (PnA44)	4	Electroni (Denomi	c Gear Ratio nator)	1 to 1073741824	_	1	After restart	
23 (PnA46)	4	Absolute	Encoder Origin Offset	-1073741823 to 1073741823	1 reference unit	0	Immedi- ately <sup>*2</sup>	
24 (PnA48)	4	Multiturr	h Limit Setting	0 to 65535	Rev	65535	After restart	
		Limit Set	ting	0 to 33H	0000H			
		bit 0	P-OT (0: Enabled, 1: Disab	oled)				
		bit 1	N-OT (0: Enabled, 1: Disat	oled)				
		bit 2	Reserved					Machine
25 (Bp (1 (1))	4	bit 3	Reserved			0000H	After	Specifica-
(FIIA4A)		bit 4	P-SOT (0: Disabled, 1: Ena	abled)			Testart	tion Related Parameters
		bit 5	N-SOT (0: Disabled, 1: En	abled)				
		bit 6	Reserved					
		bit 7 to 31	Reserved				-	
26	4	Forward Softwara Limit		-1073741823	1 reference	1073741823		Immedi-
(PnA4C)	4	Forward	Sonware Limit	1073741823	unit	10/3/41823	ately	
27 (PnA4E)	4	Reserved	by System	-	-	0	Immedi- ately	
28 (PnA50)	4	Reverse S	Software Limit	-1073741823 to 1073741823	1 reference unit	-1073741823	Immedi- ately	
29 (PnA52)	4	Reserved	by System	_	_	0	Immedi- ately	
		Speed Ur	iit <sup>*3</sup>	0 to 4	-			
		0000H	Reference unit/sec					
41		0001H	Reference unit/min				After	
(PnA82)	4	0002H	Percentage (%) of rated spe	eed <sup>*4</sup>		0	restart	
		0003H	min <sup>-1*4</sup>					
		0004H	Max. motor speed/400000	00H <sup>*5</sup>				
		Speed De	$1 \text{ Init}^{4}, *5$					Unit System
42		(Set the y	value of "n" used as the			0	After	Related
(PnA84)	4	exponent	in $10^{n}$ when calculating	-3 to 3	_	0	restart	1 arameters
		the Speed	l Unit (41).)					
43	Δ	Position U	Unit	0	—	0	After	
(PnA86)	4	0000H	Reference unit			0	restart	
44 (Pp 499)	4	Position I (Set the v	Base Unit value of "n" used as the	0	_	0	After	
(PNA88)	4	exponent in 10 <sup>n</sup> when calculating the Position Unit (43).)					restart	

Note: When using parameters that are enabled after restarting the DRIVER, a CONFIG command must be input or the power must be turned OFF and then ON again.

\*2. Available after the SENS\_ON command is input.

\*3. When using fully-closed loop control, set 0000H (Reference unit/sec).

\*4. When either 0002H or 0003H is selected for the Speed Unit (parameter 41), set the Speed Base Unit (parameter 42) to a number between -3 and 0.

\*5. When 0004H is selected for the Speed Unit (parameter 41), set the Speed Base Unit (parameter 42) to 0.



Parameter No.	Size		Name		Units [Resolution]	Factory Setting	Enabled Timing	Category
		Accelera	tion Unit	-	_			
45 (PnA8A)	4	0000H	Reference unit/sec <sup>2</sup>	0	After restart			
<b>``</b>		0001H	Not supported				Enabled         After         restart         After         After         restart         After         After         restart         After         After         restart	
46 (PnA8C)	4	Accelerat (Set the v exponent the Accel	tion Base Unit value of "n" used as the in 10 <sup>n</sup> when calculating leration Unit (45).)	4 to 6	_	4	After restart	
	Torque Unit   1 to 2							
47	4	0000H	Not supported			1	After	
(PnA8E)	4	0001H	Percentage (%) of rated tor	que		1	restart	
		0002H	Max. torque/40000000H <sup>*6</sup>					
48 (PnA90)	4	Torque B (Set the v exponent the Torqu	ase Unit <sup>*6</sup> value of "n" used as the in 10 <sup>n</sup> when calculating ue Unit (47).)	-5 to 0	_	0	After restart	
		Complian (read only	nce Unit System	-	-			
		Speed	<i>)</i>					
		bit 0	Reference unit/s (1: Enable					
		bit 1	Reference unit/min (1: Ena				Unit System Related Parameters	
		bit 2	Percentage (%) of rated spe					
		bit 3	min <sup>-1</sup> (rpm) (1: Enabled)					
		bit 4	Max. motor speed/4000000	)H (Hex.) (1: Ena				
		bit 5 to 7	Reserved (0: Disabled)					
		Position		-				
		bit 8	Reference unit (1: Enabled					
49 (PnA92)	4	bit 9 to 15	Reserved (0: Disabled)			0601011FH	-	
		Accelera	tion					
		bit 16	Reference unit/s <sup>2</sup> (1: Enabl	ed)				
		bit 17	msec (Acceleration time ta (0: Disabled)	ken to reach the	rated speed)	-		
		bit 18 to 23	Reserved (0: Disabled)					
		Torque	1		-			
		bit 24	Nm (N) (0: Disabled)					
		bit 25	Percentage (%) of rated tor	que (1: Enabled)	)			
		bit 26	Max. torque/40000000 (He	ex.) (1: Enabled)				
		bit 27 to 31	Reserved (0: Disabled)				l	

Note: When using parameters that are enabled after restarting the DRIVER, a CONFIG command must be input or the power must be turned OFF and then ON again.

\*6. When 0002H is selected for the Torque Unit (parameter 47), set the Torque Base Unit (parameter 48) to 0.

Parameter No.	Size	Name	Setting Range	Units [Resolution]	Factory Setting	Enabled Timing	Category
61 (PnAC2)	4	Speed Loop Gain	1000 to 2000000	0.001 Hz [0.1 Hz]	40000	Immedi- ately	
62 (PnAC4)	4	Speed Loop Integral Time Constant	150 to 512000	µs [0.01 ms]	20000	Immedi- ately	
63 (PnAC6)	4	Position Loop Gain	1000 to 2000000	0.001/s [0.1/s]	40000	Immedi- ately	A disastas aut
64 (PnAC8)	4	Feedforward Compensation	0 to 100	%	0	Immedi- ately	Related Parameters
65 (PnACA)	4	Position Loop Integral Time Constant	0 to 5000000	µs [0.1 ms]	0	Immedi- ately	
66 (PnACC)	4	Positioning Completed Width	0 to 1073741824	1 reference unit	7	Immedi- ately	
67 (PnACE)	4	NEAR Signal Width	1 to 1073741824	1 reference unit	1073741824	Immedi- ately	
81 (PnB02)	4	Exponential Function Accel/Decel Time Constant	0 to 510000	µs [0.1 ms]	0	Immedi- ately <sup>*7</sup>	
82 (PnB04)	4	Movement Average Time	0 to 510000	µs [0.1 ms]	0	Immedi- ately <sup>*7</sup>	
83 (PnB06)	4	Final Travel Distance for External Positioning	-1073741823 to 1073741823	1 reference unit	100	Immedi- ately	
84 (PnB08)	4	Homing Approach Speed	0 to 3FFFFFFFH	$\begin{array}{c c} \hline 0 \text{ to} \\ \hline FFFFFH \end{array} 10^{-3} \text{min}^{-1} \end{array} \begin{array}{c} 5000 \\ \text{value obtained} \\ \text{by converting} \\ \text{reference/s into} \\ 10^{-3} \text{min}^{-1} \end{array}$		Immedi- ately	Command Related Parameters
85 (PnB0A)	4	Homing Creep Speed	0 to 3FFFFFFFH	10 <sup>-3</sup> min <sup>-1</sup>	500 value obtained by converting reference/s into $10^{-3}$ min <sup>-1</sup>	Immedi- ately	
86 (PnB0C)	4	Final Travel Distance for Homing	-1073741823 to 1073741823	1 reference unit	100	Immedi- ately	

Note: When using parameters that are enabled after restarting the DRIVER, a CONFIG command must be input or the power must be turned OFF and then ON again.

\*7. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	Enabled Timing	Category
		Monitor	Selection 1	0 to F	_			
		0000H	APOS					
		0001H	CPOS					
		0002H	PERR					
		0003H	LPOS1					
		0004H	LPOS2					
		0005H	FSPD					
87 (PnB0E)		0006H	CSPD					
	4	0007H	TRQ			1	ately	C
		0008H	ALARM				Related Parameter s	
		0009H	MPOS		-			
		000AH	Reserved (Indefinite value)					
		000BH	Reserved (Indefinite value)					
		000CH	CMN1 (Common monitor	1)				
		000DH	CMN2 (Common monitor	2)		1		
		000EH	OMN1 (Optional monitor 1	.)				
		000FH	OMN2 (Optional monitor 2	2)				
		Monitor	Selection 2	-	_			
88 (PnB10)	4	0000H to 000FH	Same as Monitor Selection	1.		0	Immedi- ately	

Parameter No.	Size		Na	ame		Set Ra	tting nge	Units [Resolution]	Factory Setting	Enabled Timing	Category
		Monitor (CMN1)	Selection	n for SEL	_MON1	0 t	io 6	_			
		0000H	TPOS	(Target po	sition in tl	he comm					
		0001H	IPOS (Reference position in the command coordinates)								
		0002H	POS_OFSET (Offset value set in the set coordinates command (POS_SET))								
		0003H	TSPD	(Target sp	eed)						
		0004H	SPD_L	IM (Spee	d limit val	ue)					
		0005H	TRQ_I	LIM (Torc	que limit v	alue)					
			byte 2:	Current of 00H: Ph 01H: Ph 02H: Ph 03H: Ph 03H: Ph Current of 00H: Po 01H: Sp 02H: To Reserved	communic. hase 0 hase 1 hase 2 hase 3 control mo osition con beed contro orque contro 1	de trol mode ol mode					
			byte 4:	Expansio	on signal n	nonitor					
		0006H	DIT	Name	Descri	ption	value	Setting			
	4		bit 0 IF	LT for RDY1 SV LT	for latch of tion speci	Processing status for latch detec- tion specified by	0	not processed	0	Immedi- ately	Command Related Parameters
89 (PnB12)					SVCMD_CTRL. LT_REQI	CTRĹ.	1	detection processing			
			bit 1 R	LT	LT_ RDY1 Processing for latch d tion specif SVCMD ( LT_REQ2	ocessing status r latch detec- on specified by VCMD_CTRL. r_REQ2	0	Latch detection not processed			
				RDY1			1	During latch detection processing			
			bit 2, bit 3				0	Phase C			
				IT	1.1.0		1	External input signal 1			
				SEL1R	Laten Sig	nal	2	External input signal 2			
							3	External input signal 3			
							0	Phase C			
			bit 4,	LT	1.10		1	External input signal 1			
			bit 5	SEL2R	Latch Sig	nal	2	External input signal 2			
							3	External input signal 3			
			bit 6	Reserved	1 (0)						
		0007H	Reserv	ed							
		0008H	INIT_F	PGPOS (L	.ow)	64-bit of encode comma	64-bit data for the initial encoder value converted to a command value (lower 32 bits)				
		0009H	INIT_F	PGPOS (F	ligh)	64-bit data for the initial encoder value converted to a command value (higher 32 bits)					


Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	Enabled Timing	Category
8A		Monitor S (CMN2)	Monitor Select for SEL_MON2 0 to 6 -		-	0	Immedi-	
(PnB14)	4	0000H to 0006H	Same as Monitor Selection	for SEL_MON1		0	ately	
8B (PnB16)	4	Origin De	etection Range	0 to 250	1 reference unit	10	Immedi- ately	
8C (PnB18)	4	Forward	Torque Limit	0 to 800	%	100	Immedi- ately	
8D (PnB1A)	4	Reverse 7	Forque Limit	0 to 800	%	100	Immedi- ately	
8E (PnB1C)	4	Zero Spec	ed Detection Range	1000 to 10000000	$10^{-3} \min^{-1}$	20000	Immedi- ately	
8F (PnB1E)	4	Speed Co Width	vincidence Signal Output	0 to 100000	$10^{-3} \min^{-1}$	10000	Immedi- ately	
		Servo Co Enabled/I	mmand Control Field Disabled (read only)	-	-			
		bit 0	CMD_PAUSE (1: Enabled	)				
		bit 1	CMD_CANCEL (1: Enable	ed)				
		bit 2, 3	STOP_MODE (1: Enabled	)				
		bit 4, 5	ACCFIL (1: Enabled)	ACCFIL (1: Enabled)				
		bit 6, 7	Reserved (0: Disabled)			G 1		
		bit 8	LT_REQ1 (1: Enabled)			Related		
		bit 9	LT_REQ2 (1: Enabled)	T_REQ2 (1: Enabled)				Parameter
90 (PpB20)	4	bit 10, 11	LT_SEL1 (1: Enabled)			0FFF3F3FH	_	8
(PND20)		bit 12, 13	LT_SEL2 (1: Enabled)					
		bit 14, 15	Reserved (0: Disabled)					
		bit 16 to 19	SEL_MON1 (1: Enabled)					
		bit 20 to 23	SEL_MON2 (1: Enabled)					
		bit 24 to 27	SEL_MON3 (1: Enabled)					
		bit 28 to 31	Reserved (0: Disabled)					

Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	Enabled Timing	Category			
		Servo Co Enabled/	mmand Status Field Disabled (read only)	_	0						
		bit 0	CMD_PAUSE_CMP (1: E	nabled)							
		bit 1	CMD_CANCEL_CMP (1:	CMD_CANCEL_CMP (1: Enabled) Reserved (0: Disabled)							
		bit 2, 3	Reserved (0: Disabled)								
		bit 4, 5	ACCFIL (1: Enabled)								
		bit 6, 7	Reserved (0: Disabled)								
		bit 8	L_CMP1 (1: Enabled)								
		bit 9	L_CMP2 (1: Enabled)								
		bit 10	POS_RDY (1: Enabled)								
91 (D. Doo)	4	bit 11	PON (1: Enabled)			0FFF3F33H	_				
(PnB22)		bit 12	M_RDY (1: Enabled)								
		bit 13	SV_ON (1: Enabled)								
		bit 14, 15	Reserved (0: Disabled)								
		bit 16 to 19	SEL_MON1 (1: Enabled)								
		bit 20 to 23	SEL_MON2 (1: Enabled)								
		bit 24 to 27	SEL_MON3 (1: Enabled)				(	Command			
		bit 28 to 31	Reserved (0: Disabled)					Related Parameters			
		I/O Bit E (Output) (read only	nabled/Disabled y)	_	_						
		bit 0 to 3	Reserved (0: Disabled)								
		bit 4	V_PPI (1: Enabled)			•					
		bit 5	P_PPI (1: Enabled)								
		bit 6	P_CL (1: Enabled)								
		bit 7	N_CL (1: Enabled)								
92		bit 8	G_SEL (1: Enabled)			0075015011					
(PnB24)	4	bit 9 to 11	G_SEL (0: Disabled)			007F01F0H	-				
		bit 12 to 15	Reserved (0: Disabled)								
		bit 16 to 19	BANK_SEL (1: Enabled)								
		bit 20 to 22	SO1 to SO3 (1: Enabled)								
		bit 23	Reserved (0: Disabled)								
		bit 24 to 31	Reserved (0: Disabled)								

Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	Enabled Timing	Category
		I/O Bit En (Input) (read only	nabled/Disabled	_	_			
		bit 0	Reserved (0: Disabled)					
		bit I	DEC (1: Enabled)					
		bit 2	P-OT (1: Enabled)					
		bit 3	N-OI (I: Enabled)		-			
		bit 4	EXTT (1: Enabled)					
		bit 5	EX12 (1: Enabled)					
	4	bit 6	EXT3 (1: Enabled)					
		bit 7	ESTP (1: Enabled)					
		bit 8	Reserved (0: Disabled)					
93		bit 9	BRK_ON (1: Enabled)					Command
(PnB26)		bit 10	P-SOT (1: Enabled)			FF0FFEFEH	_	Parameter
		bit 11	N-SOT (1: Enabled)					S
		bit 12	DEN (1: Enabled)					
		bit 13	NEAR (1: Enabled)					
		bit 14	PSET (1: Enabled)					
		bit 15	ZPOINT (1: Enabled)					
		bit 16	T_LIM (1: Enabled)					
		bit 17	V_LIM (1: Enabled)					
		bit 18	V_CMP (1: Enabled)					
		bit 19	ZSPD (1: Enabled)					
		bit 20 to 23	Reserved (0: Disabled)					
		bit 24 to 31	I0_STS1 to 8 (1: Enabled)					

# 8.27.3 Common Parameters and Corresponding Device Parameters

Category	Common Parameters	Meaning	Corresponding Device Parameter	Remark
	1	Encoder Type	-	
	2	Motor Type	-	
	3	Semi-closed/Fully-closed Type	-	
	4	Rated Speed	-	
Dovico	5	Maximum Output Speed	-	
Information	6	Speed Multiplier	-	
Related	7	Rated Torque	-	
Falameters	8	Maximum Output Torque	-	
	9	Torque Multiplier	-	
	0A	Resolution (Rotary)	-	
	0B	Scale Pitch (Linear)	-	
	0C	Pulses per Scale Pitch (Linear)	-	
	21	Electronic Gear Ratio (Numerator)	Pn20E	
	22	Electronic Gear Ratio (Denominator)	Pn210	
	23	Absolute Encoder Origin Offset	Pn808	
	24	Multiturn Limit Setting	Pn205	
Machine Specification Related Parameters	25	Limit Setting	Pn50A Pn50B Pn801	
	26	Forward Software Limit	Pn804	
	27	Reserved by System	-	
	28	Reverse Software Limit	Pn806	
	29	Reserved by System	-	
	41	Speed Unit	-	
	42	Speed Base Unit	-	
	43	Position Unit	-	
Unit System	44	Position Base Unit	-	
Parameters	45	Acceleration Unit	-	
	46	Acceleration Base Unit	-	
	47	Torque Unit	-	
	48	Torque Base Unit	-	
	61	Speed Loop Gain	Pn100	
	62	Speed Loop Integral Time Constant	Pn101	
Adjustment	63	Position Loop Gain	Pn102	
Related	64	Feedforward Compensation	Pn109	
Parameters	65	Position Loop Integral Time Constant	Pn11F	
	66	Positioning Completed Width	Pn522	
	67	NEAR Signal Width	Pn524	

Common Parameters and Corresponding Device Parameters

Category	Common Parameters	Meaning	Corresponding Device Parameter	Remark
	81	Exponential Function Accel/Decel Time Constant	Pn811	
	82	Movement Average Time	Pn812	
	83	Final Travel Distance for External Positioning	Pn814	EX_POSING, EX_FEED
	84 <sup>*1</sup>	Homing Approach Speed	Pn817, Pn842	ZRET
	85 <sup>*2</sup>	Homing Creep Speed	Pn818, Pn844	ZRET
	86	Final Travel Distance for Homing	Pn819	ZRET
	87	Monitor Selection 1	-	
	88	Monitor Selection 2	-	
	89	Monitor Select for SEL_MON1	-	
	8A	Monitor Select for SEL_MON2	-	
Command Related	8B	Origin Detection Range	Pn803	
Parameters	8C	Forward Torque Limit	Pn404	
	8D	Reverse Torque Limit	Pn405	
	8E	Zero Speed Detection Range	Pn502	
	8F	Speed Coincidence Signal Output Width	Pn503	
	90	Servo Command Control Field Enabled/Disabled	-	
	91	Servo Command Status Field Enabled/Disabled	-	
	92	I/O Bit Enabled/Disabled (Output)	-	
	93	I/O Bit Enabled/Disabled (Input)	-	

Common Parameters and Corresponding Device Parameters

\*1. The common parameter 84 is linked with Pn817 or Pn824. At factory setting, the value of Pn817 is effective. When Pn817 is set to zero or a value outside the allowable range, the value of Pn824 will become effective. After the value of Pn824 become effective, the value stays effective even if the value of Pn817 within the allowable range is set to parameter 84.

\*2. The common parameter 85 is linked with Pn818 or Pn844. At factory setting, the value of Pn818 is effective. When Pn818 is set to zero or a value outside the allowable range, the value of Pn844 will become effective. After the value of Pn844 become effective, the value stays effective even if the value of Pn818 within the allowable range is set to parameter 85.

#### 8.28 Virtual Memory Space

The virtual memory space is the memory area that can be accessed by using the read memory command (MEM\_RD: 1DH) and write memory command (MEM\_WR: 1EH).

By adopting the concept of virtual memory, the memory areas that vary among devices and vendors can be accessed at common addresses.





### 8.29 Information Allocated to Virtual Memory

The ID information, common parameter and adjustment operation areas are allocated to virtual memory.

### 8.29.1 ID Information Area

When accessing virtual memory using the MEM\_RD or MEM\_WR command, use virtual memory addresses. The address map is given below.

For details, refer to the ID\_CODE value in 8.27.2 *Read ID Command (ID\_RD: 03H)* that corresponds to the one in the following table.

Data in this area can also be read by using the ID\_RD command.

(He)	c.)	ID_CODE	(Hex.)		ID_CODE	(Hex.)		ID_CODE
0000 000	)F		0000 02BF	Reserved	-	0000 3FFF		
			0000 02A0	Sub Device 2 Version	A8H		Reserved	-
	List of Supported	2014	0000 029F					
	Main Commands	3011				0000 03A0	Sub Device 6 Version	E8H
				Sub Davias 2 Name		0000 039F		
0000 000	co			Sub Device 2 Name	AUH			
0000 00E	F							
0000 008	C	-	0000 0280				Sub Device 6 Name	E0H
0000 000			0000 027F	Reserved	-			
0000 000	A MAC Address	-	0000 0260	Sub Device 1 Version	98H			
0000 000	Supported Communication Mode	20H	0000 025F			0000 0380		
	Reserved (00000000HEX)	-				ľ		
	Reserved (00000000HEX)	-					Reserved	-
	Profile Type (Current Value)	1DH		Sub Device 1 Name	90H			
0000 007	Number of Transmission Bytes (Current Value)	1CH				0000 0360	Sub Device 5 Version	D8H
0000 006	C Number of Transmission Bytes	1BH	0000 0240			0000 035F		
0000 000	Maximum Value of Communication Cycle	1AH	0000 023F					
0000 000	Minimum Value of Communication Cycle	19H		Reserved	-			
0000 000	0 Granularity of Transmission Cycle	18H	0000 0220				Sub Device 5 Name	DOH
0000 005	C Maximum Value of Transmission Cycle	17H	0000 021F					
0000 005	Minimum Value of Transmission Cycle	16H						
0000 005	4 Profile Version 3	15H		Main Device Name	80H	0000 0340		
0000 005	50 Profile Type 3	14H		Main Device Hame	0011			
0000 004	C Profile Version 2	13H					Reserved	-
0000 004	18 Profile Type 2	12H						
0000 004	4 Profile Version 1	11H	0000 0200			0000 0320	Sub Device 4 Version	C8H
0000 004	0 Profile Type 1	10H	0000 01FF			0000 031F		
0000 003	C Reserved (0000000HEX)	-		Reserved	-			
0000 003	Reserved (0000000HEX)	-	0000 0120					
0000 003	34		0000 011F				Sub Device 4 Name	COH
	Serial No	06H		List of Supported	40H			
	Schartes.	0011		Common Parameters		0000 0300		
						0000 02FF	Reserved	-
0000 001	18		0000 0100			0000 02E0	Sub Device 3 Version	B8H
0000 001	4 Supported Extended Address	05H	0000 00FF			0000 02DF		
0000 001	0 Device Definition File Version	04H						
0000 000	C Device Version	03H		List of Supported	38H		Sub Device 3 Name	BOH
0000 000	08 Device Code	02H		Subcommands			East Derive of Harris	2011
0000 000	Vendor ID Code	01H						
0000 000	00 Reserved (0000000HEX)	-	0000 00E0			0000 02C0		

### 8.29.2 Common Parameter Area

When accessing virtual memory using the MEM\_RD or MEM\_WR command, use virtual memory addresses. The address map is given below.

Data in this area can also be read using the SVPRM\_RD or SVPRM\_WR command.

For details, refer to the common parameter No. in 8.27.2 *List of Common Parameters* that corresponds to the one in the following table.

(	(Hex.)		Common Parameter No.		(Hex.)		Common Parameter No.
0001	0124	Supported Unit	49H	0001	FFFF		
0001	0120	Torque Base Unit	48H			Beenered (00000000UEV)	
0001	011C	Torque Unit	47H			Reserved (0000000HEX)	-
0001	0118	Acceleration Base Unit	46H	0001	0250		
0001	0114	Acceleration Unit	45H	0001	024C	I/O Bit Enabled/Disabled	93H
0001	0110	Position Base Unit	44H	0001	0248	I/O Bit Enabled/Disabled	92H
0001	010C	Position Unit	43H	0001	0244	SVCMD_STAT field Enabled/Disabled	91H
0001	0108	Speed Base Unit	42H	0001	0240	SVCMD_CTRL field Enabled/Disabled	90H
0001	0104	Speed Unit	41H	0001	023C	Speed Coincidence Signal Output Width	8FH
0001	0100	Reserved (00000000HEX)	-	0001	0238	Zero Speed Detection Range	8EH
0001	00FC			0001	0234	Reverse Torque Limit	8DH
		Reserved (00000000HEX)	-	0001	0230	Forward Torque Limit	8CH
0001	00A4			0001	022C	Origin Detection Range	8BH
0001	00A0	Reverse Software Limit	28H	0001	0228	Monitor Select for SEL_MON2	8AH
0001	009C	Reserved (00000000HEX)	-	0001	0224	Monitor Select for SEL_MON1	89H
0001	0098	Forward Software Limit	26H	0001	0220	Monitor Selection 2	88H
0001	0094	Limit Setting	25H	0001	021C	Monitor Selection 1	87H
0001	0090	Multiturn Limit	24H	0001	0218	Final Travel Distance for Homing	86H
0001	008C	Absolute Encoder Origin Offset	23H	0001	0214	Homing Creep Speed	85H
0001	0088	Electronic Gear Ratio (Denominator)	22H	0001	0210	Homing Approach Speed	84H
0001	0084	Electronic Gear Ratio (Numerator)	21H	0001	020C	Final Travel Distance for External Positioning	83H
0001	0080			0001	0208	Movement Average Time	82H
		Reserved (00000000HEX)	-	0001	0204	Exponential Function Acceleration/ Deceleration Time Constant	81H
0001	0034			0001	0200	Reserved (00000000HEX)	-
0001	0030	Pulses per Scale Pitch	0CH	0001	01FC		
0001	002C	Linear Scale Pitch	0BH			Reserved (00000000HEX)	_
0001	0028	Resolution (Rotary)	0AH			Reserved (00000001EX)	_
0001	0024	Torque Multiplier	09H	0001	01A0		
0001	0020	Maximum Output Torque	08H	0001	019C	NEAR Signal Width	67H
0001	001C	Rated Torque	07H	0001	0198	Positioning Completed Width	66H
0001	0018	Speed Multiplier	06H	0001	0194	Position Loop Integral Time Constant	65H
0001	0014	Maximum Output Speed	05H	0001	0190	Feedforward Compensation	64H
0001	0010	Rated Speed	04H	0001	018C	Position Loop Gain	63H
0001	000C	Semi-closed/Fully-closed Type	03H	0001	0188	Speed Loop Integral Time Constant	62H
0001	8000	Motor Type	02H	0001	0184	Speed Loop Gain	61H
0001	0004	Encoder Type	01H	0001	0180	Received (000000004EV)	
0001	0000	Reserved (00000000HEX)	-	0001	0128		-



### 8.29.3 Adjustment Operation Area

Use the MEM\_RD or MEM\_WR command to access this area. The address map is given below.

For the command communication procedure for adjustment operations, refer to 8.13.11 Write Memory Command (MEM\_WR: 1EH).

Address		Description	Data Size (Byte)	Data Type			
8000 4000HEX	Description	he area where the command codes specifying adjustment operations are written					
0000 4000 ILX	Name	Command code	2	Binary Data			
8000 4002HEX	Description	The area where commands for preparing or starting adjustment operations are written					
	Name	Start command	2	Binary Data			



9 Troubleshooting	2
9.1 Alarm Displays	2
9.1.1 List of Alarms	3
9.1.2 Troubleshooting of Alarms	5
9.2 Warning Displays	24
9.2.1 List of Warnings	24
9.2.2 Troubleshooting of Warnings	26
9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning	32
9.4 Troubleshooting Malfunction Based on Operation and Conditions of the Servomotor	33

# 9 Troubleshooting

### 9.1 Alarm Displays

The following sections describe troubleshooting in response to alarm displays.

The alarm name, alarm meaning, alarm stopping method, and alarm reset capability are listed in order of the alarm numbers in *9.1.1 List of Alarms*.

The causes of alarms and troubleshooting methods are provided in 9.1.2 Troubleshooting of Alarms.

"6" of the figure, "B" of the alphabet, and "D" are displayed as follows.





### 9.1.1 List of Alarms

This section provides list of alarms.

After its cause has been removed, the alarm can be deactivated in any of the methods marked **O** in the alarm reset column.

				Alarm reset				
	Alarm Number	Alarm Name	Servo motor Stop ping Method <sup>*1</sup>	Power OFF ↓ ON	Alarm warning clear command [ALM-CLR]	SigmaWin+ [Alarm] [Display Alarm]   Reset button	SigmaWin+ [Setup] [Software Reset] L Execute button	
	A.020	Parameter Checksum Error 1	Gr.1	0	-	-	0	
	A 021	Parameter Format Error 1	Gr 1	0	_	_	0	
	A.022	System Checksum Error 1	Gr.1	0	-	-	0	
	A.030	Main Circuit Detector Error	Gr.1	0	0	0	0	
	A.040	Parameter Setting Error 1	Gr.1	0	-	-	0	
	A 041	Encoder Output Pulse Setting Error	Gr 1	0	-	-	0	
	A 042	Parameter Combination Error	Gr 1	0	_	_	0	
	A 044	Semi-closed/Eully-closed Loop Control Parameter Setting Error	Gr 1	0	_	_	0	
	Δ 04Δ	Parameter Setting Error 2	Gr 1	0	-	-	0	
	A 050	Combination Error	Gr 1	0	0	0	0	
	A 051		Gr 1	0	-	-	0	
	A 0B0	Cancelled Servo ON Command Alarm	Gr 1	0	0	0	0	
	A 100	Overcurrent or Heat Sink Overbeated	Gr 1	0	-	-	0	
	A 300	Regeneration Error	Gr 1	0	0	0	0	
	A 320	Regenerative Overload	Gr 2	0	0	0	0	
	A 330	Main Circuit Bower Supply Wiring Error	Gr.1	0	0	0	0	
	A.330		Gr.1	0	0	0	0	
	A.400		Gr.1	0	0	0	0	
	A.410	Main Circuit Capacitor Overvoltage	Gr.1	0		-	0	
	A.430		Gr.1	0	$\bigcirc$	0	0	
	A.510	Overspeed	Gr.1	0	0	0	0	
E	A.511	Vibration Alarm	Gr.1	0	0	0	0	
Ala	A.520	Autotuning Alarm	Gr.1	0	0	0	0	
	A.321		Gr.1	0	0	0	0	
	A.710	Overload: Low Load	GI.Z	0	0	0	0	
	A.720	Dynamic Brake Overlead	GI.I	0	0	0	0	
	A.730	Overlaged of Overlage Overlaged	Gr.1	0	0	0	0	
	A.731	Uverload of Surge Current Limit Resistor	GI.I	0	0	0	0	
	A.740	Real Silik Overheated	Gr.1	0	0	0	0	
	A.7AU	Built-In Fan In DRIVER Stopped	Gr.1	0	0	0	0	
	A./AD	Encoder Chackaum Error	GI.I	0	0	0	0	
	A.010	Abaskuta Encoder Detter / Error	GI.I	0	-	_	0	
	A.020	Absolute Encoder Battery Error	Gr.1	0	-	-	0	
	A.030	Encoder Data Elloi	Gr.1	0			0	
	A.040	Encoder Overboated	Gr.1	0			0	
	0C0.A	Encoder Overheated	GI.I	0			0	
		External Encoder Error of Madula		0			0	
				0	0	0	0	
	A.8A1	External Encoder Error of Sensor	Gr.1	0	0	0	0	
	A.8A2	External Encoder Error of Position	Gr.1		0	0	0	
	A.8A3	External Encoder Overspeed	Gr.1		0	0	0	
	A.8A5	External Encoder Overheated	Gr.1	0	0	0	0	
	A.8A6	Regeneration Error	Gr.1	0	0	0	0	
	A.B31	Current Detection Error 1	Gr.1	$\cup$	-	-	0	

							(cont d)
N					A	larm reset	
	Alarm Number	Alarm Name	Servo motor Stop ping Method <sup>*1</sup>	Power OFF ↓ ON	Alarm warning clear command [ALM-CLR]	SigmaWin+ [Alarm] [Display Alarm]   Reset button	SigmaWin+ [Setup]   [Software Reset]   Execute button
	Δ B32	Current Detection Error 2	Gr 1	0	-	-	
F	A B33	Current Detection Error 3	Gr 1	0	_	_	0
ŀ	A R6A	MECHATROLINK Communications ASIC Error 1	Gr 1	0	_	_	0
-	A B6B	MECHATROLINK Communications ASIC Error 2	Gr 2	0	_	_	0
F	A RE0	System Alarm 0	Gr 1	0	_	_	0
-	A BF1	System Alarm 1	Gr 1	0	_	_	0
F	A BF2	System Alarm 2	Gr 1	0	-	_	0
F	A BF3	System Alarm 3	Gr 1	0	-	_	0
F	A.BF4	System Alarm 4	Gr.1	0	-	-	0
-	A.C10	Servo Overrun Detected	Gr.1	0	0	0	0
Ī	A.C80	Absolute Encoder Clear Error and Multiturn Limit Setting Error	Gr.1	0	-	-	0
	A.C90	Encoder Communications Error	Gr.1	0	-	_	0
	A.C91	Encoder Communications Position Data Error	Gr.1	0	-	-	0
	A.C92	Encoder Communications Timer Error	Gr.1	0	-	-	0
	A.CA0	Encoder Parameter Error	Gr.1	0	-	-	0
	A.CB0	Encoder Echoback Error	Gr.1	0	-	-	0
	A.CC0	Multiturn Limit Disagreement	Gr.1	0	-	-	0
	A.CF1	Feedback Option Module Communications Error (Reception error)	Gr.1	0	-	-	0
	A.CF2	Feedback Option Module Communications Error (Timer stop)	Gr.1	0	-	-	0
	A.D00	Position Error Overflow	Gr.1	0	0	0	0
	A.D01	Position Error Overflow Alarm at Servo ON	Gr.1	0	0	0	0
	A.D02	Position Error Overflow Alarm by Speed Limit at Servo ON	Gr.2	0	0	0	0
Ę	A.D10	Motor-load Position Error Overflow	Gr.2	0	0	0	0
Alaı	A.E02	MECHATROLINK Internal Synchronization Error 1	Gr.1	0	0	0	0
	A.E40	MECHATROLINK Transmission Cycle Setting Error	Gr.2	0	0	0	0
Ī	A.E41	MECHATROLINK Communications Data Size Setting Error	Gr.2	0	0	0	0
	A.E42	MECHATROLINK Station Address Setting Error	Gr.2	0	-	-	0
F	A.E50	MECHATROLINK Synchronization Error	Gr.2	0	0	0	0
	A.E51	MECHATROLINK Synchronization Failed	Gr.2	0	0	0	0
	A.E60	MECHATROLINK Communications Error (Reception error)	Gr.2	0	0	0	0
	A.E61	MECHATROLINK Transmission Cycle Error (Synchronization interval error)	Gr.2	0	0	0	0
	A.E62	MECHATROLINK Communications Error (FCS error)	Gr.2	0	0	0	0
	A.E63	MECHATROLINK Synchronization Frame Not Received Alarm	Gr.2	0	0	0	0
	A.E71	Safety Option Module Detection Failure	Gr.1	0	-	-	0
	A.E72	Feedback Option Module Detection Failure	Gr.1	0	-	-	0
	A.E74	Unsupported Safety Option Module	Gr.1	0	-	-	0
	A.E75	Unsupported Feedback Option Module	Gr.1	0	-	-	0
	A.EA2	DRV Alarm 2 (DRIVER WDC error)	Gr.2	0	0	0	0
	A.EB1	Safety Function Signal Input Timing Error	Gr.1	0	-	-	0
	A.ED1	Command Execution Timeout	Gr.2	0	0	0	0
	A.F10	Main Circuit Cable Open Phase	Gr.2	0	0	0	0
	FL-1 <sup>*2</sup>	System Alarm	-	0	-	-	-
	FL-2 <sup>72</sup>		-	0	-	-	-
-	CPF00	Digital Operator Transmission Error 1	-	0	-	-	-
-	CPF01	Digital Operator Transmission Error 2	-	0	-	-	-
	A	Not an error	-	-	-	-	-

\*1 Gr.1: The servomotor is stopped according to the setting in Pn001.0 if an alarm occurs. Pn001.0 is factory-set to stop the servomotor by applying the DB.

Gr.2: The servomotor is stopped according to the setting in Pn00B.1 if an alarm occurs. Pn00B.1 is factory-set to stop the servomotor by setting the speed reference to "0." The servomotor under torque control will always use the Gr.1 method to stop. By setting Pn00B.1 to 1, the servomotor stops using the same method as Gr.1. When coordinating a number of servomotors, use this stopping method to prevent machine damage that may result due to differences in the stop method.

\*2 These alarms are not stored in the alarm history and are displayed only in the panel display.



### 9.1.2 Troubleshooting of Alarms

If an error occurs in servo drives, an alarm display such as A.  $\Box \Box \Box$  and CPF  $\Box \Box$  will appear on the panel display.

Refer to the following table to identify the cause of an alarm and the action to be taken.

AlarmNumber: Alarm Name (Alarm Description)	AlarmNumber:     Alarm Name     Cause     Investigative Actions       arm Description)     Investigative Actions		Corrective Actions	
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	Set the power supply voltage within the specified range, and set Fn005 to initialize the parameter.	
	The power supply went OFF while changing a parameter set- ting.	Check the circumstances when the power supply went OFF.	Set Fn005 to initialize the parameter and then set the parameter again.	
A.020: Parameter	The number of times that parameters were written exceeded the limit.	Check to see if the parameters were frequently changed through the host PC or PLCetc.	The DRIVER may be faulty. Replace the DRIVER. Reconsider the method of writing parameters.	
Checksum Error 1 (The parameter data in the DRIVER is incorrect.)	Malfunction caused by noise from the AC power supply or grounding line, static electricity noise, etc.	Turn the power supply ON and OFF several times. If the alarm still occurs, there may be noise interference.	Take countermeasures against noise.	
	Gas, water drops, or cutting oil entered the DRIVER and caused failure of the internal components.	Check the installation conditions.	The DRIVER may be faulty. Replace the DRIVER.	
	A DRIVER fault occurred.	Turn the power supply ON and OFF several times. If the alarm still occurs, the DRIVER may be faulty.	The DRIVER may be faulty. Replace the DRIVER.	
A.021: Parameter Format Er- ror 1 (The parameter data in	The software version of DRIVER that caused the alarm is older than that of the written parameter.	Check Fn012 to see if the set soft- ware version agrees with that of the DRIVER. If not, an alarm may occur.	Write the parameter of another DRIVER of the same model with the same software version. Then turn the power OFF and then ON again.	
incorrect.)	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.	
A.022:	The power supply voltage suddenly dropped.	Measure the power supply voltage.	The DRIVER may be faulty. Replace the DRIVER.	
System Checksum Error 1	The power supply went OFF while setting an utility function.	Check the circumstances when the power supply went OFF.	The DRIVER may be faulty. Replace the DRIVER.	
(The parameter data in the DRIVER is incorrect.)	A DRIVER fault occurred.	Turn the power supply ON and OFF several times. If the alarm still occurs, the DRIVER may be faulty.	The DRIVER may be faulty. Replace the DRIVER.	
A.030: Main Circuit Detector Error	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.	
A 040 <sup>.</sup>	The DRIVER and servomotor capacities do not match each other.	Check the combination of DRIVER and servomotor capacities.	Select the proper combination of DRIVER and servomotor capacities.	
Parameter Setting Error 1	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.	
(The parameter setting was out of the setting	The parameter setting is out of the setting range.	Check the setting ranges of the parameters that have been changed.	Set the parameter to a value within the setting range.	
range.)	The electronic gear ratio is out of the setting range.	Check the electronic gear ratio. The ratio must satisfy: 0.001 < (Pn20E/Pn210) < 4000.	Set the electronic gear ratio in the range: 0.001< (Pn20E/Pn210) < 4000.	



Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
A.041: Encoder Output Pulse Setting Error	The encoder output pulse (Pn212) is out of the setting range and does not satisfy the setting conditions.	Check the parameter Pn212.	Set Pn212 to a correct value.
	The speed of program JOG operation (Fn004) is lower than the setting range after having changed the electronic gear ratio (Pn20E/Pn210) or the servomotor.	Check if the detection conditions <sup>*1</sup> are satisfied.	Decrease the setting of the electronic gear ratio (Pn20E/Pn210).
A.042: <sup>*1</sup> Parameter Combination Error	The speed of program JOG operation (Fn004) is lower than the setting range after having changed the setting of the pro- gram JOG movement speed (Pn533).	Check if the detection conditions <sup>*1</sup> are satisfied.	Increase the setting of the program JOG movement speed (Pn533).
	The moving speed of advanced autotuning is lower than the setting range after having changed the electronic gear ratio (Pn20E/ Pn210) or the servomotor.	Check if the detection conditions <sup>*1</sup> are satisfied.	Decrease the setting of the electronic gear ratio (Pn20E/Pn210).
A.044: Semi-closed/Fully- closed Loop Control Parameter Setting Error	The setting of the fully-closed module does not match with that of Pn002.3.	Check the settings of Pn002.3.	The setting of fully-closed module must be compatible with the setting of Pn002.3.
A.04A:	For a 4-byte parameter bank, no registration in two consecutive bytes for two bank members.	-	Change the number of bytes for bank members to an appropriate value.
Error 2	The total amount of bank data exceeds 64. (Pn900 × Pn901 > 64)	_	Reduce the total amount of bank data to 64 or less.
A.050: Combination Error	The DRIVER and servomotor capacities do not match each other.	Check the capacities to see if they satisfy the following condition: $(1/4) \leq ($ Servomotor capacity / DRIVER capacity $\leq 4)$	Select the proper combination of DRIVER and servomotor capacities.
servomotor capacities do not correspond.)	An encoder fault occurred.	Replace the servomotor and see if the alarm occurs again.	Replace the servomotor (encoder).
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.051: Unsupported Device Alarm	An unsupported serial converter unit, encoder, or external encoder is connected to the DRIVER.	Check the product specifications, and select the correct model.	Select the correct combination of units.
A.0b0: Cancelled Servo ON Command Alarm	After executing the utility function to turn ON the power to the motor, the servo ON command (SV_ON) was sent from the host PC or PLCetc.	_	Turn the DRIVER power sup- ply OFF and then ON again or exe- cute a software reset.

\*1. Detection conditions

If one of the following conditions detected, an alarm occurs.

• Pn533 [min<sup>-1</sup>] × 
$$\frac{\text{Encoder resolution}}{6 \times 10^5} \le \frac{\text{Pn20E}}{\text{Pn210}}$$
  
• Max Motor Speed [min<sup>-1</sup>] ×  $\frac{\text{Encoder resolution}}{\text{About } 3.66 \times 10^{12}} \ge \frac{\text{Pn20E}}{\text{Pn210}}$ 

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	Incorrect wiring or contact fault of main circuit cables.	Check the wiring. Refer to 3.1 Main Circuit Wiring.	Correct the wiring.
	Short-circuit or ground fault of main circuit cables.	Check for short-circuits across the servomotor terminal phases U, V, and W, or between the grounding and servomotor terminal phases U, V, or W. Refer to <i>3.1 Main Circuit Wiring</i> .	The cable may be short-circuited. Replace the cable.
	Short-circuit or ground fault inside the servomotor.	Check for short-circuits across the servomotor terminal phases U, V, and W, or between the grounding and servomotor terminal phases U, V, or W. Refer to <i>3.1 Main Circuit Wiring</i> .	The servomotor may be faulty. Replace the servomotor.
	Short-circuit or ground fault inside the DRIVER.	Check for short-circuits across the servomotor connection terminals U, V, and W on the DRIVER, or between the grounding and terminal U, V, or W. Refer to <i>3.1 Main</i> <i>Circuit Wiring</i> .	The DRIVER may be faulty. Replace the DRIVER.
A.100:	Incorrect wiring or contact fault of the regenerative resistor.	Check the wiring. Refer to 3.7 Connecting Regenerative Resistors.	Correct the wiring.
Overcurrent or Heat Sink Overheated (An overcurrent flowed through the IGBT or heat sink of DRIVER overheated.)	The dynamic brake (DB: Emergency stop executed from the DRIVER) was frequently activated, or the DB overload alarm occurred.	Check the power consumed by DB resistance (Un00B) to see how many times the DB has been used. Or, check the alarm history display Fn000 to see if the DB overload alarm A.730 or A.731 was reported.	Change the DRIVER model, operating conditions, or the mechanism so that the DB does not need to be used so frequently.
	The generated regenerative resistor value exceeded the DRIVER regenerative energy processing capacity.	Check the regenerative load ratio (Un00A) to see how many times the regenerative resistor has been used.	Check the operating condition including overload, and reconsider the regenerative resistor value.
	The DRIVER regenerative resistance is too small.	Check the regenerative load ratio (Un00A) to see how many times the regenerative resistor has been used.	Change the regenerative resistance value to a value larger than the DRIVER minimum allowable resistance value.
	A heavy load was applied while the servomotor was stopped or running at a low speed.	Check to see if the operating conditions are outside servo drive specifications.	Reduce the load applied to the servomotor or increase the operating speed.
	Malfunction caused by noise interference.	Improve the wiring or installation environment, such as by reducing noise, and check to see if the alarm recurs.	Take countermeasures for noise, such as correct wiring of the FG. Use an FG wire size equivalent to the DRIVER main circuit wire size.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
A.300: Regeneration Error	Regenerative resistor capacity (Pn600) is set to a value other than 0 for a LECYU2-V5, V7, and V8, and a regenerative resistor is notconnected.	Check the regenerative resistor connection and the value of the Pn600.	Connect the regenerative resistor, or set Pn600 to 0 if no regenerative resistor is required.
	The jumper between the power supply terminals B2 and B3 is removed for the DRIVERs other than the DRIVERs shown above.	Confirm that a jumper is mounted between the power supply terminals B2 and B3.	Correctly mount a jumper.
	The regenerative resistor is incorrectly wired, or is removed or disconnected.	Check the regenerative resistor connection.	Correctly connect the regenerative resistor.
	A DRIVER fault occurred.	_	While the main circuit power supply is OFF, turn the control power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.320: Regenerative Over- load	The power supply voltage exceeds the specified limit.	Measure the power supply voltage.	Set the power supply voltage within the specified range.
	Insufficient external regenerative resistance, regenerative resistor capacity, or DRIVER capacity. Or, regenerative power has been continuously flowing back.	Check the operating condition or the capacity.	Change the regenerative resistance, regenerative resistor capacity, or DRIVER capacity. Reconsider the operating conditions.
	Regenerative power continuously flowed back because negative load was continuously applied.	Check the load applied to the servo- motor during operation.	Reconsider the system including servo, machine, and operating conditions.
	The setting of parameter Pn600 is smaller than the regenerative resistor's capacity.	Check the regenerative resistor connection and the value of the Pn600.	Set the Pn600 to a correct value.
	The external regenerative resistance is too high.	Check the regenerative resistance.	Change the regenerative resistance to a correct value or use an regenerative resistor of appropriate capacity.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	The regenerative resistor disconnected when the DRIVER power supply voltage was high.	Measure the resistance of the regenerative resistor using a measuring instrument.	When using a regenerative resistor built in the DRIVER: Replace the DRIVER. When using an regenerative option: Replace the regenerative option.
	In the AC power input mode, DC power was supplied.	Check the power supply to see if it is a DC power supply.	Correct the settings to match the actual power supply specifications.
A.330: Main Circuit Power	In the DC power input mode, AC power was supplied.	Check the power supply to see if it is an AC power supply.	Correct the settings to match the actual power supply specifications.
Supply Wiring Error (Detected when the power to the main circuit is turned ON.)	Regenerative resistor capacity (Pn600) is set to a value other than 0 for a LECYU2-V5, V7, and V8, and an regenerative option is not connected.	Check the regenerative option connection and the value of the Pn600.	Connect the regenerative option, or set Pn600 to 0 if no regenerative resistor is required.
	The jumper between the power supply terminals B2 and B3 is removed for the DRIVERs other than the DRIVERs shown above.	Confirm that a jumper is mounted between the power supply terminals B2 and B3.	Correctly mount a jumper.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A 400-	<ul> <li>For 200-VAC DRIVERs: The AC power supply voltage exceeded 290 V.</li> <li>For 200-VAC DRIVERs: with DC power supply input: The DC power supply voltage exceeded 410 V.</li> </ul>	Measure the power supply voltage.	Set AC/DC power supply voltage within the specified range.
	The power supply is unstable, or was influenced by a lightning surge.	Measure the power supply voltage.	Improve the power supply conditions by installing a surge absorber, etc. Then, turn the power supply OFF and ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
	Voltage for AC power supply was too high during acceleration or deceleration.	Check the power supply voltage and the speed and torque during operation.	Set AC power supply voltage within the specified range.
Overvoltage (Detected in the DRIVER main circuit	The external regenerative resistance is too high for the actual operating conditions.	Check the operating conditions and the regenerative resistance.	Select a regenerative resistance value appropriate for the operating conditions and load.

Confirm that the moment of inertia

ratio is within the allowable range.

### (cont'd)

Increase the deceleration time, or

Turn the control power OFF and then ON again while the main circuit power supply is OFF. If the

alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.

reduce the load.



power supply section.)

The moment of inertia ratio

A DRIVER fault occurred.

exceeded the allowable value.

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	<ul> <li>For 200-VAC DRIVERs: The AC power supply voltage is 120 V or less.</li> </ul>	Measure the power supply voltage.	Set the power supply voltage within the specified range.
A.410:	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.
Undervoltage (Detected in the DRIVER main circuit	Occurrence of instantaneous power interruption.	Measure the power supply voltage.	When the instantaneous power cut hold time (Pn509) is set, decrease the setting.
power suppry section.)	The DRIVER fuse is blown out.	_	Replace the DRIVER, connect a reactor, and run the DRIVER.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.450: Main-Circuit Capacitor Overvoltage	A DRIVER fault occurred.	_	Replace the DRIVER.
	The order of phases U, V, and W in the servomotor wiring is incorrect.	Check the motor wiring.	Confirm that the servomotor is correctly wired.
A.510: Overspeed	A reference value exceeding the overspeed detection level was input.	Check the input value.	Reduce the reference value or adjust the gain.
exceeds the maximum.)	The motor speed exceeded the maximum.	Check the motor speed waveform.	Reduce the speed reference input gain, adjust the servo gain, or reconsider the operating conditions.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A 511 <sup>.</sup>	The encoder output pulse frequency exceeded the limit.	Check the encoder output pulse set- ting.	Decrease the setting of the encoder output pulse (Pn212).
Overspeed of Encoder Output Pulse Rate	The encoder output pulse output frequency exceeded the limit because the motor speed was too high.	Check the encoder output pulse out- put setting and motor speed.	Decrease the motor speed.
A.520: Vibration Alarm	Abnormal vibration was detected at the motor speed.	Check for abnormal noise from the servomotor, and check the speed and torque waveforms during operation.	Reduce the motor speed or reduce the speed loop gain (Pn100).
	The moment of inertia ratio (Pn103) value is greater than the actual value or is greatly changed.	Check the moment of inertia ratio.	Set the moment of inertia ratio (Pn103) to an appropriate value.
A.521: Autotuning Alarm (Vibration was detected while executing the one- parameter tuning, Easy- FFT, or tuning-less function.)	The servomotor vibrated considerably while performing tuning- less function.	Check the motor speed waveform.	Reduce the load so that the moment of inertia ratio falls within the allowable value, or raise the load level using the tuning-less levels setting (Fn200) or reduce the rigidity level.
	The servomotor vibrated considerably during one-parameter tuning or EasyFFT.	Check the motor speed waveform.	Check the operation procedure of corresponding function and take a corrective action.



			()
Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	Incorrect wiring or contact fault of servomotor and encoder.	Check the wiring.	Confirm that the servomotor and encoder are correctly wired.
A.710: A.720:	Operation beyond the overload protection characteristics.	Check the servomotor overload characteristics and executed run command.	Reconsider the load conditions and operating conditions. Or, increase the motor capacity.
Overload A.710: High Load A.720: Low Load	Excessive load was applied during operation because the servomotor was not driven due to mechanical problems.	Check the executed operation reference and motor speed.	Remove the mechanical problems.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
	The servomotor rotates because of external force.	Check the operation status.	Take measures to ensure the servo- motor will not rotate because of external force.
A.730: A.731: Dynamic Brake Over- load (An excessive power consumption of dynamic brake was detected.)	The rotating energy at a DB stop exceeds the DB resistance capacity.	Check the power consumed by DB resistance (Un00B) to see how many times the DB has been used.	Reconsider the following: - Reduce the motor reference speed. - Reduce the moment of inertia ratio. - Reduce the number of times of the DB stop operation.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.740: Overload of Surge Current Limit Resistor (The main circuit power is turned ON/OFF too frequently.)	The inrush current limit resistor operation frequency at the main circuit power supply ON/OFF operation exceeds the allowable range.	_	Reduce the frequency of turning the main circuit power supply ON/OFF.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
	The surrounding air temperature is too high.	Check the surrounding air temperature using a thermostat.	Decrease the surrounding air temperature by improving the DRIVER installation conditions.
	The overload alarm has been reset by turning OFF the power too many times.	Check the alarm history display (Fn000) to see if the overload alarm was reported.	Change the method for resetting the alarm.
A.7A0 : Heat Sink Overheated (Detected when the heat sink temperature exceeds 100°C.)	Excessive load or operation beyond the regenerative energy processing capacity.	Check the accumulated load ratio (Un009) to see the load during operation, and the regenerative load ratio (Un00A) to see the regenerative energy processing capacity.	Reconsider the load and operating conditions.
	Incorrect DRIVER installation orientation or/and insufficient space around the DRIVER.	Check the DRIVER installation conditions.	Install the DRIVER correctly as specified.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.7AB: Built-in Fan in DRIVER Stopped	The fan inside the DRIVER stopped.	Check for foreign matter or debris inside the DRIVER.	Remove foreign matter or debris from the DRIVER. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.



1	- 17	-1)
(CO	nt.	a۱
(00)		u,

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	Alarm occurred when the power to the absolute encoder was initially turned ON.	Check to see if the power was turned ON initially.	Set up the encoder (Fn008).
A 910-	The encoder cable disconnected, and connected again.	Check to see if the power was turned ON initially.	Confirm the connection and set up the encoder (Fn008).
Encoder Backup Error (Only when an absolute encoder is connected.) (Detected on the encoder side.)	The power from both the control power supply (+5 V) from the DRIVER and the battery power supply is not being sup- plied.	Check the encoder connector battery or the connector contact status.	Replace the battery or take similar measures to supply power to the encoder, and set up the encoder (Fn008).
side.)	An absolute encoder fault occurred.	_	If the alarm cannot be reset by set- ting up the encoder again, replace the servomotor.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.820: Encoder Checksum	An encoder fault occurred.	_	Set up the encoder again using Fn008. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
(Detected on the encoder side.)	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.830: Absolute Encoder	The battery connection is incorrect.	Check the battery connection.	Reconnect the battery.
Battery Error (The absolute encoder	The battery voltage is lower than the specified value 2.7 V.	Measure the battery voltage.	Replace the battery.
battery voltage is lower than the specified value.)	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.840: Encoder Data Error (Detected on the encoder side.)	An encoder malfunctioned.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
	Malfunction of encoder because of noise interference, etc.	_	Correct the wiring around the encoder by separating the encoder cable from the motor cable or by checking the grounding and other wiring.
A.850: Encoder Overspeed (Detected when the control power supply was turned ON.) (Detected on the encoder side.)	The servomotor speed is higher than 200 min <sup>-1</sup> when the control power supply was turned ON.	Check the motor rotating speed (Un000) to confirm the servomotor speed when the power is turned ON.	Reduce the servomotor speed to a value less than 200 min <sup>-1</sup> , and turn ON the control power supply.
	An encoder fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	The ambient operating temperature around the servomotor is too high.	Measure the ambient operating temperature around the servomotor.	The ambient operating temperature must be 40°C or less.
A.860: Encoder Overbeated	The motor load is greater than the rated load.	Check the accumulated load ratio (Un009) to see the load.	The motor load must be within the specified range.
(Only when an absolute encoder is connected.) (Detected on the encoder side.)	An encoder fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.8A0: External Encoder Error	Setting the zero point position of external absolute encoder failed because the servomotor rotated.	Before setting the zero point position, use the fully-closed feedback pulse counter (Un00E) to confirm that the servomotor is not rotating.	The servomotor must be stopped while setting the zero point position.
	An external encoder fault occurred.	_	Replace the external encoder.
A.8A1: External Encoder Error	An external encoder fault occurred.	_	Replace the external encoder.
of Module	A serial converter unit fault occurred.	_	Replace the serial converter unit.
A.8A2: External Encoder Error of Sensor (Incremental)	An external encoder fault occurred.	_	Replace the external encoder.
A.8A3: External Encoder Error of Position (Absolute)	An external absolute encoder fault occurred.	_	The external absolute encoder may be faulty. Refer to the encoder manufacturer's instruction manual for corrective actions.
A.8A5: External Encoder Overspeed	The overspeed from the external encoder occurred.	Check the maximum speed of the external encoder.	Keep the external encoder below its maximum speed.
A.8A6: External Encoder Overheated	The overheat from the external encoder occurred.	_	Replace the external encoder.
A.b31: Current Detection Error 1	The current detection circuit for phase U is faulty.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.b32: Current Detection Error 2	The current detection circuit for phase V is faulty.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.b33: Current Detection Error	The detection circuit for the cur- rent is faulty.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
U C	The motor cable is disconnected.	Check for disconnection of the motor cable.	Correct the servomotor wiring.
A.b6A: MECHATROLINK Communications ASIC Error 1	DRIVER MECHATROLINK communication section fault.	-	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.



Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
A.b6b: MECHATROLINK Communications ASIC Frror 2	MECHATROLINK data reception error occurred due to noise interference.	_	Take measures against noise. Check the MECHATROLINK communications cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communications cable.
	DRIVER MECHATROLINK communication section fault.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.bF0: System Alarm 0	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.bF1: System Alarm 1	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.bF2: System Alarm 2	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.bF3 <sup>:</sup> System Alarm 3	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.bF4: System Alarm 4	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
	The order of phases U, V, and W in the servomotor wiring is incorrect.	Check the motor wiring.	Confirm that the servomotor is correctly wired.
A.C10: Servo Overrun Detected (Detected when the servomotor power is ON.)	An encoder fault occurred.	_	If the alarm still occurs after turning the power OFF and then ON again, even though the servomotor is correctly wired, the servomotor may be faulty. Replace the servomotor.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.C80: Absolute Encoder	An encoder fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
Clear Error and Multi- turn Limit Setting Error	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.

			(******)
Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
A.C90: Encoder	Contact fault of connector or incorrect wiring for encoder cable.	Check the connector contact status for encoder cable.	Re-insert the connector and confirm that the encoder is correctly wired.
	Cable disconnection for encoder cable or short-circuit. Or, incorrect cable impedance.	Check the encoder cable.	Use the cable with the specified rating.
	Corrosion caused by improper temperature, humidity, or gas, short-circuit caused by intrusion of water drops or cutting oil, or connector contact fault caused by vibration.	Check the operating environment.	Improve the operating environmental conditions, and replace the cable. If the alarm still occurs, replace the DRIVER.
	Malfunction caused by noise interference.	_	Correct the wiring around the encoder by separating the encoder cable from the motor cable or by checking the grounding and other wiring.
	A DRIVER fault occurred.	_	Connect the servomotor to another DRIVER, and turn ON the control power. If no alarm occurs, the DRIVER may be faulty. Replace the DRIVER.
	Noise interference occurred on the I/O signal line because the encoder cable is bent and the sheath is damaged.	Check the encoder cable and connector.	Confirm that there is no problem with the cable layout.
A.C91 : Encoder Communications	The encoder cable is bundled with a high-current line or near a high-current line.	Check the cable layout for encoder cable.	Confirm that there is no surge volt- age on the cable.
Position Data Error	The FG potential varies because of influence from machines on the servomotor side, such as the welder.	Check the cable layout for encoder cable.	Properly ground the machines to separate from the encoder FG.
	Noise interference occurred on the I/O signal line from the encoder.	_	Take countermeasures against noise for the encoder wiring.
	Excessive vibration and shocks were applied to the encoder.	Check the operating environment.	Reduce the machine vibration or correctly install the servomotor.
A.C92: Encoder Communications Timer Error	An encoder fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.CA0: Encoder Parameter Error	An encoder fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	The wiring and contact for encoder cable are incorrect.	Check the wiring.	Correct the wiring.
	Noise interference occurred due to incorrect cable specifications of encoder cable.	_	Use tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of at least 0.12 mm <sup>2</sup> .
	Noise interference occurred because the wiring distance for the encoder cable is too long.	_	The wiring distance must be 50 m max.
A.Cb0: Encoder Echoback Error	The FG potential varies because of influence from machines on the servomotor side, such as the welder.	Check the cable layout for encoder cable.	Properly ground the machines to separate from encoder FG.
	Excessive vibration and shocks were applied to the encoder.	Check the operating environment.	Reduce the machine vibration or correctly install the servomotor.
	An encoder fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
	When using a direct drive (DD) servomotor, the multiturn limit value (Pn205) is different from that of the encoder.	Check the value of the Pn205.	Correct the setting of Pn205 (0 to 65535).
A.CC0: Multiturn Limit Disagreement	The multiturn limit value of the encoder is different from that of the DRIVER. Or, the multi- turn limit value of the DRIVER has been changed.	Check the value of the Pn205 of the DRIVER.	Execute Fn013 at the occurrence of alarm.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
	Wiring of cable between serial converter unit and DRIVER is incorrect or contact is faulty.	Check the external encoder wiring.	Correct the cable wiring.
A.CF1: Feedback Option Module Communications Error (Reception error)	The specified cable is not used between serial converter unit and DRIVER.	Confirm the external encoder wiring specifications.	Use the specified cable.
	Cable between serial converter unit and DRIVER is too long.	Measure the length of this cable.	Use 20-m cable max.
	Sheath of cable between serial converter unit and DRIVER is broken.	Check the cable for damage.	Replace the cable.
A.CF2: Feedback Option Module	Noise interferes with the cable between serial converter unit and DRIVER.	_	Correct the wiring around serial converter unit, e.g., separating I/O signal line from main circuit cable or grounding.
Communications Error (Timer stop)	A serial converter unit fault occurred.	_	Replace the serial converter unit.
	A DRIVER fault occurred.	_	Replace the DRIVER.



Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
	The servomotor U, V, and W wirings is faulty.	Check the motor cable connection.	Confirm that there is no contact fault in the motor wiring or encoder wiring.
A.d00: Position Error Over- flow (Position error exceeded the value set in the excessive position error alarm level (Pn520).)	The position reference speed is too high.	Reduce the reference speed, and operate the DRIVER.	Reduce the position reference speed or acceleration of position reference. Or, reconsider the electronic gear ratio.
	The acceleration of the position reference is too high.	Reduce the reference acceleration, and operate the DRIVER.	Reduce the reference acceleration of the position reference using a MECHATROLINK command, or smooth the acceleration of the position reference by selecting the position reference filter (ACCFIL) using a MECHATROLINK command.
	Setting of the excessive position error alarm level (Pn520) is low against the operating condition.	Check the alarm level (Pn520) to see if it is set to an appropriate value.	Set the Pn520 to proper value.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.d01: Position Error Over- flow Alarm at Servo ON	This alarm occurs if the servomotor power is turned ON when the position error is greater than the set value of Pn526 while the servomotor power is OFF.	alarm occurs if the omotor power is turned ON in the position error is greater the set value of Pn526 while servomotor power is OFF. Check the position error amount (Un008) while the servomotor power is OFF.	
A.d02: Position Error Over- flow Alarm by Speed Limit at Servo ON	When the position errors remain in the error counter, Pn529 limits the speed if the servomotor power is ON. If Pn529 limits the speed in such a state, this alarm occurs when position references are input and the number of position errors exceeds the value set for the excessive position error alarm level (Pn520).	_	Correct the excessive position error alarm level (Pn520). Or, adjust the speed limit level at servo ON (Pn529).
A.d10: Motor-load Position	Motor rotation direction and external encoder installation direction are opposite.	Check the and the external encoder installation direction.	Install the external encoder in the opposite direction, or change the setting of the external encoder usage method (Pn002.3) to reverse the direction.
	Mounting of the load (e.g., stage) and external encoder joint installation are incorrect.	Check the external encoder mechanical connection.	Check the mechanical joints.
A.E02: MECHATROLINK	MECHATROLINK transmission cycle fluctuated.	_	Remove the cause of transmission cycle fluctuation at host PC or PLCetc.
Internal Synchronization Error 1	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.E40:       Setting of MECHATROLINK         MECHATROLINK       Setting of MECHATROLINK         transmission Cycle       Setting is out of         Setting Error       Setting error		Check the MECHATROLINK transmission cycle setting.	Set the transmission cycle to the proper value.



Alarm Number: Alarm Name (Alarm Description)	larm Number: Alarm Name Cause Investigative Actions rm Description)		Corrective Actions
A.E41: MECHATROLINK Communications Data Size Setting Error	.E41: ECHATROLINK ommunications Data ize Setting Error		Reset the setting of the DIP switch S3 to change the number of transmission bytes to the proper value.
A.E42: MECHATROLINK	The station address is out of the allowable setting range.	Check the rotary switches, S1 and S2, to see if the station address is within the allowable range from 03 to EF.	Check the setting for the station address of the host PC or PLCetc, and reset the setting of the rotary switches, S1 and S2 to change the address to the proper value between 03 and EF.
Station Address Setting       Two or more stations on the Check that two or more station communications network have the communications network same address.         WDT data of heat PC or       Check the WDT data underline for the same address.	Check that two or more stations on the communications network have the same address.	Check the setting for the station address of the host PC or PLCetc, and reset the setting of the rotary switches, S1 and S2 to change the address to the proper value between 03 and EF.	
	WDT data of host PC or PLCetc was not updated correctly.	Check the WDT data updating for the host PC or PLCetc.	Update the WDT data at the host PC or PLCetc correctly.
Synchronization Error	A DRIVER fault occurred.		Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.E51: MECHATROLINK Synchronization	WDT data of host PC or PLCetc was not updated correctly at the synchronization communications start, and synchronization communications could not start.	Check the WDT data updating for the host PC or PLCetc.	Update the WDT data at the host PC or PLCetc correctly.
	A DRIVER fault occurred.		Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
	MECHATROLINK wiring is incorrect.	Check the MECHATROLINK wirings.	Correct the MECHATROLINK wiring. Connect the terminator correctly.
A.E60: MECHATROLINK Communications error (Reception error)	MECHATROLINK data reception error occurred due to noise interference.	_	Take measures against noise. Check the MECHATROLINK communications cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communications cable.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.E61: MECHATROLINK Transmission Cycle	MECHATROLINK transmission cycle fluctuated.	Check the MECHATROLINK transmission cycle setting.	Remove the cause of transmission cycle fluctuation at host PC or PLCetc.
(Synchronization interval error)	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.



			(cont'd)
Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
A.E62: MECHATROLINK Communications error	MECHATROLINK wiring is incorrect.	Check the MECHATROLINK wirings.	Correct the MECHATROLINK wiring.
(FCS error)	MECHATROLINK data reception error occurred due to noise interference.	_	Take measures against noise. ChecktheMECHATROLINKcommunications cable and FG wiringand take measures such as addingferritecoreontheMECHATROLINKcommunicationscable.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.E63: MECHATROLINK Synchronization	MECHATROLINK wiring is incorrect.	Check the MECHATROLINK wirings.	Correct the MECHATROLINK wiring.
Frame Not Received Alarm	MECHATROLINK data reception error occurred due to noise interference.	_	Take measures against noise. Check the MECHATROLINK communications cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communications cable.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
	The connection between the DRIVER and the safety option module is faulty.	Check the connection between the DRIVER and the safety option module.	Correctly connect the safety option module.
A.E71: Safety Option Module Detection Failure	The safety option module was disconnected.	_	Execute Fn014 (Resetting configuration error of option module) with using the SigmaWin+ and turn the power supply OFF and then ON again.
	A safety option module fault occurred.	-	Replace the safety option module.
	A DRIVER fault occurred.	_	Replace the DRIVER.
	The connection between the DRIVER and the Feedback Option Module is Faulty.	Check the connection between the DRIVER and the Feedback Option Module.	Correctly connect the Feedback Option Module.
A.E72: Feedback Option Module Detection Failure	The Feedback Option Module was disconnected.	_	Execute resetting configuration error in option modules (Fn014) and turn the power supply OFF and then ON again.
	A Feedback Option Module fault occurred.	_	Replace the Feedback Option Module.
	A DRIVER fault occurred.	-	Replace the DRIVER.

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions		
A.E74:	A safety option module fault occurred.	_	Replace the safety option module.		
Option Module	A unsupported safety option module was connected.	Refer to the catalog of the connected safety option module.	Connect a compatible safety option module.		
A.E75:	A feedback option module fault occurred.	_	Replace the feedback option module.		
Unsupported Feed- back Option Module	A unsupported feedback option module was connected.	Refer to the catalog of the connected feedback option module or the manual of the DRIVER.	Connect a compatible feedback option module.		
Α ΕΔ2 <sup>.</sup>	MECHATROLINK transmission cycle fluctuated.	Check the MECHATROLINK transmission cycle setting.	Remove the cause of transmission cycle fluctuation at host PC or		
DRV Alarm 2 (DRIVER WDT error)	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.		
A.Eb1	Please contact SMC.				
A.Ed1:	A timeout error occurred when	Check the motor status when the command is executed.	Execute the SV_ON or SENS_ON command only when the motor is not running.		
Command Execution Timeout	using an MECHATROLINK command.	For fully-closed loop control, check the status of the external encoder after an output is made to execute the command.	Execute the SENS_ON command only when an external encoder is connected.		
A F10:	The three-phase power supply wiring is incorrect.	Check the power supply wiring.	Confirm that the power supply is correctly wired.		
Main Circuit Cable Open Phase (With the main power	The three-phase power supply is unbalanced.	Measure the voltage at each phase of the three-phase power supply.	Balance the power supply by changing phases.		
supply ON, voltage was low for more than 1 second in an R, S, or T phase.) (Detected when the main power supply was turned	A single-phase power is input without setting Pn00B.2 (power supply method for three-phase DRIVER) to 1 (single-phase power supply).	Check the power supply and the parameter setting.	Match the parameter setting to the power supply.		
ON.)	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.		

Alarm Number: Alarm Name (Alarm Description)	Cause	Investigative Actions	Corrective Actions
FL-1 <sup>*2</sup> : System Alarm	DRIVER failure	_	Turn the power supply OFF and then ON again. If the alarm still
FL-2 <sup>*2</sup> : System Alarm		-	occurs, the DRIVER may be faulty. Replace the DRIVER.
CPF00 <sup>*3</sup> : Digital Operator	The contact between the digital operator and the DRIVER is faulty.	Check the connector contact.	Insert securely the connector or replace the cable.
Transmission Error 1	Malfunction caused by noise interference.		Keep the digital operator or the cable away from noise sources.
CPF01 <sup>*3</sup> :	A digital operator fault occurred.		Disconnect the digital operator and then re-connect it. If the alarm still occurs, the digital operator may be faulty. Replace the digital operator.
Transmission Error 2	A DRIVER fault occurred.		Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.

\*2. These alarms are not stored in the alarm history and are displayed only in the panel display.

\*3. Digital operator is made of the YASUKAWA ELECTRIC Ltd.

### 9.2 Warning Displays

The following sections describe troubleshooting in response to warning displays.

The warning name and warning meaning output are listed in order of the warning numbers in 9.2.1 List of Warnings.

The causes of warnings and troubleshooting methods are provided in 9.2.2 Troubleshooting of Warnings.

#### 9.2.1 List of Warnings

This section provides list of warnings.

After its cause has been removed, the warning can be deactivated in any of the methods marked **O** in the warning reset column.

#### (1) Commands for the MECHATROLINK-III standard servo profile

			Warning reset				
	Warning Number	Warning Name	Automatically	Power OFF ↓ ON	Alarm warning clear command [ALM-CLR]	SigmaWin+ [Alarm] [Display Alarm]   Reset button	SigmaWin+ [Setup] [Software Reset] L Execute button
	A.900 <sup>*3</sup>	Position Error Overflow	-	0	0	0	0
	A.901 <sup>*3</sup>	Position Error Overflow Alarm at Servo ON	-	0	0	0	0
	A.910 <sup>*3</sup>	Overload	-	0	0	0	0
	A.911 <sup>*3</sup>	Vibration	-	0	0	0	0
	A.920 <sup>*3</sup>	Regenerative Overload	-	0	0	0	0
	A.921 <sup>*3</sup>	Dynamic Brake Overload	_	0	0	0	0
	A.930 <sup>*3</sup>	Absolute Encoder Battery Error	-	0	0	0	0
	A.94A <sup>*4</sup>	Data Setting Warning 1 (Parameter Number Error)	0	0	0	0	0
	A.94B <sup>*4</sup>	Data Setting Warning 2 (Out of Range)	0	0	0	0	0
	A.94C <sup>*4</sup>	Data Setting Warning 3 (Calculation Error)	0	0	0	0	0
	A.94D <sup>*4</sup>	Data Setting Warning 4 (Parameter Size)	0	0	0	0	0
bu	A.94E <sup>*4</sup>	Data Setting Warning 5 (Latch Mode Error)	-	0	0	0	0
E	A.95A <sup>*4</sup>	Command Warning 1 (Unsatisfying Command)	0	0	0	0	0
Na Na	A.95B <sup>*4</sup>	Command Warning 2 (Non-supported Command)	0	0	0	0	0
_	A.95D <sup>*4</sup>	Command Warning 4 (Command Interference)	0	0	0	0	0
	A.95E <sup>*4</sup>	Command Warning 5 (Subcommand Disable)	0	0	0	0	0
	A.95F <sup>*4</sup>	Command Warning 6 (Undefined Command)	0	0	0	0	0
	A.960 <sup>*4</sup>	MECHATROLINK Communications Warning	-	0	0	0	0
	A.962 <sup>*4</sup>	MECHATROLINK Communications Warning (FCS Error)	-	0	0	0	0
	A.963*4	MECHATROLINK Communications Warning (Synchronization Frame Not Received)	-	0	0	0	0
	A.971 <sup>*5</sup>	Undervoltage	-	0	0	0	0
	A.97A <sup>*4</sup>	Command Warning 7 (Phase Error)	0	0	0	0	0
	A.97B <sup>-4</sup>	Data Clamp (Out of Range)	0	0	0	0	0
	A.9A0 <sup>*3</sup>	Overtravel	-	0	0	0	0

\*3. Use Pn008.2 to activate or not the warning detection.

\*4. Use Pn800.1 to activate or not the warning detection.

\*5. Use Pn008.1 to activate or not the warning detection.

\*6. If using the commands for the MECHATROLINK-III standard servo profile, the warning will automatically be cleared after the correct command is received.

1	(2)	) Commands for the MECHATROI INK-II-compatible prot	file
	<u>م</u>		iiiC

		Warning Name		Warning reset			
	Warning Number			Alarm warning clear command [ALM-CLR]	SigmaWin+ [Alarm] [Display Alarm]   Reset button	SigmaWin+ [Setup] [Software Reset]   Execute button	
	A.900 <sup>*3</sup>	Position Error Overflow	0	0	0	0	
	A.901 <sup>*3</sup>	Position Error Overflow Alarm at Servo ON	0	0	0	0	
	A.910 <sup>*3</sup>	Overload	0	0	0	0	
	A.911 <sup>*3</sup>	Vibration	0	0	0	0	
	A.920 <sup>*3</sup>	Regenerative Overload	0	0	0	0	
	A.921 <sup>*3</sup>	Dynamic Brake Overload	0	0	0	0	
	A.930 <sup>-3</sup>	Absolute Encoder Battery Error	0	0	0	0	
	A.94A <sup>*4</sup>	Data Setting Warning 1 (Parameter Number Error)	0	0	0	0	
	A.94B <sup>*4</sup>	Data Setting Warning 2 (Out of Range)	0	0	0	0	
	A.94C <sup>*4</sup>	Data Setting Warning 3 (Calculation Error)	0	0	0	0	
	A.94D*4	Data Setting Warning 4 (Parameter Size)	0	0	0	0	
Б	A.94E <sup>*4</sup>	Data Setting Warning 5 (Latch Mode Error)	0	0	0	0	
i.	A.95A <sup>*4</sup>	Command Warning 1 (Unsatisfying Command)	0	0	0	0	
/ar	A.95B <sup>*4</sup>	Command Warning 2 (Non-supported Command)	0	0	0	0	
5	A.95D <sup>*4</sup>	Command Warning 4 (Command Interference)	0	0	0	0	
	A.95E <sup>*4</sup>	Command Warning 5 (Subcommand Disable)	0	0	0	0	
	A.95F <sup>*4</sup>	Command Warning 6 (Undefined Command)	0	0	0	0	
	A.960 <sup>*4</sup>	MECHATROLINK Communications Warning	0	0	0	0	
	A.962 <sup>*4</sup>	MECHATROLINK Communications Warning (FCS Error)	0	0	0	0	
	A.963 <sup>*4</sup>	MECHATROLINK Communications Warning (Synchronization Frame Not Received)	0	0	0	0	
	A.971 <sup>*5</sup>	Undervoltage	0	0	0	0	
	A.97A <sup>*4</sup>	Command Warning 7 (Phase Error)	0	0	0	0	
	A.97B <sup>*4</sup>	Data Clamp (Out of Range)	0	0	0	0	
	A.9A0 <sup>*3</sup>	Overtravel	0	0	0	0	

\*3. Use Pn008.2 to activate or not the warning detection.

\*4. Use Pn800.1 to activate or not the warning detection.

\*5. Use Pn008.1 to activate or not the warning detection.

## 9.2.2 Troubleshooting of Warnings

Refer to the following table to identity the cause of a warning and the action to be taken. Contact SMC if the problem cannot be solved by the described corrective action.

Warning Number: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions
	The servomotor U, V, and W wirings is faulty.	Check the motor cable connection.	Confirm that there is no contact fault in the motor wiring or encoder wiring.
	The DRIVER gain is too low.	Check the DRIVER gain.	Increase the servo gain by using the function such as advanced autotuning.
A.900: Position Error Overflow	The acceleration of the position reference is too high.	Reduce the reference acceleration, and operate the DRIVER.	Reduce the reference acceleration of the position reference using a MECHATROLINK command, or smooth the acceleration of the position reference by selecting the position reference filter (ACCFIL) using a MECHATROLINK command.
	Setting of the excessive position error alarm level (Pn520) is low against the operating condition.	Check the alarm level (Pn520) to see if it is set to an appropriate value.	Set the Pn520 to proper value.
	A DRIVER fault occurred.	_	Turn the power supply OFF and then ON again. If the alarm still occurs, the DRIVER may be faulty. Replace the DRIVER.
A.901: Position Error Overflow Alarm at Servo ON	When the servomotor power is ON, the position error exceeded the parameter setting (Pn526×Pn528/100).	_	Set an appropriate value for the excessive position error warning level at servo ON (Pn528).
	Incorrect wiring or con- tact fault of servomotor and encoder.	Check the wiring.	Confirm that the servomotor and encoder are correctly wired.
A.910: Overload	Operation beyond the overload protection characteristics.	Check the motor overload characteristics and executed run command.	Reconsider the load conditions and operating conditions. Or, increase the motor capacity.
(Warning before alarm A.710 or A.720 occurs)	Excessive load was applied during operation because the servomotor was not driven due to mechanical problems.	Check the executed operation reference and motor speed.	Remove the mechanical problems.
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
	Abnormal vibration was detected at the motor speed.	Check for abnormal noise from the servomotor, and check the speed and torque waveforms during operation.	Reduce the motor speed or reduce the servo gain by using the function such as one-parameter tuning.

The moment of inertia ratio (Pn103) value is greater than the actual value or is greatly changed.	Check the moment of inertia ratio.	Set the moment of inertia ratio (Pn103) to an appropriate value.
---	------------------------------------	--

(cont'd	)
(001100	·/

Warning Number: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions
	The power supply volt- age exceeds the specified limit.	Measure the power supply voltage.	Set the power supply voltage within the specified range.
A.920: Regenerative Overload (Warning before the alarm A.320 occurs)	Insufficient external regenerative resistance, regenerative resistor capacity, or DRIVER capacity. Or, regenerative power has been continuously flowing back.	Check the operating condition or the capacity.	Change the regenerative resistance, regenerative resistor capacity, or DRIVER capacity. Reconsider the operating conditions.
	Regenerative power continuously flowed back because negative load was continuously applied.	Check the load to the servomotor during operation.	Reconsider the system including servo drives, machine, and operating conditions.
	The servomotor rotates because of external force.	Check the operation status.	Take measures to ensure the servomotor will not rotate because of external force.
A.921: Dynamic Brake Overload (Warning before the alarm A.731	The rotating energy at a DB stop exceeds the DB resistance capacity.	Check the power consumed by DB resistance (Un00B) to see how many times the DB has been used.	Reconsider the following: - Reduce the motor reference speed. - Reduce the moment of inertia ratio. - Reduce the number of times of the DB stop operation.
occurs)	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.930: Absolute Encoder Battery	The battery connection is incorrect.	Check the battery connection.	Reconnect the battery.
Error (The absolute encoder battery voltage is lower	The battery voltage is lower than the specified value 2.7 V.	Measure the battery voltage.	Replace the battery.
than the specified value.) * Only when an absolute encoder is connected.	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.
A.94A: Data Setting Warning 1 (Parameter Number Error)	Disabled parameter number was used.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Use the correct parameter number.
A.94B: Data Setting Warning 2 (Out of Range)	Attempted to send values outside the range to the command data.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Set the value of the parameter within the allowable range.
A.94C: Data Setting Warning 3 (Calculation Error)	Calculation result of set value is incorrect.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Set the value of the parameter within the allowable range.
A.94D: Data Setting Warning 4 (Parameter Size)	Parameter size set in command is incorrect.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Use the correct parameter size.



Warning Number: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions	
A.94E Data Setting Warning 5 (Latch mode error)	Latch mode error is detected.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Change the setting value of Pn850 or the LT_MOD data for the LTMOD_ON command sent by the host PC or PLCetc to the proper value.	
A.95A Command Warning 1 (Unsatisfying Command)	Command sending condition is not satisfied.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Send a command after command sending condition is satisfied.	
A.95B Command Warning 2 (Non-supported Command)	DRIVER received unsupported command.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Do not sent an unsupported command.	
A.95D Command Warning 4 (Command Interference)	Command sending condition for latch-related commands is not satisfied.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Send a command after command sending condition is satisfied.	
A.95E Command Warning 5 (Subcommand Disable)	Subcommand sending condition is not satisfied.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Send a command after command sending condition is satisfied.	
A.95F Command Warning 6 (Undefined Command)	Undefined command was sent.	Refer to 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning to determine which command was the cause of the warning.	Do not use an undefined command.	
	MECHATROLINK wiring is incorrect.	Confirm the wiring.	Correct the MECHATROLINK wiring. Or, connect a terminal connector to the terminal station.	
A.960 MECHATROLINK Communications Warning	MECHATROLINK data reception error occurred due to noise interference.	Confirm the installation conditions.	Take measures against noise. Check the MECHATROLINK communications cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communications cable.	
	A DRIVER fault occurred.	_	A fault occurred in the DRIVER. Replace the DRIVER.	
			(cont'd)	
--	--	--------------------------------------	---	--
Warning Num- ber: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions	
	MECHATROLINK wiring is incorrect.	Confirm the wiring.	Correct the MECHATROLINK wiring. Or, connect a terminal to the terminal station.	
A.962 MECHATROLINK Communications Warning (FCS Error)	MECHATROLINK data reception error occurred due to noise interference.	Confirm the installation conditions.	Take measures against noise. Check the MECHATROLINK communica- tions cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communi- cations cable.	
(FCS EII0I)	A DRIVER fault occurred.	_	A fault occurred in the DRIVER. Replace the DRIVER.	
	MECHATROLINK wiring is incorrect.	Confirm the wiring.	Correct the MECHATROLINK wir- ing. Or, connect a terminal to the terminal station.	
A.963 MECHATROLINK Communica- tions Warning (Synchronization Frame Not Received)	MECHATROLINK data reception error occurred due to noise interference.	Confirm the installation conditions.	Take measures against noise. Check the MECHATROLINK communica- tions cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communi- cations cable.	
	A DRIVER fault occurred.	_	A fault occurred in the DRIVER. Replace the DRIVER.	
A.971: Under- voltage	<ul> <li>a) For 100 VAC DRIVERs: The AC power supply voltage is 60 V or less.</li> <li>b) For 200-VAC DRIVERs: The AC power supply voltage is 140 V or less.</li> <li>c) For 400-VAC DRIVERs: The AC power supply voltage is 280 V or less.</li> </ul>	Measure the power supply voltage.	Set the power supply voltage within the specified range.	
	The power supply volt- age dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.	
	Occurrence of instanta- neous power interrup- tion.	Measure the power supply voltage.	When the instantaneous power cut hold time (Pn509) is set, decrease the setting.	
	The DRIVER fuse is blown out.	_	Replace the DRIVER and con- nect a reactor to the DRIVER.	
	A DRIVER fault occurred.	_	The DRIVER may be faulty. Replace the DRIVER.	



			(cont'd)
Warning Num- ber: Warning Name (Warning Description)	Cause	Investigative Actions	Corrective Actions
A.97A Command Warning 7 (Phase Error)	A command that cannot be executed in the cur- rent phase was sent.	_	Send a command after command sending condition is satisfied.
A.97B Data Clamp (Out Of Range)	The set command data was clamped to a mini- mum or maximum value out of the allow- able setting range.	_	Set the value of the command data within the allowable range.
A.9A0: Overtravel (Overtravel status is detected.)	When the servomotor power is ON, over- travel status is detected.	Check the input signal monitor (Un005) to check the status of the overtravel signals.	<ul> <li>Refer to 9.4 Troubleshooting Malfunction Based on Operation and Conditions of the Servomotor. Even if overtravel signals were not shown by the input signal monitor (Un005), momentary overtravel may have been detected. Take the following precautions.</li> <li>a) Do not specify movements that would cause overtravel from the host PC or PLCetc.</li> <li>b) Check the wiring of the overtravel signals.</li> <li>c) Take countermeasures for noise.</li> </ul>

#### 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning

The command data received on occurrence of an alarm or warning, such as a data setting warning (A.94 $\Box$ ) or a command warning (A.95 $\Box$ ) can be monitored using the following parameters. The following is an example of the data when an alarm/warning has occurred in the normal state.

Command Byte Order	Command Data Storage at Alarm/Warning Occurrence		
Dyte order	CMD	RSP	Example: Pn8A8 = 87 65 43 21
0	Pn890.1 to 0	Pn8A8.1 to 0	·
1	Pn890.3 to 2	Pn8A8.3 to 2	
2	Pn890.5 to 4	Pn8A8.5 to 4	·
3	Pn890.7 to 6	Pn8A8.7 to 6	
4 to 7	Pn892	Pn8AA	-
8 to 11	Pn894	Pn8AC	-
12 to 15	Pn896	Pn8AE	-
16 to 19	Pn898	Pn8B0	-
20 to 23	Pn89A	Pn8B2	-
24 to 27	Pn89C	Pn8B4	-
28 to 31	Pn89E	Pn8B6	
32 to 35	Pn8A0	Pn8B8	
36 to 39	Pn8A2	Pn8BA	
40 to 43	Pn8A4	Pn8BC	
44 to 47	Pn8A6	Pn8BE	

Command Data Monitor at Alarm/Warning Occurrence: Pn890 to Pn8A6 Response Data Monitor at Alarm/Warning Occurrence: Pn8A8 to Pn8BE

Note 1. Data is stored in little endian byte order and displayed in the hexadecimal format.
 2. For details on commands, refer to *8 MECHATROLINK-III Commands*.

## 9.4 Troubleshooting Malfunction Based on Operation and Conditions of the Servomotor

Troubleshooting for the malfunctions based on the operation and conditions of the servomotor is provided in this section.

Be sure to turn OFF the servo system before troubleshooting items shown in bold lines in the table.

Problem	Probable Cause	Investigative Actions	Corrective Actions	
	The control power supply is not ON.	Check voltage between control power terminals.	Correct the wiring.	
	The main circuit power supply is not ON.	Check the voltage between main circuit power terminals.	Correct the wiring.	
	Wiring of I/O signal connector CN1 is faulty or disconnected.	Check if the connector CN1 is properly inserted and connected.	Correct the connector CN1 connection.	
	Wiring for motor cable or encoder cable is disconnected.	Check the wiring.	Correct the wiring.	
	Overloaded	Run under no load and check the load status.	Reduce load or replace with larger capacity servomotor.	
	Encoder type differs from parameter setting (Pn002.2).	Check the settings for parameter Pn002.2.	Set parameter Pn002.2 to the encoder type being used.	
Servomotor Does Not Start	Settings for the input signal selections (Pn50A, Pn50B and Pn511) is incorrect.	Check the settings for parameters Pn50A, Pn50B and Pn511.	Correct the settings for parameter Pn50A, Pn50B and Pn511.	
	SV_ON command is not sent.	Check the command sent from the host PC or PLCetc.	Send the SV_ON command.	
	SENS_ON command is not sent.	Check the command sent from the host PC or PLCetc.	Send the command in the correct DRIVER sequence.	
	The forward run prohibited (P-OT) and reverse run prohibited (N-OT) input signals are turned OFF.	Check P-OT or N-OT input signal.	Turn P-OT or N-OT input signal ON.	
	The safety input signal (/HWBB1 or /HWBB2) remains OFF.	Check the /HWBB1 and /HWBB2 input signal.	Set the /HWBB1 and /HWBB2 input signal to ON. When not using the safety function, mount the safety function jumper connector (provided as an accessory) on the CN8.	
	A DRIVER fault occurred.	_	Replace the DRIVER.	
Servomotor	Servomotor wiring is incorrect.	Check the wiring.	Correct the wiring.	
Moves Instantaneously, and then Stops	Encoder wiring is incorrect.	Check the wiring.	Correct the wiring.	
Servomotor Speed Unstable	Wiring connection to servomotor is defective.	Check connections of power line (phases U, V, and W) and encoder connectors.	Tighten any loose terminals or connectors and correct the wiring.	
Servomotor Rotates Without Reference Input	A DRIVER fault occurred.	_	Replace the DRIVER.	
	Improper Pn001.0 setting	Check the setting for parameter Pn001.0.	Correct the setting for parameter Pn001.0.	
Dynamic Brake Does Not Operate	DB resistor disconnected	Check if excessive moment of inertia, motor overspeed, or DB frequently activated occurred.	Replace the DRIVER, and reduce the load.	
	DB drive circuit fault	_	There is a defective component in the DB circuit. Replace the DRIVER.	



Problem	Probable Cause	Investigative Actions	Corrective Actions
	The servomotor largely vibrated during execution of tuning-less function.	Check the motor speed waveform.	Reduce the load so that the moment of inertia ratio becomes within the allowable value, or increase the load level or lower the tuning level for the tuning-less levels setting (Fn200).
		Check if there are any loose mounting screws.	Tighten the mounting screws.
	Mounting is not secured.	Check if there is misalignment of couplings.	Align the couplings.
		Check if there are unbalanced couplings.	Balance the couplings.
	Bearings are defective.	Check for noise and vibration around the bearings.	Replace the servomotor.
	Vibration source at the driven machine.	Check for any foreign matter, damage, or deformations on the machinery's movable parts.	Contact the machine manufacturer.
	Noise interference due to incorrect I/O signal cable specifications.	The I/O signal cable must be tinned annealed copper shielded twistedpair or screened unshielded twistedpair cable with a core of 0.12 mm <sup>2</sup> min.	Use the specified I/O signal cable.
Abnormal Noise	Noise interference due to length of I/O signal cable.	Check the length of the I/O signal cable.	The I/O signal cable length must be no more than 3 m.
from Servomotor	Noise interference due to incorrect cable specifications of encoder cable.	The encoder cable must be tinned annealed copper shielded twisted- pair or screened unshielded twistedpair cable with a core of $0.12$ mm <sup>2</sup> min.	Use the specified encoder cable.
	Noise interference due to length of encoder cable.	Check the length of the encoder cable.	The encoder cable must be no more than 50 m.
	Noise interference due to damaged encoder cable.	Check if the encoder cable is bent and the sheath is damaged.	Replace the encoder cable and correct the cable layout.
	Excessive noise to the encoder cable.	Check if the encoder cable is bundled with a high-current line or near a high-current line.	Correct the cable layout so that no surge is applied.
	The FG potential varies because of influence from machines on the servomotor side, such as the welder.	Check if the machines are correctly grounded.	Properly ground the machines to separate from the encoder FG.
	DRIVER pulse counting error due to noise interference	Check if there is noise interference on the I/O signal line from the encoder.	Take measures against noise in the encoder wiring.
	Excessive vibration and shock to the encoder	Check if vibration from the machine occurred or servomotor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.).	Reduce vibration from the machine, or secure the servomotor installation.
	An encoder fault occurred.	_	Replace the servomotor.

			(cont'd)
Problem	Probable Cause	Investigative Actions	Corrective Actions
	Unbalanced servo gains	Check to see if the servo gains have been correctly adjusted.	Execute the advanced autotuning.
	Speed loop gain value (Pn100) too high.	Check the speed loop gain (Pn100). Factory setting: Kv = 40.0 Hz	Reduce the speed loop gain (Pn100).
Servomotor Vibrates at Frequency of	Position loop gain value (Pn102) too high.	Check the position loop gain (Pn102). Factory setting: Kp = 40.0/s	Reduce the position loop gain (Pn102).
Approx. 200 to 400 Hz.	Incorrect speed loop integral time constant (Pn101)	Check the speed loop integral time constant (Pn101). Factory setting: Ti = 20.0 ms	Correct the speed loop integral time constant (Pn101).
Problem         Probable Cause         Investigative Actions         Corrective Actions           Servomotor         Speed loop gain value (Ph100) too high.         Check to see if the servo gains have been correctly adjusted.         Execute the advanced autout (Ph100).           Frequency of Approx. 200 to 400 Hz.         Position loop gain value (Ph100) too high.         Check the speed loop gain (Ph100).         Reduce the position loop gain (Ph102).           Incorrect speed loop integral time constant (Ph101).         Check the speed loop gain (Ph100).         Correct the speed loop integral time constant (Ph101).         Correct the speed loop integral time constant (Ph101).         Correct the moment of inertia (Ph102).           Incorrect moment of inertia ratio Overshort or Spring         Unbalanced servo gains         Check the speed loop gain (Ph100).         Reduce the position loop gain (Ph102).           Speed loop gain value (Ph102)         Check the speed loop gain (Ph100).         Reduce the position loop gain (Ph102).         Reduce the position loop gain (Ph102).           Spred loop gain value (Ph102)         Check the speed loop gain (Ph100).         Reduce the position loop gain (Ph102).         Reduce the speed loop integral time constant (Ph101).         Correct the speed loop integral time constant (Ph101).         Correct the speed loop integral time constant (Ph102).         Correct the speed loop integral time constant (Ph101).         Correct the speed loop integral time constant (Ph102).             Noise interference due to length of encoder cabbe.<	Correct the moment of inertia ratio (Pn103).		
	Unbalanced servo gains	Check to see if the servo gains have been correctly adjusted.	Execute the advanced autotuning.
High Motor Speed	Speed loop gain value (Pn100) too high	Check the speed loop gain (Pn100). Factory setting: Kv = 40.0 Hz	Reduce the speed loop gain (Pn100).
High Motor Speed Overshoot on Starting and Stop-	Position loop gain value (Pn102) too high	Check the position loop gain (Pn102). Factory setting: Kp = 40.0/s	Reduce the position loop gain (Pn102).
ping	Incorrect speed loop integral time constant (Pn101)	Check the speed loop integral time constant (Pn101). Factory setting: Ti = 20.0 ms	Correct the speed loop integral time constant (Pn101).
	Incorrect moment of inertia ratio data (Pn103)	Check the moment of inertia ratio (Pn103).	Correct the moment of inertia ratio (Pn103).
	Noise interference due to incorrect cable specifications of encoder cable.	The encoder cable must be tinned annealed copper shielded twistedpair or screened unshielded twistedpair cable with a core of 0.12 mm <sup>2</sup> min.	Use the specified encoder cable.
	Noise interference due to length of encoder cable.	Check the length of the encoder cable.	The encoder cable must be no more than 50 m.
	Noise interference due to damaged encoder cable.	Check if the encoder cable is bent and the sheath is damaged.	Replace the encoder cable and correct the cable layout.
	Excessive noise to the encoder cable.	Check if the encoder cable is bundled with a high-current line or near a high-current line.	Correct the cable layout so that no surge is applied.
Absolute Encoder Position Difference Error	FG potential varies because of influence of machines such as welders at the servomotor.	Check if the machines are correctly grounded.	Ground machines correctly, and prevent diversion to the FG on the encoder side.
saved in the host PC or PLCetc when the power	DRIVER pulse counting error due to noise interference	Check if there is noise interference on the I/O signal line from the encoder.	Take measures against noise in the encoder wiring.
was turned OFF is different from the position when the power was next turned ON.)	Excessive vibration and shock to the encoder	Check if vibration from the machine occurred or servomotor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.).	Reduce vibration from the machine, or secure the servomotor installation.
	An encoder fault occurred.	-	Replace the servomotor.
	A DRIVER fault occurred. (The pulse count does not change.)	_	Replace the DRIVER.
		Check the error detection section of the host PC or PLCetc.	Correct the error detection section of the host PC or PLCetc.
	Host PC or PLCetc multiturn data reading error	Check if the host PC or PLCetc is executing data parity checks.	Execute a multiturn data parity check.
		Check noise in the cable between the DRIVER and the host PC or PLCetc.	Take measures against noise, and again execute a multiturn data par- ity check.



(	со	nť	d)
	~~	• • •	~,

Problem	Probable Cause	Investigative Actions	Corrective Actions	
TODICITI		Check the external power supply	Correct the external power supply	
		(+24 V) voltage for the input signal.	(+24 V) voltage.	
	Forward or reverse run prohibited	Check if the overtravel limit switch operates properly.	Correct the overtravel limit switch.	
	signal is input.	Check if the overtravel limit switch is wired correctly.	Correct the overtravel limit switch wiring.	
		Check the settings for parameters Pn50A and Pn50B.	Correct the settings for parameters Pn50A and Pn50B.	
		Check the fluctuation of the external power supply (+24 V) voltage for the input signal.	Stabilize the external power supply (+24 V) voltage.	
Overtravel (OT)	Forward or reverse run prohibited signal malfunctioning.	Check if the overtravel limit switch operates correctly.	Correct the overtravel limit switch.	
		Check if the overtravel limit switch wiring is correct. (check for damaged cables or loose screws.)	Correct the overtravel limit switch wiring.	
	Incorrect forward or reverse run prohibited signal (P-OT/N-OT)	Check if the P-OT signal is allocated in Pn50A.3.	If another signal is allocated in Pn50A.3, allocate P-OT.	
	allocation (parameters Pn50A.3, Pn50B.0)	Check if the N-OT signal is allocated in Pn50B.0.	If another signal is allocated in Pn50B.0, allocate N-OT.	
	Incorrect servomotor stop method	Check the settings for parameters Pn001.0 and Pn001.1 when the servomotor power is OFF.	Select a servomotor stop method other than "coast to stop."	
	selection	Check the settings for parameters Pn001.0 and Pn001.1 when in torque control.	Select a servomotor stop method other than "coast to stop."	
Improper Stop	Improper limit switch position and dog length	-	Install the limit switch at the appropriate position.	
Position by Overtravel (OT) Signal	The overtravel limit switch position is too short for the coasting distance.	_	Install the overtravel limit switch at the appropriate position.	

Problem	Probable Cause	Investigative Actions	Corrective Actions
	Noise interference due to incorrect encoder cable specifications	The encoder cable must be tinned annealed copper shielded twistedpair or screened unshielded twistedpair cable with a core of 0.12 mm <sup>2</sup> min.	Use the specified encoder cable.
	Noise interference due to length of encoder cable.	Check the length of the encoder cable.	The encoder cable must be no more than 50 m.
	Noise influence due to damaged encoder cable.	Check if the encoder cable is bent and the sheath is damaged.	Replace the encoder cable and modify the cable layout.
	Excessive noise to encoder cable.	Check if the encoder cable is bundled with a high-current line or near a high-current line.	Change the cable layout so that no surge is applied.
	The FG potential varies because of influence from machines on the servomotor side such as the welder.	Check if the machines are correctly grounded.	Properly ground the machines encoder FG.
Position Error	DRIVER pulse count error due to noise	Check if the I/O signal line from the encoder is influenced by noise.	Take measures against noise in the encoder wiring.
(without Alarm)	Excessive vibration and shock to the encoder	Check if vibration from the machine occurred or servomotor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.).	Reduce the machine vibration or mount the servomotor securely.
	Unsecured coupling between machine and servomotor	Check if a position error occurs at the coupling between machine and servomotor.	Secure the coupling between the machine and servomotor.
	Noise interference due to improper I/O signal cable specifications	The I/O signal cable must be tinned annealed copper shielded twistedpair or screened unshielded twistedpair cable with a core of 0.12 mm <sup>2</sup> min.	Use input signal cable with the specified specifications.
	Noise interference due to length of I/O signal cable	Check the I/O signal cable length.	The I/O signal cable length must be no more than 3 m.
	An encoder fault occurred. (The pulse count does not change.)	_	Replace the servomotor.
	A DRIVER fault occurred.	—	Replace the DRIVER.
	Ambient operating temperature too high	Measure the servomotor ambient operating temperature.	Reduce the ambient operating temperature to 40°C or less.
Servomotor	Servomotor surface dirty	Visually check the surface.	Clean dust and oil from the surface.
Overheated	Servomotor overloaded	Check the load status with monitor.	If overloaded, reduce load or replace with larger capacity DRIVER and servomotor.

10. List of Parameters	2
10.1 List of Parameters	2
10.1.1 Utility Functions	2
10.1.2 Parameters	3
10.1.3 MECHATROLINK-III Common Parameters	7
10.2 Parameter Recording Table	5

# 10. List of Parameters

### 10.1 List of Parameters

## 10.1.1 Utility Functions

The following list shows the available utility functions.

Parameter No.	Function	Reference Section
Fn000	Alarm history display	6.2
Fn002	JOG operation	6.3
Fn003	Origin search	6.4
Fn004	Program JOG operation	6.5
Fn005	Initializing parameter settings	6.6
Fn006	Clearing alarm history	6.7
Fn008	Absolute encoder multiturn reset and encoder alarm reset	4.7.4
Fn00C	Offset adjustment of analog monitor output	6.8
Fn00D	Gain adjustment of analog monitor output	6.9
Fn00E	Automatic offset-signal adjustment of the motor current detection signal	6.10
Fn00F	Manual offset-signal adjustment of the motor current detection signal	6.11
Fn010	Write prohibited setting	6.12
Fn011	Production information display	6.13
Fn013	Multiturn limit value setting change when a multiturn limit disagreement alarm occurs	4.7.6
Fn014	Resetting configuration error in option modules	6.14
Fn01B	Vibration detection level initialization	6.15
Fn020	Origin setting	6.16
Fn030	Software reset	6.17
Fn200	Tuning-less levels setting	5.2.2
Fn201	Advanced autotuning	5.3.2
Fn202	Advanced autotuning by reference	5.4.2
Fn203	One-parameter tuning	5.5.2
Fn204	Anti-resonance control adjustment function	5.6.2
Fn205	Vibration suppression function	5.7.2
Fn206	EasyFFT	6.18
Fn207	Online vibration monitor	6.19

Note: Execute the utility function with SigmaWin+.

#### 10.1.2 Parameters



									(	cont'd)
Parameter No.	Size	Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
	2	Application Function Switch 2	n Select	0000 to 4113	_	0011	After restart	Setup	_	_
	4 di n. [	h 3rd 2nd 1st git digit digit digit								
	MECHATROLINK Command Position and Speed Control Option							Reference Section		
0 Reserved (Do not set.) 1 TLIM operates as the torque limit values.						*1				
							Bp002			2 1
PHUUZ			JK	3 Keserved (Do not set.)						
			Torque Control Option					Reference Section		
			0 R	eserved (Do not s	et.)					*1
			1 V	'LIM operates as t	s the speed limit value.					
										Reference
			- Absolute	Encoder Usag	e					Section
			0 U	lses absolute enco	der as an abso	olute encoder	:			47
			1 U	lses absolute enco	der as an incr	emental enco	oder.			
		[	Make	r setting : Do	o not chan	ige.				

\*1. For details, refer to *8* MECHATROLINK-III Commands.

Parameter No.	Size	Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section			
	2	Application Function S Switch 6	Select	0000 to 005F		0002	Immediately	Setup	_	5.1.3			
	4t di n. C	h 3rd 2nd 1st git digit digit digit						1		1			
		A	Analog N	Ionitor 1 Signal	Selection								
		-	00	Motor rotating spe	ed (1 V / 100	0 min <sup>-1</sup> )							
			01	Speed reference ()	V / 1000 mir	1 <sup>-1</sup> )							
			02	Torque reference (	1 V/100% rat	ed torque)							
			03	Position error (0.0	5 V/l referenc	ce unit)							
			04 1	Position amplifier	error (after el	ectronic gear	s) (0.05 V/1 encod	ler pulse un	it)				
Pn006			<b>0</b> 5 j	Position reference	speed (1 V / 1	1000 min <sup>-1</sup> )							
			06	Reserved (Do not	use.)								
			07	Motor-load position error (0.01 V/1 reference unit)									
			08	Positioning compl	etion (position	ning complet	ed: 5 V, positioning	g not compl	eted: 0 V)				
			09	Speed feedforward	1 (1 V / 1000 i	min <sup>-1</sup> )							
			0A (	Torque feedforwa	d (1 V/100%	rated torque)							
			0B .	Active gain (1st ga	ain: 1 V, 2nd g	;ain: 2 V)							
		_	0C (	Completion of pos	ition referenc	e (completed	: 5 V, not complete	d: 0 V)					
			0D j	External encoder s	peed (1 V / 1	000 min <sup>-1</sup> : Va	alues at motor shaft	t)					
			Deserver	d (Do not obono									
			Reserved	u (Do not chang	le.)								
		F	Reserve	d (Do not chang	e.)								
		Application Function S	Select							1			
	2	Switch 7	501001	0000 to 005F	—	0000	Immediately	Setup	—	5.1.3			
	4 di n. [	h 3rd 2nd 1st git digit digit digit											
		A	Analog M	Nonitor 2 Signal	Selection								
			00 1	Motor rotating spee	ed (1 V / 1000	min <sup>-1</sup> )							
			01 s	opeed reference (1	V / 1000 min	-1)							
			02 1	lorque reference (l	V/100% rate	d torque)							
		_	03 F	Position error (0.05	V/l referenc	e unit)							
		_	04 F	Position amplifier (	error (after ele	ctronic gears	) (0.05 V/ 1 encode	er pulse uni	t)				
Pn007		_	05 F	Position reference	speed (1 V / 1	000 min <sup>-1</sup> )							
		_	06 F	Reserved (Do not u	(Se.)								
		_	07 1	Viotor-load position	n error (0.01 \	//1 reference	unit)		4-1-0 XD				
		–	00 1	Solutioning comple	ci II ( looo	ing complete	a: 5 v, positioning	not comple	ted: 0 V)				
		_	0.0 1	opeed feedforward	(1 V / 1000 n	nm <sup>-+</sup> )							
		-		Active gain (1st ga	in: 1 V 2nd e	ated torque)							
		-	00 0	Completion of posi	tion reference	(completed:	5 V not completed	: 0 V)					
		–	OD T	Parterma l'anna dar ar	and (1 V / 10	001. V.	bas at motor shaft						
		–	External encoder speed (1 V / 1000 mm : Values at motor shart)										
		F	Reserve	d (Do not chang	e.)								
	Reserved (Do not change.)												

										(cont u)
Parameter No.	Size	Na	ame	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
	2	Application Fu Switch 8	unction Select	0000 to 7121	I	4000	After restart	Setup	—	-
	n. [	th 3rd 2nd 1 igit digit digit d	lst Jigit							
			Lowered	Battery Voltage	e Alarm/Wa	rning Selec	tion			Reference Section
			0 0	Outputs alarm (A.S	330) for lowe	red battery vo	ltage.			472
			1 0	)utputs warning (4	A.930) for lov	vered battery	voltage.			4.7.3
Pn008			Function	Selection for U		Reference Section				
			0 I	)oes not detect un	dervoltage.					
	<ol> <li>Detects warning and limits torque by host controller.</li> </ol>									4.3.7
			2	Detects warning a	and limits tor	que by Pn42	4 and Pn425. (Only	y in the DR	IVER)	
	Warning Detection Selection									
			0 E	etects warning.						921
	1 Does not detect warning (except for A.971).									
	Reserved (Do not change.)									
	2	Application Fu Switch 9	inction Select	0000 to 0111	_	0010	After restart	Tuning	_	_
	<sup>4t</sup> مان n. ۲	h 3rd 2nd 19 git digit digit di ]	st igit							
			Reserved	(Do not chang	e.)					
				-						
<b>D</b> =000			Current C	ontrol Method	Selection					Reference Section
Ph009			0 C1	urrent control met	thod 1					583
			1 Ci	urrent control met	thod 2					
			Speed De	tection Method	Selection					Reference Section
	0 Speed detection 1									
			1 Sp	peed detection 2						5.0.5
			Reserved	(Do not chang	e.)					

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section		
	2	Application Function Select Switch B	0000 to 1111	—	0000	After restart	Setup	_	_		
	4 n.[	th 3rd 2nd 1st igit digit digit digit 									
		Param	eter Display Sele	ction					Reference Section		
		0	Setup parameters						2.4.1		
			All parameters								
Pn00B		Alarm	Gr.2 Stop Method	I Selection		Reference Section					
		0	Stops the motor by	setting the sp	eed referenc	e to "0".			4.3.5		
	1 Same setting as Pn001.0 (Stops the motor by applying DB or by coasting).										
		Power	Supply Method for	or Three-ph	ase SERVO	OPACK			Reference Section		
		0	Three-phase power	r supply					3.1.3		
	1 Single-phase power supply										
	Reserved (Do not change.)										
	2	Application Function Select Switch C	0000 to 0111	_	0000	After restart	Setup	_	4.5, 4.5.1		
	4 n.[	th 3rd 2nd 1st igit digit digit digit	- <b>-</b>								
		Select	ion of Test withou	t a Motor							
		0	Disables test with	out a motor.							
			Enables test witho	ut a motor.							
Pn00C		Encod	er Resolution for	Test withou	t a Motor						
		0	13 bits								
		1	20 bits								
		Encod	er Type for Test w	vithout a Mo	otor						
		0	Incremental encod	er							
	1 Absolute encoder										
		Reser	ved (Do not chang	ge.)							

1	
(co)	nť/d)
100	110 01/

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
	2	Application Function Select Switch D	0000 to 1001	_	0000	Immediately	Setup	_	-
Pn00D	n. E	th 3rd 2nd 1st igit digit digit digit Reserve Reserve Reserve Overtrav 0 1 1 1	d (Do not chang d (Do not chang d (Do not chang el Warning Dete Does not detect ov Detects overtravel	ge.) ge.) ge.) ection Selec ertravel warni warning.	tion ng.				Reference Section 4.3.2
Pn081	2	Maker setting	Do not change	<b>.</b>					
Pn100	2	Speed Loop Gain	10 to 20000	0.1 Hz	400	Immediately	Tuning	_	
Pn101	2	Speed Loop Integral Time Constant	15 to 51200	0.01 ms	2000	Immediately	Tuning	_	
Pn102	2	Position Loop Gain	10 to 20000	0.1/s	400	Immediately	Tuning	_	
Pn103	2	Moment of Inertia Ratio	0 to 20000	1%	100	Immediately	Tuning	_	5.8.1
Pn104	2	2nd Speed Loop Gain	10 to 20000	0.1 Hz	400	Immediately	Tuning	—	
Pn105	2	2nd Speed Loop Integral Time Constant	15 to 51200	0.01 ms	2000	Immediately	Tuning	—	
Pn106	2	2nd Position Loop Gain	10 to 20000	0.1/s	400	Immediately	Tuning	_	
Pn109	2	Feedforward Gain	0 to 100	1%	0	Immediately	Tuning	_	
Pn10A	2	Feedforward Filter Time Constant	0 to 6400	0.01 ms	0	Immediately	Tuning	_	5.9.1

1		1
(CO)	nť	d)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	Wł Ena	hen abled	Classi- fication	Profile	Reference Section
	2	Application Function for Gain Select Switch	0000 to 5334	_	0000		_	_	_	_
	4 n.[	th 3rd 2nd 1st igit digit digit I I I I I I I I I I I I I I I I I I I	1	I	L	1		1		
		Mode Sv	witch Selection				When Enable	d Cla	assification	Reference Section
		0	Uses internal toro (Level setting: Pr	que reference : 110C).	as the conditi	ion				
		1	Uses speed refere setting: Pn10D).	ence as the co	ndition (Leve	el 🛛				
Pn10B		2	Uses acceleration Pn10E).	Uses acceleration as the condition (Level setting: Pn10E).				tely	Setup	5.9.2
THIOD		3	Uses position erro Pn10F).	or as the cond	ition (Level s	etting:				
		4	No mode switch	function avail	able.					
		Speed L	oop Control Me	thod			When Enable	d Cla	assification	Reference Section
		0	PI control						5.4	
		2 to 3	I-P control Reserved (Do not	change.)			After res	tart	Setup	-
		Reserve	d (Do not chang	ge.)		I				
		Reserve	d (Do not chan	ne )						
Pn10C	2	Mode Switch (torque refer-	0 to 800	1%	200	Imme	diately	Tunino		
	-	ence) Mode Switch (speed refer-	0.0000	170	200			Tunne		_
Pn10D	2	ence)	0 to 10000	1 min <sup>-1</sup>	0	Imme	diately	Tuning	-	5.9.2
Pn10E	2	Mode Switch (acceleration)	0 to 30000	$1 \text{ min}^{-1}/\text{ s}$	0	Imme	diately	Tuning	_	_
Pn10F	2	Mode Switch (position error)	0 to 10000	reference unit	0	Imme	diately	Tuning	-	
Pn11F	2	Position Integral Time Constant	0 to 50000	0.1 ms	0	Imme	diately	Tuning		5.9.4
Pn121	2	Friction Compensation Gain	10 to 1000	1%	100	Imme	diately	Tuning	. –	
Pn122	2	2nd Gain for Friction Compensation	10 to 1000	1%	100	Imme	diately	Tuning	-	
Pn123	2	Friction Compensation Coefficient	0 to 100	1%	0	Imme	diately	Tuning	-	5.8.2
Pn124	2	Friction Compensation Frequency Correction	-10000 to 10000	0.1 Hz	0	Imme	diately	Tuning	_	
Pn125	2	Friction Compensation Gain Correction	1 to 1000	1%	100	Imme	diately	Tuning		
Pn131	2	Gain Switching Time 1	0 to 65535	1 ms	0	Imme	diately	Tuning	-	
Pn132	2	Gain Switching Time 2	0 to 65535	1 ms	0	Imme	diately	Tuning	-	4
Pn135	2	Waiting Time 1	0 to 65535	1 ms	0	Imme	diately	Tuning	-	5.8.1
Pn136	2	Gain Switching Waiting Time 2	0 to 65535	1 ms	0	Imme	diately	Tuning	_	

										(cont u)	
Parameter No.	Size	Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section	
	2	Automatic Gain Char Related Switch 1	ngeover	0000 to 0052	_	0000	Immediately	Tuning	_	5.8.1	
	n. [	th 3rd 2nd 1st ligit digit digit digit		I		L	L			L	
			. Gain Swi	itching Selectio	n Switch						
			0 N	fanual gain swite	hing						
			1 8	hanges gain man	ually using G	-SEL of the s	ervo command out	put signals (	(SVCMD_IO	).	
			2 A	Automatic gain sw	itching patter	nl					
			C	hanges automatic	ally 1st gain t	to 2nd gain w	when the switching of	condition A	is satisfied.		
Pn139			Changes automatically 2nd gain to 1st gain when the switching condition A is not safes								
111133			- Gain Swi	itching Conditio	n A						
			0	Positioning comp	letion signal (	(/COIN) ON					
			1	Positioning comp	letion signal (	(/COIN) OFF					
			2	Positioning near	signal (/NEAI	R) ON					
			3	Positioning near	signal (/NEA)	R) OFF		OFF			
			5	Position reference	e innut ON	= 0 and post	tion reference input	OFF			
				rosada reference	- mput off						
			- Reserved	d (Do not chan <u>o</u>	ge.)						
			Reserver	d (Do not chan)	( 91						
Dp12D	Reserved (Do not change.)										
FILID	2	Model Following Co	ntrol	100 to 2000	1 70	2000	mineulatery	Tunnig	_	5.6.4	
	2	Related Switch	nuoi	0000 to 1121	_	0100	Immediately	Tuning	_	-	
	4th 3rd 2nd 1st									1	
	n. Ľ										
			Model Fo	llowing Control	Selection						
			0 D	oes not use mode	l following co	ontrol.					
			1 U	ses model follow	ing control.						
			) (ile and in a	0	alaatiaa						
			vibration	Suppression S	election	rection					
Pn140		-	1 P	erforms vibration	suppression of	over the speci	fied frequency.				
		-	2 P	erforms vibration	suppression o	- over two diffe	erent kinds of frequ	encies.			
			Vibration	Suppression A	djustment S	Selection			R	leference Section	
			0 D	oes not adjust vib	ration suppre	ssion automa	tically using utility	function.	5.3	3.1, 5.4.1,	
			1 A	djusts vibration s	uppression au	tomatically u	using utility function	n.	5.:	5.1, 5.7.1	
									R	eference	
			Selection	of Speed Feed	Iforward (VI	-F) / Torque	e Feedforward (1	TFF)		Section	
			0 D	oes not use mode	l following co	ontrol and spe	eed/torque feedforw	rard togethe	ar. 5.1	3.1, 5.4.1	
		-	1 U	ses model follow	ing control an	d speed/torq	ue feedforward toge	ether.			
Pn141	2	Model Following Co Gain	ntrol	10 to 20000	0.1/s	500	Immediately	Tuning	_	_	
Pn142	2	Model Following Co Gain Compensation	ntrol	500 to 2000	0.1%	1000	Immediately	Tuning	_	_	



									(cont'd)
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
Pn143	2	Model Following Control Bias (Forward Direction)	0 to 10000	0.1%	1000	Immediately	Tuning	_	_
Pn144	2	Model Following Control Bias (Reverse Direction)	0 to 10000	0.1%	1000	Immediately	Tuning	_	_
Pn145	2	Vibration Suppression 1 Frequency A	10 to 2500	0.1 Hz	500	Immediately	Tuning	_	-
Pn146	2	Vibration Suppression 1 Frequency B	10 to 2500	0.1 Hz	700	Immediately	Tuning	_	-
Pn147	2	Model Following Control Speed Feedforward Compensation	0 to 10000	0.1%	1000	Immediately	Tuning	_	_
Pn148	2	2nd Model Following Control Gain	10 to 20000	0.1/s	500	Immediately	Tuning	_	_
Pn149	2	2nd Model Following Control Gain Compensation	500 to 2000	0.1%	1000	Immediately	Tuning	_	_
Pn14A	2	Vibration Suppression 2 Frequency	10 to 2000	0.1 Hz	800	Immediately	Tuning	_	_
Pn14B	2	Vibration Suppression 2 Compensation	10 to 1000	1%	100	Immediately	Tuning	_	-
	2	Control Related Switch	0000 to 0011	_	0011	After restart	Tuning	—	-
Pn14E	4t di n. C	h 3rd 2nd 1st git digit digit Model Fo 0 Mo 1 Mo	llowing Control del Following Cor del Following Cor	Type Select atrol 1 atrol 2	ction				Reference Section 5.3.1, 5.4.1, 5.5.1
F1114F		Tuning-le 0 Tur 1 Tur Reserved	ss Type Selection ing-less type 1 ing-less type 2 I (Do not change.)						Reference Section 5.2.2
	Reserved (Do not change.)								

										(cont'd)	
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	Wh Ena	nen bled	Classi- fication	Profile	Reference Section	
	2	Anti-Resonance Control Related Switch	0000 to 0011	_	0010	Immed	liately	Tuning	_	5.3.1, 5.4.1, 5.5.1, 5.7.1	
		Anti-Res	onance Control	Selection							
Pn160		0 Do	es not use anti-reso es anti-resonance c	nance control ontrol	L.						
		Anti-Res	Anti-Resonance Control Adjustment Selection								
			1         Adjusts anti-resonance control automatically using utility function.								
			d (De estates	- )	-						
		Reserve	d (Do not chang	e.)							
		Reserve	d (Do not chang	e.)							
Pn161	2	Anti-Resonance Frequency	10 to 20000	0.1 Hz	1000	Immed	liatelv	Tuning	_		
Pn162	2	Anti-Resonance Gain Compensation	1 to 1000	1%	100	Immed	liately	Tuning	_		
Pn163	2	Anti-Resonance Damping Gain	0 to 300	1%	0	Immed	liately	Tuning	_		
Pn164	2	Anti-Resonance Filter Time Constant 1 Compensation	-1000 to 1000	0.01 ms	0	Immed	liately	Tuning	_	_	
Pn165	2	Anti-Resonance Filter Time Constant 2 Compensation	-1000 to 1000	0.01 ms	0	Immed	liately	Tuning	_	_	
	2	Tuning-less Function Related Switch	0000 to 2411	_	1401	-	_	_	_	_	
	4 n.[	th 3rd 2nd 1st igit digit digit digit	ess Function Se	lection			When	Classi	fication	Reference	
			Display tuning las	function			Enabled	Cidaal	incauon	Section	
			Enables tuning-less	function.		A	fter resta	nt Se	etup	5.2	
Pn170		Control	Method during S	peed Contro	ol		When Enabled	Classi	fication	Reference Section	
		0 Us	es as speed control				fter resta	rt Se	tun	5.2	
		1 <sup>Us</sup> po	es as speed control sition control.	and uses the I	iost controlle	r for			p		
		Rigidity	Level			E	When Enabled	Classif	fication	Reference Section	
		0 to 4	Sets rigidity level.			In	nmediatel	y Se	tup	5.2	
		Load Le	vel				When Enabled	Class	ification	Reference Section	
		0 to 2	Sets load level.			I	nmediate	ly S	etup	5.2	
Pn205	2	Multiturn Limit Setting	0 to 65535	1 rev	65535	After	restart	Setup	—	4.7.5	

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section	
	2	Position Control Function Switch	0000 to 2210		0010	After restart	Setup	_	-	
Pn207	4: di n. E	th 3rd 2nd 1st git digit digit Reserved Reserved //COIN O	d (Do not chang d (Do not chang d (Do not chang utput Timing Outputs when the positioning comple filtering is 0. Outputs when the positioning comple	e.) e.) position error eted width (Pr position error eted width (Pr position error eted width (Pr	absolute valu a522). absolute valu a522), and th absolute valu a522), and th	ne is the same or le ne is the same or le e reference after po ne is the same or le e position reference	ss than the ss than the ss than the ss than the e input is 0.	ence	Reference Section 4.8.6	
Pn20A	4	Maker setting	Do not change	·.						
Pn20E	4	Electronic Gear Ratio (Numerator)	1 to 1073741824	1	1	After restart	Setup	_	443	
Pn210	4	Electronic Gear Ratio (Denominator)	1 to 1073741824         1         1         After restart         Setup							
Pn212	4	Encoder Output Pulses	16 to         1 P/rev         2048         After restart         Setup							
Pn22A	2	Maker setting	Do not change	Do not change.						

								(	(cont'd)			
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section			
	2	Position Control Expanded Function Switch	0000 to 0001	_	0000	After reset	Setup	_	5.8.6			
Pn230	n. E	in 3rd 2nd 1st igit digit digit Backlas	sh Compensati Compensates wi Compensates wi ed (Do not cha	on Direction th a reference th a reference nge.)	n e in the forw e in the reve	ard direction. rse direction.						
		Reserve	ed (Do not cha	nge.)								
		Reserve	ed (Do not cha	nge.)								
Pn231	4	Backlash Compensation Value	-500000 to 500000	0.1 reference unit	0	Immediately	Setup	_	5.8.6			
Pn233	2	Backlash Compensation Time Constant	0 to 65536	0.01 ms	0	Immediately	Setup	_	5.8.6			
Pn281	2	Maker setting	Maker setting Do not change.									
Pn304	2	JOG Speed0 to 100001 min <sup>-1</sup> 500ImmediatelySetup										
Pn305	2	Soft Start Acceleration Time	0 to 10000	1 ms	0	Immediately	Setup	_				
Pn306	2	Soft Start Deceleration Time	0 to 10000	1 ms	0	Immediately	Setup	_	_			
	2 4 n. [	Vibration Detection Switch th 3rd 2nd 1st igit digit digit digit	0000 to 0002	_	0000	Immediately	Setup					
		Vibration	Detection Sele	ection					Reference Section			
		0 1	Does not detect vi	bration.								
Pn310		1	Outputs warning (	(A.911) when	vibration is d	letected.			6.15			
			Outputs atariii (A.	.520) wilei vi	oration is det	ectea.						
		Reserved	d (Do not chan <u>o</u>	ge.)								
		Reserved	d (Do not chang	je.)								
		Reserved	d (Do not chan <u>o</u>	je.)								
Pn311	2	Vibration Detection Sensibility	50 to 500	1%	100	Immediately	Tuning	_	6.15			
Pn312	2	Vibration Detection Level	0 to 5000	1 min <sup>-1</sup>	50	Immediately	Tuning	-				
Pn324	2	Moment of Inertia Calculating Start Level	0 to 20000	1%	300	Immediately	Setup	_	5.3.2			
Pn401	2	Torque Reference Filter Time Constant	0 to 65535	0.01 ms	100	Immediately	Tun- ing	_	5.9.3			

										(cont'd)
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	۱ E	When nabled	Classi- fication	Profile	Reference Section
Pn402	2	Forward Torque Limit	0 to 800	1%	800	Imr	nediately	Setup	_	461
Pn403	2	Reverse Torque Limit	0 to 800	1%	800	Imn	nediately	Setup	_	4.0.1
Pn404	2	Forward External Torque Limit	0 to 800	1%	100	Imr	nediately	Setup	_	462
Pn405	2	Reverse External Torque Limit	0 to 800	1%	100	Imr	nediately	Setup	_	4.0.2
Pn406	2	Emergency Stop Torque	0 to 800	1%	800	Imr	nediately	Setup	-	4.3.2
Pn407	2	Speed Limit during Torque Control	0 to 10000	1 min <sup>-1</sup>	10000	Imr	nediately	Setup	_	4.8.8
	2	Torque Related Function Switch	0000 to 1111	-	0000		_	_	_	_
Pn408	n. C	git digit digit	Notch Filter Sel NA Jses 1st step notch i imit Selection Uses the smaller of the value of Pn407 Uses the smaller of and the value of Pn p Notch Filter Se N/A Uses 2nd step notch	ection filter for torqu the maximum as the speed the overspeed 407 as the speed election	e reference. n motor speed imit value. d detection sp eed limit valu	d and peed te.	When Enabled When Enabled After rest When Enabled Immediate	Class	sification Setup Sification Setup Setup	Reference Section Reference Section 4.8.8 Reference Section 5.9.3
		Friction	Compensation F	unction Sel	ection		When Enabled	Clas	sification	Reference Section
		0	Disables fric	tion compension compension	ation function	n. I.	Immediat	ely	Setup	5.8.2
Pn409	2	1st Notch Filter Frequency	50 to 5000	1 Hz	5000	Imr	nediately	Tuning	_	
Pn40A	2	1st Notch Filter Q Value	50 to 1000	0.01	70	Imr	nediately	Tuning	_	
Pn40B	2	1st Notch Filter Depth	0 to 1000	0.001	0	Imn	nediately	Tuning		
Pn40C	2	2nd Notch Filter Frequency	50 to 5000	1 Hz	5000	Imr	nediately	Tuning	_	
Pn40D	2	2nd Notch Filter Q Value	50 to 1000	0.01	70	Imr	nediately	Tuning	_	5.9.3
Pn40E	2	2nd Notch Filter Depth	0 to 1000	0.001	0	Imr	nediately	Tuning	-	
Pn40F	2	2nd Step 2nd Torque Reference Filter Frequency	100 to 5000	1 Hz	5000	Immediately		Tuning	_	
Pn410	2	2nd Step 2nd Torque Reference Filter Q Value	50 to 100	0.01	50	Immediately		Tuning	_	
Pn412	2	1st Step 2nd Torque Reference Filter Time Constant	0 to 65535	0.01 ms	100	Imr	nediately	Tuning	_	5.8.1

								(*	cont'd)
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
Pn424	2	Torque Limit at Main Circuit Voltage Drop	0 to 100	1%	50	Immediately	Setup	_	
Pn425	2	Release Time for Torque Limit at Main Circuit Voltage Drop	0 to 1000	1 ms	100	Immediately	Setup	_	4.3.7
Pn456	2	Sweep Torque Reference Amplitude	1 to 800	1%	15	Immediately	Tuning	_	6.18
	2	Notch Filter Adjustment Switch	0000 to 0101	_	0101	Immediately	Tuning	_	5.2.1 5.3.1 5.5.1
Pn460	n. E	h 3rd 2nd 1st git digit digit Notch Fil Reserver	ter Adjustment Does not adjust 1: Adjust 1st step no d (Do not chang ter Adjustment Does not adjust 2n Adjust 2nd step no	Selection 1 at step notch f tch filter auto ge.) Selection 2 d step notch f tch filter auto	ilter automat matically usi ilter automat matically usi	ically using utility f ng utility function. ically using utility f ng utility function.	function.		
		Reserve	d (Do not chan <u>o</u>	je.)		-			
Pn501	2	Zero Clamp Level	0 to 10000	1 min <sup>-1</sup>	10	Immediately	Setup	_	_
Pn502	2	Rotation Detection Level	1 to 10000	1 min <sup>-1</sup>	20	Immediately	Setup	_	4.8.3
Pn503	2	Speed Coincidence Signal Output Width	0 to 100	1 min <sup>-1</sup>	10	Immediately	Setup	_	4.8.5
Pn506	2	Lock Reference - Servo OFF Delay Time	0 to 50	10 ms	0	Immediately	Setup	_	
Pn507	2	Lock Reference Output Speed Level	0 to 10000	1 min <sup>-1</sup>	100	Immediately	Setup	_	4.3.4
Pn508	2	Waiting Time for Lock Signal When Motor Running	10 to 100	10 ms	50	Immediately	Setup	_	
Pn509	2	Instantaneous Power Cut Hold time	20 to 1000	1 ms	20	Immediately	Setup	_	4.3.6

(	cont'd)

No.         Size         Name         Range         Onis         Setting         Enabled         fication         Profile         Section           2         Input Signal Selection 1         0000 to FFF1         -         1881         After restart         Setup         -         -         -           4th         3rd         2nd         1st digit digit digit         -         1881         After restart         Setup         - <t< th=""><th>Parameter</th><th>0:</th><th>News</th><th></th><th>Setting</th><th>1.1 11</th><th>Factory</th><th>When</th><th>Classi-</th><th>Dusfile</th><th>Reference</th></t<>	Parameter	0:	News		Setting	1.1 11	Factory	When	Classi-	Dusfile	Reference
2       Input Signal Selection 1       0000 to FFF1       _       1881       After restart       Setup       _       _         4th       3rd       2nd       1st       digit digit       1st	No.	Size	Name		Range	Units	Setting	Enabled	fication	Profile	Section
Pn50A Pn50A Pn50A Pn50A Pn50A A Forward run allowed when CN1-13 input signal is ON (closed). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-13 input signal is OFF (open). Forward run allowed when CN1-19 input signal is OFF (open). Forward run allowed when CN1-19 input signal is OFF (open). Forward run allowed when CN1-19 input signal is OFF (open). Forward run allowed when CN1-19 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-19 input signal is OFF (open). Forward run allowed when CN1-19 input signal is OFF (open). Forward run allowed when CN1-19 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 input signal is OFF (open). Forward run allowed when CN1-10 i		2	Input Signal Selection	n 1	0000 to FFF1	Ι	1881	After restart	Setup	_	_
E         Forward run allowed when CN1-11 input signal is OFF (open).           F         Forward run allowed when CN1-12 input signal is OFF (open).	Pn50A	4 n.[	th 3rd 2nd 1st igit digit digit	Reserved Reserved P-OT Sig 0 1 2 3 1 2 3 3 4 5 5 3 4 5 5 3 4 5 5 3 4 5 5 3 4 5 7 3 8 9 3 4 5 7 3 7 2 3 3 1 2 3 3 1 2 3 3 1 2 3 3 1 2 3 3 1 2 3 3 1 2 3 3 1 2 3 3 1 2 5 5 1 2 3 1 2 1 3 1 2 1 1 1 1	d (Do not chang d (Do not chang d (Do not chang d (Do not chang nal Mapping (F Forward run allow Forward run allow	je.) je.) je.) forward run red when CN red when CN	prohibited 1 1-13 input sign 1-7 input sign 1-9 input sign 1-10 input sign 1-11 input sign 1-12 input sign 1-13 input sign 1-8 input sign 1-9 input sign 1-9 input sign 1-10 input sign 1-10 input sign 1-10 input sign 1-11 input sign	when OFF (oper mal is ON (closed). mal is OFF (open). mal is OFF (open).	1)))		Reference Section 4.3.2

Parameter No.	Size		Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section		
	2	Input Sig	gnal Selectio	on 2	0000 to FFFF	_	8882	After restart	Setup	_	-		
	4t di n. [	h 3rd 2 git digit d	2nd 1st ligit digit		•								
				N-OT Sig	inal Mapping (R	everse run	prohibited	when OFF (oper	1))	F	Reference Section		
				0 1	Reverse run allow	ed when CN1	-13 input sign	nal is ON (closed).					
			-	1 1	Reverse run allow	ed when CN1	-7 input signa	al is ON (closed).					
			-	2 1	Reverse run allow	ed when CN1	-8 input signa	al is ON (closed).					
				3 1	Reverse run allowed when CN1-9 input signal is ON (closed).								
				4 1	Reverse run allowed when CN1-10 input signal is ON (closed).								
				5 1	Neverse run allowed when CN1-11 input signal is ON (closed).								
				7 1	Reverse run allowed when CN1-12 input signal is ON (closed).								
				8 1	Reverse run prohibited.								
				9 1	Reverse run allow	ed when CN1	-13 input sign	al is OFF (open)					
				A 1	Reverse run allow	ed when CN1	-7 input signa	al is OFF (open).					
			-	B 1	Reverse run allow	ed when CN1	-8 input signa	al is OFF (open).					
				C I	Reverse run allow	ed when CN1	-9 input signa	al is OFF (open).					
			-	D 1	Reverse run allow	ed when CN1	-10 input sign	nal is OFF (open).					
		E         Reverse run allowed when CN1-11 input signal is OFF (open).											
			F         Reverse run allowed when CN1-11 input signal is OFF (open).										
			i I	Reserved	l (Do not chang	e.)	when ON	elecced))		F	Reference		
				IP-CL SIG	gnai wapping (1	orque Limit	when ON (	ciosed))			Section		
			-	0	Active when CN1	13 input sign	al is ON (clo	sed).					
			-	1 1	Active when CN1	-7 input signal	is ON (close	ed).					
			-	2 1	Active when CN1	-8 input signal	15 ON (close	ed).					
			-	3 1	Active when CN1-	-> input signal	al is ON (close	ea).					
			-		Active when CN1-	11 input sign	al is ON (closed)	eu).					
			-	6	Active when CN1.	-12 input sign	al is ON (clo						
			-	7	Always active (fix	ed).							
			-	8 1	Not active (fixed)						4.6.2		
			-	9	Active when CN1	-13 input sign	al is OFF (op	en).					
			-	A	Active when CN1	7 input signal	is OFF (ope	n).					
			-	в	Active when CN1-8 input signal is OFF (open).								
			-	С	Active when CN1-9 input signal is OFF (open).								
			-	D	Active when CN1	10 input sign	al is OFF (op	en).					
			-	E A	Active when CN1	11 input sign:	al is OFF (op	en).					
			-	F J	Active when CN1	12 input sign	al is OFF (op	en).					
				/N-CL Sig	gnal Mapping (1	Forque Limit	when ON (	closed))		F	Reference Section		
				0 to F	Same as /P-CL signal mapping						4.6.2		
			-		-								

Parameter No.	Size	Name	)	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section	
	2	Output Signal Sel	ection 1	0000 to 3333	_	0000	After restart	Setup	_	_	
	4 n.[	th 3rd 2nd 1st igit digit digit digit I I I I I I I I I I I I I I I I I I I		I		I		1 1			
			- Positioni	ing Completion	Signal Map	oping (/COI	N)		R	eference Section	
			0	Disabled (the abo	ve signal is n	iot used.)					
			1	Outputs the signa		4.8.6					
			2	Outputs the signa	l from CN1-2	23, 24 output	terminal.				
Pn50E			3	3 Outputs the signal from CN1-25, 26 output terminal.							
			Speed C	oincidence Det	tection Sigr	nal Mapping	) (/V-CMP)		R	eference Section	
			0 to 3	Same as /COIN	Signal Mapp	ing.				4.8.5	
			Servomo	otor Rotation De	etection Sig	ınal Mappir	ng (/TGON)		Re	eference Section	
			0 to 3	Same as /COIN	Signal Mapp	ing.				4.8.3	
	Servo Ready Signal Mapping (/S-RDY)										
			0 to 3	Same as /COIN	Signal Mapp	ing.				4.8.4	
	2	Output Signal Sel	ection 2	0000 to 3333	_	0100	After restart	Setup	_	<u> </u>	
	4 n. [	th 3rd 2nd 1st igit digit digit digit									
			Torque L	orque Limit Detection Signal Mapping (/CLT)							
			- 0	Disabled (the ab	ove signal is	not used.)	i				
			2	Outputs the sign	al from CN1-	-23, 24 output to	t terminal.			4.6.3	
			3	Outputs the sign	al from CN1-	25, 26 outpu	t terminal.				
Pn50F			Speed Li	imit Detection S	ignal Mapp	oing (/VLT)			R	eference Section	
			0 to 3	Same as /CLT Sig	mal Mapping					4.8.8	
			Brake Si	gnal Mapping (	/BK)				R	eference Section	
	0 to 3 Same as /CLT Signal Mapping.									4.3.4	
			Warning	Signal Mapping	g (/WARN)				R	eference Section	
			0 to 3	0 to 3 Same as /CLT Signal Mapping.							

									-
Size	Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
2	Output Signal Select	tion 3	0000 to 0333	_	0000	After restart	Setup	_	-
n. E	th 3rd 2nd 1st igit digit digit								Poferance
		Near Sig	nal Mapping (/I		Section				
		0 1	Disabled (the abo						
		1 (	Outputs the signal		487				
		2 (	Outputs the signal		4.0.7				
		3 (	Outputs the signal	from CN1-2	5, 26 termina	al.			
		Reserved	d (Do not chang d (Do not chang d (Do not chang	ge.) ge.) ge.)					
	2 4 di n. L	Size Name          Size       Name         2       Output Signal Select         4th       3rd       2nd       1st         digit       digit       digit       digit       digit         n.       Image: Control of the select selec	Size Name          Size       Name         2       Output Signal Selection 3         4th       3rd       2nd       1st         digit       digit       digit       0       1         0       1       0       1       0       1         2       0       3       0       1       0       1         2       0       3       0       1       0       0       0       0       0       0       0       1       0 <th>Size     Name     Setting Range       2     Output Signal Selection 3     0000 to 0333       4th     3rd     2nd     1st digit       digit     digit     digit       Near     Signal Mapping (/I       0     Disabled (the abord 1)       1     Outputs the signal 2)       2     Outputs the signal 3)       3     Outputs the signal 3)       Reserved (Do not change 1)       Reserved (Do not change 1)</th> <th>Size     Name     Setting Range     Units       2     Output Signal Selection 3     0000 to 0333     -       4th     3rd     2nd     1st digit     0000 to 0333     -       Near Signal Mapping (/NEAR)     0     Disabled (the above signal is not 1     0       0     Disabled (the above signal from CN1-1 2     0     Outputs the signal from CN1-2 3       3     Outputs the signal from CN1-2       3     Outputs the signal from CN1-2       Reserved (Do not change.)       Reserved (Do not change.)</th> <th>Size       Name       Setting Range       Units       Factory Setting         2       Output Signal Selection 3       0000 to 0333       -       0000         4th       3rd       2nd       1st digit digit digit       0       0       0       0         Near Signal Mapping (/NEAR)       -       0       Disabled (the above signal is not used.)       1       0       0       0       1.2       2.2       0       1.2       2.2       0       1.2       2.2       0       1.2       2.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.4       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6</th> <th>Size       Name       Setting Range       Units       Factory Setting       When Enabled         2       Output Signal Selection 3       0000 to 0333       –       0000       After restart         4th       3rd       2nd       1st digit digit       0       0100 to 0333       –       0000       After restart         1       Near Signal Mapping (/NEAR)       –       0       Disabled (the above signal is not used.)       1       0       0       0       0       11       0       11       0       11       0       12       2       0       0       0       0       1       1       0       1       0       1</th> <th>Size       Name       Setting Range       Units       Factory Setting       When Enabled       Classi- fication         2       Output Signal Selection 3       0000 to 0333       -       0000       After restart       Setup         4th       3rd       2nd       1st       0000 to 0333       -       0000       After restart       Setup         4th       3rd       2nd       1st       0       Disabled (the above signal is not used.)       -       -       0       Disabled (the above signal is not used.)       -</th> <th>Size       Name       Setting Range       Units       Factory Setting       When Enabled       Classi- fication       Profile         2       Output Signal Selection 3       0000 to 0333       -       0000       After restart       Setup       -         4th       3rd       2nd       1st digit digit digit       0       Near Signal Mapping (/NEAR)       F         0       Disabled (the above signal is not used.)       1       Outputs the signal from CN1-1, 2 terminal.       -         2       Outputs the signal from CN1-23, 24 terminal.       -       -       -         3       Outputs the signal from CN1-25, 26 terminal.       -       -         Reserved (Do not change.)       -       -       -       -</th>	Size     Name     Setting Range       2     Output Signal Selection 3     0000 to 0333       4th     3rd     2nd     1st digit       digit     digit     digit       Near     Signal Mapping (/I       0     Disabled (the abord 1)       1     Outputs the signal 2)       2     Outputs the signal 3)       3     Outputs the signal 3)       Reserved (Do not change 1)       Reserved (Do not change 1)	Size     Name     Setting Range     Units       2     Output Signal Selection 3     0000 to 0333     -       4th     3rd     2nd     1st digit     0000 to 0333     -       Near Signal Mapping (/NEAR)     0     Disabled (the above signal is not 1     0       0     Disabled (the above signal from CN1-1 2     0     Outputs the signal from CN1-2 3       3     Outputs the signal from CN1-2       3     Outputs the signal from CN1-2       Reserved (Do not change.)       Reserved (Do not change.)	Size       Name       Setting Range       Units       Factory Setting         2       Output Signal Selection 3       0000 to 0333       -       0000         4th       3rd       2nd       1st digit digit digit       0       0       0       0         Near Signal Mapping (/NEAR)       -       0       Disabled (the above signal is not used.)       1       0       0       0       1.2       2.2       0       1.2       2.2       0       1.2       2.2       0       1.2       2.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.2       2.4       1.2       2.4       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6       1.2       2.6	Size       Name       Setting Range       Units       Factory Setting       When Enabled         2       Output Signal Selection 3       0000 to 0333       –       0000       After restart         4th       3rd       2nd       1st digit digit       0       0100 to 0333       –       0000       After restart         1       Near Signal Mapping (/NEAR)       –       0       Disabled (the above signal is not used.)       1       0       0       0       0       11       0       11       0       11       0       12       2       0       0       0       0       1       1       0       1       0       1	Size       Name       Setting Range       Units       Factory Setting       When Enabled       Classi- fication         2       Output Signal Selection 3       0000 to 0333       -       0000       After restart       Setup         4th       3rd       2nd       1st       0000 to 0333       -       0000       After restart       Setup         4th       3rd       2nd       1st       0       Disabled (the above signal is not used.)       -       -       0       Disabled (the above signal is not used.)       -	Size       Name       Setting Range       Units       Factory Setting       When Enabled       Classi- fication       Profile         2       Output Signal Selection 3       0000 to 0333       -       0000       After restart       Setup       -         4th       3rd       2nd       1st digit digit digit       0       Near Signal Mapping (/NEAR)       F         0       Disabled (the above signal is not used.)       1       Outputs the signal from CN1-1, 2 terminal.       -         2       Outputs the signal from CN1-23, 24 terminal.       -       -       -         3       Outputs the signal from CN1-25, 26 terminal.       -       -         Reserved (Do not change.)       -       -       -       -

Parameter No.	Size	Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section			
	2	Input Signal Selection	on 5	0000 to FFFF	_	6543	After restart	Setup		3.3.1			
	n. [	th 3rd 2nd 1st igit digit digit	Homing D 0 A 1 A 2 A	Deceleration Swite active when CN1-1 active when CN1-7 active when CN1-8	ch Signal Ma 3 input signal 7 input signal i 8 input signal i	pping (/DEC is ON (closed s ON (closed) s ON (closed)	) 1). 1.						
			3 A	ctive when CN1-9	) input signal i	s ON (closed)							
			4 A	ctive when CN1-1	0 input signal	is ON (closed	i).						
			5 A	Active when CN1-11 input signal is ON (closed).									
			6 A	Active when CN1-12 input signal is ON (closed).									
			7 N	Not active (fixed).									
			9 A	Active when CN1-13 input signal is OFF (open).									
			A A	ctive when CN1-7	input signal i	s OFF (open).							
			B A	ctive when CN1-8	3 input signal i	s OFF (open).	•						
			C A	ctive when CN1-9	) input signal i	s OFF (open).							
Pn511			D A	ctive when CN1-1	0 input signal	is OFF (open	).						
			E A	ctive when CN1-1	1 input signal	is OFF (open	).						
			FA	ctive when CN1-1	2 input signal	is OFF (open	).						
			External L	atch Signal Map	ping (/EXT1)								
			4 A	ctive when CN1-1	0 input signal	is ON (closed	l).						
			5 A	ctive when CN1-1	1 input signal	is ON (closed	Ŋ.						
			6 A	ctive when CN1-1	2 input signal	is ON (closed	i).						
			7 N	lot active (fixed).									
			D A	ctive when CN1-1	0 signal is OF	F (open).							
			E A	ctive when CN1-1	1 signal is OF	F (open).							
			F A	ctive when CN1-1	2 signal is OF	F (open).							
			0 to 3 9 to C	Not active (fixed).									
			External L	atch 2 Signal Ma	apping (/EXT	2)							
			0 to C	Same as /EXT1 sig	nal mapping.								
			External L	atch 3 Signal Ma	apping (/EXT	3)							
			0 to C S	to C Same as /EXT1 signal mapping.									

								(*	cont'd)
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
	2	Output Signal Inverse Setting	0000 to 0111	-	0000	After restart	Setup	_	3.3.2
	n. [	th 3rd 2nd 1st igit digit digit digit							
		Output S	Signal Inversion	for CN1-1	or -2 Termi	nal			
		0 1	Does not inverse (	outputs.					
			Inverses outputs.						
Pn512		Output S	Signal Inversion	for CN1-23	3 or -24 Ter	minal			
		0 1	Does not inverse (	outputs.					
		1	Inverses outputs.						
		Output S	Signal Inversion	for CN1-25	5 or -26 Ten	minal			
		0 1	Does not inverse (	outputs.					
		1 1	Inverses outputs.						
		Posonio	d (Do not chan	(00)					
Dn517	2	Pasarwad (Do not change )	d (Do not chan	gc./	0000		1		
	2	Reserved (Do not change.)	-	_	0000	_	_	_	_
Pn51B	4	Maker setting	Do not chai	nge.					
Pn51E	2	Warning Level	10 to 100	1%	100	Immediately	Setup	_	9.2.1
Pn520	4	Excessive Position Error Alarm Level	1 to 1073741823	1 reference unit	5242880	Immediately	Setup	_	5.1.4 9.1.1
Pn522	4	Positioning Completed Width	0 to 1073741824	1 reference unit	7	Immediately	Setup	_	4.8.6
Pn524	4	NEAR Signal Width	1 to 1073741824	1 reference unit	1073741824	Immediately	Setup	_	4.8.7
Pn526	4	Excessive Position Error Alarm Level at Servo ON	1 to 1073741823	1 reference unit	5242880	Immediately	Setup	_	
Pn528	2	Excessive Position Error Warning Level at Servo ON	10 to 100	1%	100	Immediately	Setup	_	5.1.4
Pn529	2	Speed Limit Level at Servo ON	0 to 10000	1 min <sup>-1</sup>	10000	Immediately	Setup	_	
Pn52A	2	Maker setting	Do not char	nge.					
Pn52B	2	Overload Warning Level	1 to 100	1%	20	Immediately	Setup	_	
Pn52C	2	Derating of Base Current at Detecting Overload of Motor	10 to 100	1%	100	After restart	Setup	_	4.3.8
Pn52D	2	Reserved (Do not change.)	_	_	50	_	-	_	_
Pn52F	2	Reserved (Do not change.)	_	_	0FFF	_	_	_	-

1		1
(CO)	nť	d)

Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section			
	2	Program JOG Operation Related Switch	0000 to 0005	_	0000	Immediately	Setup	_	6.5			
	41 di n. C	th 3rd 2nd 1st igit digit digit I I I I I I I I I I I I I I I I I I I	I	I	<u> </u>	I			<u> </u>			
		Program	JOG Operation Switch									
		7) 0	Vaiting time Pn53	$5 \rightarrow Forward$	movement P	n531) × Number o	fmovemen	its Pn536				
		1 (7	Vaiting time Pn53	$5 \rightarrow \text{Reverse}$	movement Pr	n531) $ imes$ Number o	f movemen	ts Pn536				
		2 (1	Vaiting time Pn53 Vaiting time Pn53	$5 \rightarrow Forward$ $5 \rightarrow Reverse :$	movement P movement P	n531) × Number o 1531) × Number o	of movemen f movemen	ts Pn536 ts Pn536				
Pn530		3 (7	Vaiting time Pn53 Vaiting time Pn53	$5 \rightarrow \text{Reverse}$ $5 \rightarrow \text{Forward}$	movement Pr movement P	n531) × Number o n531) × Number o	f movemen of movemer	ts Pn536 its Pn536				
		4 (V R	Vaiting time Pn53 everse movement	5 → Forward Pn531) × Nu	movement P unber of mov	n531 → Waiting tir vements Pn536	ne Pn535 -	*				
		5 (7	Vaiting time Pn53	$5 \rightarrow \text{Reverse}$	movement Pr	n531 → Waiting tin	ne Pn535	*				
			orward movement	11051) ~ 14	differ of filo	venients i in 550						
		Reserved	l (Do not chang	e.)								
		Reserved	(Do not chang	e.)								
		Reserved	Reserved (Do not change.)									
			1 4-	1	[							
Pn531	4	Distance	1 to 1073741824	reference unit	32768	Immediately	Setup	_				
Pn533	2	Program JOG Movement Speed	1 to 10000	1 min <sup>-1</sup>	500	Immediately	Setup		6.5			
Pn534	2	Program JOG Acceleration/ Deceleration Time	2 to 10000	1 ms	100	Immediately	Setup	_	0.5			
Pn535	2	Program JOG Waiting Time	0 to 10000	1 ms	100	Immediately	Setup	-				
Pn536	2	Number of Times of Program JOG Movement	0 to 1000	1 time	1	Immediately	Setup					
Pn550	2	Analog Monitor 1 Offset Voltage	-10000 to 10000	0.1 V	0	Immediately	Setup	-				
Pn551	2	Analog Monitor 2 Offset Voltage	-10000 to 10000	0.1 V	0	Immediately	Setup	_	512			
Pn552	2	Analog Monitor Magnification (×1)	-10000 to 10000	×0.01	100	Immediately	Setup	_	5.1.5			
Pn553	2	Analog Monitor Magnification (×2)	-10000 to 10000	×0.01	100	Immediately	Setup	_				
Pn560	2	Remained Vibration Detection Width	1 to 3000	0.1%	400	Immediately	Setup	_	5.7.1			
Pn561	2	Overshoot Detection Level	0 to 100	1%	100	Immediately	Setup	_	5.3.1 5.4.1			
Pn600	2	Regenerative Resistor Capacity *2	Depends on DRIVER Capacity *3	10 W	0	Immediately	Setup	_	3.7.2			
Pn601	2	Reserved (Do not change.)	-	-	0	-	-	_	-			

\*2. Normally set to "0." When using an external regenerative resistor, set the capacity (W) of the regenerative resistor.

\*3. The upper limit is the maximum output capacity (W) of the DRIVER.



											(cont d)			
Parameter No.	Size		Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section			
	2	Communio	cations Cor	ntrol	-	_	1040	Immediately	Setup	-	_			
	n. [	th 3rd 2r ligit digit di	nd 1st git digit	- MECHATROLINK-III Communications Check Mask (for debug)										
				0 1	No mask									
				1 1	Ignores MECHAT	ROLINK con	nmunications	error (A.E6□).						
				2 1	Ignores WDT erro	r (A.E5□).								
				3 1	Ignores both MEC	HATROLINI	K communica	tions error (A.E6	l) and WD1	and WDT error (A.E5□).				
				- Warning	Check Mask									
				0 1	No mask									
				1 1	Ignores data settin	g warning (A	.94□).							
				2 1	Ignores command									
				3 1	Ignores both data	setting warnir	warning (A.94 <sup>(D)</sup> ) and command warning (A.95 <sup>(D)</sup> ).							
				4 1	Ignores communications warning (A.96).									
				5 1	Ignores both data	setting warnir	ıg (A.94□) a:	nd communications	warning (A	A.96□).				
<b>D</b> 000				6 1	Ignores both com	nand warning	(A.95🗆) and	d communications v	warning (A.	96□).				
Pn800				7 1	Ignores data setting warning (A.94), command warning (A.95) and communications warning (A.96).									
				8 1	Ignores command warning 7 (A.97A) and data clamp (A.97B).									
				9 1	Ignores data settin	g warning (A	.94□), comm	and warning 7 (A.	97A) and da	ata elamp (A.	97B).			
				<b>A</b> 1	Ignores command	warning (A.9	5□) and con	imand warning 7 (A	4.97A) and	data clamp (A	A.97B).			
				B	Ignores data settin and data clamp (A	g warning (A .97B).	.94□), comm	and warning (A.95	□), comma	and warning 7	(A.97A)			
				C I	Ignores communio	ations warnin	ıg (A.96□), c	ommand warning 7	7 (A.97A) a	nd data elamı	o (A.97B).			
				D	Ignores data settin (A.97A) and data	g warning (A clamp (A.97E	.94□), comm 8).	unications warning	g (A.96□),	command wa	rning 7			
				E	Ignores command (A.97A) and data	warning (A.9 clamp (A.97E	5□), commu 8).	nications warning (	(A.96□), co	ommand warr	uing 7			
				F	Ignores data setting warning (A.94□), command warning (A.95□), communications warning (A.96□), command warning 7 (A.97A) and data clamp (A.97B).									
				Reserve	rved (Do not change.)									
					······································									
				Automat	ic warning-clea	r (for debug	) *							
				0 No	warning-clear (fo	r debug)								
				1 Automatic warning-clear (for MECHATROLINK-III specifications)										

\*9. This parameter is enabled only for MECHATROLINK-III standard servo profile.

				(cont'd)									
Parameter No.	Size	Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section			
	2	Application Function (Software LS)	_	_	0003	Immediately	Setup	I	4.3.3				
	4 n. [	th 3rd 2nd 1st igit digit digit digit											
			Software Limit Function										
			0 1	Enables forward an	d reverse softv	ware limit.							
			1 1	Disables forward so	oftware limit.								
			2 1	Disables reverse so	ftware limit.								
Pn801			3 1	Disables software li	mit in both di	rections.							
			Deserves	De est shares	<b>`</b>								
			Reserved	(Do not change.	)								
			Software	Limit for Referen	ce								
			0 1	Disables software li	mit for refere	nce.							
			1 1	Enables software lin	nit for referen	ice.							
			Reserved	d (Do not change.)									
Pn803	2	Origin Range	0 to 250	l reference unit	10	Immediately	Setup	_	*1				
Pn804	4	Forward Software Li	1073741823 to 1073741823	1 reference unit	1073741823	Immediately	Setup	_	433				
Pn806	4	Reverse Software Li	- 1073741823 to 1073741823	1 reference unit	-1073741823	Immediately	Setup	_					
Pn808	4	Absolute Encoder O Offset	- 1073741823 to 1073741823	1 reference unit	0	Immediately*4	Setup	_	4.7.7				
Pn80A	2	1st Linear Accelerat Constant	1 to 65535	10000 reference unit/s <sup>2</sup>	100	Immediately <sup>*5</sup>	Setup		*1				
Pn80B	2	2nd Linear Accelerat Constant	1 to 65535	10000 reference unit/s <sup>2</sup>	100	Immediately <sup>*5</sup>	Setup		*1				
Pn80C	2	Acceleration Constan Switching Speed	0 to 65535	100 reference unit/s	0	Immediately <sup>*5</sup>	Setup	_	*1				
Pn80D	2	1st Linear Decelerat Constant	ion	1 to 65535	10000 reference unit/s <sup>2</sup>	100	Immediately <sup>*5</sup>	Setup	_	*1			

\*1. For details, refer to *8 MECHATROLINK-III Commands*.

\*4. Available after the SENS\_ON command is input.

\*5. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

								(	cont'd)
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
Pn80E	2	2nd Linear Deceleration Constant	1 to 65535	10000 reference unit/s <sup>2</sup>	100	Immediately <sup>*5</sup>	Setup	Ι	*1
Pn80F	2	Deceleration Constant Switching Speed	0 to 65535	100 reference unit/s	0	Immediately <sup>*5</sup>	Setup	Ι	*1
Pn810	2	Exponential Function Acceleration/Deceleration Bias	0 to 65535	100 reference unit/s	0	Immediately <sup>*6</sup>	Setup	_	*1
Pn811	2	Exponential Function Acceleration/Deceleration Time Constant	0 to 5100	0.1 ms	0	Immediately <sup>*6</sup>	Setup	Ι	*1
Pn812	2	Movement Average Time	0 to 5100	0.1 ms	0	Immediately*6	Setup	_	*1
Pn814	4	Final Travel Distance for External Positioning	-1073741823 to 1073741823	1 reference unit	100	Immediately	Setup	_	*1
	2	Homing Mode Setting	-	-	0000	Immediately	Setup	$M2^{*10}$	-
Pn816	n. E	liti digit digit digit digit digit digit Homing Di 0 Fo 1 Ro Reserved Reserved	rection orward everse (Do not change.) (Do not change.)	)					
		Reserved	(Do not change.)	)					
Pn817 <sup>*7</sup>	2	Homing Approach Speed (Homing Approach Speed 1)	0 to 65535	100 reference unit/s	50	Immediately <sup>*5</sup>	Setup	_	*1
Pn818 <sup>*8</sup>	2	Homing Creep Speed(Hom- ing Approach Speed 2)	0 to 65535	100 reference unit/s	5	Immediately <sup>*5</sup>	Setup	_	*1
Pn819	4	Final Travel Distance for Homing	-1073741823 to 1073741823	1 reference unit	100	Immediately	Setup	_	*1

\*1. For details, refer to *8 MECHATROLINK-III Commands*.

\*5. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

\*6. The settings are updated only if the sending of the reference has been stopped (DEN is set to 1).

\*7. The set value of Pn842 is valid when the set value of Pn817 is 0. Software version 0023 or higher is required to use Pn842.

\*8. The set value of Pn844 is valid when the set value of Pn818 is 0. Software version 0023 or higher is required to use Pn844.

 $\pm 10. \ \mbox{This parameter}$  is enabled only for MECHATROLINK-II-compatible profile.



Parameter No.	Size	Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section		
	2	Input Signal Monito Selection	or	_	_	0000	Immediately	Setup	M2 <sup>*10</sup>	-		
	n. [	th 3rd 2nd 1st ligit digit digit digit										
			IO12 Sign	nal Mapping								
			1 0	No mapping								
			1 1	Monitors CN1-13 in	nput terminal.							
			2 1	Monitors CN1-7 inj	out terminal.							
			3 1	Monitors CN1-8 inp	out terminal.							
			4 1	Monitors CN1-9 inp	out terminal.							
Pn81E				Againtons CN1-10 in	nput terminal.							
			7	Monitors CN1-12 in	nput terminal.							
				nonitors crt1-12 h	iput terminai.							
			- IO13 Sigr	nal Mapping								
			0 to 7 5	Same as IO2 signal	mapping.							
			- IO14 Signal Mapping									
			0 to 7 5	0 to 7 Same as IO2 signal mapping.								
		L	0 to 7	5 7     Same as IO2 signal mapping.								
	2	Command Data All	ocation			0010	After restart	Setup	M2*10	*1		
	4	th 3rd 2nd 1st				0010	The Testart	Betup	1012			
	d	ligit digit digit digit										
	n. I	┯┛┗┯┛┗┯┛										
			- Option Field Allocation									
			0 Disables OPTION bit allocation.									
			1 I	1 Enables OPTION bit allocation.								
Pn81F			I									
			Position Control Command TFF/TLIM Function Allocation									
			0 1	Disables allocation.								
			1 I	Enables allocation.								
			Reserved	(Do not change.	)							
			Reserved	(Do not change.	)							
Pn820	4	Forward Latching Allowable		-2147483648	1 reference	0	Immediately	Setup		*1		
		Area		2147483647	unit	Ŭ	miniculately	Scrup	_			
Pn822		Reverse Latching A	llowable	-2147483648	1							
	Λ	Reverse Latening H	rea		f	0	Image - 1 1	Cata		*1		
Pn820	4	Forward Latching A Area	- Reserved	<ul> <li>(Do not change.</li> <li>-2147483648 to 2147483647</li> <li>-2147483648</li> </ul>	) reference unit 1	0	Immediately	Setup	_	*1		

\*1. For details, refer to 8 MECHATROLINK-III Commands.

\*10. This parameter is enabled only for MECHATROLINK-II-compatible profile.

(co)	nť	d)
(00		u,

Parameter No.	Size		Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
		Option M	Ionitor 1 Selection	-	-					
		0000H	Motor rotating speed [1000000H/overspee	d detection posi	tion]					
		0001H	Speed reference [1000000H/overspee	d detection posi	tion]					
		0002H	Torque [1000000H/m	nax. torque]						
		0003H	Position error (lower	32 bits) [refere	nce unit]					
		0004H	Position error (upper	32 bits) [refere	nce unit]					
		0005H	System reserved							
		0006H	System reserved							
		000AH	Encoder count (lower	r 32 bits) [refer	ence unit]					
		000BH	Encoder count (upper	r 32 bits) [refer	ence unit]					
		000CH	FPG count (lower 32	bits) [reference	e unit]					
		000DH	FPG count (upper 32	bits) [reference	e unit]					
		0010H	Un000: Motor rotatin	ng speed [min <sup>-1</sup> ]	]					
		0011H	Un001: Speed referen	nce [min <sup>-1</sup> ]						
		0012H	Un002: Torque refere	ence [%]						
		0013H	Un003: Rotational ar from the phase-C orig	ngle 1 (encoder gin: decimal dis	pulses splay)					
		0014H	Un004: Rotational an	ngle 2 [deg]					_	
		0015H	Un005: Input signal i	monitor						
Pn824	2	0016H	Un006: Output signa	l monitor		0000	Immediately	Setup		*1
		0017H	Un007: Input position	n reference spe	ed [min <sup>-1</sup> ]					
		0018H	Un008: Position error	r [reference uni	t]					
		0019H	Un009: Accumulated	l load ratio [%]						
		001AH	Un00A: Regenerative	e load ratio [%]						
		001BH	Un00B: DB resistanc [%]	e consumption	power					
		001CH	Un00C: Input referen unit]	nce counter [ref	erence					
		001DH	Un00D: Feedback pu pulse]	ilse counter [en	coder					
		001EH	Un00E: Fully-closed counter [external enc	loop feedback	pulse ]					
		001FH	System reserved							
		0023H	Primary multi-turn da	ata [Rev]						
		0024H	Primary incremental	data [pulse]						
		0027H	Un022: Installation e	nvironment mo	nitor					
		0080H	Previous value of late (LPOS) [encoder pul	ched feedback p se]	oosition					
		0081H	Previous value of late (LPOS2) [encoder pu	ched feedback p ilse]	oosition				M2*9	
		0084H	Continuous latch stat	us					IVI.3 -	
		Others	Reserved (Do not set	.)						

\*1. For details, refer to 8 MECHATROLINK-III Commands.

\*9. This parameter is enabled only for MECHATROLINK-III standard servo profile.


										(cont'd)		
Parameter No.	Size		Name		Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section	
		Option M	Ionitor 2 Sele	ection	-	-	0000	Immediately				
Pn825	2	0000H	Sama as On	tion Mo	nitor 1 Calastion				Setup	_	*1	
		0084H	Same as Op		intor i Selectior	1.						
Pn827	2	Linear De 1 for Stop	eceleration C oping	onstant	1 to 65535	10000 reference unit/s <sup>2</sup>	100	Immediately <sup>*5</sup>	Setup	_	*1	
Pn829	2	SVOFF V (SVOFF stop)	Vaiting Time at deceleratio	on to	0 to 65535	10 ms	0	Immediately <sup>*5</sup>	Setup	_	*1	
	2	Option Fi	eld Allocatio	on 1	0000 to 1E1E	_	1813	After restart	Setup	M2 <sup>*10</sup>	-	
	n. [	th 3rd 2 ligit digit d	igit digit	0 to E	CCEII hit positio							
					CCFIL OIL positio							
Pn82A				0 I	Disables ACCFIL 1	it allocation.						
FIIOZA			-	1 E	nables ACCFIL b	it allocation.						
			_									
				0 to E	SEL bit position							
			-	0 1	Nachlas CREL bit	allocation						
				1 E	inables GSEL bit a	allocation.						
	2	Ortion E			0000 to		1010	A Stan and a stant	C a ta a a	<b>x c</b> * 10		
	2	Option Fi	leid Allocatio	on Z	1F1F	_	IDIC	After restart	Setup	M2 <sup>10</sup>	_	
	n. [	th 3rd 2 igit digit d	igit digit									
				0 to F V	PPI bit position							
Pn82B				0 E	Disables V_PPI bit	allocation.						
			_	1 E	nables V_PPI bit a	allocation.						
			_									
				0 to F P	_PI_CLR bit posit	tion						
				0 1	Disables P. PI. CLR bit allocation							
				1 E	Enables P PI CLR bit allocation.							
			_									

\*1. For details, refer to 8 MECHATROLINK-III Commands.

\*5. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

 $\pm 10. \ \mbox{This parameter}$  is enabled only for MECHATROLINK-II-compatible profile.



\*10. This parameter is enabled only for MECHATROLINK-II-compatible profile.

		(cont'd)										
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section			
	2	Motion Setting	0000 to 0001	-	0000	After restart	Setup	_	*1			
	n. [	h 3rd 2nd 1st git digit digit digit	aar Annal/Danal Const	ant Selection								
			Uses Pn80A to Pn8	0F and Pn827.	(Setting of F	n834 to Pn840 disa	ibled)					
Pn833			1 Uses Pn834 to Pn8	40. (Setting of	Pn80A to Pn	80F and Pn827 disa	ibled)					
			ł									
		Re	served (Do not change	.)								
		Re	teserved (Do not change.)									
		Re	served (Do not change	(Do not change.)								
Pn834	4	1st Linear Acceleration Constant 2	1 to 20971520	10000 reference unit/s <sup>2</sup>	100	Immediately *5	Setup	_	*1			
Pn836	4	2nd Linear Acceleration Constant 2	1 to 20971520	10000 reference unit/s	100	Immediately *5	Setup	_	*1			
Pn838	4	Acceleration Constant Switching Speed 2	0 to 2097152000	1 reference unit/s	0	Immediately *5	Setup	-	*1			
Pn83A	4	1st Linear Deceleration Constant 2	1 to 20971520	10000 reference unit/s <sup>2</sup>	100	Immediately *5	Setup	_	*1			
Pn83C	4	2nd Linear Deceleration Constant 2	1 to 20971520	10000 reference unit/s <sup>2</sup>	100	Immediately *5	Setup	_	*1			
Pn83E	4	Deceleration Constant Switching Speed 2	0 to 2097152000	1 reference unit/s	0	Immediately *5	Setup	_	*1			
Pn840	4	Linear Deceleration Constant 2 for Stopping	1 to 20971520	10000 reference unit/s <sup>2</sup>	100	Immediately *5	Setup	_	*1			
Pn842 <sup>*7</sup>	4	Homing Approach Spee (Homing Approach Spee	d 0 to ed 12) 20971520	100 reference unit/s	0	Immediately *5	Setup	_	*1			
Pn844 <sup>*8</sup>	4	Homing Creep Speed (H ing Approach Speed 22)	lom- 0 to 20971520	100 reference unit/s	0	Immediately *5	Setup	_	*1			
Pn850	2	Latch Sequence Number	0 to 8	_	0	Immediately	Setup	_	*1			
Pn851	2	Continuous Latch Count	0 to 255	-	0	Immediately	Setup	_	*1			

\*1. For details, refer to 8 MECHATROLINK-III Commands.

\*5. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

\*7. The set value of Pn842 is valid when the set value of Pn817 is 0. Software version 0023 or higher is required to use Pn842.

\*8. The set value of Pn844 is valid when the set value of Pn818 is 0. Software version 0023 or higher is required to use Pn844.





\*9. This parameter is enabled only for MECHATROLINK-III standard servo profile.



\*9. This parameter is enabled only for MECHATROLINK-III standard servo profile.



									(cont d)				
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section				
	2	SVCMD_IO (output signal monitor) Allocation 1	0000 to 1717	_	0000	Immediately	Setup	M3 <sup>*9</sup>	_				
	n. [	th 3rd 2nd 1st igit digit digit											
		Allocat	ion for CN1-1, -2 Ou	tput Signal M	Monitor (SVC	CMD-IO)							
		0	Sets CN1-1, -2 outp	ut terminal m	onitor to D24	(IO1_STS1).							
			Sets CN1-1, -2 outp	ut terminal m	onitor to D25	(IO2_STS1).							
		2	Sets CN1-1, -2 outp	ut terminal m	onitor to D26	(IO3_SIS1). (IO4_STS1)							
		4	Sets CN1-1, -2 outp	ut terminal m	onitor to D28	(IO4_3131). (IO5_STS1).							
		5	Sets CN1-1, -2 outp	ut terminal m	onitor to D29	(IO6_STS1).							
Pn868		6	Sets CN1-1, -2 outp	ut terminal m	onitor to D30	(IO7_STS1).							
1 11000		7	Sets CN1-1, -2 outp	ut terminal m	onitor to D31	(IO8_STS1).							
		CN1-1,	-2 Output Signal M	onitor Select	ion								
		0	Disables bit allocati	on for CN1-1,	-2 output ter	minal monitor.							
			Enables bit allocatio	n for CN1-1,	-2 output tem	ninal monitor.							
		Allocat	ion for CN1-23, -24	Output Signa	al Monitor (S	VCMD IO)							
		0 to 7	Same as the allocati	on for CN1-1,	-2 output sig	nal monitor.							
	CN1-23, -24 Output Signal Monitor Selection												
		0	Disables bit allocati	on for CN1-23	3, -24 output	terminal monitor.							
		1	Enables bit allocation	on for CN1-23	, -24 output to	erminal monitor.							
	2	SVCMD_IO (output signal monitor) Allocation 2	0000 to 1717	-	0100	Immediately	Setup	M3 <sup>*9</sup>	_				
	n. [	th 3rd 2nd 1st igit digit digit digit											
		Allocat	on for CN1-25, -26	Output Signa	al Monitor (S	VCMD_IO)							
		0 to 7	Same as the allocati	on for CN1-1,	-2 output sig	nal monitor.							
Pn869													
1 11005		CN1-2	5, -26 Output Signal	Monitor Sele	ection								
		0	Disables bit allocati	on for CN1-25	5, -26 output	terminal monitor.							
			Enables bit allocatio	n for CN1-25	, -26 output to	erminal monitor.							
		Reserv	ed (Do not change.)	)									
		Reserv	ed (Do not change.)	)									
Pn880	2	Station Address Monitor (for maintenance, read only)	03 to EFH	_	0	Immediately	Setup	_	_				
Pn881	2	Setting Transmission Byte Monitor [byte] (for maintenance, read only)	17, 32, 48	_	0	Immediately	Setup	_	_				

\*9. This parameter is enabled only for MECHATROLINK-III standard servo profile.



								(0	cont'd)
Parameter No.	Size	Name	Setting Range	Units	Factory Setting	When Enabled	Classi- fication	Profile	Reference Section
Pn882	2	Transmission Cycle Setting Monitor [0.25 µs] (for maintenance, read only)	0 to FFFFH	_	0	Immediately	Setup	_	_
Pn883	2	Communications Cycle Set- ting Monitor [x transmission cycle] (for maintenance, read only)	0 to 32	_	0	Immediately	Setup	_	_
Pn88A	2	MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)	0 to 65535	_	0	Immediately	Setup	_	_
Pn890 to Pn8A6	4	Command Data Monitor at Alarm/Warning Occurs (for maintenance, read only)	0 to FFFFFFFFH	_	0	Immediately	Setup	_	*1
Pn8A8 to Pn8BE	4	Response Data Monitor at Alarm/Warning Occurs (for maintenance, read only)	0 to FFFFFFFFH	_	0	Immediately	Setup	_	*1
Pn900	2	Parameter Bank Number	0 to 16	_	0	After restart	Setup	-	*1
Pn901	2	Parameter Bank Member Number	0 to 15	_	0	After restart	Setup	_	*1
Pn902 to Pn910	2	Parameter Bank Member Definition	0000H to 08FFH	_	0	After restart	Setup	_	*1
Pn920 to Pn95F	2	Parameter Bank Data (non- volatile memory save dis- abled)	0000H to FFFFH	_	0	Immediately	Setup	_	*1

\*1. For details, refer to *8 MECHATROLINK-III Commands*.

## 10.1.3 MECHATROLINK-III Common Parameters

The following list shows the common parameters used by all devices for MECHATROLINK-III. These common parameters are used to make settings from the host PC or PLC...etc via MECHATROLINK communications. Do not change settings with the digital operator or any other device.

Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
		Encoder	Гуре (read only)	0 to 1	_	_		
01 PnA02	4	0000H	Absolute encoder				-	
		0001H	Incremental encoder					
02	4	Motor Ty	pe (read only)	0 to 1	_	_		
PnA04	4	0000H	Rotational servomotor					
03	4	Semi-clos (read only	sed/Fully-closedType y)	0 to 1	_	_		
PnA06	4	0000H	Semi-closed				_	
		0001H	Fully-closed					
04 PnA08	4	Rated Spe	eed (read only)	0 to FFFFFFFFH	min <sup>-1</sup>	_	_	Device
05 PnA0A	4	Maximur	n Output Speed (read only)	0 to FFFFFFFFH	min <sup>-1</sup>	_	_	Related Parameters
06 PnA0C	4	Speed Mu	ultiplier (read only)	-1073741823 to 1073741823	_	_	_	
07 PnA0E	4	Rated To	rque (read only)	0 to FFFFFFFFH	N.m	_	_	
08 PnA10	4	Maximum only)	n Output Torque (read	0 to FFFFFFFFH	N.m	_	_	
09 PnA12	4	Torque M	Iultiplier (read only)	-1073741823 to 1073741823	-	_	-	
0A PnA14	4	Resolutio	on (read only)	0 to FFFFFFFFH	pulse/rev	-	-	
21 PnA42	4	Electroni	c Gear Ratio (Numerator)	1 to 1073741824	-	1	After restart	
22 PnA44	4	Electronic tor)	c Gear Ratio (Denomina-	1 to 1073741824	-	1	After restart	
23 PnA46	4	Absolute	Encoder Origin Offset	-1073741823 to 1073741823	1 reference unit	0	Immedi- ately <sup>*1</sup>	
24 PnA48	4	Multiturn	Limit Setting	0 to 65535	Rev	65535	After restart	
		Limit Set	ting	0 to 33H	0000H			Machine
		Bit 0	P-OT (0: Enabled, 1: Disab	led)				specifica- tion Related
		Bit 1	N-OT (0: Enabled, 1: Disab	oled)				Parameters
		Bit 2	Reserved					
25	4	Bit 3	Reserved			0000H	After	
PNA4A		Bit 4	P-SOT (0: Disabled, 1: Ena	bled)			restart	
		Bit 5	N-SOT (0: Disabled, 1: Ena	ibled)				
		Bit 6	Reserved					
		Bit 7 to 31	Reserved					

\*1. Available after the SENS\_ON command is input.



								(cont'd)
Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
26 PnA4C	4	Forward	Software Limit	-1073741823 to 1073741823	1 reference unit	1073741823	Immedi- ately	
27 PnA4E	4	Reserved	(Do not use.)	-	_	0	Immedi- ately	Machine Specifica- tion Related
28 PnA50	4	Reverse S	Software Limit	-1073741823 to 1073741823	1 reference unit	-1073741823	Immedi- ately	Parameters
29 PnA52	4	Reserved	(Do not use.)	_	_	0	Immedi- ately	
		Speed Un	iit <sup>*2</sup>	0 to 4	_			
		0000H	reference unit/sec	I				
41		0001H	reference unit/min				After	
PnA82	4	0002H	Percentage (%) of rated spe	ed <sup>*3</sup>		0	restart	
		0003H	min <sup>-1*3</sup>					
		0004H	Max. motor speed/4000000	0H <sup>*4</sup>				
42 PnA84	4	Speed Ba (Set the v exponent the Speed	se Unit salue of "n" used as the in $10^n$ when calculating I Unit (41).) <sup>*3*4</sup>	-3 to 3	_	0	After restart	
43		Position U	Jnit	0	_		After	
PnA86	4	0000H	reference unit			0	restart	
44 PnA88	4	Position I (Set the v exponent the Positi	Base Unit alue of "n" used as the in 10 <sup>n</sup> when calculating on Unit (43).)	0	_	0	After restart	Unit System Related
		Accelerat	ion Unit	-	_			Parameters
45 PnA8A	4	0000H	reference unit/sec <sup>2</sup>			0	After restart	
		0001H	Not supported					
46 PnA8C	4	Accelerat (Set the v exponent the Accel	ion Base Unit alue of "n" used as the in 10 <sup>n</sup> when calculating eration Unit (45).)	4 to 6	_	4	After restart	
		Torque U	nit	1 to 2	-			
47	4	0000H	Not supported			1	After	
PnA8E	4	0001H	Percentage (%) of rated toro	lue		1	restart	
		0002H	Max. torque/40000000H <sup>*5</sup>					
48 PnA90	4	Torque B (Set the v exponent the Torqu	ase Unit <sup>*5</sup> alue of "n" used as the in 10 <sup>n</sup> when calculating e Unit (47).)	-5 to 0	-	0	After restart	

\*2. When using fully-closed loop control, set 0000H (Reference unit/sec).

\*3. When either 0002H or 0003H is selected for the Speed Unit (parameter 41), set the Speed Base Unit (parameter 42) to a number between -3 and 0.

\*4. When 0004H is selected for the Speed Unit (parameter 41), set the Speed Base Unit (parameter 42) to 0.

\* 5. When 0002H is selected for the Torque Unit (parameter 47), set the Torque Base Unit (parameter 48) to 0.

							(cont'	d)
Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
49 PnA92	4	Compliar Speed Bit 0 Bit 1 Bit 2 Bit 2 Bit 3 Bit 4 Bit 4 Bit 5 to 7 Position Bit 8 Bit 9 to 15 Accelerat Bit 16 Bit 17 Bit 16 Bit 17 Bit 18 to 23 Torque Bit 24 Bit 25 Bit 26 Bit 27 to 31	reference unit/s (1: Enabled reference unit/min (1: Enabled Percentage (%) of rated spec min <sup>-1</sup> (rpm) (1: Enabled) Max. motor speed/4000000 Reserved (0: Disabled) reference unit (1: Enabled) Reserved (0: Disabled) ion reference unit/s <sup>2</sup> (1: Enabled msec (Acceleration time tak (0: Disabled) Reserved (0: Disabled) N.m (N) (0: Disabled) Percentage (%) of rated torr Max. torque/4000000H (1: Reserved (0: Disabled)	- ) led) ed (1: Enabled) H (1: Enabled) d) cen to reach the rat	red speed)	0601011FH		Unit System Related Parameters
61 PnAC2	4	Speed Lo	op Gain	1000 to 2000000	0.001 Hz [0.1 Hz]	40000	Immedi- ately	
62 PnAC4	4	Speed Lo	op Integral Time Constant	150 to 512000	µs [0.01 ms]	20000	Immedi- ately	
63 PnAC6	4	Position I	Loop Gain	1000 to 2000000	0.001/s [0.1/s]	40000	Immedi- ately	A dinator
64 PnAC8	4	Feedforw	ard Compensation	0 to 100	1%	0	Immedi- ately	Related Parameters
65 PnACA	4	Position I stant	Loop Integral Time Con-	0 to 5000000	µs [0.1 ms]	0	Immedi- ately	
66 PnACC	4	Positioni	ng Completed Width	0 to 1073741824	1 reference unit	7	Immedi- ately	
67 PnACE	4	NEAR Si	gnal Width	1 to 1073741824	1 reference unit	1073741824	Immedi- ately	

								(cont'd)
Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
81 PnB02	4	Exponent Time Cor	tial Function Accel/Decel	0 to 510000	µs [0.1 ms]	0	Immedi- ately <sup>*6</sup>	
82 PnB04	4	Movemen	nt Average Time	0 to 510000	µs [0.1 ms]	0	Immedi- ately <sup>*6</sup>	
83 PnB06	4	Final Tra Positionii	vel Distance for External ng	-1073741823 to 1073741823	1 reference unit	100	Immedi- ately	
84 PnB08	4	Homing A	Approach Speed	0 to 3FFFFFFFFH	10 <sup>-3</sup> min <sup>-1</sup>	5000 Value converted reference/s into 10 <sup>-3</sup> min <sup>-1</sup>	Immedi- ately	
85 PnB0A	4	Homing	Creep Speed	0 to 3FFFFFFFH	10 <sup>-3</sup> min <sup>-1</sup>	500 Value converted reference/s into 10 <sup>-3</sup> min <sup>-1</sup>	Immedi- ately	
86 PnB0C	4	Final Tra	vel Distance for Homing	-1073741823 to 1073741823	1 reference unit	100	Immedi- ately	
87 PnB0E	4	Monitor S 0000H 0001H 0002H 0003H 0004H 0005H 0006H 0007H 0008H 0009H 0000H 0000CH 0000CH	Selection 1 APOS CPOS PERR LPOS1 LPOS2 FSPD CSPD TRQ ALARM MPOS Reserved (Undefined value) Reserved (Undefined value) CMN1 (Common monitor 1 CMN2 (Common monitor 2 OMN1 (Optional monitor 1	0 to F		1	Immedi- ately	Command Related Parameters
88 PnB10	4	Monitor S 0000H to 000FH	Selection 2 Same as Monitor Selection	-	_	0	Immedi- ately	

\*6. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

Parameter No.	Size		Ν	lame		Setting Ra	ange	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
		Monitor S (CMN1)	Selectio	on for SEL_N	ION1	0 to 6		_			
		0000H	TPOS	(Target posit	tion in th	e reference c	coordina	ates)			
		0001H	IPOS	(Reference p	osition i	n the referen	ce coor	dinates)			
		0002H	POS_ (POS_	OFSET (Offs _SET))	set value	set in the set	t coordi	nates command			
		0003H	TSPD	(Target spee	d)						
		0004H	SPD_	LIM (Speed	limit val	ue)					
		0005H	TRQ_	LIM (Torque	e limit va	lue)					
			SV_S' Monit Byte 001 011 021 031 Byte 001 011 021 Byte Byte	TAT for e 1: Current c H: Phase 0 H: Phase 1 H: Phase 2 H: Phase 3 e 2: Current c H: Position c H: Speed con H: Speed con H: Torque co e 3: Reserved	ommunio ontrol mo ontrol m trol mod ntrol mo	cations phase ode ode le de monitor	e				
			Bit	Name	Co	ontents	Value	Setting			
89			<b>D</b> : ( 0		Process for latel	ing status h detection	0	Latch detection not processed		Immedi-	Command
89 PnB12	4	0006H	Bit 0		SVCMI	a by D_CTRL, Q1	1	During latch detection processing	0	ately	Related Parameters
			6H Bit 1	IT RDY1	Processing sta for latch detec	ing status h detection	0	Latch detection not processed			
					SVCMI LT_RE	D_CTRL, Q2	1	During latch detection processing			
							0	Phase C			
			Bit 2.				1	External input signal 1			
			Bit 3	LT_SEL1R	Latch s	ignal	2	External input signal 2			
							3	External input signal 3			
							0	Phase C			
			Bit 4.				1	External input signal 1			
			Bit 5	LT_SEL2R	Latch s	ıgnal	2	External input signal 2			
							3	External input signal 3			
			Bit 6	Reserved (0	)						

								(cont'd)
Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
84		Monitor S (CMN2)	Selection for SEL_MON2	0 to 6	_		Immedi-	
PnB14	4	0000H to 0006H	Same as Monitor Selection	for SEL_MON1.		0	ately	
8B PnB16	4	Origin De	etection Range	0 to 250	1 reference unit	10	Immedi- ately	
8C PnB18	4	Forward '	Torque Limit	0 to 800	1%	100	Immedi- ately	
8D PnB1A	4	Reverse 7	Forque Limit	0 to 800	1%	100	Immedi- ately	
8E PnB1C	4	Zero Spe	ed Detection Range	1000 to 10000000	10 <sup>-3</sup> min <sup>-1</sup>	20000	Immedi- ately	
8F PnB1E	4	Speed Co Width (re	oincidence Signal Output ead only)	0 to 100000	10 <sup>-3</sup> min <sup>-1</sup>	10000	Immedi- ately	
		Servo Co Enabled/I Bit 0	mmand Control Field Disabled (read only) CMD_PAUSE (1: Enabled)	_	-			
		Bit 1	CMD_CANCEL (1: Enable	ed)				Command
		Bit 2, 3	STOP_MODE (1: Enabled)	)				Related
		Bit 4, 5	ACCFIL (1: Enabled)					Parameters
		Bit 6, 7	Reserved (0: Disabled)					
		Bit 8	LT_REQ1 (1: Enabled)					
		Bit 9	LT_REQ2 (1: Enabled)					
90 PpB20	4	Bit 10, 11	LT_SEL1 (1: Enabled)			0FFF3F3FH	_	
1 11020		Bit 12, 13	LT_SEL2 (1: Enabled)					
		Bit 14, 15	Reserved (0: Disabled)					
		Bit 16 to 19	SEL_MON1 (1: Enabled)					
		Bit 20 to 23	SEL_MON2 (1: Enabled)					
		Bit 24 to 27	SEL_MON3 (1: Enabled)					
		Bit 28 to 31	Reserved (0: Disabled)					

Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
		Servo Co Enabled/I	mmand Status Field Disabled (read only)	_	0			
		Bit 0	CMD_PAUSE_CMP (1: Er	nabled)				
		Bit 1	CMD_CANCEL_CMP (1: )	Enabled)				
		Bit 2, 3	Reserved (0: Disabled)					
		Bit 4, 5	ACCFIL (1: Enabled)					
		Bit 6, 7	Reserved (0: Disabled)					
		Bit 8	L_CMP1 (1: Enabled)					
		Bit 9	L_CMP2 (1: Enabled)					
		Bit 10	POS_RDY (1: Enabled)					
91 PnB22	4	Bit 11	PON (1: Enabled)			0FFF3F33H	-	
		Bit 12	M_RDY (1: Enabled)					
		Bit 13	SV_ON (1: Enabled)					
		Bit 14, 15	Reserved (0: Disabled)					
		Bit 16 to 19	SEL_MON1 (1: Enabled)					
		Bit 20 to 23	SEL_MON2 (1: Enabled)					
		Bit 24 to 27	SEL_MON3 (1: Enabled)					Command Related
		Bit 28 to 31	Reserved (0: Disabled)					Parameters
		I/O Bit En (read only	nabled/Disabled (Output) y)	_	-			
		Bit 0 to 3	Reserved (0: Disabled)					
		Bit 4	V_PPI (1: Enabled)					
		Bit 5	P_PPI (1: Enabled)					
		Bit 6	P_CL (1: Enabled)					
		Bit 7	N_CL (1: Enabled)					
92	4	Bit 8	G_SEL (1: Enabled)					
PnB24	4	Bit 9 to 11	G_SEL (0: Disabled)			007F01F0H	_	
		Bit 12 to 15	Reserved (0: Disabled)					
		Bit 16 to 19	BANK_SEL (1: Enabled)					
		Bit 20 to 22	SO1 to SO3 (1: Enabled)					
		Bit 23	Reserved (0: Disabled)			1		
		Bit 24 to 31	Reserved (0: Disabled)					

								(cont'd)
Parameter No.	Size		Name	Setting Range	Units [Resolution]	Factory Setting	When Enabled	Classifica- tion
		I/O Bit Er (read only	nabled/Disabled (Input) y)	_	_			
		Bit 0	Reserved (0: Disabled)					
		Bit 1	DEC (1: Enabled)					
		Bit 2	P-OT (1: Enabled)			]		Command Related Parameters
		Bit 3	N-OT (1: Enabled)					
		Bit 4	EXT1 (1: Enabled)					
		Bit 5	EXT2 (1: Enabled)					
		Bit 6	EXT3 (1: Enabled)					
		Bit 7	ESTP (1: Enabled)				_	
		Bit 8	Reserved (0: Disabled)			ļ		
93		Bit 9	BRK_ON (1: Enabled)					
PnB26	4	Bit 10	P-SOT (1: Enabled)			FF0FFEFEH		
		Bit 11	N-SOT (1: Enabled)					Parameters
		Bit 12	DEN (1: Enabled)					
		Bit 13	NEAR (1: Enabled)					
		Bit 14	PSET (1: Enabled)					
		Bit 15	ZPOINT (1: Enabled)					
		Bit 16	T_LIM (1: Enabled)					
		Bit 17	V_LIM (1: Enabled)					
		Bit 18	V_CMP (1: Enabled)					
		Bit 19	ZSPD (1: Enabled)					
		Bit 20 to 23	Reserved (0: Disabled)					
		Bit 24 to 31	I0_STS1 to 8 (1: Enabled)					

## 10.2 Parameter Recording Table

Use the following table for recording parameters.

Note: Pn10B, Pn170, and Pn408 have two kinds of digits: the digit which does not need the restart after changing the set- tings and the digit which needs the restart. The underlined digits of the factory setting in the following table show the digit which needs the restart.

Parameter	Factory Setting		Name	When Enabled
Pn000	0000		Basic Function Select Switch 0	After restart
Pn001	0000		Application Function Select Switch 1	After restart
Pn002	0011		Application Function Select Switch 2	After restart
Pn006	0002		Application Function Select Switch 6	Immediately
Pn007	0000		Application Function Select Switch 7	Immediately
Pn008	4000		Application Function Select Switch 8	After restart
Pn009	0010		Application Function Select Switch 9	After restart
Pn00B	0000		Application Function Select Switch B	After restart
Pn00C	0000		Application Function Select Switch C	After restart
Pn00D	0000		Application Function Select Switch D	After restart
Pn081	0000		Maker setting	-
Pn100	400		Speed Loop Gain	Immediately
Pn101	2000		Speed Loop Integral Time Constant	Immediately
Pn102	400		Position Loop Gain	Immediately
Pn103	100		Moment of Inertia Ratio	Immediately
Pn104	400		2nd Speed Loop Gain	Immediately
Pn105	2000		2nd Speed Loop Integral Time Con- stant	Immediately
Pn106	400		2nd Position Loop Gain	Immediately
Pn109	0		Feedforward Gain	Immediately
Pn10A	0		Feedforward Filter Time Constant	Immediately
Pn10B	<u>000</u> 0		Application Function for Gain Select Switch	_
Pn10C	200		Mode Switch (torque reference)	Immediately
Pn10D	0		Mode Switch (speed reference)	Immediately
Pn10E	0		Mode Switch (acceleration)	Immediately
Pn10F	0		Mode Switch (position error)	Immediately
Pn11F	0		Position Integral Time Constant	Immediately
Pn121	100		Friction Compensation Gain	Immediately
Pn122	100		2nd Gain for Friction Compensation	Immediately
Pn123	0		Friction Compensation Coefficient	Immediately
Pn124	0		Friction Compensation Frequency Correction	Immediately
Pn125	100		Friction Compensation Gain Correc- tion	Immediately
Pn131	0		Gain Switching Time 1	Immediately
Pn132	0		Gain Switching Time 2	Immediately
Pn135	0		Gain Switching Waiting Time 1	Immediately
Pn136	0		Gain Switching Waiting Time 2	Immediately



Parameter	Factory Setting		Name	When Enabled
Pn139	0000		Automatic Gain Changeover Related Switch 1	Immediately
Pn13D	2000		Current Gain Level	Immediately
Pn140	0100		Model Following Control Related Switch	Immediately
Pn141	500		Model Following Control Gain	Immediately
Pn142	1000		Model Following Control Gain Com- pensation	Immediately
Pn143	1000		Model Following Control Bias (Forward Direction)	Immediately
Pn144	1000		Model Following Control Bias (Reverse Direction)	Immediately
Pn145	500		Vibration Suppression 1 Frequency A	Immediately
Pn146	700		Vibration Suppression 1 Frequency B	Immediately
Pn147	1000		Model Following Control Speed Feedforward Compensation	Immediately
Pn148	500		2nd Model Following Control Gain	Immediately
Pn149	1000		2nd Model Following Control Gain Compensation	Immediately
Pn14A	800		Vibration Suppression 2 Frequency	Immediately
Pn14B	100		Vibration Suppression 2 Compensa- tion	Immediately
Pn14F	0011		Control Related Switch	After restart
Pn160	0010		Anti-Resonance Control Related Switch	Immediately
Pn161	1000		Anti-Resonance Frequency	Immediately
Pn162	100		Anti-Resonance Gain Compensation	Immediately
Pn163	0		Anti-Resonance Damping Gain	Immediately
Pn164	0		Anti-Resonance Filter Time Con- stant 1 Compensation	Immediately
Pn165	0		Anti-Resonance Filter Time Con- stant 2 Compensation	Immediately
Pn170	14 <u>01</u>		Tuning-less Function Related Switch	—
Pn205	65535		Multiturn Limit Setting	After restart
Pn207	0010		Position Control Function Switch	After restart
Pn20A	32768		Maker setting	-
Pn20E	1		Electronic Gear Ratio (Numerator)	After restart
Pn210	1		Electronic Gear Ratio (Denominator)	After restart
Pn212	2048		Encoder Output Pulses	After restart
Pn22A	0000		Maker setting	-
Pn230	0000		Position Control Expanded Function Switch	After reset
Pn231	0		Backlash Compensation Value	Immediately
Pn233	0		Backlash Compensation Time Con- stant	Immediately
Pn281	20		Maker setting	-
Pn304	500		JOG Speed	Immediately
Pn305	0		Soft Start Acceleration Time	Immediately



			(cont'd)
Parameter	Factory Setting	Name	When Enabled
Pn306	0	Soft Start Deceleration Time	Immediately
Pn310	0000	Vibration Detection Switch	Immediately
Pn311	100	Vibration Detection Sensibility	Immediately
Pn312	50	Vibration Detection Level	Immediately
Pn324	300	Moment of Inertia Calculating Start Level	Immediately
Pn401	100	Torque Reference Filter Time Constant	Immediately
Pn402	800	Forward Torque Limit	Immediately
Pn403	800	Reverse Torque Limit	Immediately
Pn404	100	Forward External Torque Limit	Immediately
Pn405	100	Reverse External Torque Limit	Immediately
Pn406	800	Emergency Stop Torque	Immediately
Pn407	10000	Speed Limit during Torque Control	Immediately
Pn408	00 <u>0</u> 0	Torque Related Function Switch	_
Pn409	5000	1st Notch Filter Frequency	Immediately
Pn40A	70	1st Notch Filter Q Value	Immediately
Pn40B	0	1st Notch Filter Depth	Immediately
Pn40C	5000	2nd Notch Filter Frequency	Immediately
Pn40D	70	2nd Notch Filter Q Value	Immediately
Pn40E	0	2nd Notch Filter Depth	Immediately
Pn40F	5000	2nd Step 2nd Torque Reference Filter Frequency	Immediately
Pn410	50	2nd Step 2nd Torque Reference Filter Q Value	Immediately
Pn412	100	1st Step 2nd Torque Reference Filter Time Constant	Immediately
Pn415	0	Reserved	-
Pn423	0000	Reserved	-
Pn424	50	Torque Limit at Main Circuit Voltage Drop	Immediately
Pn425	100	Main Circuit Voltage Drop	Immediately
P11430	15	Sweep lorque Reference Amplitude	Immediately
Pn460	0101	Notch Filter Adjustment Switch	Immediately
Ph501	10	Zero Clamp Level	Immediately
Pn502	20	Rotation Detection Level	Immediately
Pn503	10	Width	Immediately
Pn506	0	Time	Immediately
Pn507	100	Lock Reference Output Speed Level	Immediately
Pn508	50	Waiting Time for Lock Signal When Motor Running	Immediately
Pn509	20	Instantaneous Power Cut Hold Time	Immediately
Pn50A	1881	Input Signal Selection 1	After restart
Pn50B	8882	Input Signal Selection 2	After restart
Pn50E	0000	Output Signal Selection 1	After restart



		(cont	d)
Parameter	Factory Setting	Name	When Enabled
Pn50F	0100	Output Signal Selection 2	After restart
Pn510	0000	Output Signal Selection 3	After restart
Pn511	6543	Input Signal Selection 5	After restart
Pn512	0000	Output Signal Inverse Setting	After restart
Pn517	0000	Reserved	-
Pn51B	1000	Excessive Error Level Between Servomotor and Load Positions	Immediately
Pn51E	100	Excessive Position Error Warning Level	Immediately
Pn520	5242880	Excessive Position Error Alarm Level	Immediately
Pn522	7	Positioning Completed Width	Immediately
Pn524	1073741824	NEAR Signal Width	Immediately
Pn526	5242880	Excessive Position Error Alarm Level at Servo ON	Immediately
Pn528	100	Excessive Position Error Warning Level at Servo ON	Immediately
Pn529	10000	Speed Limit Level at Servo ON	Immediately
Pn52A	20	Multiplier per One Fully- closed Rotation	Immediately
Pn52B	20	Overload Warning Level	Immediately
Pn52C	100	Derating of Base Current at Detecting Overload of Motor	After restart
Pn52D	50	Reserved	-
Pn52F	0FFF	Reserved	-
Pn530	0000	Program JOG Operation Related Switch	Immediately
Pn531	32768	Program JOG Movement Distance	Immediately
Pn533	500	Program JOG Movement Speed	Immediately
Pn534	100	Program JOG Acceleration/Deceleration Time	Immediately
Pn535	100	Program JOG Waiting Time	Immediately
Pn536	1	Number of Times of Program JOG           Movement	Immediately
Pn550	0	Analog Monitor 1 Offset Voltage	Immediately
Pn551	0	Analog Monitor 2 Offset Voltage	Immediately
Pn552	100	Analog Monitor Magnification (·1)	Immediately
Pn553	100	Analog Monitor Magnification (·2)	Immediately
Pn560	400	Remained Vibration Detection Width	Immediately
Pn561	100	Overshoot Detection Level	Immediately
Pn600	0	Regenerative Kesistor Capacity	Immediately
Pno01	0	Communications Control	- Immod:-+-1-
P1800	1040	Application Function Select 6	immediately
Pn801	0003	(Software LS)	Immediately
Pn803	10	Origin Range	Immediately
Pn804	1073741823	Forward Software Limit	Immediately
Pn806	-1073741823	Reverse Software Limit	Immediately



			(cont'd)
Parameter	Factory Setting	Name	When Enabled
Pn808	0	Absolute Encoder Origin Offset	Immediately *1
Pn80A	100	1st Linear Acceleration Constant	Immediately *2
Pn80B	100	2nd Linear Acceleration Constant	Immediately *2
Pn80C	0	Acceleration Constant Switching Speed	Immediately *2
Pn80D	100	1st Linear Deceleration Constant	Immediately *2
Pn80E	100	2nd Linear Deceleration Constant	Immediately *2
Pn80F	0	Deceleration Constant Switching Speed	Immediately *2
Pn810	0	Exponential Function Acceleration/ Deceleration Bias	Immediately *2
Pn811	0	Exponential Function Acceleration/ Deceleration Time Constant	Immediately *2
Pn812	0	Movement Average Time	Immediately *2
Pn814	100	Final Travel Distance for External Positioning	Immediately *2
Pn816	0000	Homing Mode Setting	Immediately *2
Pn817	50	Homing Approach Speed (Homing Approach Speed 1)	Immediately *2
Pn818	5	Homing Creep Speed (Homing Approach Speed 2)	Immediately *2
Pn819	100	Final Travel Distance for Homing	Immediately*2
Pn81E	0000	Input Signal Monitor Selection	Immediately
Pn81F	0010	Command Data Allocation	After restart
Pn820	0	Forward Latching Allowable Area	Immediately
Pn822	0	Reverse Latching Allowable Area	Immediately
Pn824	0000	Option Monitor 1 Selection	Immediately
Pn825	0000	Option Monitor 2 Selection	Immediately
Pn827	100	Linear Deceleration Constant 1 for Stopping	Immediately *2
Pn829	0	SVOFF Waiting Time (SVOFF at deceleration to stop)	Immediately
Pn82A	1813	Option Field Allocation 1	After restart
Pn82B	1D1C	Option Field Allocation 2	After restart
Pn82C	1F1E	Option Field Allocation 3	After restart
Pn82D	0000	Option Field Allocation 4	After restart
Pn82E	0000	Option Field Allocation 5	After restart
Pn833	0000	Motion Setting	After restart
Pn834	100	1st Linear Acceleration Constant 2	Immediately*2

\*1. Enabled after the SENS\_ON is entered.

\*2. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

		(cont'	d)
Parameter	Factory Setting	Name	When Enabled
Pn836	100	2nd Linear Acceleration Constant 2	Immediately*2
Pn838	0	Acceleration Constant Switching Speed 2	Immediately *2
Pn83A	100	1st Linear Deceleration Constant 2	Immediately*2
Pn83C	100	2nd Linear Deceleration Constant 2	Immediately*2
Pn83E	0	Deceleration Constant Switching Speed 2	Immediately *2
Pn840	100	Linear Deceleration Constant 2 for Stopping	Immediately *2
Pn842	0	Homing Approach Speed (Homing Approach Speed12)	Immediately *2
Pn844	0	Homing CreepSpeed (Homing Approach Speed 22)	Immediately *2
Pn850	0	Latch Sequence Number	Immediately
Pn851	0	Continuous Latch Count	Immediately
Pn852	0000	Latch Sequence Signal 1 to 4 Setting	Immediately
Pn853	0000	Latch Sequence Signal 5 to 8 Setting	Immediately
Pn860	0000	SVCMD_IO (input signal monitor) Allocation 1	Immediately
Pn861	0000	SVCMD_IO (input signal monitor) Allocation 2	Immediately
Pn862	0000	SVCMD_IO (input signal monitor) Allocation 3	Immediately
Pn863	0000	SVCMD_IO (input signal monitor) Allocation 4	Immediately
Pn864	0000	SVCMD_IO (input signal monitor) Allocation 5	Immediately
Pn865	0000	SVCMD_IO (input signal monitor) Allocation 6	Immediately
Pn866	0000	SVCMD_IO (input signal monitor) Allocation 7	Immediately
Pn868	0000	SVCMD_IO (output signal monitor) Allocation 1	Immediately
Pn869	0100	SVCMD_IO (output signal monitor) Allocation 2	Immediately
Pn880	0	Station Address Monitor (for maintenance, read only)	Immediately
Pn881	0	Setting Transmission Byte Monitor [byte] (for maintenance, read only)	Immediately
Pn882	0	Transmission Cycle Setting Monitor [0.25 μs] (for maintenance, read only)	Immediately
Pn883	0	Communications Cycle Setting Monitor [x transmission cycle] (for maintenance, read only)	Immediately
Pn88A	0	MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)	Immediately

\*2. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

				(cont'd)
Parameter	Factory Setting		Name	When Enabled
Pn890 to Pn8A6	0		Command Data Monitor at Alarm/ Warning Occurs (for maintenance, read only)	Immediately
Pn8A8 to Pn8BE	0		Response Data Monitor at Alarm/ Warning Occurs (for maintenance, read only)	Immediately
Pn900	0		Parameter Bank Number	After restart
Pn901	0		Parameter Bank Member Number	After restart
Pn902 to Pn910	0		Parameter Bank Member Definition	After restart
Pn920 to Pn95F	0		Parameter Bank Data (nonvolatile memory save disabled)	Immediately
01 PnA02	-		Encoder Type (read only)	-
02 PnA04	-		Motor Type (read only)	-
03 PnA06	-		Semi-closed/Fully-closed Type (read only	-
04 PnA08	_		Rated Speed (read only)	-
05 PnA0A	-		Maximum Output Speed (read only)	-
06 PnA0C	-		Speed Multiplier (read only)	-
07 PnA0E	-		Rated Torque (read only)	-
08 PnA10	-		Maximum Output Torque (read only)	-
09 PnA12	-		Torque Multiplier (read only)	-
0A PnA14	-		Resolution (read only)	-
21 PnA42	1		Electronic Gear Ratio (Numerator)	After restart
22 PnA44	1		Electronic Gear Ratio (Denominator)	After restart
23 PnA46	0		Absolute Encoder Origin Offset	Immediately*1
24 PnA48	65535		Multiturn Limit Setting	After restart
25 PnA4A	0000H		Limit Setting	After restart
26 PnA4C	1073741823		Forward Software Limit	Immediately
27 PnA4E	0		Reserved (Do not use.)	Immediately
28 PnA50	- 1073741823		Reverse Software Limit	Immediately

\*1. Available after the SENS\_ON command is input.



			(cont'd)	
Parameter	Factory Setting		Name	When Enabled
29 PnA52	0		Reserved (Do not use.)	Immediately
41 PnA82	0		Speed Unit	After restart
42 PnA84	0		Speed Base Unit	After restart
43 PnA86	0		Position Unit	After restart
44 PnA88	0		Position Base Unit	After restart
45 PnA8A	0		Acceleration Unit	After restart
46 PnA8C	4		Acceleration Base Unit	After restart
47 PnA8E	1		Torque Unit	After restart
48 PnA90	0		Torque Base Unit	After restart
49 PnA92	0601011FH		Compliance Unit System (read only)	-
61 PnAC2	40000		Speed Loop Gain	Immediately
62 PnAC4	20000		Speed Loop Integral Time Constant	Immediately
63 PnAC6	40000		Position Loop Gain	Immediately
64 PnAC8	0		Feedforward Compensation	Immediately
65 PnACA	0		Position Loop Integral Time Constant	Immediately
66 PnACC	7		Positioning Completed Width	Immediately
67 PnACE	1073741824		NEAR Signal Width	Immediately
81 PnB02	0		Exponential Function Accel/Decel Time Constant	Immediately*2
82 PnB04	0		Movement Average Time	Immediately*2
83 PnB06	100		Final Travel Distance for External Positioning	Immediately
84 PnB08	5000 Value con- verted refer- ence/s into 10 <sup>-3</sup> min <sup>-1</sup>		Homing Approach Speed	Immediately

\*2. Change the setting when the reference is stopped (DEN is set to 1), because the change will affect the output during operation.

			(cont'd)
Parameter	Factory Setting	Name	When Enabled
85 PnB0A	500 Value con- verted refer- ence/s into 10 <sup>-3</sup> min <sup>-1</sup>	Homing Creep Speed	Immediately
86 PnB0C	100	Final Travel Distance for Homing	Immediately
87 PnB0E	1	Monitor Selection 1	Immediately
88 PnB10	0	Monitor Selection 2	Immediately
89 PnB12	0	Monitor Selection for SEL_MON (CMN1)	<sup>1</sup> Immediately
8A PnB14	0	Monitor Selection for SEL_MON (CMN2)	<sup>2</sup> Immediately
8B PnB16	10	Origin Detection Range	Immediately
8C PnB18	100	Forward Torque Limit	Immediately
8D PnB1A	100	Reverse Torque Limit	Immediately
8E PnB1C	20000	Zero Speed Detection Range	Immediately
8F PnB1E	10000	Speed Coincidence Signal Output Width (read only)	Immediately
90 PnB20	0FFF3F3FH	Servo Command Control Field Enabled/Disabled (read only)	_
91 PnB22	0FFF3F33H	Servo Command Status Field Enabled/Disabled (read only)	_
92 PnB24	007F01F0H	I/O Bit Enabled/Disabled (Output) (read only)	) _
93 PnB26	FF0FFEFEH	I/O Bit Enabled/Disabled (Input) (read only)	_

## Revision history

No.LEC-OM07101 Feb./2014 1st printing No.LEC-OM07102 Aug./2014 2nd printing Correction of words

## **SMC** Corporation

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021 JAPAN Tel: + 81 3 5207 8249 Fax: +81 3 5298 5362 URL <u>http://www.smcworld.com</u>

Note: Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.

© 2014 SMC Corporation All Rights Reserved

