



# Operation Manual

PRODUCT NAME

Air Gripper for Collaborative Robots

MODEL / Series / Product Number

RMHS Series

**SMC Corporation**

# Contents

Safety Instructions .....	- 2 -
1. List of included items .....	- 4 -
1-1. Common included items .....	- 4 -
1-2. Parts exclusive for each robot manufacturer included in the package エラー! ブックマークが定義されていません。	
2. How to order .....	- 5 -
3. Product Specifications .....	- 8 -
3-1. Product Specifications .....	- 8 -
3-2. Valve Specifications .....	- 8 -
3-3. Solenoid Specifications .....	- 9 -
3-4. Auto Switch Specifications .....	- 9 -
3-5. Gripping force .....	- 10 -
3-6. Gripping Point .....	- 10 -
3-7. Names and function of product parts .....	- 11 -
3-8. Connector and pin layout .....	- 12 -
3-9. Internal circuit diagram .....	- 14 -
4. Installation .....	- 17 -
4-1. Installation .....	- 17 -
4-2. Wiring .....	- 19 -
4-3. Piping .....	- 19 -
4-4. Finger open / close speed adjustment .....	- 20 -
5. Dimensions .....	- 21 -
5-1. Air gripper .....	- 21 -
5-2. Protection cover .....	- 21 -
5-3. Valve option .....	- 22 -
5-4. Dedicated flange .....	- 23 -
5-5. Position of the center of gravity and TCP .....	- 24 -
6. Maintenance .....	- 25 -
6-1. Precautions .....	- 25 -
6-2. Exploded view .....	- 26 -
6-3. Replacement Parts .....	- 27 -
6-4. Procedures for replacing parts .....	- 30 -
7. Precautions for use .....	- 34 -
7-1. Precautions for Design .....	- 34 -
7-2. Air supply .....	- 34 -
7-3. Piping .....	- 35 -
7-4. Operating environment .....	- 35 -
7-5. Lubrication .....	- 35 -



# Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)\*1), and other safety regulations.

\*1) ISO 4414: Pneumatic fluid power -- General rules relating to systems.

ISO 4413: Hydraulic fluid power -- General rules relating to systems.

IEC 60204-1: Safety of machinery -- Electrical equipment of machines.(Part 1: General requirements)

ISO 10218: Manipulating industrial robots -Safety.

etc.



## Caution

**Caution** indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.



## Warning

**Warning** indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.



## Danger

**Danger** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

## Warning

### 1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results.

The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product.

This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

### 2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly.

The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

### 3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.

2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.

3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

### 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.

2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.

3. An application which could have negative effects on people, property, or animals requiring special safety analysis.

4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.



# Safety Instructions

## **Caution**

### **The product is provided for use in manufacturing industries.**

The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.  
If anything is unclear, contact your nearest sales branch.

## **Limited warranty and Disclaimer/Compliance Requirements**

The product used is subject to the following “Limited warranty and Disclaimer” and “Compliance Requirements”.

Read and accept them before using the product.

### **Limited warranty and Disclaimer**

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.  
Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.**
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.  
This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.**
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.**

### **Compliance Requirements**

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction(WMD) or any other weapon is strictly prohibited.**
- 2. The export of SMC products or technology from one country to another is governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of an SMC product to another country, ensure that all local rules governing that export are known and followed.**

## **Caution**


### **SMC products are not intended for use as instruments for legal metrology.**

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country.

Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

# 1. List of included items


## 1-1. Common included items



### **Air gripper x1**


- Component configuration
- Solenoid valve x2
- Auto switch x2
- Fingers with opening/closing speed adjustment mechanism
- Tube fitting for air supply (applicable tube outer diameter 4)
- M8 Connector (Plug)

## **Optional goods**




### **Main plate ASSY x1**

This is an assembly necessary for installing the air gripper to the robot.



### **Protection cover x3(diameter)**

Attachment of a protective cover prevents exposure of the gripper corners.



### **Connector cable dedicated to robot x1**

This is a cable equipped with a dedicated connector compatible with the robot.

## 1-2. Parts exclusive for each robot manufacturer included in the package


- Parts exclusive for Mitsubishi Electric (identification symbol: 031N, 031P) included in the package.



\* Please use the included one-touch fittings for piping work.

### **Optional parts**

\*Included in the package when E (with the main plate assembly) is selected for the manual changer option.



- Parts exclusive for Yaskawa Electric (identification symbol: 041N, 041P, 042N, 042P) included in the package

**Optional parts**

\* Included in the package when E (with the main plate assembly) is selected for the manual changer option.


		<p><b><u>Bracket ASSY x1</u></b></p> <ul style="list-style-type: none"> <li>-Equipment Configuration</li> <li>-Flange x1</li> <li>-Mounting bolt x4</li> <li>-Positioning pin x1</li> </ul>	
<p>MOTOMAN-HC10</p>	<p>MOTOMAN-HC10DT</p>		
			<p><b><u>Cable Fixture-</u></b></p> <ul style="list-style-type: none"> <li>INSULOK® tie x2</li> <li>INSULOK® tie mount x2</li> <li>Fixing bolt x2</li> <li>Bolt for plug x2</li> </ul>

- Parts exclusive parts for KUKA (Identification symbol: 061P) included in the package

	<p><b><u>One touch fittings x2</u></b> <b><u>(KQ2L04-99A1)</u></b></p>
--	--

\* Please use the included one-touch fittings for piping work.

## 2. How to order



### ○Table of compatible robot list

Symbol	Switch	Robot manufacturer	Supported models	Switch output	Valve polarity	Symbol	Switch	Robot manufacturer	Supported models	Switch output	Valve polarity				
011	P	UNIVERSAL ROBOTS	UR3e	PNP	-COM	081	P	SIASUN	SCR3	PNP	-COM				
			UR5e						SCR5						
			UR10e						GCR3-620						
			UR16e						GCR5-910						
021	N	OMRON TECHMAN ROBOT	TM5	NPN	+COM				GCR10-1300						
			TM12						GCR14-1400						
			TM14						GCR20-1100						
031	N	Mitsubishi Electric	MELFA ASSISTA (RV-5AS-D)	NPN	+COM				091			N	JAKA	JAKA Zu3	NPN
	P			PNP	-COM	JAKA Zu7									
041	N	YASKAWA Electric	MOTOMAN-HC10	NPN	+COM	JAKA Zu12									
	P			PNP	-COM	JAKA Zu3									
042	N			MOTOMAN-HC10DT	NPN	+COM	JAKA Zu7								
	P				PNP	-COM	JAKA Zu12								
043	N		MOTOMAN-HC10(S)DTP	MOTOMAN-HC20(S)DTP	NPN	+COM	101	N		AUBO	AUBO-i3			NPN	+COM
					PNP	-COM					AUBO-i5				
	P			MOTOMAN-HC10(S)DTP	MOTOMAN-HC20(S)DTP	PNP			-COM		AUBO-i10				
051	P	FANUC	CRX-5iA	PNP	-COM	111	P	HAN'S ROBOT	E03	PNP	-COM				
			CRX-10iA(L)						E05						
			CRX-20iA						E10						
			CRX-25iA												
061	P	KUKA	LBR-iiwa (media flange : I/O Pneumatic)	PNP	-COM	121	P	ABB	Swiftly	PNP	-COM				
071	P	Doosan Robotics	H2017	PNP	-COM	*Please contact our nearest sales office for the compatibility with robots not listed in the compatible robot list.									
			H2515												
			M0609												
			M0617												
			M1013												
			M1509												



## 3. Product Specifications

### 3-1. Product Specifications

	Item	Specification	
Common	Installation standard	Compliant with ISO9409-1-50-4-M6 *1)	
	Fluid	Air	
	Operating pressure	0.1 to 0.6 MPa	
	Ambient and operating fluid temperature	-10 to 50 °C *2)	
	Repeatability	±0.01 mm	
	Maximum operating frequency	60 C.P.M.	
	Lubrication	Non-lube	
	Operating method	Double acting	
	Gripping force Actual value per finger (N) *3)	External gripping force	118 N
		Internal Gripping force	130 N
	Opening/ closing stroke (both sides)	8 mm	
	Weight *4)	776 g*4)	
	Connector shape	M8/8 Pin (Plug)	
	Air supply (P) port	One touch fittings (φ4)	
Supply voltage	DC24V±10%*2)		
solenoid valve	Model	V114	
Auto switch	Model	D-M9N/D-M9P	
Exhaust throttle valve	Model	ASN2-M5-X937	

\*1) Robots whose end effector mounting standard differs are equipped with a dedicated mounting flange.( See P5.)

\*2) Only when the compatible robot is KUKA's LBR-iiwa, the power supply voltage is DC24V (-15%/+20%) and the maximum operating temperature is 40°C.

\*3) These are values at the stroke center when the pressure is 0.5 MPa and the gripping point distance L is 30 mm.

\*4) This is the value excluding the weights of the protection cover and connector cable.

### 3-2. Valve Specifications

Items	Specifications
Ambient and fluid temperatures	-10 to 5°C (4°C *1) No freezing
Manual override	Non-locking push, Locking slotted
Mounting position	Unrestricted
Enclosure	Dustproof

\*In case of robot identification code 061

### 3-3. Solenoid Specifications

Items	Specifications
Coil rated voltage	DC24V
Allowable voltage fluctuation	-10 to +10%(-15 to +20% <sup>*1</sup> )
Power consumption	0.4W(0.55W)
Surge voltage suppressor	varistor

\*In case of robot identification code 061



### 3-4. Auto Switch Specifications

Items	Specifications
Output type	NPN / PNP (Depends on the robots.)
Power supply voltage	DC24V
Current consumption	10 mA or less
Load voltage	28 VDC or less (NPN)
Load current	40 mA or less
Internal voltage drop	0.8 V or less at 10 mA (2 V or less at 40 mA)
Leakage current	100 $\mu$ A or less at 24 VDC



### 3-5. Gripping force

Indication of effective gripping force The effective gripping force shown in the graphs to the right is expressed as  $F$ , which is the thrust of one finger when all 3 of the fingers and attachments are in full contact with the workpiece as shown in the figure below.

#### External grip




#### Internal grip




### 3-6. Gripping Point

The workpiece gripping point distance should be within the gripping force ranges given for each pressure in the effective gripping force graphs below. • If operated with the workpiece gripping point beyond the indicated ranges, an excessive offset load will be applied to the sliding section of the fingers, which can have an adverse effect on the service life of the product.


#### External grip



#### Internal grip



### 3-7. Names and function of product parts



Name	Function
Solenoid valve (1)	Control of opening/closing actions of finger
Solenoid valve (2)	Control of opening/closing actions of finger
Auto switch (1)	Detection of closing action of finger
Auto switch (2)	Detection of opening action of finger
Exhaust throttle valve with silencer (1)	Speed control of opening action of finger
Exhaust throttle valve with silencer (2)	Speed control of closing action of finger


#### ■ Valve ON / OFF state and gripper action

Energization state of valve		Gripper action		
Solenoid valve (1)	Solenoid valve (2)	Basic type	Normal open	Normal close
OFF	OFF	No pressure applied*1	Finger opening	Finger closing
ON	OFF	Finger opening	No pressure applied*1	Pressure applied to both sides*2
OFF	ON	Finger closing	Pressure applied to both sides*2	No pressure applied*1
ON	ON	Pressure applied to both sides*2	Finger closing	Finger opening


\*1 When no pressure is applied, air is not supplied to the cylinders on both the open and close sides. The gripping force becomes zero, and the fingers can be moved by hand.

\*2 When pressure is applied to both sides, air is supplied to the cylinders on both the open and close sides. Due to the characteristics of the construction of internal parts, a small force is generated in the opening direction.

■ Pneumatic circuit diagram



**3-8.Connector and pin layout**



■ Pin layout

Symbol	Company name	PIN No.	Function
011P 043N 043P 051P 081P 121P	UNIVERSAL ROBOTS YASKAWA Electric DTP"Series FANUC SIASUN ABB	1	-
		2	-
		3	Auto switch (Finger closing direction)
		4	Auto switch (Finger opening direction)
		5	+24V
		6	Valve (2) ON/OFF
		7	Valve (1) ON/OFF
		8	GND
021N	OMRON TECHMAN ROBOT	1	+24V
		2	Auto switch (Finger opening direction)
		3	Auto switch (Finger closing direction)
		4	-
		5	Valve (1)ON/OFF
		6	Valve (2)ON/OFF
		7	-
		8	GND


Symbol	Company name	PIN No.	Function
<b>031N</b> <b>031P</b>	Mitsubishi Electric	1	GND
		2	+24V
		3	Valve (1) ON/OFF
		4	Valve (2) ON/OFF
		5	-
		6	-
		7	Auto switch (Finger closing direction)
		8	Auto switch (Finger opening direction)
<b>041N</b> <b>041P</b> <b>042N</b> <b>042P</b> <b>111P</b>	YASKAWA Electric HAN'S ROBOT	1	+24V
		2	GND
		3	Valve (1) ON/OFF
		4	Valve (2) ON/OFF
		5	Auto switch (Finger opening direction)
		6	Auto switch (Finger closing direction)
		7	-
		8	-
<b>061P</b>	KUKA	1	+24V
		2	-
		3	Auto switch (Finger opening direction)
		4	Auto switch (Finger closing direction)
		5	Valve (1) ON/OFF
		6	Valve (2) ON/OFF
		7	-
		8	GND
<b>071P</b>	Doosan Robotics	1	Auto switch (Finger opening direction)
		2	Valve (1) ON/OFF
		3	Valve (2) ON/OFF
		4	-
		5	+24V
		6	-
		7	Auto switch (Finger closing direction)
		8	GND
<b>091N</b> <b>091P</b>	JAKA	1	+24V
		2	Auto switch (Finger opening direction)
		3	Auto switch (Finger closing direction)
		4	Valve (1) ON/OFF
		5	Valve (2) ON/OFF
		6	-
		7	-
		8	GND
<b>101N</b>	AUBO	1	GND
		2	+24V
		3	Auto switch (Finger opening direction)
		4	Auto switch (Finger closing direction)
		5	Valve (1) ON/OFF
		6	-
		7	Valve (2) ON/OFF
		8	-

### 3-9. Internal circuit diagram

Symbol	011P	Company name	UNIVERSAL ROBOTS	Symbol	021N	Company name	OMRON TECHMAN ROBOT
Switch output	PNP	Valve	-COM	Switch output	NPN	Valve	+COM
Symbol	031N	Company name	Mitsubishi Electric	Symbol	031P	Company name	Mitsubishi Electric
Switch output	NPN	Valve	+COM	Switch output	PNP	Valve	-COM
Symbol	041N,042N	Company name	YASKAWA Electric	Symbol	041P,042P	Company name	YASKAWA Electric
Switch output	NPN	Valve	+COM	Switch output	PNP	Valve	-COM
Symbol	043N	Company name	YASKAWA Electric	Symbol	043P	Company name	YASKAWA Electric
Switch output	NPN	Valve	+COM	Switch output	PNP	Valve	-COM

Symbol	051P	Company name	FANUC	Symbol	061P	Company name	KUKA
Switch output	PNP	Valve	-COM	Switch output	PNP	Valve	-COM
Symbol	071P	Company name	Doosan Robotics	Symbol	081P	Company name	SIASUN
Switch output	PNP	Valve	-COM	Switch output	PNP	Valve	-COM
Symbol	091N	Company name	JAKA	Symbol	091P	Company name	JAKA
Switch output	NPN	Valve	+COM	Switch output	PNP	Valve	-COM
Symbol	101N	Company name	AUBO	Symbol	111P	Company name	HAN'S ROBOT
Switch output	NPN	Valve	+COM	Switch output	PNP	Valve	-COM





## 4. Installation


### Warning

1. Install and operate the product only after reading the Operation Manual carefully and understanding its contents. Also, keep the manual where it can be referred to as necessary.
2. When installing the products, allow access for maintenance.
3. Do not scratch or dent the air gripper by dropping or bumping it when mounting.  
Slight deformation can cause inaccuracies or a malfunction.
4. Tighten the screw within the specified torque range when mounting the attachment.  
Tightening with a torque above the limit can cause malfunction, while insufficient tightening can cause slippage and dropping.
5. When mounting the gripper, tighten the screws to the appropriate torque within the limiting range.  
Tightening with a torque above the range may cause malfunction, while insufficient tightening may cause slippage and dropping.

### 4-1. Installation


#### ■ Mounting product

- 1) Insert parallel pins to the pin holes of the robot tool flange.
- 2) Insert the parallel pins by aligning them with the long holes of the main plate ASSY, and mount the main plate onto the robot with the supplied hexagon thin socket head bolts. (Tightening torque:  $5.2 \pm 0.5 \text{ N}\cdot\text{m}$ )
- 3) Confirm that the clamber bolts on the main plate ASSY are loosened, and align the clammers with the flange grooves on the air gripper side.
- 4) Tighten the clamber bolts to mount the air gripper. (Tightening torque:  $3.0 \pm 0.3 \text{ N}\cdot\text{m}$ )




- Installation of dedicated flange (identification symbol: 031N, 031P, 041N, 041P, 042N, 042P)  
Before mounting the main plate ASSY, mount the dedicated flange.

- Flange dedicated to Mitsubishi Electric




- Flange dedicated to YASKAWA Electric  
\*Figure by MOTOMAN-HC10DT



- How to mount attachment


When attaching or detaching the finger attachment, use the tightening torque shown in the table below.



Bolt	Max. tightening torque
M4x0.7	1.5±0.15 N·m

■ How to mount protection cover

When attaching or detaching a protective cover, use the tightening torque shown in the table below.




Bolt	Max.tightening torque
M3x0.5	0.63±0.06 N·m

**4-2. Wiring**

Connect a cable between the air gripper connector and the connector on the tool flange. For the connector pin layout and internal circuit, refer to “3-5 Connector pin layout” and “3-6 Internal circuit diagram.”


- \* Do not energize the product while securing the connector.
- \* Secure the connector so that it does not become loose.



**4-3. Piping**


■ Tubing

Connect a tube (applicable tube O.D. φ4) to the air supply port. To remove the tube, pull out the tube while pushing the release button.




#### 4-4. Finger open / close speed adjustment

- \*For adjustment of the opening of the exhaust restrictor, use a flat blade screwdriver.
- \*Adjust the openings of two exhaust restrictors to approximately the same level. If they are extremely different from each other, the operation may become unstable.




# 5. Dimensions

## 5-1. Air gripper




## 5-2. Protection cover

When the protective cover is mounted, the following dimensions change from when the cover is not mounted.



### 5-3. Valve option


When a valve option (normally open or normally closed) is selected, a piping plate that switches the valve flow path is included with the valve.




## 5-4. Dedicated flange

\* The air grippers for Mitsubishi Electric and YASKAWA Electric (identification symbol: 031N, 031P, 041N, 041P, 042N, 042P) come with dedicated flanges (including mounting bolts).


### ■ Flange for ASSISTA from Mitsubishi Electric



### ■ Flange for MOTOMAN-HC10 from YASKAWA Electric




### ■ Flange for MOTOMAN-HC10DT from YASKAWA Electric





## 5-5. Position of the center of gravity and TCP

TCP (tool center point) indicates the coordinates of the tip of the finger. Change the value of TCP when a finger attachment is installed in accordance with the finger attachment in use.



	X	Y	Z
Center of gravity[mm]	0.53	-1.26	53.17
TCP[mm]	0	0	104

## 6. Maintenance

### 6-1. Precautions

#### Warning

1. Perform maintenance or inspection in accordance with the procedures indicated in the operation manual.

If handled improperly, malfunction and damage of machinery or equipment may occur.

2. If handled improperly, compressed air can be dangerous. The assembly, handling, repair and element replacement of pneumatic systems should be performed by a knowledgeable and experienced person.

3. Drain air grippers, etc. on a regular basis.

4. When air grippers are removed, first confirm that measures are in place to prevent any workpieces from dropping, run-away of equipment, etc. Then cut off the supply pressure and electric power and exhaust all compressed air from the system using the residual pressure release function.

When the equipment is restarted, proceed with caution after confirming that appropriate measures are in place to prevent cylinders from sudden movement.

5. Do not allow people to enter or place objects in the carrying path of the air gripper.

Otherwise, injury or an accident may occur.

6. Do not put hands, etc. in between the air gripper fingers or attachments.


Otherwise, injury or an accident may occur.

7. When removing the air gripper, first confirm that no workpieces are being held and then release the compressed air before removing the air gripper.

If a workpiece is still being held, there is a danger of it being dropped.

## 6-2. Exploded view

\* Cables are omitted from the diagram.



## 6-3. Replacement Parts

### ■ Table of product numbers of replacement parts

Part Name		Order number	Parts included	
Gripper ASSY		RMH-A26-01	Air gripper	
Protection cover ASSY		RMH-A26-08	Protection cover, Mounting Bolt	
Dedicated flange	Mitsubishi Electric 031N,031P	JMHZ-A16-X7400-BRK-01	Dedicated flange Mounting Bolt	
	YASKAWA Electric 041N,041P	JMHZ-A16-X7400-BRK-02	Dedicated flange Mounting Bolt	
	YASKAWA Electric 042N,042P	JMHZ-A16-X7400-BRK-03	Cable fixtures	
Auto switch ASSY <sup>*1</sup>	PNP	RMH-A00-05P	Auto switch ASSY	
	NPN	RMH-A00-05P		
3 port solenoid valve	Normal open <sup>*2</sup>		V124-5MOU	
	Normal close		V114-5MOU	
	KUKA 061P	Normal open <sup>*2,3</sup>	V114-5MOU-X647	3 port solenoid valve Mounting Bolt
		Normal close <sup>*3</sup>	V124-5MOU-X647	
Main plate ASSY	Other than the following		RMH-A00-09-A	
	Symbol 071P,081P,101N		RMH-A00-09-B	
	Symbol 091N,091P,121P		RMH-A00-09-C	
Piping plate ASSY <sup>*2</sup>		RMH-A00-06	Piping plate, Mounting Bolt, Gasket	
One touch fittings		KQ2S04-M5N		
Exhaust throttle valve silencer		ASN2-M5-X937		


\*1 An auto switch ASSY is an assembly part in which two auto switches are integrated into one part. When replacing an auto switch, replacement is conducted in units of auto switch ASSY. (An individual auto switch cannot be replaced.)

\*2 When installing a normally-open valve, a piping plate ASSY is necessary.

\*3 When KUKA is used, a 3-port solenoid valve is available as a special order.

### ■ Bolts and positioning pins for main plate ASSY mounting

Bolts and positioning pins for main plate ASSY are included with the main plate ASSY, but can be ordered in quantities of 1 or more by the part numbers listed below.




### Dimensions

Part No.	Part name	A	$\phi B$	C	$\phi D$
RMH-A00-14	Hexagon thin socket head bolt	10	10	—	—
RMH-A00-15		8	10	—	—
RMH-A00-16	Positioning pin	—	—	10	6h8
RMH-A00-17		—	—	15	6h8

Main plate ASSY Compatible robot

Supported robots	Hexagon thin socket head bolt		Positioning pin	
	Part No.	pcs	Part No.	pcs
011	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
021	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
031	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
041	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
042	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
043	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
051	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
061	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
071	RMH-A00-15	Four/Unit	RMH-A00-16	One/Unit
081	RMH-A00-15	Four/Unit	RMH-A00-16	One/Unit
091	RMH-A00-14	Four/Unit	RMH-A00-17	One/Unit
101	RMH-A00-15	Four/Unit	RMH-A00-16	One/Unit
111	RMH-A00-14	Four/Unit	RMH-A00-16	One/Unit
121	RMH-A00-14	Four/Unit	RMH-A00-17	One/Unit

■ Connector cable



Symbol	Robot manufacturer	A Air gripper side	B Robot side	Part No.
011P	UNIVERSAL ROBOTS	M8 8 Pin connector (Socket)	M8 8 Pin connector (Socket)	RMH-A00-11-A
021N	OMRON TECHMAN ROBOT		M8 8 Pin connector (Plug)	RMH-A00-11-B
031N 031P	Mitsubishi Electric		M12 8 Pin connector (Plug)	RMH-A00-11-C
041N 041P 042N 042P 043N 043P	YASKAWA Electric		Made by MOLEX 51227-0800	MH-7400-ADP-D-01
051P	FANUC		M8 8 Pin connector (Socket)	RMH-A00-11-A
061P	KUKA		M8 8 Pin connector (Plug)	RMH-A00-11-B
071P	Doosan Robotics		M8 8 Pin connector (Socket)	RMH-A00-11-B
081P	SIASUN		M8 8 Pin connector (Socket)	RMH-A00-11-A
091N 091P	JAKA		M8 8 Pin connector (Plug)	RMH-A00-11-B
101N	AUBO		M8 8 Pin connector (Socket)	RMH-A00-11-A
111P	HAN'S ROBOT		M12 12 Pin connector (Plug)	RMH-A00-11-D
121P	ABB		M8 3 Pin, M8 4 Pin connector (Plug)	RMH-A00-11-E


## 6-4. Procedures for replacing parts

■ Procedures for replacing gripper ASSY

- 1) Loosen the screws of the auto switch.
- 2) Loosen the hexagon socket head cap screws (M5x40) and remove the gripper assembly from the flange.
- 3) Replace the gripper and mount the dismantled parts by following the above steps in the reverse order.

\* Precaution

- ① When disassembling the product, take care not to lose the positioning pin and O-ring.
- ② **The lengths of the cables of two auto switches are different from each other.** When installing the auto switches, fix them in the orientation shown in Step 2) of the figure below.



■ Procedures for replacing auto switch ASSY

- 1) Follow the same steps as Step 1) and Step 2) in “Procedures for replacing gripper ASSY.”
- 2) Loosen the hexagon socket head cap screws (M4x8) and remove the flange.
- 3) Loosen the hexagon socket head cap screws (M4x8) and remove the tool plate.
- 4) Take the auto switches out from the tool plate side to the extent that the connector of the substrate in the module base is visible.
- 5) Replace the auto switch ASSY by disconnecting the connector and mount the dismantled parts by following the above steps in the reverse order.

\* Precaution

- When disassembling the product, take care not to lose the positioning pin and O-ring.

	Step2)	Step3)
Image	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">                     Hexagon socket head cap screw (M4x8) width across flats 3                      tightening torque : <math>1.5 \pm 0.15 \text{ N} \cdot \text{m}</math> </div>	<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">                     Hexagon socket head cap screw (M4x8) width across flats 3                      tightening torque : <math>1.5 \pm 0.15 \text{ N} \cdot \text{m}</math> </div>
Image	<div style="text-align: center;">Step4)</div>	







■ Procedures for replacing solenoid valve (valve option: basic type)

- 1) Loosen the cross recessed head machine screw (M2X5) and take the solenoid valve out.
- 2) Remove the connector and replace the valve. (The product number of the replacement valve is **V114-5MOU**)

\* Precaution

- ① A gasket is mounted on the solenoid valve. Take care not to lose the gasket or have dirt attach on it at the time of replacement.
- ② Refer to Precaution 2 and mount the solenoid valve while placing the cable with a marking to be below the other cable.

	Step1)	Step2)
Image	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">                     Cross recessed round head Screw(M2x5) Tightening torque: 0.1±0.01 N·m                 </div> 	
Image		 <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-top: 10px;">                     Mount the solenoid valve while placing the cable with a marking below the other cable.                 </div>


■ Solenoid valve replacement procedure (valve option: normally open, normally closed)  
 In the normally open or normally closed version, a piping plate is assembled between the valve on one side and the module base. The valve on the side with the piping plate should be replaced with V124-5MOU and the valve on the other side with V114-5MOU. The replacement procedure is the same as for the basic type.

■ Procedures for replacing solenoid valve (valve option: when replacing basic type with normally open type or normally close type)

- 1) Remove the valve by following the same procedures as those for basic type.
- 2) Install the O-ring on the piping plate.
- 3) Mount the connector to the valve, and install the valve on top of the piping plate.

\* Precaution

- ① When installing the gasket on the piping plate, pay attention not to have dirt attach to it.
- ② Refer to p. 32, (Precaution 2) and mount the solenoid valve while placing the cable with a marking be below the other cable.



● Combination of valve option and valve product number

	Solenoid valve(1)	Solenoid valve(2)
<b>Basic form</b>	V114-5MOU	V114-5MOU
<b>Normal open</b>	V124-5MOU+Piping plate ASSY	V114-5MOU
<b>Normal close</b>	V114-5MOU	V124-5MOU+Piping plate ASSY

\*In the case of identification code 061, the valve part numbers will be changed to V114-5MOU-X647 and V124-5MOU-X647, respectively.

## 7. Precautions for use

### 7-1. Precautions for Design

#### Warning

1. The product is designed for use only in compressed air systems. Do not operate at pressures or temperatures, etc., beyond the range of the specifications, as this can cause damage or malfunction of the cylinder and other equipment. (Refer to the specifications.)  
Please contact SMC if using fluids other than compressed air. The product cannot be guaranteed if is used outside of the specification range.
2. Take safety measures (e.g. mounting protective covers) when there is a danger of fingers being caught in a gripper or workpieces causing damage, etc.
3. There is a danger of workpieces dropping if there is a decrease in gripping force due to a drop in circuit pressure caused by a power failure, etc. It is necessary to take measures such as drop prevention so that injury and damage to machinery or equipment can be prevented.
4. If the product is used for a purpose other than the transportation of a workpiece such as positioning or clamping, please consult SMC.

#### Caution

1. Finite orbit type guide is used in the actuator finger part. By using this, when there are inertial force which cause by movements or rotation to the actuator, steel ball will move to one side and this will cause a large resistance degrade the accuracy. When there are inertial force which cause by movements or rotation to the actuator, operate the finger to full stroke.

### 7-2. Air supply

#### Warning

1. Please contact SMC when using the product in applications other than with compressed air.
2. Compressed air containing a large amount of drainage can cause the malfunction of pneumatic equipment. An air dryer or water separator should be installed upstream from filters.
3. If condensation in the drain bowl is not emptied on a regular basis, the bowl will overflow and allow the condensation to enter the compressed air lines. This causes the malfunction of pneumatic equipment. If the drain bowl is difficult to check and remove, the installation of a drain bowl with an auto drain option is recommended.
4. Use clean air.  
Do not use compressed air that contains chemicals, synthetic oils including organic solvents, salt or corrosive gases, etc., as it can cause damage or malfunction of equipment.  
For detailed information regarding the quality of the compressed air described above, refer to SMC's "Air Cleaning Systems".

#### Caution

1. When dry air is used as the fluid, degradation of the lubrication properties inside the equipment may occur, resulting in reduced reliability (or reduced service life) of the equipment. Please consult with SMC.
2. Install air filters.  
Install an air filter at the upstream side of valve. Select an air filter with a filtration degree of 5µm or finer.
3. Install an aftercooler, air dryer or drain catch before the filter and take appropriate measures.  
Compressed air that contains excessive foreign material may cause malfunction of valves and other pneumatic equipment.  
Therefore, take appropriate measures to ensure air quality, such as by providing an aftercooler, air dryer or water separator.
4. Use the product within the specified fluid and ambient temperature range.  
If the fluid temperature is 5°C or Cable at the bottom, the moisture in the circuit could freeze, causing damage to the seals and leading to equipment malfunction. Therefore, take appropriate measures to prevent freezing.

For detailed information regarding the quality of the compressed air described above, refer to SMC's "Air Cleaning Systems".

### 7-3. Piping

#### Caution

1. Refer to the Fittings and Tubing Precautions (Best Pneumatics) for handling one touch fittings.
2. Before piping  
Before piping, blow air (flush) or clean the piping to remove any cutting chips, cutting oil, dust, etc.

### 7-4. Operating environment

#### Warning

- 1) Do not use in an atmosphere where corrosive gases, chemicals, sea water, water or water steam is present.
2. Do not expose the product to direct sunlight for an extended period of time.
3. **Do not operate in a location subject to vibration or impact.**
4. Do not mount the product in locations where it is exposed to radiant heat.
5. Do not use this product in an area that is dusty, or in an environment in which water or oil splashes on to the cylinder.

#### Caution

1. Martensitic stainless steel is used for the finger guide rail, so make sure that anti-corrosiveness is inferior to the austenitic stainless steel. Especially rust may be generated in environments that allow water drops from condensation to stay on the surface.

### 7-5. Lubrication

#### Caution

1. The non-lube type air gripper is lubricated at the factory, and can be used without any further lubrication.

If a lubricant is used in the system, use turbine oil Class 1 (with no additive) ISO VG32.

Furthermore, once lubrication is applied, it must be continued.

If lubrication is later stopped, malfunction can occur due to loss of the original lubricant.

Refer to the Material Safety Data Sheet (MSDS) of the hydraulic fluid when supplying the fluid.

Revision history
------------------

## SMC Corporation

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021 JAPAN

Tel: + 81 3 5207 8249 Fax: +81 3 5298 5362

URL <https://www.smcworld.com>

---

Note: Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.  
© 2023 SMC Corporation All Rights Reserved