# Vacuum Filter

# **Prevents vacuum equipment trouble**

Nominal filtration rating 5, 40, 80 µm

Large flow capacity

\* Large flow type ( $\Delta P = at 4 kPa$ )

Dust

# 2 types are available for different applications.

## Large flow type Dust



Air coming from the IN side is filtered by the element after passing through the deflector.





Water drop removal type Water drop

Air coming from the IN side is rotated when passing through the fans in the deflector. Moisture is separated by centrifugal force.

Foreign matter

AFJ40-04-40-T-D WORKING PRESS. -100 - 0 kPm

Water drop


## Elements can be reused by washing them.

\* For 40 µm and 80 µm

# Water drops can be removed.\*1

- \*1 Water drop removal ratio: 80%. At recommended flow rate (representative values).
- \*1 For water drop removal type










New (RoHS)









done in hand.

Vacuum Filter AFJ20-D to AFJ40-D									
Symbol Vacuum filte	er		How to Order	AFJ20-D	AFJ30-D	AFJ40-D			
AFJ		B-80 4 5		Option and Semi-s · Select one each for a · When more than of indicate in alphanum Example) AFJ30-F03E	to <b>c</b> . one specificationeric order.				
		Symbol	Description		Bod	<b>D</b> ly size 30 40			
2	Pipe thread type	— N F	Rc NPT G		• • •	• • • • • •			
8	Port size	+ 01 02 03 04	1/8 1/4 3/8 1/2		_	 0 0 - 0			
4	Bracket	+  B*1	None With bracket	•	• • • •				
<b>(</b> ) No	ominal filtration degree	+ 5 40 80	5 μm 40 μm 80 μm	• • •	• • • • • •				
+ S Type T + + + +			Water drop removal type Large flow type			• • • •			
lard	a Bowl *2	+  6 +	Polycarbonate bowl Nylon bowl	•	• • • •				
Semi-standard	b Flow direction		Flow direction: Left to right Flow direction: Right to left	t	•				
	c Pressure unit	— <b>Z</b> *3	Unit on product label: kPa, ° Unit on product label: psi, °	Unit on product label: kPa, °C					

\*1 Option B is not assembled and supplied loose at the time of shipment. The assembly consists of 2 types of the bracket and 2 mounting screws.
\*2 Refer to Chemical data on page 6 for chemical resistance of the bowl.
\*3 For pipe thread type NPT.
\*4 O: For pipe thread type NPT only

# AFJ20-D to AFJ40-D Series

#### **Standard Specifications**

	AFJ	20-D	AFJ	30-D	AFJ40-D					
Port size			1/8	1/4	1/4	3/8	1/4	3/8	1/2	
Fluid	Air									
Ambient and fluid	–5 to 60 °C (No freezing)									
Proof pressure			0.5 MPa							
Operating pressu	–100 to 0 kPa									
Vacuum release p	0.5 MPa or less									
Nominal filtration	5 μm, 40 μm, 80 μm									
Drain capacity			8 0	cm <sup>3</sup>	25 (	cm <sup>3</sup>	45 cm <sup>3</sup>			
Bowl material			Polycarbonate							
Bowl guard			-	<ul> <li>Standard (Polycarbonate)</li> </ul>						
	Water drop removal type (-S)	<b>5</b> μ <b>m</b>	80	100	180	230	200	310	370	
		<b>40</b> μ <b>m</b>	100	130	210	340	230	390	500	
Recommended flow rate *5		<b>80</b> µm	100	130	210	340	230	390	500	
[l/min (ANR)]	Large flow type (-T)	<b>5</b> μ <b>m</b>	100	140	190	250	210	350	440	
		<b>40</b> μ <b>m</b>	120	180	230	380	250	480	660	
	( ')	<b>80</b> μ <b>m</b>	<b>80</b> μ <b>m</b> 120		230	300		400	000	
Weight [kg]	Weight [kg]			9 kg	0.17	7 kg	0.35 kg			

\*1 5  $\mu m$  elements use fiber type element which filtrate 5  $\mu m.$ 

\*2 The element for 40  $\mu m$  uses a resin mesh with openings of 40  $\mu m$  in height and width.

\*3 The element for 80  $\mu m$  uses a resin mesh with openings of 80  $\mu m$  in height and width.


\*4 The size of solid particles collectable by the element 40 μm (80 μm) shall be 40 μm (80 μm) or more in depth x height x width.

\*5 The amount of processed air when the initial pressure loss is 4 kPa.

#### Flow Rate Characteristics (Representative values)

Flow rate [l/min (ANR)]

**SMC** 





Flow rate [l/min (ANR)]

# AFJ20-D to AFJ40-D Series


#### **Dimensions**


### AFJ20-D





#### AFJ30-D, AFJ40-D






Model	Standard specifications							Optional specifications Bracket mount								
	Р	Α	В	С	D	E	G	J	М	Ν	Q	R	S	Т	U	۷
AFJ20-D	1/8, 1/4	40	79.3	17.5	21	_	25	21	30	27	22	5.4	8.4	60	2.3	28
AFJ30-D	1/4, 3/8	53	104.3	21.5	26.5	30	35	26.5	41	35	25	6.5	13	71	2.3	32
AFJ40-D	1/4, 3/8, 1/2	70	136.1	25.5	35.5	38.4	40	35.5	50	52	30	8.5	12.5	88	2.3	39



#### **Bracket Assembly**



# **M** Warning

1. The standard bowl for the vacuum filter is made of polycarbonate. Do not use in an environment where they are exposed to or come in contact with organic solvents, chemicals, cutting oil, synthetic oil, alkali, and thread lock solutions.

Material Туре Chemical name Application examples Polycar-Nylon bonate Hydrochloric acid Acid washing Acid Sulfuric acid, Phosphoric acid Δ × liquid for metals Chromic acid Sodium hydroxide (Caustic soda) Degreasing of metals Potash Industrial salts Alkaline Calcium hydroxide (Slack lime) × 0 Water-soluble Ammonia water cutting oil Carbonate of soda Sodium sulfide Inorganic Sulfate of potash ×  $\triangle$ salts Sulfate of soda Carbon tetrachloride Cleansing liquid for metals Chlorine Chloroform Printing ink х Δ solvents Ethylene chloride Dilution Methylene chloride Benzene Coatings Aromatic Toluene x Δ series Dry cleaning Paint thinner  $\bigcirc$ : Essentially safe  $\triangle$ : Some effects may occur. X: Effects will occur.

Chemical resistance of polycarbonate or nylon bowl

			Material				
Туре	Chemical name	Application examples	Polycar- bonate	Nylon			
Ketone	Acetone	Photographic film Dry cleaning	×	×			
Relone	Methyl ethyl ketone Cyclohexane	Textile industries	^	~			
Alcohol	Ethyl alcohol IPA Methyl alcohol	Antifreeze Adhesives	Δ	×			
Oil	Gasoline Kerosene	-	×	0			
Ester	Phthalic acid dimethyl Phthalic acid diethyl Acetic acid	Synthetic oil Anti-rust additives	×	0			
Ether	Methyl ether Ethyl ether	Brake oil additives	×	0			
Amino	Methyl amino	Cutting oil Brake oil additives Rubber accelerator	×	×			
Others	Thread-lock fluid Sea water Leak tester	-	×	Δ			
$\bigcirc$ : Essentially safe $\triangle$ : Some effects may occur. X: Effects will occur.							

2. Oil included in air cannot be separated.



$\underline{\mathbb{N}}$	Safety I	nstructions	These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of				
				or <b>"Danger."</b> They are all important notes for safety and must be nternational Standards (ISO/IEC) <sup>1)</sup> , and other safety regulations.			
Ŵ	Danger:	<b>Danger</b> indicates a hazard wit which, if not avoided, will result injury.	0	<ol> <li>ISO 4414: Pneumatic fluid power – General rules and safety requirements for systems and their components.</li> <li>ISO 4413: Hydraulic fluid power – General rules and safety requirements for systems and their components.</li> </ol>			
À	Warning:	<b>Warning</b> indicates a hazard w which, if not avoided, could read injury.		<ul> <li>IEC 60204-1: Safety of machinery – Electrical equipment of machinery – Electrical equipment of machinery (Part 1: General requirements)</li> <li>ISO 10218-1: Robots and robotic devices - Safety requirements for industrial robots - Part 1: Robots.</li> </ul>			
$\triangle$	Caution:	<b>Caution</b> indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.		etc.			

## ▲ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

#### 2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
  - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
  - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
  - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- Our products cannot be used beyond their specifications. Our products are not developed, designed, and manufactured to be used under the following conditions or environments. Use under such conditions or environments is not covered.
  - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
  - 2. Use for nuclear power, railways, aviation, space equipment, ships, vehicles, military application, equipment affecting human life, body, and property, fuel equipment, entertainment equipment, emergency shut-off circuits, press clutches, brake circuits, safety equipment, etc., and use for applications that do not conform to standard specifications such as catalogues and operation manuals.
  - Use for interlock circuits, except for use with double interlock such as installing a mechanical protection function in case of failure. Please periodically inspect the product to confirm that the product is operating properly.

## ▲ Caution

We develop, design, and manufacture our products to be used for automatic control equipment, and provide them for peaceful use in manufacturing industries. Use in non-manufacturing industries is not covered.

Products we manufacture and sell cannot be used for the purpose of transactions or certification specified in the Measurement Act.

The new Measurement Act prohibits use of any unit other than SI units in Japan.

### Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".Read and accept them before using the product.

#### Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first. <sup>2)</sup> Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
- 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

#### **Compliance Requirements**

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

#### **SMC Corporation (Europe)**

Austria Belgium Bulgaria +359 (0)2807670 Croatia Czech Republic +420 541424611 www.smc.cz Denmark +45 70252900 Estonia +372 651 0370 Finland +358 207513513 France Germany +49 (0)61034020 Greece +30 210 2717265 Hungary +36 23513000 Ireland Italv +39 03990691 Latvia +371 67817700

+43 (0)2262622800 www.smc.at +32 (0)33551464 www.smc.be www.smc.bg +385 (0)13707288 www.smc.hr www.smcdk.com www.smcee.ee www.smc.fi +33 (0)164761000 www.smc-france.fr www.smc.de www.smchellas.gr www.smc.hu www.smcitalia.it www.smc.lv

office@smc.at info@smc.be office@smc.bg office@smc.hr office@smc.cz smc@smcdk.com info@smcee.ee smcfi@smc.fi supportclient@smc-france.fr info@smc.de sales@smchellas.gr office@smc.hu +353 (0)14039000 www.smcautomation.ie sales@smcautomation.ie mailbox@smcitalia.it info@smc.lv

Lithuania +370 5 2308118 Netherlands +31 (0)205318888 Norway +47 67129020 +48 222119600 Poland +351 214724500 Portugal Romania +40 213205111 Russia +7 (812)3036600 Slovakia +421 (0)413213212 www.smc.sk +386 (0)73885412 Slovenia Spain +34 945184100 Sweden +46 (0)86031240 Switzerland +41 (0)523963131 Turkey UК +44 (0)845 121 5122 www.smc.uk

www.smclt.lt www.smc.nl www.smc-norge.no www.smc.pl www.smc.eu www.smcromania.ro www.smc.eu www.smc.si www.smc.eu www.smc.nu www.smc.ch +90 212 489 0 440 www.smcturkey.com.tr

info@smclt.lt info@smc.nl post@smc-norge.no sales@smc.pl apoioclientept@smc.smces.es smcromania@smcromania.ro sales@smcru.com office@smc.sk office@smc.si post@smc.smces.es smc@smc.nu info@smc.ch info@smcturkey.com.tr sales@smc.uk

South Africa +27 10 900 1233 www.smcza.co.za zasales@smcza.co.za