

Pin Cylinder: Single Acting, Spring Return

New

RoHS


Ø 4, Ø 6, Ø 10, Ø 16

A short-stroke miniature cylinder with a shorter overall length

The installation space can be significantly reduced because this cylinder can be recessed directly into a machine or installed on a panel. Thus, the machine can be made more compact.



Application Examples



Rod end cap can now be ordered with the cylinder.

It is not necessary to order a rod end cap for the applicable cylinder separately.


Example **CJPS16-15Z-T**

Rod end cap

| | | Without cap |
|---|--------------------------|-------------|
| T | Rod end cap (Flat type) | |
| U | Rod end cap (Round type) | |

One-touch fitting can be connected. (Panel mount type)

Ø 2 One-touch fitting, miniature fitting, and speed controller can be connected.



Applicable for the change of the rod end shape (-XA□)

(Simple Specials) 18 p. 6

CJP Series

16 mm bore size is now available.

(Changed from the existing product: 15 mm)

Specifications and dimensions are the same as the existing product.



CAT.EUS20-265A-UK

Pin Cylinder: Single Acting, Spring Return

CJP Series

Ø 4, Ø 6, Ø 10, Ø 16



How to Order

Embedded type

Panel mount type

CJP B 16 - 15 H4 Z - T -

Pin cylinder

Mounting

| | |
|----------|------------------|
| B | Panel mount type |
| S | Embedded type |

Panel mount type **Embedded type**

Bore size

| | |
|-----------|-------|
| 4 | 4 mm |
| 6 | 6 mm |
| 10 | 10 mm |
| 16 | 16 mm |

Standard stroke [mm]

| | |
|----------------------|-----------|
| Ø 4, Ø 6, Ø 10, Ø 16 | 5, 10, 15 |
|----------------------|-----------|

Made to order (Ø 6 to Ø 16)
* For details, refer to the table below.

Rod end cap

| | Without cap | |
|----------|--------------------------|--------------------------|
| T | Rod end cap (Flat type) | Rod end cap (Flat type) |
| U | Rod end cap (Round type) | Rod end cap (Round type) |

* Rod end cap is included in the same package. Use the rod end nut of the standard cylinder to tighten the rod end cap.
* Applicable for rod end with thread type

Rod end thread

| | |
|----------|----------------|
| — | With thread |
| B | Without thread |


Hose nipple
(Hose nipple is not attached to the embedded type.)

| | |
|-----------|----------------------|
| — | Without hose nipple |
| H4 | For Ø 4/Ø 2.5 tubing |
| H6 | For Ø 6/Ø 4 tubing |

* For details, refer to page 8.

Symbol

Single acting, Spring return



Made to Order (Ø 6 to Ø 16)
(For details, refer to pages 6 and 7.)

| Symbol | Specifications |
|-------------|--------------------------------|
| XA □ | Change of rod end shape |
| XC17 | Pin cylinder with rod quenched |
| XC22 | Fluororubber seals |

Moisture Control Tube IDK Series



When operating an actuator with a small diameter and a short stroke at a high frequency, dew condensation (water droplets) may occur inside the piping depending on the conditions. Simply connecting the moisture control tube to the actuator will prevent dew condensation from occurring. For details, refer to the **Catalogue** on <https://www.smc.eu>.

Specifications

| | | | |
|---------------------------------------|---------------------------|---------------------------------------|---|
| Action | | Single acting, Spring return | |
| Maximum operating pressure | | 0.7 MPa | |
| Minimum operating pressure | Ø 4 | 0.3 MPa | |
| | Ø 6 | 0.2 MPa | |
| | Ø 10, Ø 16 | 0.15 MPa | |
| Proof pressure | | 1 MPa | |
| Ambient and fluid temperatures | | -10 to 70 °C (No freezing) | |
| Lubrication | | Not required (Non-lube) | |
| Piston speed | | 50 to 500 mm/s | |
| Cushion | | None | |
| Stroke length tolerance | | +1.0 0 | |
| Rod end type | | With thread/Without thread | |
| Mounting | | Panel mount type | Embedded type |
| Accessory (Standard equipment) | Standard equipment | Mounting nut (2) Rod end nut (2)*1 | Mounting nut (1) Gasket (1) Rod end nut (2)*1 |
| | Option | Hose nipple (Excludes Ø 4) | — |

*1 When rod end is threaded

* For details about the hose nipple (accessory), refer to page 8.

Weight

| Bore size [mm] | Stroke [mm] | | |
|-------------------|-------------|------|------|
| | 5 | 10 | 15 |
| 4 | 10 | 13 | 15 |
| 6 | 10.6 | 13.1 | 15.6 |
| 10 | 28 | 33 | 38 |
| 16 | 72 | 82 | 92 |

* Weight of hose nipple (4 g) for panel mounting is excluded.

Hose Nipple Dedicated for Panel Mount Type (With fixed orifice)

| Applicable tubing | Part no. |
|----------------------|----------|
| For Ø 4/Ø 2.5 tubing | CJ-5H-4 |
| For Ø 6/Ø 4 tubing | CJ-5H-6 |

Theoretical Output

| Bore size [mm] | Operating direction | Operating pressure [MPa] | | |
|-------------------|------------------------|--------------------------|------|-------|
| | | 0.3 | 0.5 | 0.7 |
| 4 | OUT | 0.97 | 3.48 | 6.00 |
| | IN | 1.0 | | |
| 6 | OUT | 4.56 | 10.2 | 15.9 |
| | IN | 1.42 | | |
| 10 | OUT | 17.6 | 33.3 | 49.0 |
| | IN | 2.45 | | |
| 16 | OUT | 44.5 | 84.7 | 124.9 |
| | IN | 5.04 | | |

Spring Reaction Force

| Bore size [mm] | Stroke [mm] | Retracted side | Extended side |
|-------------------|----------------|-------------------|------------------|
| 4 | 5, 10, 15 | 2.80 | 1.00 |
| 6 | 5, 10, 15 | 3.92 | 1.42 |
| 10 | 5, 10, 15 | 5.98 | 2.45 |
| 16 | 5, 10, 15 | 15.78 | 5.04 |


* Same spring force for each stroke

Allowable Kinetic Energy

⚠ Caution


When driving an inertial load, operate a cylinder with kinetic energy within the allowable value. The range in the chart below that is delineated by bold solid lines indicates the relation between load mass and maximum driving speeds.

| Bore size [mm] | 4 | 6 | 10 | 16 |
|------------------------------|----------------------|--------------------|--------------------|---------------------|
| Piston speed [m/s] | 0.05 to 0.5 | | | |
| Allowable kinetic energy [J] | 0.5×10^{-3} | 3×10^{-3} | 8×10^{-3} | 19×10^{-3} |




Allowable Lateral Load

Strictly observe the limiting range of lateral load on a piston rod. (Refer to the below graph.) If this product is used beyond the limits, it may shorten the machine's life or cause damage.




Construction (Not able to disassemble.)

Panel Mount Type



Embedded Type



Component Parts

| No. | Description | Material | Note |
|-----|---------------|--|--|
| 1 | Tube | Brass | Electroless nickel plating |
| 2 | Piston | Stainless steel | |
| 3 | Collar | Ø 4, Ø 6, Ø 10 Brass | Ø 4, Ø 6, Ø 10 Electroless nickel plating |
| | | Ø 16 Oil-impregnated sintered alloy | Ø 16 — |
| 4 | Return spring | Steel wire | Zinc chromating |
| 5 | Piston seal | NBR | |
| 6 | Mounting nut | Ø 4 Brass | Electroless nickel plating |
| | | Ø 6, Ø 10, Ø 16 Steel | Zinc chromating |
| 7 | Rod end nut | Steel | Zinc chromating |
| 8 | Seal retainer | Stainless steel | Only applicable to Ø 6, Ø 10, and Ø 16 |
| 9 | Gasket | NBR | Embedded type only |

Replacement Parts: Gasket


| Bore size [mm] | Order no. | Contents |
|----------------|-----------|-------------|
| 4 | CJPS4-G | Above no. ⑨ |
| 6 | CJPS6-G | |
| 10 | CJPS10-G | |
| 16 | CJPS16-G | |

* For the embedded type
 * Since gaskets (1 0 pcs./set) do not include a grease pack (10 g), order it separately.


Grease pack part number:
GR-S-010 (10 g)

Dimensions

Panel Mount Type CJPB4




CJPB6/10/16




| Bore size | A | B | C | E | F | | | G | H | MM | NN | R | S | | | W | Z | | | Q |
|-----------|----|----|------|---|-----------------|------------------|------------------|-----|-----|----------|-----------|----|-----------------|------------------|------------------|---|-----------------|------------------|------------------|---|
| | | | | | 5 st | 10 st | 15 st | | | | | | 5 st | 10 st | 15 st | | 5 st | 10 st | 15 st | |
| 4 | 6 | 10 | 11.5 | 3 | 13 | 21 | 29 | 6.5 | 7.5 | M2 x 0.4 | M8 x 1.0 | 7 | 16 | 24 | 32 | 3 | 23.5 | 31.5 | 39.5 | 2 |
| 6 | 7 | 12 | 13.9 | 6 | 12.5 | 19.5 | 26.5 | 8.5 | 9 | M3 x 0.5 | M10 x 1.0 | 9 | 18.5 | 25.5 | 32.5 | 3 | 27.5 | 34.5 | 41.5 | 3 |
| 10 | 10 | 19 | 22 | 6 | 14.5 | 21 | 28 | 12 | 12 | M4 x 0.7 | M15 x 1.5 | 13 | 20.5 | 27 | 34 | 4 | 32.5 | 39 | 46 | 5 |
| 16 | 12 | 27 | 31 | 7 | 16.5 | 22.5 | 29 | 19 | 14 | M5 x 0.8 | M22 x 1.5 | 20 | 23.5 | 29.5 | 36 | 5 | 37.5 | 43.5 | 50 | 6 |

Embedded Type CJPS4




CJPS6/10/16



| Bore size | A | B | C | E | F | | | G | H | K | MM | NN | R | S | | | W | Z | | | Q |
|-----------|----|----|------|---|-----------------|------------------|------------------|-----|-----|-----|----------|-----------|----|-----------------|------------------|------------------|---|-----------------|------------------|------------------|---|
| | | | | | 5 st | 10 st | 15 st | | | | | | | 5 st | 10 st | 15 st | | 5 st | 10 st | 15 st | |
| 4 | 6 | 10 | 11.5 | 6 | 10 | 18 | 26 | 6.5 | 7.5 | — | M2 x 0.4 | M8 x 1.0 | 7 | 16 | 24 | 32 | 3 | 23.5 | 31.5 | 39.5 | 2 |
| 6 | 7 | 12 | 13.9 | 6 | 12.5 | 19.5 | 26.5 | 8.5 | 9 | 3.5 | M3 x 0.5 | M10 x 1.0 | 9 | 18.5 | 25.5 | 32.5 | 3 | 27.5 | 34.5 | 41.5 | 3 |
| 10 | 10 | 19 | 22 | 6 | 14.5 | 21 | 28 | 12 | 12 | 3.5 | M4 x 0.7 | M15 x 1.5 | 13 | 20.5 | 27 | 34 | 4 | 32.5 | 39 | 46 | 5 |
| 16 | 12 | 27 | 31 | 7 | 16.5 | 22.5 | 29 | 19 | 14 | 4.2 | M5 x 0.8 | M22 x 1.5 | 20 | 23.5 | 29.5 | 36 | 5 | 37.5 | 43.5 | 50 | 6 |

Recommended Mounting Hole Dimensions for Embedded Type

Machining dimensions for mounting




| Bore size | Stroke | A | B | C | D | E | F |
|-----------|--------|------|------|------|-----|-----------|-----|
| 4 | 5 | 12 | 8.5 | 6 | 3.5 | M8 x 1.0 | 6.5 |
| | 10 | 20 | 16.5 | 14 | | | |
| | 15 | 28 | 24.5 | 22 | | | |
| 6 | 5 | 16 | 12.5 | 10 | 3.5 | M10 x 1.0 | 8.5 |
| | 10 | 23 | 19.5 | 17 | | | |
| | 15 | 30 | 26.5 | 24 | | | |
| 10 | 5 | 17 | 13.5 | 10.5 | 3.5 | M15 x 1.5 | 12 |
| | 10 | 23.5 | 20 | 17 | | | |
| | 15 | 30.5 | 27 | 24 | | | |
| 16 | 5 | 19 | 14.5 | 11.5 | 4.5 | M22 x 1.5 | 19 |
| | 10 | 25 | 20.5 | 17.5 | | | |
| | 15 | 31.5 | 27 | 24 | | | |

* E and Ø F should be machined in a concentric manner.


Accessory Bracket Dimensions

Rod End Cap

Flat Type: CJ-CF□



Round Type: CJ-CR□



Material: Polyacetal [mm]


| Part no. | | Applicable bore size [mm] | A | D | L | MM | N | RR | W |
|-----------------|-----------------|---------------------------|----|----|----|----------|---|----|----|
| Flat type | Round type | | | | | | | | |
| CJ-CF004 | CJ-CR004 | 4 | 5 | 6 | 9 | M2 x 0.4 | 3 | 6 | 5 |
| CJ-CF006 | CJ-CR006 | 6 | 6 | 8 | 11 | M3 x 0.5 | 5 | 8 | 6 |
| CJ-CF010 | CJ-CR010 | 10 | 8 | 10 | 13 | M4 x 0.7 | 6 | 10 | 8 |
| CJ-CF016 | CJ-CR016 | 16 | 10 | 12 | 15 | M5 x 0.8 | 7 | 12 | 10 |

* Rod end nut is not included when rod end cap is ordered individually. (Please use the rod end nut of the standard cylinder.)

* Applicable only for the rod end with the thread type

Accessory


Mounting Nut (Standard equipment): SNPS-□□



Material: Ø 4 Brass Ø 6, Ø 10, Ø 16 Steel [mm]

| Part no. | Applicable bore size [mm] | d | H | B | C | Maximum tightening torque [N·m] |
|------------------|---------------------------|-----------|---|----|------|---------------------------------|
| SNPS-004 | 4 | M8 x 1.0 | 3 | 10 | 11.5 | 1.2 |
| SNPS-006C | 6 | M10 x 1.0 | 3 | 12 | 13.9 | 4.2 |
| SNPS-010C | 10 | M15 x 1.5 | 4 | 19 | 22 | 16.7 |
| SNPS-016C | 16 | M22 x 1.5 | 5 | 27 | 31 | 30.6 |

Rod End Nut (Standard equipment): NTJ-004, NTP-□




Material: Steel [mm]

| Part no. | Applicable bore size [mm] | d | H | B | C | Maximum tightening torque [N·m] |
|----------------|---------------------------|----------|-----|-----|-----|---------------------------------|
| NTJ-004 | 4 | M2 x 0.4 | 1.6 | 4 | 4.6 | 0.1 |
| NTP-006 | 6 | M3 x 0.5 | 1.8 | 5.5 | 6.4 | 0.3 |
| NTP-010 | 10 | M4 x 0.7 | 2.4 | 7 | 8.1 | 0.8 |
| NTP-016 | 16 | M5 x 0.8 | 3.2 | 8 | 9.2 | 1.6 |

* With rod end thread

Related Products

Refer to the Catalogue on
<https://www.smc.eu>.



CJP Series

Simple Specials

The following changes are dealt with through the Simple Specials System.

Symbol

1 CJP (Ø 6 to Ø 16): Change of Rod End Shape





-XA0/1/10/11

Applicable Series

| Series | | Action | Symbol for change of rod end shape |
|------------|--|---|-------------------------------------|
| CJP | Standard type Single acting, Spring return | CJP Single acting (Spring return) | Ø 6 to Ø 16 XA0, XA1, XA10, XA11 |

Precautions

- SMC will make appropriate arrangements if no dimension, tolerance, or finish instructions are given in the diagram.
- Standard dimensions marked with "*" will be as follows to the rod diameter (D). Enter any special dimension you require.
Ø 6 to Ø 16 $\frac{1}{8}$ D – 1 mm
- Please contact SMC separately for the piston rod end pattern part numbers other than the table above.
- "A0" is the same shape as the standard type.
(The specifications of A0 are that only dimensions A and H are changed from the standard type.)

| Symbol: A0 | Symbol: A1 | Symbol: A10 | Symbol: A11 |
|---|---|--|---|
|  |  |  |  |

1 Pin Cylinder with Rod Quenched

Symbol
-XC17

The piston rod material is changed and the rod end is quenched.

Applicable Series

| Series | Description | Model | Action | Note |
|--------|--------------|-------|-----------------------------|--------------|
| CJP | Pin cylinder | CJPB | Single acting (Panel mount) | Excludes Ø 4 |
| | | CJPS | Single acting (Embedded) | Excludes Ø 4 |

How to Order

Standard model no.

-XC17

- * Only the rod end without thread is available. The symbol B for the rod end type is not used any more.


Pin cylinder with rod quenched

Specifications: Same as the standard type

Construction (Dimensions are the same as the standard type.)

- * The shape and the dimension of quenched part of the rod end are the same for both panel mount type and embedded type.
- * The figure below shows the panel mount type.

CJPB



2 Fluororubber Seals

Symbol
-XC22

Applicable Series

| Series | Description | Model | Action | Note |
|--------|--------------|-------|-----------------------------|--------------|
| CJP | Pin cylinder | CJPB | Single acting (Panel mount) | Excludes Ø 4 |
| | | CJPS | Single acting (Embedded) | Excludes Ø 4 |

How to Order

Standard model no.

-XC22

Fluororubber seals

Specifications

| | |
|--|---------------------------|
| Seal material | Fluororubber |
| Specifications other than the above and dimensions | Same as the standard type |

- * Please confirm with SMC, as the type of chemical and the operating temperature may not allow the use of this product.



CJP Series

Specific Product Precautions

Be sure to read this before handling the products. Please consult with SMC for the use other than the specifications.

Piping

⚠ Caution

The following fittings are recommended for this cylinder connection. However, there may be a case where the piston speed exceeds 500 mm/s even with the recommended fittings for this cylinder. Use a speed controller in such cases.


| Cylinder bore size | Applicable tubing O.D. | Fitting type | Connection thread | Model | |
|---------------------|------------------------|---|-------------------|------------|--|
| Ø 4 | Ø 2 | One-touch fitting | M3 x 0.5 | KQ2□02-M3G | |
| | | Miniature fitting | | M-3AU-2 | |
| Ø 6 Ø 10 Ø 16 | | One-touch fitting | M5 x 0.8 | KQ2□02-M5N | |
| | | Miniature fitting | | M-5AU-2 | |
| | Ø 4/2.5 | Dedicated hose nipple (with fixed orifice) | | CJ-5H-4 | |
| | Ø 6/4 | | | CJ-5H-6 | |

* Please be aware that cylinder speed may slow down on the retracting side when using the above One-touch fittings and miniature fittings with a cylinder bore size of Ø 16.

Hose nipple


CJ-5H-4

(For Ø 4/Ø 2.5 tubing)



CJ-5H-6

(For Ø 6/Ø 4 tubing)



In addition to the above fittings and hose nipples, the below fittings can also be attached to the cylinder. When using the below fittings, be sure to provide a speed controller after adjusting it to 500 mm/s or less.

| Cylinder bore size | Applicable tubing O.D. | Fitting type | Connection thread | Model |
|--------------------|------------------------|-------------------|-------------------|------------|
| Ø 4 | 3.2 | One-touch fitting | M3 x 0.5 | KQ2□23-M3G |
| | 4 | | | KQ2□04-M3G |
| Ø 6 | 3.2 | | M5 x 0.8 | KQ2□23-M5□ |
| Ø 10 | 4 | | | KQ2□04-M5□ |
| Ø 16 | 6 | | | KQ2□06-M5□ |

Recommended Speed Controller

| Applicable tubing O.D. [mm] | Connection thread | Elbow type meter-in | Universal type meter-in | In-line type meter-in |
|-----------------------------|-------------------|---------------------|-------------------------|-----------------------|
| Ø 2 | M3 | AS1211F-M3-02 | — | AS1002F-02 |
| | M5 | AS1211F-M5E-02A | — | |
| Ø 3.2 | M3 | AS1211F-M3-23 | AS1311F-M3-23 | AS1002F-23 |
| | M5 | AS1211F-M5E-23A | AS1311F-M5E-23A | |
| Ø 4 | M3 | AS1211F-M3-04 | AS1311F-M3-04 | AS1002F-04 |
| | M5 | AS1211F-M5E-04A | AS1311F-M5E-04A | |
| Ø 6 | M5 | AS1211F-M5E-06A | AS1311F-M5E-06A | AS1002F-06 |

* For details about One-touch fittings, miniature fittings and speed controllers (applicable tubing O.D. Ø 2 only), refer to the **Catalogue** on <https://www.smc.eu>. Also, for details about speed controllers (applicable tubing O.D. Ø 3.2 to Ø 6), refer to the **Catalogue** on <https://www.smc.eu>.

* Refer to the Fittings and Tubing Precautions (**Catalogue** on <https://www.smc.eu>) for handling One-touch fittings.

Mounting




⚠ Caution

Do not use it in such a way that a load could be applied to the piston rod during the retraction.

The spring that is built into the cylinder provides only enough force to retract the piston rod. Thus, if a load is applied, the piston rod may not be able to retract to the end of the stroke.

Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of “Caution,” “Warning” or “Danger.” They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC) ¹⁾, and other safety regulations.

-  **Caution:** **Caution** indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
-  **Warning:** **Warning** indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.
-  **Danger:** **Danger** indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.

- 1) ISO 4414: Pneumatic fluid power – General rules relating to systems.
ISO 4413: Hydraulic fluid power – General rules relating to systems.
IEC 60204-1: Safety of machinery – Electrical equipment of machines.
(Part 1: General requirements)
ISO 10218-1: Manipulating industrial robots - Safety.
etc.

Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

Caution

1. The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.
If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.
If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following “Limited warranty and Disclaimer” and “Compliance Requirements”. Read and accept them before using the product.

Limited warranty and Disclaimer

1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first. ²⁾ Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
- 2) Vacuum pads are excluded from this 1 year warranty.
A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

Caution

SMC products are not intended for use as instruments for legal metrology.

Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country.
Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.

Safety Instructions

Be sure to read “Handling Precautions for SMC Products” (M-E03-3) before using.

SMC Corporation (Europe)

| | | | |
|----------------|-------------------|-----------------------|------------------------|
| Austria | +43 (0)2262622800 | www.smc.at | office@smc.at |
| Belgium | +32 (0)33551464 | www.smc.be | info@smc.be |
| Bulgaria | +359 (0)2807670 | www.smc.bg | office@smc.bg |
| Croatia | +385 (0)13707288 | www.smc.hr | office@smc.hr |
| Czech Republic | +420 541424611 | www.smc.cz | office@smc.cz |
| Denmark | +45 70252900 | www.smc.dk.com | smc@smcdk.com |
| Estonia | +372 6510370 | www.smc.pneumatics.ee | smc@info@smcee.ee |
| Finland | +358 207513513 | www.smc.fi | smcffi@smc.fi |
| France | +33 (0)164761000 | www.smc-france.fr | info@smc-france.fr |
| Germany | +49 (0)61034020 | www.smc.de | info@smc.de |
| Greece | +30 210 2717265 | www.smchellas.gr | sales@smchellas.gr |
| Hungary | +36 23513000 | www.smc.hu | office@smc.hu |
| Ireland | +353 (0)14039000 | www.smcautomation.ie | sales@smcautomation.ie |
| Italy | +39 03990691 | www.smcitalia.it | mailbox@smcitalia.it |
| Latvia | +371 67817700 | www.smc.lv | info@smc.lv |

| | | | |
|-------------|---------------------|-------------------------|-----------------------------|
| Lithuania | +370 5 2308118 | www.smc.lt | info@smc.lt |
| Netherlands | +31 (0)205318888 | www.smc.nl | info@smc.nl |
| Norway | +47 67129020 | www.smc-norge.no | post@smc-norge.no |
| Poland | +48 222119600 | www.smc.pl | office@smc.pl |
| Portugal | +351 214724500 | www.smc.eu | apoioclientept@smc.smces.es |
| Romania | +40 213205111 | www.smcromania.ro | smcromania@smcromania.ro |
| Russia | +7 (812)3036600 | www.smc.eu | sales@smcru.com |
| Slovakia | +421 (0)413213212 | www.smc.sk | office@smc.sk |
| Slovenia | +386 (0)73885412 | www.smc.si | office@smc.si |
| Spain | +34 945184100 | www.smc.eu | post@smc.smces.es |
| Sweden | +46 (0)86031240 | www.smc.nu | smc@smc.nu |
| Switzerland | +41 (0)523963131 | www.smc.ch | info@smc.ch |
| Turkey | +90 212 489 0 440 | www.smc.pnomatik.com.tr | info@smcpnomatik.com.tr |
| UK | +44 (0)845 121 5122 | www.smc.uk | sales@smc.uk |

| | | | |
|--------------|-----------------|-----------------|---------------------|
| South Africa | +27 10 900 1233 | www.smcza.co.za | zasales@smcza.co.za |
|--------------|-----------------|-----------------|---------------------|