


5.0 MPa Pneumatic Equipment Series



5.0 MPa

Pneumatic


Applications include air-blowing, charging fluid into a vessel, or discharging (Blow-molding equipment, etc.)



Features 1

SMC

Equipment Variations



	Description	Features	Maximum operating	Series			Port	size			Daga
	Description	Features	pressure (MPa)	Series	1/4	1/2	3/4	1	1 1/4	11/2	Page
	Pilot operated		5.0	VCH41(N.C.)			•	•			P.1
	2 port solenoid valve		5.0	VCH42(N.O.)			•	•			
	Check valve	Service life: 10 million cycles A polyurethane elastoner	5.0	VCHC40			•	•			P.5
	Pilot operated 3 port solenoid valve	poppet is adopted as a valve part. This improves durability undera high pressure envoronment.	5.0	VCH410		•	•	•			P.7
1	Direct operated regulator		Inlet pressure 6.0	VCHR30			•	•			P.15
¥	(Relieving type)		Set pressure 0.5 to 5.0	VCHR40				•		•	F.13
and the second se	01	Noise reduction 35 dB(A)	5.0	VCHN3			•	•			
	Silencer	(At supply pressure 4.0 MPa, back pressure 2.0 MPa) Reduction of clogging with double-layer construction	(Relief valve release pressure: 1.8 MPa)	VCHN4				•	•	•	P.21

Related Equipment


Pressure switch	2-colour display Metal body (Aluminum die-cast)	10.0 15.0	ISE75(H)	•			
 Made to Orde	r P.24		121				

1 6.0 MPa pilot operated regulator (Air operated type) —


2 22.0 MPa 2 port air operated valve

3 5.0 MPa pressure sensor —

5.0 MPa Pilot Operated 2 Port Solenoid Valve & Check Valve Series VCH40/VCHC40 For Air



5.0 MPa Pilot Operated 2 Port Solenoid Valve Series VCH40



Specifications

Model		Model	VCH41 (N.C.)	VCH42 (N.O.)	
	Val	ve construction	Pilot operated, d	iaphragm poppet	
	Fluid		Air, Insert gas		
	Orifice		ø16	ø17.5	
	C value (Effective area)		17 dm ³ /(s•bar) (85 mm ²)	22 dm ³ /(s•bar) (110 mm ²)	
	Flow	b	0.08	0.11	
_	char	Cv	4.5	5.8	
fio	Мах	a operating pressure	5.0	MPa	
ifice	Ор	erating pressure	0.5 to 5	5.0 MPa	
Valve specification	Fluid temperature		–5 to 80°C		
le s	Ambient temperature		−5 to 80°C		
Valv	Body material		Brass		
-	Main seal material		Polyurethane elastomer		
	Enclosure		Drip proof (Equivalent to IP65)		
		rt size	G3/4, 1 (G thread for hydraulics and pneumatics conforming to ISO1179		
	Imp resi	act/Vibration Note 1) stance	300/100 m/s ^{2 Note 2)}		
	Мо	unting orientation	Unres	tricted	
	Weight		1.67 kg	1.9 kg	
<u>e</u>	S Rated voltage		12 VDC, 24 VDC		
icat	Allowable voltage fluctuation		±10% of ra	ted voltage	
Coil specification	Electrical entry		DIN connector		
il sp	Coi	il insulation type	Class B		
ပိ	Po	wer consumption	5 W (DC)		
Note	Note 1) Impact resistance: No malfunction resulted in an impact test using a				


Note 1) Impact resistance:

No malfunction resulted in an impact test using a drop impact tester. The test was performed one time each in the axial and right angle directions of the main valve and armature, for both energised and de-energised states. (Value in the initial stage) No malfunction resulted in 8.3 to 2000 Hz. a one-sweep test performed in the axial

Vibration resistance: No malfunction resulted in 8.3 to 2000 Hz, a one-sweep test performed in the axial and right angle directions of the main valve and armature for both energised and de-energised states. (Value in the initial stage)

Note 2) Vibration resistance is 50 m/s² when a light/surge voltage suppressor is attached.

Response Time




Note 1) DC solenoid without a light/surge voltage suppressor

Note 2) DC solenoid with an indicator light: It will cause delays around 20 to 30 msec in the OFF response time.


Series VCH40

Construction



Component Parts

No.	Description	Material
1	Body	Brass
2	O-ring	NBR
3	Diaphragm assembly	Polyurethane elastomer
	Diapinagin assembly	Stainless steel
4	Main valve guide	Resin
5	Poppet spring	Stainless steel
6	Hexagon socket head cap screw	Carbon steel
7	Bonnet	Brass
8	Hexagon socket head cap screw (with SW)	Carbon steel
9	O-ring	NBR
10	Armature assembly	—
11	Return spring	Stainless steel
12	Tube assembly	Stainless steel
13	Nut	Brass
14	Rubber mount	NBR
15	DIN connector type solenoid coil	_
16	Clip	Carbon steel
17	DIN terminal gasket	CR
18	DIN connector	_




Component Parts


No.	Description	Material
1	Body	Brass
2	O-ring	NBR
3	Diamhrann accamhlu	Polyurethane elastomer
3	Diaphragm assembly	Stainless steel
4	Main valve guide	Resin
5	Poppet spring	Stainless steel
6	Bonnet plate	Brass
7	Hexagon socket head cap screw	Carbon steel
8	O-ring	NBR
9	Valve spring	Stainless steel
10	Poppet	H-NBR
11	Bonnet	Brass
12	Hexagon socket head cap screw (with SW)	Carbon steel
13	Armature assembly	
14	Return spring	Stainless steel
15	Tube assembly	Stainless steel
16	Nut	Brass
17	Rubber mount	NBR
18	DIN connector type solenoid coil	_
19	Clip	Carbon steel
20	DIN terminal gasket	CR
21	DIN connector	_

Dimensions

VCH41 (N.C.)



VCH42 (N.O.)






5.0 MPa Check Valve Series VCHC40

How to Order

VCHC40-06 <u>G</u>




 Thread type (G thread for hydraulics and pneumatics conforming to ISO1179-1)

Port size
06 3/4
10 1

Specifications

	Model	VCHC40
Operating pressure		0.05 to 5.0 MPa
Cracking pressure		0.05 MPa
Orifice diameter		ø16
ੁੰ C value (Effective area)		28 dm ³ /(s•bar) (140 mm ²)
Flow	b	0.15
chara		7.4
Fluid		Air, Insert gas
Fluid temperature		–5 to 80°C
Ambient temperature		–5 to 80°C
Bo	ody material	Brass
Se	al material	Polyurethane elastomer
Port size		G3/4, 1 (G thread for hydraulics and pneumatics conforming to ISO1179-1)
Mounting orientation		Unrestricted
W	eight	1.02 kg

Construction





Component Parts


No.	Description	Material
1	Body	Brass
2	O-ring	NBR
3	Piston	Aluminum + Hard anodized
4	Poppet	Polyurethane elastomer
5	Set screw	Stainless steel
6	O-ring	NBR
7	Nut	Stainless steel
8	Guide ring	Resin
9	Spring	Stainless steel
10	Plate	Steel + Electroless nickel plated
11	Hexagon socket head cap screw (with SW)	Carbon steel

Dimensions


VCHC40








5.0 MPa Pilot Operated 3 Port Solenoid Valve Series VCH400 For Air



Specifications

		Model	VCI	1410		
	Va	Ive construction	Pilot operated, d	Pilot operated, diaphragm poppet		
	Flu	lid	Air, Ins	sert gas		
	Ori	ifice	Ø	18		
	C value (Effective area) b Cv Cv		G1/2 1→2:20 dm ³ /(s•bar) (100mm ²) 2→3:22 dm ³ /(s•bar) (110mm ²)	G3/4, 1 1→2:22 dm ³ /(s•bar) (110mm ²) 2→3:24 dm ³ /(s•bar) (120mm ²)		
	low	b	G1/2 0.26	G3/4, 1 0.36		
specification	charad	Cv	$\begin{array}{cccc} G1/2 & \begin{array}{ccc} 1 \rightarrow 2 & 5.3 \\ 2 \rightarrow 3 & 5.8 \end{array}$	$G3/4, 1 \qquad \begin{array}{ccc} 1 \rightarrow 2 & 5.8 \\ 2 \rightarrow 3 & 6.3 \end{array}$		
liji	Ma	x. operating pressure	5.0	MPa		
Se	Ор	erating pressure Note 1)	0.5 to 5.0 MPa			
S	Flu	uid temperature	−5 to 80°C			
Valve	An	nbient temperature	−5 to 80°C			
∧	Во	dy material	Aluminum + H	Hard anodized		
	Main seal material		Polyurethane elastomer			
	En	closure	Drip proof (Equ	uivalent to IP65)		
		rt size		d pneumatics conforming to ISO1179-1)		
	Impa	act/Vibration resistance Note 2)	300/100 m/s ^{2 Note 3)}			
	Мо	ounting orientation	Unrestricted			
	We	eight	G1/2, 3/4: 1.83 kg, G1: 2.11 kg			
U.	Ra	ted voltage	12 VDC, 24 VDC			
Icat	Allo	wable voltage fluctuation	±10% of rated voltage			
Coil specification	Ele	ectrical entry	DIN connector			
l sp	Co	il insulation type	Class B			
B Power consumption 5 W (DC), 1			13 VA (AC)			

Response Time




Note 1) DC solenoid without a light/surge voltage suppressor

Note 2) DC solenoid with an indicator light: It will cause delays around 20 to 30 msec in the OFF response time.

Note 1) When used as a selector valve (pressurising ports 1, 3), the pressure should be within the range of port 1 pressure port 3 pressare x 2 (2 times). Impact resistance: No malfunction resulted in an impact test using a drop impact tester. The test was performed one time each in the axial and right angle directions of the main valve and armature, for both energised and de-energised states. (Value in the initial stage) Vibration resistance: No malfunction resulted in 8.3 to 2000 Hz, a one-sweep test performed in the axial and right angle directions of the main valve and Note 2) Impact resistance:

armature for both energised and de-energised states. (Value in the initial stage) Note 3) Vibration resistance is 50 m/s² when a light/surge voltage suppressor is attached.

Construction




Component Parts


No.	Description	Material
1	Body	Aluminum + Hard anodized
2	O-ring	NBR
3	O-ring	NBR
4	Hexagon socket head cap screw	Carbon steel
5	Piston A	Aluminum + Hard anodized
6	Piston B	Aluminum + Hard anodized
7	O-ring	NBR
8	Poppet	Polyurethane elastomer
9	Guide ring	Resin
10	O-ring	NBR
11	Ring	Resin
12	Rod	Stainless steel
13	Hexagon nut	Brass
14	Hexagon nut class 3	Stainless steel
15	Poppet spring	Stainless steel
16	Plate	Steel + Electroless nickel plated
17	Hexagon socket head cap screw (with SW)	Carbon steel
18	Bonnet	Aluminum + Hard anodized
19	O-ring	NBR
20	Return spring	Stainless steel
21	Armature assembly	—
22	Tube assembly	Stainless steel
23	Nut	Brass
24	Rubber mount	NBR
25	DIN connector type solenoid coil	
26	Round S-type retaining ring	Carbon steel
27	DIN terminal gasket	CR
28	DIN connector	
		0

Series VCH400

Dimensions

VCH410





SMC

n nn nn n

Series VCH Safety Instructions

These safety instructions are intended to prevent a hazardous situation and/or equipment damage. These instructions indicate the level of potential hazard by labels of **"Caution"**, **"Warning"** or **"Danger"**. To ensure safety, be sure to observe ISO 4414 Note 1), JIS B 8370 Note 2) and other safety practices.

Caution: Operator error could result in injury or equipment damage.
Warning: Operator error could result in serious injury or loss of life.
Danger: In extreme conditions, there is a possible result of serious injury or loss of life.

Note 1) ISO 4414: Pneumatic fluid power – General rules relating to systems Note 2) JIS B 8370: General Rules for Pneumatic Equipment

<u> Warning</u>

1. The compatibility of the equipment is the responsibility of the person who designs the system or decides its specifications.

Since the products specified here are used in various operating conditions, their compatibility with a specific system must be based on specifications or post analysis and/or tests to meet your specific requirements. The expected performance and safety assurance are the responsibility of the person who has determined the compatibility of the system. This person should continuously review the suitability of all items specified, referring to the latest catalogue information and taking into consideration the possibility of equipment failure when configuring a system. Be particularly careful in determining the compatibility with the fluid to be used.

2. Only trained personnel should operate machinery and equipment.

The fluid (high pressure) can be dangerous if handled incorrectly. Assembly, handling or maintenance of the system should be performed by trained and experienced operators.

- 3. Do not service machinery/equipment or attempt to remove components until the safety is confirmed.
 - 1. Inspection and maintenance of machinery/equipment should only be performed once measures to prevent falling or runaway of the driven object have been confirmed. Measures to prevent danger from a fluid should also be confirmed.
 - 2. When equipment is removed, confirm that safety processes mentioned above, release the fluid pressure and be certain there is no danger from fluid leakage or fluid remaining in the system.
 - 3. Carefully restart the machinery, confirming that safety measures are being implemented.
- 4. Contact SMC if the product will be used in any of the following conditions:
 - 1. Conditions and environments beyond the given specifications, or if product is used outdoors.
 - 2. With fluids whose application causes concern due to the type of fluid or additives, etc.
 - 3. An application which has the possibility of having a negative effect on people, property, or animals, requiring special safety analysis.
- 5. This product is not certified according to the High Pressure Gas Safety Law (in Japan).



Be sure to read this before handling.

Design

Warning

1. Cannot be used as an emergency shutoff valve, etc.

The valves presented in this catalogue are not designed for safety applications such as an emergency shutoff valve. If the valves are used in this type of system, other reliable safety assurance measures should also be adopted.

2. Extended periods of continuous energisation The solenoid coil will generate heat when continuously energised. Avoid using in a tightly shut container. Install it in a wellventilated area. Furthermore, do not touch it while it is being energised or right after it is energised.

3. This solenoid valve cannot be used for explosion proof applications.

4. Maintenance space

The installation should allow sufficient space for maintenance activities.

5. Actuator drive

When an actuator, such as a cylinder, is to be driven using a valve, take appropriate measures to prevent potential danger caused by actuator operation.

6. Use caution regarding exhaust port freezing.

If a high pressure air (more than 1.0 MPa) is quickly exhausted, there may be an occurrence in which the valve will not switch properly or the service life will substantially decrease due to condensation or freezing caused by the substantial temperature change. When condensation or freezing occurs, take measures such as using a freeze-reducing silencer (VCHNF series), etc.

7. Use caution regarding back pressure.

- 2) In the case of a 3 port solenoid valve, when the valve is being switched, high pressure air will be introduced into the lower pressure side. Therefore, when using this product as a selector valve for switching between high and medium pressures, a relief type regulator (VCHR series) must be used for the medium pressure side.

Selection

Warning

1. Confirm the specifications.

Give careful consideration to the operating conditions such as the application, fluid and environment, and use within the operating ranges specified in this catalogue.

2. Fluid

Corrosive gas

Cannot be used since it will lead to cracks by stress corrosion or result in other incidents.

3. Air quality

1) Use clean air.

Do not use compressed air which includes chemicals, synthetic oils containing organic solvents, salt or corrosive gases, etc., as it can cause damage or malfunction.

2) Install air filters.

Install air filters close to valves at their upstream side. A filtration degree of 5 μm or less should be selected.

3) Install an air dryer or after-cooler, etc.

Compressed air that includes excessive drainage may cause malfunction of valves and other pneumatic equipment. To prevent this, install an air dryer or after cooler, etc.

4) If excessive carbon powder is generated, eliminate it by installing mist separators at the upstream side of valves. If excessive carbon powder is generated by the compressor, it may adhere to the inside of the valves and cause a malfunction.

Refer to SMC's Best Pneumatics 2004 catalogue for further details on compressed air quality.

4. Ambient environment

Use within the operable ambient temperature range. Confirm the compatibility between the product's composition materials and the ambient atmosphere. Be sure that the fluid used does not touch the external surface of the product.

5. Supply source

If the primary side air is throttled, flow may be reduced resulting in the malfunction of the switch or instability in the response time because of the pilot operated solenoid valve. Conduct piping work suited for the secondary side piping (air consumption).

Also, when a regulator is installed, the air supply will stop right after the solenoid valve is switched due to the response time of the regulator. Thus, when using it below the minimum operating pressure, adjust the pipe size, length or provide an air tank, etc.






Be sure to read this before handling.

Selection

A Caution

1. Leakage voltage

Particularly when using a resistor in parallel with a switching element and using a C-R element (surge voltage suppressor) to protect the switching element, take note that leakage current will flow through the resistor, C-R element, etc., creating a possible danger that the valve may not turn off.



DC coil: 2% or less of rated voltage

Mounting

Warning

1. If air leakage increases or equipment does not operate properly, stop operation.

After mounting is completed, confirm that it has been done correctly by performing a suitable function test.

- **2.** Do not apply external force to the coil section. Be sure to apply the wrench to the external part of the piping connection. (Hexagonal parts or width across flats) Also, use caution when mounting a silencer or piping to the pilot exhaust port (G1/4) on top of the VCH410 series 3 port solenoid valve.
- **3. Be sure not to position the coil downwards.** When mounting a valve with its coil positioned downwards, foreign objects in the fluid will adhere to the iron core leading to a malfunction.
- 4. Avoid sources of vibration, or adjust the mounting arm from the body to the minimum length so that resonance will not occur.

Piping

▲ Caution


1. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

Avoid pulling, compressing, or bending the valve body when piping.

2. Wrapping of pipe tape

Pipe tape is not necessary since this product uses a pneumatic and hydraulic purpose G thread which conforms to ISO 1179-1. When an R (taper) thread is used, leave 1 to 2 threads at the tip exposed before winding the piping thread around it 4 to 5 times.



3. Always tighten threads with the proper tightening torque.

When attaching fittings to valves, tighten with the proper tightening torque shown below.

Tightening Torque for Piping

Connection threads	Proper tightening torque N·m
G, Rc 1/2	28 to 30
G, Rc 3/4	28 to 30
G, Rc 1	36 to 38

4. Connection of piping to products

When connecting piping to a product, refer to its instruction manual to avoid mistakes regarding the supply port, etc.

- Port 1: Supply port
- Port 2: Output port

Port 3: Exhaust port

Note) Supply port when used as a selector valve. However, use within the range of port 1 pressure poart 3

pressure x 2 (2 times).





Be sure to read this before handling.

Wiring

A Caution

- As a rule, use electrical wire with a cross sectional area of 0.5 to 1.25 mm² for wiring. Furthermore, do not allow excessive force to be applied to the lines.
- 2. Use electrical circuits which do not generate chattering in their contacts.
- 3. Use voltage which is within $\pm 10\%$ of the rated voltage. In cases with a DC power supply where importance is placed on responsiveness, stay within $\pm 5\%$ of the rated value. The voltage drop is the value in the lead wire section connecting the coil.
- 4. When a surge from the solenoid affects the electrical circuitry, install a surge absorber, etc., in parallel with the solenoid.


Or, adopt an option that comes with the surge voltage protection circuit. (However, a surge voltage occurs even if the surge voltage protection circuit is used. For details, please consult with SMC.)

Electrical Connections

A Caution

DIN connector

Since internal connections are as shown below for the DIN connector, make connections to the power supply accordingly.




Terminal no.	1	2
DIN terminal	+ ()	- (+)


* There is no polarity.

• Use the compatible heavy-duty cords with cable O.D. of ø6 to 12 mm.

• Use the tightening torques below for each section.



Note) For an outside cable diameter of ø9 to 12 mm, remove the internal parts of the rubber seal before using.



SMC



Be sure to read this before handling.

Operating Environment

Warning

- 1. Do not use the valves in an atmosphere having corrosive gases, chemicals, salt water, water, steam, or where there is direct contact with any of these.
- 2. Do not use in explosive atmospheres.
- 3. Do not use in locations subject to vibration or impact.
- 4. Do not use in locations where radiated heat will be received from nearby heat sources.
- 5. Employ suitable protective measures in locations where there is contact with water droplets, oil or welding spatter, etc.

Maintenance

Warning

1. Removing the product

- 1. Shut off the fluid supply and release the fluid pressure in the system.
- 2. Shut off the power supply.
- 3. Dismount the product.

2. Low frequency operation

Switch valves at least once every 30 days to prevent malfunction. Also, in order to use it under the optimum state, conduct a regular inspection once every six months.

Maintenance


A Caution

1. Storage

In the case of long term storage, thoroughly remove all moisture to prevent rust and deterioration of rubber materials, etc.

2. Exhaust the drain from an air filter periodically.


6.0 MPa Direct Operated Regulator (Relieving Type) Series VCHR




Specifications

Model	VCHR30	VCHR40			
Valve construction Piston type					
Valve material	Polyurethane elastomer				
Relief mechanism	Relievi	ng type			
Port size	G3/4, G1	G1, G1•1/2			
Thread type	G thread for hydraulics and pneumatics conforming to ISO1179				
Fluid	Air				
Max. operating pressure	Max. operating pressure 6.0 MPa				
Set pressure range	0.5 to 5	5.0 MPa			
Fluid temperature	–5 to 60°C				
Ambient temperature	–5 to 60°C				
Weight	4.4 kg	6.2 kg			

Pressure Characteristics




Flow Characteristics





Series VCHR

Construction




Component Parts


No.	Description	Material
1	Body	Aluminum + Hard anodized
2	Bonnet	Aluminum + Hard anodized
3	Valve	Stainless steel
4	Valve spool	Stainless steel
5	Piston	Steel + Electroless nickel plated
6	Spring guide	Steel + Electroless nickel plated
7	Spring seat	Steel + Electroless nickel plated
8	Spool guide	Aluminum + Hard anodized
9	Seal A	Resin
10	Seal B	Resin
11	Guide ring	Resin
12	Adjusting bolt	Stainless steel
13	Return spring	Stainless steel
14	Cushion	Polyurethane elastomer
15	Poppet	Polyurethane elastomer
16	Plate	Steel + Electroless nickel plated
17	Spring	Stainless steel
18	Guide ring	Resin
19	Guide ring	Resin
20	Hexagon socket head cap screw	Carbon steel
21	Hexagon nut	Carbon steel
22	Hexagon bolt	Carbon steel
23	Spring washer	Carbon steel
24	O-ring	NBR
25	O-ring	NBR
26	O-ring	NBR
27	O-ring	NBR
28	Hexagon socket head plug	Carbon steel

Dimensions

VCHR30



VCHR40



4



Caution on Design

A Warning

- 1. Consult with SMC when leakage is never permitted because of the operating environment, or if fluids other than air will be used.
- 2. Be sure to install a safety device as output pressure exceeding the set pressure value could cause equipment damage or malfunctions on the outlet side.

A Caution

1. Using the product outside the specified range is not allowed. Consult with SMC when using the product outside the specified range of operating pressure, temperature, pressure, etc.

Selection

Warning

- 1. Grease may leak into the outlet side because it has been applied to the inner sliding parts and seals. Contact SMC when such cases should be avoided.
- 2. Contact SMC as the set pressure of the outlet side may fluctuate when air has not been consumed for a long period of time, or when the product is used in a shut-off or balancing circuit on the outlet side.
- 3. The set outlet side pressure range should be less than 85% of the inlet side pressure. Setting a pressure exceeding 85% may be subject to fluctuation of flow or pressure in the inlet side, resulting in unstable operation.
- 4. The maximum value in catalogue set pressure range has a tolerance. Therefore, the pressure setting may exceed this value.
- 5. Confirm with SMC when the product will be used in circuits, requiring highly precise relief sensitivity or setting precision.

Mounting

Caution

- 1. Confirm the "IN" and "OUT" showing the inlet/outlet of the air flow or arrow mark before connection. Reverse connections will result in malfuction.
- 2. Provide adequate space for maintenance or operation in the upper, lower and front of each product. Regarding this space, refer to the dimensions of each product.

Adjustment

Warning

1. Adjust while confirming the pressure gauge value in the inlet and outlet sides. Overrotating the handle will damage the inner components.

A Caution

- 1. Adjust after carefully confirming the inlet pressure.
- 2. Setting the pressure with the handle should be conducted in the upper direction. Setting the pressure in the lower direction may result in the pressure to the drop below the original set pressure. Turning the handle clockwise will increase the outlet side pressure. Meanwhile, turning counterclockwise will decrease the pressure.

Piping

A Warning

1. When tightening a screw on the piping material, use the recommended torque, holding the female side.

Insufficient torque will cause looseness or inferior sealing. However, overtightening will cause damage to the thread. Also, tightening without holding the female side will put excessive direct stress on brackets, etc., resulting in damage, etc.

- 2. Use caution so twisting or bending other than the self-weight moment will not be applied to the product. Otherwise, it will result in damage. Support the external piping separately.
- 3. Inflexible piping such as steel piping is subject to excessive moment loads or transmission of vibrations from the piping side. Use flexible tubing, etc. between them to avoid it.



Adjustment	
------------	--

A Caution

1. When adjusting the outlet side pressure, moment is applied to the adjusting bolt. Support it separately so that any moment is not applied to the external pipings.

Reference for Handle Moment Unit: N-m							
Set pressure	1 MPa	2 MPa	3 MPa	4 MPa	5 MPa		
Torque	3	6	9	12	15		

2. When adjusting the outlet side pressure, the adjusting bolt (32 mm width across flats) can be rotated with a wrench. A screwdriver of approximately 20 to 30 mm can also be used for easy adjustments, using the (ø11) hole on the width across flats.

Piping

Warning

1. When tightening a screw on the piping material, use the recommended torque, holding the female side.

Insufficient torque will cause looseness or inferior sealing. However, overtightening will cause damage to the thread. Also, tightening without holding the female side will put excessive direct stress on brackets, etc., resulting in damage, etc.

Recommended Tightening Torque	Unit: N•m
-------------------------------	-----------


Connecting thread	3/4	1	1•1/2
Torque	28 to 30	36 to 38	48 to 50

Disassembly

A Caution

1. This product cannot be disassembled since it is made of precision components with specific tolerances.

5.0 MPa Silencer Series VCHN





@SMC

Specifications

Model	VCHN3 VCHNF3		INF3	VCHN4			VCHNF4			
Fluid	Air, Insert gas									
Max. operating pressure (MPa)				5.0 (5	olenoid va	lve inlet pres	ssure)			
Relief valve opening pressure (MPa)	1.8									
Port size	R3/4	R1	R3/4	R1	R1	R1•1/4	R1•1/2	R1	R1•1/4	R1•1/2
Effective area (mm ²)	200	280	160	180	280	370	370	180	320	320
Sound absorbing material effective area (Single) (mm ²) 43		420 500					0			
Fluid temperature (°C)	5 to 80									
Ambient temperature (°C)	5 to 80									
Noise reduction dB(A)		35 (Supply pres	sure 4.0 M	Pa, Back pre	essure 2.0 N	IPa)			

Construction/Dimensions





						(mm)
Model	Port size (R)	Α	В	С	D	Weight (g)
VCHN3-06	3/4	200	ø72	ø74	41	590
VCHNF3-06	3/4	200	ø72	ø74	41	710
VCHN3-10	1	200	ø72	ø74	41	605
VCHNF3-10	1	200	ø72	ø74	41	725
VCHN4-10	1	230	ø72	ø74	41	665
VCHNF4-10	1	230	ø72	ø74	41	810
VCHN4-12	1•1/4	240	ø72	ø74	54	765
VCHNF4-12	1•1/4	240	ø72	ø74	54	910
VCHN4-14	1•1/2	240	ø72	ø74	54	790
VCHNF4-14	1•1/2	240	ø72	ø74	54	935

Series VCHN Specific Product Precautions

Be sure to read this before handling.

Caution on Design

A Warning

1. The exhaust port can clog due to a clogged or frozen silencer.


Consider design safety to avoid malfunctions of the entire system. Also, under conditions conducive to freezing, use a freeze reduction model. (VCHNF series)

A Caution

1. A silencer reduces compressed air exhaust noise from the pneumatic equipment.

Noise other than that generated by the exhaust assembly (noise generated inside piping, due to equipment vibration, solenoid valve switching, etc.) cannot be reduced. As for noise generated by sources other than the exhaust, locate the cause and take measures.

2. Silencer inlet side pressure shows the solenoid valve supply pressure (P1). (See below.)



3. Noise reduction may vary, depending on the pneumatic circuit or pressure, etc. exhausted from solenoid valves.

Adjustment

A Caution

1. Select a silencer with a larger effective area (including the synthetic effective area) than the solenoid valve.

Mounting

A Caution

1. Tighten the silencer, using an appropriate wrench on the width across flats, within the range of the recommended tightening torque as shown below.

Do not use a pipe wrench. Otherwise, the silencer will be damaged.

Reco	Recommended Tightening Torque							
Conn	ecting thread	3/4	1	1•1/4	1•1/2			
	Torque	28 to 30	36 to 38	40 to 42	48 to 50			

- 2. Do not apply a lateral load on the main body during or after mounting.
- 3. When the silencer becomes loose due to vibrations from the mounted equipment, remount the silencer after applying an anti-loosening agent to the thread.

Maintenance

A Caution


1. When exhaust speed begins to slow from clogging and system functionality begins to degrade, replace with a new silencer or sound-absorbant material.

Also, be sure to confirm the actuator's operation status once $\ensuremath{\mathsf{per}}$ day.

How to Replace the Sound Absorbing Material

A Caution

1. When replacing the sound absorbing material, please follow the instructions below.



Replacement Parts

Sound Absorbing Material Part No.

Part no.	Description	Applicable model
VCHN3-EL	Sound absorbing material	For VCHN(F)3
VCHN4-EL	Sound absorbing material	For VCHN(F)4

Made to Order


For detailed dimensions, specifications and delivery, please contact SMC.

6.0 MPa piloted regulator (Air operated type)

VCHRA


Remote control is possible with electro-pneumatic regulator series ITV.


8



14


1•1/2





Specifications				
Model	VCHRA30	VCHRA40		
Valve construction	Pistor	n type		
Valve material	Polyurethan	e elastomer		
Relief mechanism	Relievi	ng type		
Port size	G3/4, G1	G1, G1•1/2		
Port size Thread standard	G thread for hydraulics and pneumatics conforming to ISO1179-1			
Fluid	Air			
Max. operating pressure	e 6.0 MPa			
Pilot pressure range	Refer to the graph.			
Set pressure range	e 0.5 to 4.5 MPa			
Fluid temperature	–5 to 60°C			
Ambient temperature	–5 to 60°C			
Weight	2.9 kg	4.1 kg		

Pilot pressure range



2 22.0 MPa 2 port air operated valve

AXT836 A

Specifications						
Symbol	Symbol Passage Piping size					
Α	N.C.	1/4" fitting integrated type				
В	N.O.	1/4" fitting integrated type				
С	N.C.	Flange type				
D	N.O.	Flange type				
Е	Double acting	1/4" fitting integrated type				





Integrated fitting type Flange type

Specifications

	A, C (N.C. type)	B, D (N.O. type)	E (Double acting)
Fluid	Air/Insert gas		
Fluid temperature	-10 to 60°C (with no freezing)		
Ambient temperature	-10 to 60°C (with no freezing)		
Operating pressure range	0 to 22.0 MPa		0 to 20.0 MPa
Proof pressure	35.0 MPa		
Pilot pressure range	0.45 to (0.7 MPa	0.3 to 0.5 MPa
Valve leakage	0.1cm ³ /min or less		
Orifice size	2.8 mm		

5.0 MPa pressure sensor



Specifications

Specifications		
Model	PSE560-X512	
Rated pressure range	0 to 5.0 MPa	
Proof pressure	10.0 MPa	



Related Equipment

2-colour display digital pressure switch Series ISE75/75H



■ 10.0 MPa: ISE75 15.0 MPa: ISE75H ■ 2-colour display Metal body (Aluminum die-cast)

IP67





Model	ISE75	ISE75H	
Rated pressure range	0 to 10.0 MPa	0 to 15.0 MPa	
Set pressure range	0.4 to 10.0 MPa	0.5 to 15.0 MPa	
Proof pressure	30.0 MPa	45.0 MPa	
Set pressure resolution	0.1 MPa		
Fluid	Fluids that will not corrode stainless steel 430 and 630		
Power supply voltage	12 to 24 VDC, Ripple (p-p) 10% or less (with power supply polarity protection)		
Current consumption	55 mA or less (at no load)		
Switch output	Outpu 1 setting; NPN open colle PNP open collector 1 Outpu PNP open collector	ctor 1 output (Pin no. 4) + output (Pin no. 2) ^{Note)} it -65:	
Max. load current	80 mA		
Max. applied voltage	30 V (with NPN output)		
Residual voltage	1 V or less (with load current of 80 mA)		
Response time	2.5 ms (Response time selections with anti-chattering funct 20 ms, 160 ms, 640 ms, 1000 ms, 2000 ms)		
Short circuit protection	With short circuit protection		

Note) The NPN and PNP outputs activate with a single set value.

SMC







EUROPEAN SUBSIDIARIES:

Austria

SMC Pneumatik GmbH (Austria). Girakstrasse 8, A-2100 Korneuburg Phone: +43 2262-62280. Fax: +43 2262-62285 E-mail: office@smc.at http://www.smc.at



SMC Pneumatics N.V./S.A. Nijverheidsstraat 20, B-2160 Wommelgem Phone: +32 (0)3-355-1464, Fax: +32 (0)3-355-1466 E-mail: post@smcpneumatics.be http://www.smcpneumatics.be



SMC Industrial Automation Bulgaria EOOD 16 kliment Ohridski Blvd., fl.13 BG-1756 Sofia Phone:+359 2 9744492, Fax:+359 2 9744519 E-mail: office@smc.bg http://www.smc.bg



Croatia

SMC Industrijska automatika d.o.o. Crnomerec 12, 10000 ZAGREB Phone: +385 1 377 66 74, Fax: +385 1 377 66 74 E-mail: office@smc.hr http://www.smceu.com



Czech Republic

SMC Industrial Automation CZ s.r.o. Hudcova 78a, CZ-61200 Brno Phone: +420 5 414 24611, Fax: +420 5 412 18034 F-mail: office@smc.cz http://www.smc.cz



Denmark SMC Pneumatik A/S Knudsminde 4B, DK-8300 Odder

Phone: +45 70252900, Fax: +45 70252901 E-mail: smc@smc-pneumatik.dk http://www.smcdk.com



Estonia SMC Pneumatics Estonia OÜ Laki 12-101, 106 21 Tallinn Phone: +372 (0)6 593540, Fax: +372 (0)6 593541

E-mail: smc@smcpneumatics.ee http://www.smcpneumatics.ee

Finland

PL72, Tiistinniityntie 4, SF-02031 ESPOO Phone: +358 207 513513, Fax: +358 207 513595 E-mail: smcfi@smc.fi http://www.smc.fi



1, Boulevard de Strasbourg, Parc Gustave Eiffel Bussy Sain Georges F-77607 Mame La Vallee Cedex 3 Phone: +33 (0)1-6476 1000, Fax: +33 (0)1-6476 1010 E-mail: contact@smc-france.fr http://www.smc-france.fr



SMC Pneumatik GmbH Boschring 13-15, D-63329 Egelsbach Phone: +49 (0)6103-4020, Fax: +49 (0)6103-402139 E-mail: info@smc-pneumatik.de http://www.smc-pneumatik.de



Greece

S. Parianopoulus S.A. 7, Konstantinopolitus S.A. 7, Konstantinoupoleos Street, GR-11855 Athens Phone: +30 (0)1-3426076, Fax: +30 (0)1-3455578 E-mail: parianos@hol.gr http://www.smceu.com



Hungary SMC Hungary Ipari Automatizálási Kft. Budafoki ut 107-113, H-1117 Budapest Phone: +36 1 371 1343, Fax: +36 1 371 1344 E-mail: office@smc-automation.hu http://www.smc-automation.hu



SMC Pneumatics (Ireland) Ltd. 2002 Citywest Business Campus, Naas Road, Saggart, Co. Dublin Phone: +353 (0)1-403 9000, Fax: +353 (0)1-464-0500 E-mail: sales@smcpneumatics.ie http://www.smcpneumatics.ie



SMC Italia S.p.A Via Garibaldi 62, I-20061Carugate, (Milano) Phone: +39 (0)2-92711, Fax: +39 (0)2-9271365 E-mail: mailbox@smcitalia.it http://www.smcitalia.it

SMC Pneumatics Latvia SIA Smerla 1-705, Riga LV-1006, Latvia Phone: +371 781-77-00, Fax: +371 781-77-01 E-mail: info@smclv.lv http:/



Savanoriu pr. 180, LT-01354 Vilnius, Lithuania Phone: +370 5 264 81 26, Fax: +370 5 264 81 26



De Ruyterkade 120, NL-1011 AB Amsterdam Phone: +31 (0)20-5318888, Fax: +31 (0)20-5318880 E-mail: info@smcpneumatics.nl http://www.smcpneumatics.nl



SMC Pneumatics Norway A/S Vollsveien 13 C, Granfos Næringspark N-1366 Lysaker Tel: +47 67 12 90 20, Fax: +47 67 12 90 21 E-mail: post@smc-norge.no http://www.smc-norge.no

Poland

SMC Industrial Automation Polska Sp.z.o.o. ul. Konstruktorska 11A, PL-02-673 Warszawa, Phone: +48 22 548 5085, Fax: +48 22 548 5087 E-mail: office@smc.pl http://www.smc.pl



Portugal SMC Sucursal Portugal, S.A. Rua de Eng^o Ferreira Dias 452, 4100-246 Porto Phone: +351 22-610-89-22, Fax: +351 22-610-89-36 E-mail: postpt@smc.smces.es http://www.smces.es



SMC Romania srl Str Frunzei 29, Sector 2, Bucharest Phone: +40 213205111, Fax: +40 213261489 E-mail: smcromania@smcromania.ro http://www.smcromania.ro

Russia

SMC Pneumatik LLC. 4B Sverdlovskaja nab, St. Petersburg 195009 Phone.:+812 718 5445, Fax:+812 718 5449 E-mail: info@smc-pneumatik.ru http://www.smc-pneumatik.ru

Slovakia SMC Priemyselná Automatizáciá, s.r.o. Námestie Martina Benku 10, SK-81107 Bratislava Phone: +421 2 444 56725, Fax: +421 2 444 56028 E-mail: office@smc.sk http://www.smc.sk



Slovenia



Spain SMC España, S.A. Zuazobidea 14, 01015 Vitoria Phone: +34 945-184 100, Fax: +34 945-184 124 E-mail: post@smc.smces.es http://www.smces.es



Sweden SMC Pneumatics Sweden AB Ekhagsvägen 29-31, S-141 71 Huddinge Phone: +46 (0)8-603 12 00, Fax: +46 (0)8-603 12 90 E-mail: post@smcpneumatics.se http://www.smc.nu



SMC Pneumatik AG Dorfstrasse 7, CH-8484 Weisslingen Phone: +41 (0)52-396-3131, Fax: +41 (0)52-396-3191 E-mail: info@smc.ch http://www.smc.ch



Entek Pnömatik San. ve Tic Ltd. Sti. Pepa Tic. Merkezi Kat: 11 No: 1625. TR-80270 Okmeydani Istanbul Phone: +90 (0)212-221-1512, Fax: +90 (0)212-221-1519 E-mail: smc-entek@entek.com.tr http://www.entek.com.tr



SMC Pneumatics (UK) Ltd Vincent Avenue, Crownhill, Milton Keynes, MK8 0AN Phone: +44 (0)800 1382930 Fax: +44 (0)1908-555064 E-mail: sales@smcpneumatics.co.uk http://www.smcpneumatics.co.uk





SMC industrijska Avtomatika d.o.o. Grajski trg 15, SLO-8360 Zuzemberk Phone: +386 738 85240 Fax: +386 738 85249 E-mail: office@smc-ind-avtom.si http://www.smc-ind-avtom.si



ARGENTINA, AUSTRALIA, BOLIVIA, BRASIL, CANADA, CHILE, CHINA, HONG KONG, INDIA, INDONESIA, MALAYSIA, MEXICO, NEW ZEALAND, PHILIPPINES, SINGAPORE, SOUTH KOREA, TAIWAN, THAILAND, USA, VENEZUELA

> http://www.smceu.com http://www.smcworld.com



Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.

//www.smclv.lv				
	Lithuania			
Deserve	and an I lake a			

