Circulating Fluid Temperature Controller Thermo-chiller Dual Channel Thermo-chiller for Lasers (RoHS) **Temperatures for 2 fluid channel systems can** be controlled individually by one chiller. Laser optical system Laser oscillator Optical system CH2 Oscillator CH1 Oscillator **Optical system** CH1 CH₂ Cooling capacity [kW] 9, 19, 26 1 (Max. 1.5) ±0.1 ±0.5 Temperature stability [°C] 5 to 35 10 to 40*1 Set temperature range [°C]

*1 CH2 ≥ CH1



CAT.EUS40-68Aa-UK







One compressor controls 2 channels.

Temperature stability: ±0.1 °C (CH1) When a load is stable

By controlling the inverter compressor, inverter fan, and electronic expansion valve simultaneously, it maintains the good temperature stability when the heat load fluctuates.



* For HRL300-A-20

Conditions

- Outdoor air temperature: 32 °C
- Circulating fluid temperature setting: 20 °C/25 °C (CH1/CH2)
- Heat load in the user's equipment: 26 kW/1 kW (CH1/CH2)
- Power supply: 200 V 60 Hz
- Circulating fluid flow rate: 125 LPM/10 LPM (CH1/CH2)
- External piping: Bypass piping + Heat load

3 operation modes of the circulating fluid pump

The pump operation mode can be selected by the touch panel

<Example of the pressure control mode>

	Operation screen Set values can be entered from the	e touch panel.
	E CH1 Pump Setting	
Pressure control mode	Press. SP	0. 45 MPa
2 Flow control mode ————————————————————————————————————	Flow SP	45. 0 lpm
3 Pump operating frequency	Output SP	50. 0 %
(rotation) control mode	Control Mode PRESS	FLOW %
Upper limit of the pressure can be set. ——	Press. Limit OFF ON	0. 45 MPa



When the product is used with the flow path switched for maintenance, the pressure adjusting function controls the discharge pressure to be stable. (Secure the specified minimum flow for each branch circuit.)

Reduced maintenance hours for the pump

Both channels use the mechanical sealless type pump.

As the pump has no external leakage of the circulating fluid, a periodic check of the pump leakage and replacement of the mechanical seal are not necessary.





CH1: Vertical pump



SMC

Variations

*1 Only available for the HRL100/200 3-phase 380 to 415 VAC (50/60 Hz) and the 3-phase 460 to 480 VAC (60 Hz)



Options in demand are standardised.

Built-in bypass circuit (CH1: Oscillator and CH2: Optical system) (Standard)



With electric conductivity control (CH2: Optical system)

DI filter + Built-in solenoid valve for control (Standard) The electric conductivity of the circulating fluid can be set with the touch panel arbitrarily.

Set control range: 0.5 to 45.0 $\mu\text{S/cm}$

Е СН2	DI Setting	
Electric Conducti	vity SP	25. 0µS/cm
Hysteresis		0. 5µS/cm
Control	AUTO	PEN CLOSE
High Electric Conductivity Alarm	OFF WRN	45. 0µS/cm
DI Valve Status		CLOSE

Set the electrical conductivity to be set by the touch panel.

Particle filter set (Standard)

Removes foreign matter in the circulating fluid

Effective in preventing foreign matter from entering the user's equipment Transparent bowl

Easy to visually confirm a dirty element

With casters and adjuster feet (Standard)



Communication functions p. 25

Serial communication (RS232C/RS485), contact I/Os (3 inputs and 6 outputs), and analogue output (2 outputs) are equipped as standard. This allows for communication with the user's equipment and system construction, depending on the application. A 24 VDC output can be also provided and is available for use with flow switches (SMC's PF3W, etc.).



Ex. 2 Remote operation signal input One of the contact inputs is used for remote operation and the other is used to monitor the flow of a flow switch. This is where their alarm outputs are taken in. Remote - Low flow switch flow





Ex. 3 Alarm and operation status

(start, stop, etc.) signal output

The alarm and status generated in the product can be output.



Output examples

Output 1 : Operation status (start, stop, etc.)

Output 2 : Outputted when alarm "FLT (operation stopped)" is generated

Output 3 : Outputted when alarm "WRN (operation continues)" is generated

"WRN (operation continues)" is generated Outputs 4 to 6 : Assigned for specified type of signals

4

Touch panel p. 24

Improved usability and visibility





Numeric keypad display

Numeric data input

2019/03/31	Min Me 15.0 2	¥ 5.0	20.	0 X
	CI	R	DI	EL
∠U. U ℃	7	8	9	
SP 20.0 °C Press. PV 0, 45 MPa	4	5	6	
Flow PV 45. 0 LPM	1	2	3	ENI
Pump CH1 CH2 LOCAL	0	±	•	

Temperature waveform display screen

Circulating fluid temperature waveform is displayed. Temp. SP / PV Graph Ξ 40.0 25.0 10.0 20. 0°C CH2 CH1 -pv 30.0°C sp 30.0°C PV -PV C ◀ SP 20. 0°C

Status screen

Provides details of the temperatures, flow rates, pressures and status in the chiller



When any alarm is generated, the screen automatically moves to the information screen and displays alarm codes and alarm contents.



Notice for maintenance is given when a part reaches its replacement period (operation time).

Information screen

Message is displayed when the replacement time (specified operation time) comes.



Ru	n Time		
CH1	100 /	20000h	RESET
CH2	100 /	20000h	RESET
	100 /	30000h	RESET
	100 /	30000h	RESET
	100 /	500h	RESET
r	100 /	500h	RESET
		100h	
	CH1 CH2	CH1 100 / CH2 100 / 100 / 100 / 100 / rr 100 /	CH1 100 / 20000h CH2 100 / 20000h 100 / 30000h 30000h 100 / 30000h 100 / 500h 100 / 500h 100 / 500h In 100 / 500h

Check operation time screen

«Operating time for pump (CH1)
 «Operating time for pump (CH2)
 «Operating time for compressor
 «Operating time of a fan
 «Usage time of a DI filter
 «Usage time of a dustproof filter
 «Operation time of a chiller



Global Supply Network-

SMC has a comprehensive network in the global market.

We now have a presence of more than 500 branch offices and distributors in 83 countries and regions worldwide, such as Asia, Oceania, North/ Central/South America, and Europe. With this global network, we are able to provide a global supply of our substantial range of products and high-quality customer service. We also provide full support to local factories, foreign manufacturing companies, and Japanese companies in each country.





SMC Thermo-chiller Variations

Lots of variations are available according to the users' requirements.

Covies			Temperature	Set temperature					Cool	ing	capa	city	[kW]				nment	International
Ser	les		[°C]	range [°C]	1.2	1.8	2.4	3	4	5	6	9	10	15	20	25	28	Enviro	standards
	HRSE Basic type		±2.0	10 to 30	•	• 1.6 kW	• 2.2 kW											Indoor use	(은 ヒム (Only 230 VAC type)
	HRS Standard t	ype	±0.1	5 to 40	•	•	•	•	•	•	•							Indoor use	(€ 분 율 ,, (Only 60 Hz)
	HRS-R Environmer resistant ty	ntally pe	±0.1	5 to 40		•		•		•								Indoor use Electrical box: IP54	(€ 比
	HRS090 Standard t	ype	±0.5	5 to 35								•						Indoor use	(€ 분 (400 V as standard)
	HRS100/1 Standard t	50 уре	±1.0	5 to 35									•	•				Outdoor installation IPX4	(€ 분 (400 V as standard)
	HRSH090 Inverter typ	be	±0.1	5 to 40								•						Indoor use	くのV as an option) (400 V as standard, 200 V as an option) (Only 200 V as an option)
	HRSH Inverter typ	be	±0.1	5 to 35									•	•	•	•	•	Outdoor installation IPX4	(400 V as standard, 200 V as an option)
	HRL Inverter	CH1	±0.1	15 to 25								9 kW			● 19 kW		● 26 kW	Indoor use	(€ 분K
dual type		CH2	±0.5	20 to 40								1	.0 kV	V (M	ax. 1	.5 k\	V)		

Circulating Fluid Line Equipment



CONTENTS

HRL Series Dual Channel Thermo-chiller for Lasers



Thermo-chiller HRL Series

How to Order/Specifications	p. 9
Cooling Capacity p	. 12
Pump Capacity	. 14
Dimensions p	. 15
Parts Descriptionp	. 22
Recommended External Piping Flow p	. 23
Cable Specifications p	. 23
Operation Display Panel p	. 24
Alarmp	. 24
Communication Functions p	. 25
Optional Accessories p	. 29

Cooling Capacity Calculation

Required Cooling Capacity Calculationp. 33
Precautions on Cooling Capacity Calculationp. 34
Circulating Fluid Typical Physical Property Values
Specific Product Precautions p. 35



Thermo-chiller

Dual Channel Thermo-chiller for Lasers

3-phase 200 VAC (50 Hz) 3-phase 200 to 230 VAC (60 Hz) HRL Series

RoHS



Specifications

Madal			HRL100)-A⊡-20	HRL200)-A⊡-20	HRL300-A□-20					
Model			CH1	CH2	CH1	CH2	CH1	CH2				
Co	oling metho	d		Air-cooled refrigeration								
Ref	rigerant			R410A (HFC)								
Ref	rigerant ch	arge	[kg]	1.	1.4 2.2 3.0							
Col	ntrol metho	d			PID control							
Ambient temperature [°C]						2 to	45					
	Circulating	g fluid			CH1: T	ap water/CH2: Tap	water, Deionised	water*1				
Set temperature range [°C]						CH1: 15 to 25	/CH2: 20 to 40					
	Cooling ca	pacity*2	[kW]	9	1* ⁸	19	1*8	26	1* ⁸			
	Heating ca	pacity*3	[kW]	1.5	1	4.5	1	6.5	1			
	Temperatu	ire stability*4	[°C]			CH1: ±0.1/	/CH2: ±0.5					
m	Bump	Rated flow (Outlet)	[l/min]	45 (0.43 MPa)	10 (0.45 MPa)	45 (0.45 MPa)	10 (0.45 MPa)	125 (0.45 MPa)	10 (0.45 MPa)			
ste	canacity	Maximum flow rate	[l/min]	120	16	130	16	180	16			
sy	oupdoity	Maximum pump head	l [m]	50	49	55	49	68	49			
uid	Settable p	ressure range*5	[MPa]	0.10 to 0.50	0.10 to 0.49	0.10 to 0.55	0.10 to 0.49	0.10 to 0.68	0.10 to 0.49			
g fl	Minimum operating flow rate ^{*6} [I/min]			20	2	25	2	40	2			
inç	Tank capacity [L]		42	7	42	7	60	7				
Bypass circuit (With valve)				Installed								
rcr	Electric con	ductivity setting range	[μ S/cm]	—	0.5 to 45.0	—	0.5 to 45.0	—	0.5 to 45.0			
Ċ	Particle filter nom	inal filtration rating (Accessory) [μm]	5								
	Circulating	g fluid outlet,		CH1: Rc1 (Symbol F: G1, Symbol N: NPT1)								
	circulating	fluid return port		CH2: Rc1/2 (Symbol F: G1/2, Symbol N: NPT1/2)								
	Tank drain	port		CH1: Rc3/4 (Symbol F: G3/4, Symbol N: NPT3/4) CH2: Rc1/2 (Symbol F: G1/2, Symbol N: NPT1/2)								
	Fluid conta	act material		CH1: Stainless steel, Copper (Heat exchanger brazing), Brass, Bronze, Fluororesin, PP, PBT, POM, PU, PC, PVC, EPDM, NBR								
	(Metal/Res	in)		CH2: Stainless steel, A	Alumina ceramic, Carbo	on, Fluororesin, PP, PB	T, POM, PU, PVC, PPS	, AS, PS, EPDM, NBR,	Ion replacement resin			
em	Power sun	nlv			3-phase 20	0 VAC (50 Hz), 3-p	hase 200 to 230 \	/AC (60 Hz)				
ysti	i ower oup	,pry			Allowable volta	ige range ±10 % (N	lo continuous volta	age fluctuation)				
als	Earth leaka	age Rated current	[A]	3	0	4	0	5	0			
rice	breaker	Sensitivity current	[mA]			3	0					
ect	Rated ope	rating current*4	[A]	1	7	3	2	4	1			
Ξ	Rated pow	er consumption*4	[kW(kVA)]	5.4 ((5.9)	10.5 ((11.0)	13.1 (14.2)			
Noi	se level (Fro	ont 1 m/Height 1 m)*	[[] [dB(A)]	7	5	7	5	7	1			
Acc	essories			Operation Manua	l (for installation/o	peration) 2 pcs. (Er	nglish 1 pc./Japane	ese 1 pc.), Particle	filter set for CH1,			
				Parti	cle tilter set for CH	2, Anchor bolt fixin	ig brackets 2 pcs.	(including 6 M8 bol	ts)*/			
We	ight (dry sta	ate)	[kg]	Appro	x. 222	Appro	x. 251	Appro	x. 315			

Use fluid in condition below as the circulating fluid.

Tap water: Standard of The Japan Refrigeration And Air Conditioning Industry Association (JRA GL-02-1994)

Deionised water: Electric conductivity 1 μS/cm or higher (Electric resistivity 1 MΩ·cm or lower)

*2 ① Ambient temperature: 32 °C, ② Circulating fluid: Tap water, ③ Circulating fluid temperature: CH1 20 °C/CH2 25 °C, ④ Circulating fluid flow rate: Rated flow, 5 Power supply: 200 VAC

3 ① Ambient temperature: 32 °C, ② Circulating fluid: Tap water, ③ Circulating fluid flow rate: Rated flow, ④ Power supply: 200 VAC
*4 ① Ambient temperature: 32 °C, ② Circulating fluid: Tap water, ③ Circulating fluid temperature: CH1 20 °C/CH2 25 °C, ④ Load: Same as the cooling capacity, ⑤ Circulating fluid flow rate: Rated flow, ⑥ Power supply: 200 VAC, ⑦ Piping length: Shortest

*5 With the pressure control mode by inverter. If the pressure control mode is not necessary, use the flow control function or the pump output setting function. *6 Fluid flow rate to maintain the cooling capacity. If the actual flow rate is lower than this, adjust the bypass valve.

*7 The anchor bolt fixing brackets (including 6 M8 bolts) are used for fixing to wooden skids when packaging the thermo-chiller. No anchor bolt is included.

*8 Max. 1.5 kW. When 1.5 kW is applied, the cooling capacity of CH1 decreases by 0.5 kW.





40 3-phase 460 to 480 VAC (60 Hz) For details, refer to "Options" on page 29.

Specifications

				HBI 100	Δ □-40	HBI 200	Δ □-40	HBL300	- Δ□-40	HBI 400-∆□-40				
Model			CH1		CH1		CH1		CH1					
Co	olina method			Air-cooled refrigeration										
Ret	rigerant			B410A (HEC)										
Ret	rigerant char	de	ka	14 1.8 2.5 37										
Co	ntrol method	3-		PID control										
Ambient temperature °C					2 to 45									
	Circulating f	luid			CH1: Tap water*1, Deionised water*9/CH2: Tap water*1, Deionised water									
Set temperature range °C				CH1: 5 to 35/CH2: 10 to 40										
	Cooling capa	acity*2	kW	9	1* ⁸	19	1* ⁸	26	1* ⁸	37	1* ⁸			
	Heating capa	acity*3	kW	1.5	1	4.0	1	6.0	1	7.5	1			
	Temperature	stability*4	°C				CH1: ±0.1	/CH2: ±0.5						
E	Rated	flow (Outlet pressure)	l/min	45 (0.43 MPa)	10 (0.45 MPa)	45 (0.45 MPa)	10 (0.45 MPa)	125 (0.45 MPa)	10 (0.45 MPa)	125 (0.45 MPa)	10 (0.45 MPa)			
ste	Max	timum flow rate	l/min	120	16* ¹²	130	16* ¹²	180	16* ¹²	180	16* ¹²			
ŝ	Max Max	imum pump head	m	50	49	55	49	68	49	68	49			
<u>o</u>	Settable pres	ssure range*5	MPa	0.10 to 0.50	0.10 to 0.49	0.10 to 0.55	0.10 to 0.49	0.10 to 0.68	0.10 to 0.49	0.10 to 0.68	0.10 to 0.49			
μ	Minimum ope	rating flow rate*6	l/min	20	2	25	2	40	2	40	2			
g	Tank capacit	y * ¹⁴	L	42	7	42	7	60	7	60	12			
tin	Bypass circu	uit (With valve)		Installed										
lla	Electric conduc	ctivity setting range	μ S/cm	0.5 to 45* ⁹	0.5 to 45	0.5 to 45* ⁹	0.5 to 45	0.5 to 45* ⁹	0.5 to 45	0.5 to 45* ⁹	0.5 to 45			
2	Particle filter nomina	I filtration rating (Accessory) μ m	5	5	5	5	5	5	5	5			
ü	Circulating fluid or	utlet, circulating fluid ret	urn port*14	CH1: Rc1 (Symbol F: G1, Symbol N: NPT1)/CH2: Rc1/2 (Symbol F: G1/2, Symbol N: NPT1/2)										
	Tank drain p	ort* ¹⁴		CH1: Rc3/4 (Symbol F: G3/4, Symbol N: NPT3/4)/CH2: Rc1/2 (Symbol F: G1/2, Symbol N: NPT1/2)										
Fluid contact material				CH1: Stainles FKM, Io CH2: Stainles FKM, Io	s steel, Copper n replacement s steel, Alumin n replacement	r (Heat exchang resin ^{*9} a ceramic, Car resin, PA ^{*15}	ger brazing)* ¹⁰ bon, Fluorores	, Fluororesin, P in, PP, PBT, PO	P, PBT, POM, M, PU, PVC, F	PU, PC, PVC, E PS, AS, PS, E	EPDM, NBR, PDM, NBR,			
ystem	Power suppl	у		3-phase 460 to 4	3-phase 380 to 180 VAC (60 Hz) A	415 VAC (50/60 H Allowable voltage	lz) Allowable volta range +4 %, -10 %	ge range ±10 % (l 6 (Max. voltage les	No continuous vol ss than 500 V and	tage fluctuation) I no continuous vo	Itage fluctuation)			
S I	Earth leakage	Rated current	Α	2	0	3	0	4	0	4	0			
Ľ.	breaker	Sensitivity current	mA				3	0						
ect	Rated operation	ting current*4	Α	8	.5	1	5	1	9	2	.3			
Ξ	Rated power	consumption*4	kW (kVA)	5.6	(5.9)	9.4 (10.2)	12.3 ((13.0)	15.1	(16.0)			
Noi	se level (Front	1 m/Height 1 m)*4	dB (A)	7	5	7	5	7	1	7	1			
Ace	cessories			Operation Ma	nual (for install filter set	ation/operation for CH2, Anch	 i) 2 pcs. (Englistion of the provident of th	h 1 pc./Japane ackets 2 pcs. (i	se 1 pc.), Parti ncluding 6 M8	cle filter set for bolts)*7	CH1, Particle			
We	ight (dry state	e)*11	kg	Appro	x. 240	Appro	x. 260	Appro	x. 330	Appro	x. 380			

Use fluid in condition below as the circulating fluid.

Tap water: Standard of The Japan Refrigeration and Air Conditioning

Industry Association (JRA GL-02-1994) ① Ambient temperature: 32 °C, ② Circulating fluid: Tap water, ③ Circulating fluid temperature: CH1 20 °C/CH2 25 °C, ④ Circulating *2 fluid flow rate: Rated flow, ⑤ Power supply: 400 VAC In the case of option T2 or T3 "CH2 High-Pressure Pump Mounted", refer to pages 29 to 31.

- *3 ① Ambient temperature: 32 °C, ② Circulating fluid: Tap water
- 3 Circulating fluid flow rate: Rated flow, 4 Power supply: 400 VAC
 1 Ambient temperature: 32 °C, 2 Circulating fluid: Tap water,
 3 Circulating fluid temperature: CH1 20 °C/CH2 25 °C, 4 Load: Same as the cooling capacity, 5 Circulating fluid flow rate: Rated flow,
 6 Power supply: 400 VAC, 7 Piping length: Shortest *4
- *5 With the pressure control mode by inverter. If the pressure control mode is not necessary, use the flow control function or the pump output setting function.
- *6 Fluid flow rate to maintain the cooling capacity. If the actual flow rate is lower than this, adjust the bypass valve. In the case of option T2 or T3

"CH2 High-Pressure Pump Mounted", refer to pages 29 to 31.

- The anchor bolt fixing brackets (including 6 M8 bolts) are used for fixing to wooden skids when packaging the thermo-chiller. No anchor bolt is included.
- *8 Max. 1.5 kW. When 1.5 kW is applied, the cooling capacity of CH1 decreases by 0.5 kW.
- *9 For Option D1 (With electric conductivity control) only
- *10 Not included for Option D1 (With electric conductivity control)
 *11 The weight will increase by 1 kg when option "D1" (CH1, CH2 electric conductivity control) or option "T2" (CH2 high-pressure pump mounted) is selected. The weight will increase by 18 kg when option "T3" (CH2 high-pressure pump mounted) is selected for the HRL300, and 15 kg when it is selected for the HRL400.
- *12 The usable flow rate range is varied depending on the pump control mode. For details, refer to pump capacity curve on page 14. *13 In the case of option T2 or T3 "CH2 High-Pressure Pump Mounted",

refer to pages 29 to 31.

*14 In the case of option T3 "CH2 High-Pressure Pump Mounted", refer to page 31.
*15 Included in options "T2" and "T3" as well as the HRL400



Specifications

			HRL100	-W□-40	HRL200-	HRL200-W□-40					
	Wodel		CH1	CH2	CH2 CH1 CH2						
Co	olina method		Water-cooled refrigeration								
Ref	frigerant			B410A	B410A (HFC)						
Ref	frigerant charge	ka		1	8						
Co	ntrol method	Ng		PID control							
Δm	bient temperature	°C	2 to 45								
AII		U	CH1. Tan water*1 Deionised water*9/CH2. Tan water*1 Deionised water								
	Set temperature range	°C	CH15 to 25/CH2: 10 to 40								
	Set temperature range		10			4 + 8					
		KW	10	*0	21.5	*0					
		KW	1.5	1	4.0 1						
	Temperature stability**	°C		CH1: ±0.1/	CH2: ±0.5						
E	Pump Rated flow (Outlet press	sure) I/min	45 (0.43 MPa)	10 (0.45 MPa)	45 (0.45 MPa)	10 (0.45 MPa)					
ste	capacity ^{*13} Maximum flow ra	te l/min	120	16* ¹²	130	16* ¹²					
ŝ	Maximum pump h	ead m	50	49	55	49					
<u>o</u>	Settable pressure range*	⁵ MPa	0.10 to 0.50	0.10 to 0.49	0.10 to 0.55	0.10 to 0.49					
flu	Minimum operating flow rat	e ^{*6} l/min	20	2	25	2					
D D	Tank capacity	L	42	7	42	7					
tin	Bypass circuit (With valve	e)		Insta	lled						
ula	Electric conductivity setting ra	nge μS/cm	0.5 to 45*9	0.5 to 45	0.5 to 45* ⁹	0.5 to 45					
5	Particle filter nominal filtration rating (Acco	ssory) um	5	5	5	5					
ö	Circulating fluid outlet, circulating fluid retu	n port	CH1: Rc1 (Symbol	F: G1. Symbol N: NPT1)/CH	2: Rc1/2 (Symbol F: G1/2, S	wmbol N: NPT1/2)					
	Tank drain port	1	CH1: Rc3/4 (Symbol F	: G3/4. Symbol N: NPT3/4)/	CH2: Rc1/2 (Symbol F: G1/2	. Symbol N: NPT1/2)					
	•		CH1: Stainless steel Copp	er (Heat exchanger brazing)	*10 Eluororesin PP PBT PC	OM PU PC PVC EPDM					
			NBR Ion replacemen	t resin ^{*9}	, 1 10010100111, 1 1, 1 2 1, 1 0	ын, то, то, шо, шон,					
	Fluid contact material		2H2: Stainless steel Alumina ceramic Carbon, Eluororesin, PP PBT POM PU PVC PPS AS PS FPDM								
			NBR, lon replacement resin, PA*14								
٦	Temperature range	°C		5 to 35							
ster	Proceure range	MPa		0.3 to	0.5						
sys	Pequired flow rate	l/min	2	5.0 10	50.5						
ter	Inlet outlet pressure differential of facility	votor MBo	Z.	0.3 or		,					
wa	Facility water inlat/outlat	valei ivira		0.3 01	0.3 or more						
ity	Pacific water met/outlet		-	Rc1 (Symbol F: G1, Symbol N: NPT1)							
acil	Fort size		Otoista a staat	O							
ű	Fiuld contact material		Stainless steel,	Stainless steel, Copper (Heat exchanger brazing), Bronze, Brass, PTFE, NBR, EPDM							
em	Power supply		3-phase 380 to 415 VAC (50/60 Hz) Allowable voltage range ±10 % (No continuous voltage fluctuation)								
yst			3-phase 460 to 480 VAC (60 Hz) A	3-phase 460 to 480 VAC (60 Hz) Allowable voltage range +4 %, -10 % (Max. voltage less than 500 V and no continuous voltage fluctuation)							
als	Earth leakage Rated current	nt A		30)						
Ľ.	breaker Sensitivity cur	rent mA)						
lect	Rated operating current**	A	12	.7	13.	3					
ш	Rated power consumptio	n*4 kW (kVA)	7.9 (8.8)	8.6 (9	9.2)					
Noi	se level (Front 1 m/Height 1 n	n)*4 dB (A)		72	2						
Act	cessories		Operation Manual (for insta	allation/operation) 2 pcs. (En	glish 1 pc./Japanese 1 pc.),	Particle filter set for CH1,					
70			Particle filter s	et for CH2, Anchor bolt fixin	g brackets 2 pcs. (including 6	6 M8 bolts)* ⁷					
We	ight (dry state)*11	kg		Approx	<. 250						
*1 L	Jse fluid in condition below as	the circulating	g fluid.	than this, adjust th	ne bypass valve. In the case of	option T2 "CH2 High-					
Т	Tap water: Standard of The Jap	an Refrigerat	ion and Air Conditioning	Pressure Pump N	lounted", refer to page 29 and	30.					
ļ	ndustry Association (JRA GL-0	2-1994)		*7 The anchor bolt fix	ng brackets (including 6 M8 bolts	s) are used for fixing to					
*2 (1) Facility water temperature: 32 °C	(2) Circulating	luid: Tap water,	wooden skids where	packaging the thermo-chiller. N	o anchor bolt is included.					
(3) Circulating fluid temperature: CH	20 °C/CH2 25	°C, (4) Circulating fluid flow rate:	*8 Max. 1.5 KW. Whe	n 1.5 KW is applied, the cooling	capacity of CH1 decreases					
- F	the appa of ention T0 "CLIC Lists"		Mountad" rafer to page 20 and 20	Dy U.5 KVV.	ith alastria conductivity control						
"3 €	n me case or opnorr r≥ O⊓2 High-r 1) Facility water temperature: 3	2 °C 2 Circu	illating fluid: Tap water	*9 TOLOPIION DT (W *10 Not included for	Ontion D1 (With electric condu	ictivity control)					
	3) Circulating fluid flow rate: Ra	ted flow (4) F	Power supply: 400 VAC	*11 The weight will inc	crease by 1 kg when option D1 "V	Vith electrical conductivity					
*4 (1) Facility water temperature: 3	2 °C. ② Circi	lating fluid: Tap water.	control" and option	T2 "CH2 High-Pressure Pump I	Nounted" is selected.					
. (3) Circulating fluid temperature	: CH1 20 °C/0	CH2 25 °C, ④ Load: Same as	*12 The usable flow	rate range is varied depending	on the pump control mode.					
t	he cooling capacity, 5 Circula	ing fluid flow	rate: Rated flow,	For details, refer	to pump capacity curve on pa	ge 14.					
(6 Power supply: 400 VAC, ⑦ F	Piping length:	Shortest	*13 In the case of op	*13 In the case of option T2 "CH2 High-Pressure Pump Mounted", refer to						

page 29 and 30. *14 Included in option "T2"

SMC

the cooling capacity, 5 Circulating fluid flow rate: Rated flow, 6 Power supply: 400 VAC, 7 Piping length: Shortest

*5 With the pressure control mode by inverter. If the pressure control mode is not necessary, use the flow control function or the pump output setting function.

*6 Fluid flow rate to maintain the cooling capacity. If the actual flow rate is lower

11

Cooling Capacity

*1 This is the cooling capacity of the CH1 side when 1 kw heat load is applied to the CH2 side. *2 Max. 1.5 kW. When 1.5 kW is applied, the cooling capacity of CH1 decreases by 0.5 kW.

HRL100-A□-20 (CH1)*1







HRL200-A -20 (CH1)*1







HRL Series Dual Channel Thermo-chiller for Lasers

Cooling Capacity

*1 This is the cooling capacity of the CH1 side when 1 kw heat load is applied to the CH2 side.
 *2 Max. 1.5 kW. When 1.5 kW is applied, the cooling capacity of CH1 decreases by 0.5 kW.





HRL200-A -40 (CH1)*1



HRL300-A□-40 (CH1)*1



HRL400-A□-40 (CH1)*1



HRL100-W□-40 (CH1)*1







HRL100/200/300/400-A/W□-40 (CH2)*2



Pump Capacity



HRL300-A -20 (CH1)



HRL100-A/W□-40 (CH1)



HRL300/400-A -40 (CH1)









HRL200-A/W -40 (CH1)



HRL100/200/300/400-A/W□-40 (CH2)



HRL Series Dual Channel Thermo-chiller for Lasers

Dimensions

HRL100-A□-20



Anchor bolt mounting position (View A)



Dimensions

HRL100-A□-40



Anchor bolt mounting position (View A)



HRL Series Dual Channel Thermo-chiller for Lasers

Dimensions

HRL200-A□-20



Anchor bolt mounting position (View A)









Thermo-chiller Dual Channel Thermo-chiller for Lasers HRL Series

Dimensions

HRL200-A□-40



Anchor bolt mounting position (View A)



HRL Series Dual Channel Thermo-chiller for Lasers

Dimensions

HRL300-A□-20



Anchor bolt mounting position (View A)









Dimensions

HRL300-A□-40



Anchor bolt mounting position (View A)



Ventilation air inlet

HRL Series Dual Channel Thermo-chiller for Lasers

Dimensions

HRL400-A□-40



Anchor bolt mounting position (View A)









Dimensions

HRL100/200-W□-40

Anchor bolt mounting position (View A)











For piping port sizes, refer to the "Parts Description" on page 22.

Parts Description



*1 When connecting a particle filter, the port size will be Rc1/2.*2

 $\ast 2\;$ For option "T3," the piping size varies. For details, refer to page 31.



Water-cooled refrigeration

Recommended External Piping Flow



External piping circuit is recommended as shown below.

No.	Description	Size	Recommended part no.	Note
1	Particle filter	Rc1 (5 μm)	Accessory	The value in () shows the nominal filtration accuracy.
2	Valve	Rc1		—
3	Flow meter	Rc1	—	Prepare a flow meter with an appropriate flow range.
4	Particle filter	Rc1/2 (5 μm)* ¹	Accessory	The value in () shows the nominal filtration accuracy.
5	Valve	Rc1/2*1	—	—
6	Pressure gauge	0 to 1.0 MPa	—	—
7	Y-strainer	Rc1 #40	HRS-S0212	Install either the strainer or filter. If foreign matter with a size of 20 μ m or more are likely to enter install the particle filter. For the
1	Filter	Rc1 (20 μm)	Refer to the table below	recommended filter, refer to the table below (*1).

*1 For Option "T3" (CH2 High-pressure pump mounted), the port size is Rc3/4.

*1 Recommended filters for facility water inlet

Applicable model	Recommended filter
HRL100	FQ1012N-10-T020-B-X61
HRL200	FGESA-10-T020A-G2

*2 The filter shown above cannot be directly connected to the thermo-chiller. Install it in the user's piping system.

Cable Specifications

Power Supply Cable and Earth Leakage Breaker (Recommended)

	Device eventhe velte ee	Terminal	Recommended		Earth leakage breaker	
Model	Power supply voltage	block screw	crimped	Cable specifications	Breaker size	Sensitivity current
	specifications	diameter	terminal		[A]	[mA]
HRL100-A□-20	3-phase 200 VAC (50 Hz)		R5.5-5	4 cores x 5.5 mm ² (4 cores x AWG 10) including grounding cable	30	
HRL200-A□-20	3-phase 200 to 230 VAC (60 Hz)		R8-5	4 cores x 8 mm ² (4 cores x AWG 8) including grounding cable	40	
HRL300-A□-20					50	
HRL100-A□-40		M5		4	20	30
HRL200-A□-40			R5.5-5	4 cores x 5.5 mm ² (4 cores x AVVG TU)	20	
HRL100/200-W□-40	3-phase 380 to 415 VAC (50/60 Hz)					
HRL300-A□-40 HRL400-A□-40	3-priase 400 to 430 VAC (00 HZ)		R8-5	4 cores x 8 mm ² (4 cores x AWG 8) including grounding cable	40	

* An example of the cable specifications is when two kinds of vinyl insulated wires with a continuous allowable operating temperature of 70 °C at 600 V, are used at an ambient temperature of 30 °C. Select the proper size of cable according to an actual condition.



Operation Display Panel

Items displayed on the home screen and setting items are shown in List of check items in inspection monitor menu.



List of Check Items in Inspection Monitor Menu

No.	CH no.	Item	Explanation		
1	Common	Menu key	Touch the key to display the menu.		
2	Common	Date and time display	Displays the date and time. Press the numeric section to set the date and time.		
3		Operating condition display	Displays TEMP READY status. Displays the control status of the circulating fluid pressure.		
4		Circulating fluid present temperature	Displays the current temperature of circulating fluid.		
5		Circulating fluid set temperature	It indicates the set temperature. Press the numeric section to change the set temperature		
6	CH1	Circulating fluid discharge pressure	It indicates the discharge pressure.		
7	Circulating fluid flow rate		It indicates the fluid flow rate. This value is not measured by a flow meter. It should be used as a reference value (rough indication). It includes the flow rate in the bypass circuit.		
8		Circulating fluid electric conductivity	It indicates the electric conductivity.*1		
9		Operating condition display	Displays TEMP READY status. Displays the control status of the circulating fluid pressure.		
10		Circulating fluid present temperature	Displays the circulating fluid temperature.		
11	040	Circulating fluid set temperature	It indicates the set temperature. Press the numeric section to change the set temperature.		
12		Circulating fluid discharge pressure	It indicates the discharge pressure.		
13		Circulating fluid flow rate	It indicates the flow rate measured by a flow meter. It does not include the flow rate in the bypass circuit.		
14		Circulating fluid electric conductivity	It indicates the electric conductivity.		
15	CH1	Independent pump operation	CH1 pump operates independently while the button is pressed.		
16	CH2	Independent pump operation	CH2 pump operates independently while the button is pressed.		
17	Common	Operation mode	o select a operation mode from the touch panel (LDCAL mode), contact input (DD mode), serial communication (SERIAL mode), or Ethernet communication (Ethernet mode).		
18		Operating condition display It indicates the run and stop status of the product.			
19		Run/Stop	To run/stop the product		

*1 Displayed for Option D1 (CH1 With electric conductivity control)

Alarm

This unit displays 39 types of alarms.

Alarm No.	Indication	Explanation
AL01	CH1 Low Level FLT	CH1 abnormal low tank fluid level
AL02	CH1 Low Level WRN	CH1 low tank fluid level
AL03	CH2 Low Level FLT	CH2 abnormal low tank fluid level
AL04	CH2 Low Level WRN	CH2 low tank fluid level
AL06	Fan Inverter	Fan failure
AL09	CH1 High Temp. FLT	CH1 abnormal rise of circulating fluid temperature
AL10	CH1 High Temp.	CH1 circulating fluid temperature rise
AL11	CH1 Low Temp.	CH1 circulating fluid temperature drop
AL12	CH1 TEMP READY Alarm	CH1 TEMP READY alarm
AL13	CH2 High Temp. FLT	CH2 abnormal rise in circulating fluid temperature
AL14	CH2 High Temp.	CH2 circulating fluid temperature rise
AL15	CH2 Low Temp.	CH2 circulating fluid temperature drop
AL16	CH2 TEMP READY Alarm	CH2 TEMP READY alarm
AL17	CH1 HX In High Temp. FLT	CH1 abnormal rise in heat exchanger inlet temperature
AL18	CH1 Press. Sensor	CH1 failure of circulating fluid discharge pressure sensor
AL19	CH1 High Press.	CH1 circulating fluid discharge pressure rise
AL20	CH1 Low Press.	CH1 circulating fluid discharge pressure drop
AL21	CH2 Press. Sensor	CH2 failure of circulating fluid discharge pressure sensor
AL22	CH2 High Press. Error	CH2 abnormal rise in circulating fluid discharge pressure
AL23	CH2 High Press.	CH2 circulating fluid discharge pressure rise

Alarm No.	Indication	Explanation
AL24	CH2 Low Press.	CH2 circulating fluid discharge pressure drop
AL25	CH2 Low Press. Error	CH2 abnormal drop in circulating fluid discharge pressure
AL26	CH2 Flow Sensor	CH2 failure of circulating fluid discharge flow sensor
AL27	CH2 High Electric Conductivity	CH2 electric conductivity increase
AL28	CH1 High Electric Conductivity	CH2 electric conductivity increase (Option D1 only)
AL30	Digital Input 1	Contact input 1 signal detection
AL31	Digital Input 2	Contact input 2 signal detection
AL33	CH2 Low Flow FLT	CH2 abnormal drop in circulating fluid flow rate
AL34	Communication	Communication error
AL35	Ambient Temp.	Outside of the ambient temperature range
AL36	Maintenance	Maintenance alarm
AL37	Refrigeration Circuit	Compressor circuit failure
AL38	Sensor	Sensor failure
AL39	Controller	Controller failure
AL40	Compressor Inverter	Compressor inverter error
AL41	Compressor Inverter Comm.	Compressor inverter communication error
AL42	CH1 Pump Inverter	CH1 pump inverter error
AL43	CH1 Pump Inverter Comm.	CH1 pump inverter communication error
AL44	CH2 Pump Inverter	CH2 pump inverter error
AL45	CH2 Pump Inverter Comm.	CH2 pump inverter communication error



HRL Series Dual Channel Thermo-chiller for Lasers

Communication Functions



*1 Make sure that the total load current is 800 mA or less. When using the power supply of this product, make sure that the total load current is 200 mA or less.

Communication Functions

Contact Input/Output, Analogue Output Pin Nos.

Pin no.	Application	Division	Default setting
1	24 VDC output	Output	
2	24 VDC input	Input	_
3	Contact input signal 1	Input	Run/Stop*1
4	Contact input signal 3	Input	Operation mode request signal (fix)*2
5	Contact output signal 6	Output	OFF*1
6	Contact output signal 1	Output	Run status signal [N.O. type] (fix)*2
7	Contact output signal 3	Output	Operation continuation "WRN" alarm signal [N.C. type] (fix)*2
8	Contact output signal 5	Output	OFF*1
9	None	_	Cannot be connected*3
10	Analogue output signal 2	Output	CH2 electric conductivity*1
11	Analogue output signal 1	Output	CH2 circulating fluid temperature*1
12	None	—	Cannot be connected*3
13	None	—	Cannot be connected*3
14	24 COM output (Common of contact input signal)	Output	—
15	Common of contact output signal 1, 2, 3, 4, 5	Output	_
16	Contact input signal 2	Input	External switch signal*1
17	None	—	Cannot be connected*3
18	Common of contact output signal 6	Output	_
19	Contact output signal 2	Output	Operation stop "FLT" alarm signal [N.C. type] (fix)*2
20	Contact output signal 4	Output	OFF*1
21	None	—	Cannot be connected*3
22	Common of analog output signal 2	Output	_
23	Common of analog output signal 1	Output	
24	None	—	Cannot be connected*3
25	None	—	Cannot be connected*3

*1 It is possible to change the setting.

*2 It is not possible to change the setting. ("N.O. type/N.C. type" can be changed.)

*3 Do not connect wiring.



Communication Functions

Serial Communication

The following operations can be performed by the serial communication RS-232C/RS-485.

Writing	Bodout
winning	neadoul
To run/stop the product	To readout the circulating fluid temperature, pressure, flow rate and electrical conductivity (CH1*1)
To change the set value of	To readout the circulating fluid temperature, pressure, flow rate and electrical conductivity (CH2)
circulating fluid temperature	To readout the status of respective parts of the product (e.g., operation status and content of alarm)
L	*1 For Option D1 (CH1 With electric conductivity control)

Wiring of Interface Cable for Serial Communication





Communication Functions

Ethernet Modbus/TCP Communication

The following operations can be performed by the Ethernet Modbus/TCP communication.

Writing	Beadout
winning	neadout
To run/stop the product	To readout the circulating fluid temperature, pressure, flow rate and electrical conductivity (CH1*1)
To change the set value of	To readout the circulating fluid temperature, pressure, flow rate and electrical conductivity (CH2)
circulating fluid temperature	To readout the status of respective parts of the product (e.g., operation status and content of alarm)
	To readout the product model and serial number

*1 For Option D1 (CH1 With electric conductivity control)

Communication Cable Wiring for Ethernet Modbus/TCP Communication





Optional Accessories

Consumables List

Part no.	Description	Qty.	Note
HRS-S0213	Dustproof filter (Lower)	1	For HRL200-A: 2 pcs. are used per unit.
HRS-S0214	Dustproof filter (Upper)	1	For HRL100/200-A: 2 pcs. are used per unit.
HRS-S0185	Dustproof filter	1	For HRL300-A: 4 pcs. are used per unit.
HRS-S0153	Dustproof filter	1	For HRL400-A: 4 pcs. are used per unit.
HRS-PF006	Particle filter element	1	Common to each model: For CH1
EJ202S-005X11	Particle filter element	1	Common to each model: For CH2 (Except option-T3)
EJ302S-005X11	Particle filter element	1	For option-T3: For CH2
HRR-DF001	DI filter replacement cartridge	1	Common to each model: For CH2
HRR-DF002	DI filter replacement cartridge	1	Common to each model: For CH1 Option D1 only

HRL Series Options

 Options have to be selected when ordering the thermo-chiller.
 It is not possible to add them after purchasing the unit.

D1 Option symbol

CH1, CH2 Electric Conductivity Control

CH1, CH2 Electric conductivity control

• For the standard model, only CH2 has electric conductivity control. However, if option "D1" is selected, CH1 also has electric conductivity control. • Contact material of the circulating fluid circuit is made from non-copper materials.

Option symbol

	CH2 Hig	h-Pressure	Pump Mount	ed
-				

CH2 High-pressure pump mounted

Possible to choose a high-pressure pump in accordance with user's piping resistance Total cooling capacity of CH1 and CH2 will decrease by heat generated in the pump.

Applicable model		HRL□-A/W□-40-T2		
		CH1	CH2	
	Rated flow rate (Outlet)	l/min	Same as standard product	20 (0.45 MPa)
Pump	Maximum flow rate	l/min	Same as standard product	30
	Maximum pump head m		Same as standard product	Same as standard product
Minimum operating flow rate I/min		l/min	Same as standard product	5
Tank capacity L		Same as standard product	Same as standard product	
Cooling capacity W		It differs from the standard cooling capacity. Refer to the table below for the details.		

Pump Capacity

HRL□-A/W□-40-T2



T2

CH2 High-Pressure Pump Mounted

Cooling Capacity





HRL300-A□-40-T2 (CH1)*1



HRL100-W□-40-T2 (CH1)*1



HRL400-A -40-T2 (CH1)*1





HRL□-A/W□-40-T2 (CH2)*2







- *1 This is the cooling capacity of the CH1 side when 1 kW heat load is applied to the CH2 side.
- *2 Up to 3.0 kW. However, when 3.0 kW heat load is applied, the cooling capacity of CH1 will decrease by 2.0 kW.



HRL Series Dual Channel Thermo-chiller for Lasers

T3 Option symbol CH2 High-Pressure Pump Mounted

-40-T3

• CH2 High-pressure pump mounted

Possible to choose a high-pressure pump in accordance with user's piping resistance Total cooling capacity of CH1 and CH2 will decrease by heat generated in the pump.

- \cdot The CH2 pump used for option T3 uses a mechanical seal.
- We will inform you of the inspection time in the maintenance notice. Please contact to service center to ask for maintenance of the pump and mechanical seal.

Applicable model		HRL300-A□-40-T3		HRL400-A□-40-T3		
		CH1	CH2	CH1	CH2	
	Rated flow rate (Outlet)	l/min	Same as standard product	38 (0.45 MPa)	Same as standard product	38 (0.45 MPa
Pump	Maximum flow rate	l/min	Same as standard product	60	Same as standard product	60
	Maximum pump head	m	Same as standard product	49	Same as standard product	49
Minimum operating flow rate I/mir		l/min	Same as standard product	10	Same as standard product	10
Tank capacity L		L	Same as standard product	12	Same as standard product	Same as standard produ
Cooling capacity W		There is a cooling capacity decrease of approx. 2 kW compar with the standard model. Refer to the table below for the deta			2 kW compared v for the details	

Port Layout (CH2)



^{*} CH1 port layout unchanged.

Pump Capacity

HRL300

HRL300-A -40-T3 (CH2)



Cooling Capacity

HRL300-A -40-T3 (CH1)*1



Cooling Capacity



*1 This is the cooling capacity of the CH1 side when 1 kW heat load is applied to the CH2 side.

*2 Up to 5.0 kW. However, when 5.0 kW heat load is applied, the cooling capacity of CH1 will decrease by 4.0 kW.





HRL Series Cooling Capacity Calculation

Required Cooling Capacity Calculation



Laser output power 6 [kW], conversion efficiency 30 % The oscillator's power consumption is, 6 [kW] ÷ 0.3 = 20 [kW] The cooling capacity required for the oscillator is 20 [kW] - 6 [kW] = 14 [kW]Considering a safety factor of 20 %, 14 $[kW] \times 1.2 = 16.8 [kW]$

Example 2: When the heat generation amount in the user's equipment is not known.

Obtain the temperature difference between inlet and outlet by circulating the circulating fluid inside the user's equipment.

Heat generation amount by user's equipment Q	: Unknown [W] ([J/s])
Circulating fluid	: Tap water*1
Circulating fluid mass flow rate qm	: (= ρ x qv ÷ 60) [kg/s]
Circulating fluid density ρ	: 1 [kg/L]
Circulating fluid (volume) flow rate qv	: 70 [l/min]
Circulating fluid specific heat C	: 4.186 x 10 ³ [J/(kg·K)]
Circulating fluid outlet temperature T1	: 293 [K] (20 [°C])
Circulating fluid return temperature T2	: 297 [K] (24 [°C])
Circulating fluid temperature difference ΛT	: 4 [K] (= T 2 – T 1)
Conversion factor: minutes to seconds (SI units)	: 60 [s/min]

*1 Refer to page 34 for the typical physical property value of tap water or other circulating fluids.

Q = qm x C x (T₂−T₁)
=
$$\frac{\rho x qv x C x \land T}{60}$$
 = $\frac{1 x 70 x 4.186 x 10^3 x 4.0}{60}$
= 19535 [J/s] ≈ 19535 [W] = 19.5 [kW]

Cooling capacity = Considering a safety factor of 20 %,



Example of conventional units (Reference) Heat generation amount by user's equipment \mathbf{Q} : Unknown [cal/h] \rightarrow [W] Circulating fluid : Tap water*1 Circulating fluid weight flow rate **qm** : (= $\rho \times qv \times 60$) [kgf/h] Circulating fluid weight volume ratio Y: 1 [kgf/L] Circulating fluid (volume) flow rate **qv** : 70 [l/min] Circulating fluid specific heat C : 1.0 x 10³ [cal/(kgf·°C)] Circulating fluid outlet temperature T1: 20 [°C] Circulating fluid return temperature T2: 24 [°C] Circulating fluid temperature difference ΛT : 4 [°C] (= T₂ - T₁) Conversion factor: hours to minutes : 60 [min/h] Conversion factor: kcal/h to kW :860 [(cal/h)/W] $Q = \frac{qm \ x \ C \ x \ (T_2 - T_1)}{qm \ x \ C \ x \ (T_2 - T_1)}$ 860 Υ **x qv x 60 x C x** Λ**T** 860 1 x 70 x 60 x 1.0 x 10³ x 4.0 860 16800000 [cal/h] 860 ≈ 19534 [W] = 19.5 [kW] Cooling capacity = Considering a safety factor of 20 %, 19.5 [kW] x 1.2 = 23.4 [kW]

Required Cooling Capacity Calculation

Example 3: When there is no heat generation, and when cooling the object below a certain temperature and period of time.

Heat quantity by cooled substance (per unit time) Q	: Unknown [W] ([J/s])
Cooled substance	: Water
Cooled substance mass m	: (= ρ x V) [kg]
Cooled substance density ρ	: 1 [kg/L]
Cooled substance total volume V	: 250 [L]
Cooled substance specific heat C	: 4.186 x 10 ³ [J/(kg·K)]
Cooled substance temperature when cooling begins Te	o : 305 [K] (32 [°C])
Cooled substance temperature after t hour Tt	: 293 [K] (20 [°C])
Cooling temperature difference ΛT	: 12 [K] (= T 0 – T t)
Cooling time At	: 900 [s] (= 15 [min])

* Refer to the following for the typical physical property values by circulating fluid.





Example of conventional units (Reference)
Heat quantity by cooled substance (per unit time) \mathbf{Q} : Unknown [cal/h] \rightarrow [W]
Cooled substance : Water
Cooled substance weight m : (= $\rho \times V$) [kgf]
Cooled substance weight volume ratio Y : 1 [kgf/L]
Cooled substance total volume V : 250 [L]
Cooled substance specific heat C : $1.0 \times 10^3 \text{ [cal/(kgf \cdot ^C)]}$
Cooled substance temperature when cooling begins To: 32 [°C]
Cooled substance temperature after t hour Tt : 20 [°C]
Cooling temperature difference ΛT : 12 [°C] (= To - Tt)
Cooling time Λt : 15 [min]
Conversion factor: hours to minutes : 60 [min/h]
Conversion factor: kcal/h to kW : 860 [(cal/h)/W]
$\mathbf{Q} = \frac{\mathbf{m} \mathbf{x} \mathbf{C} \mathbf{x} (\mathbf{T}_0 - \mathbf{T}_t)}{\Delta t \mathbf{x} \mathbf{x} 860} = \frac{\mathbf{Y} \mathbf{x} \mathbf{V} \mathbf{x} 60 \mathbf{x} \mathbf{C} \mathbf{x} \Delta \mathbf{T}}{\Delta t \mathbf{x} 860}$
<u>1 x 250 x 60 x 1.0 x 10³ x 12</u>
– 15 x 860
≈ 13953 [W] = 14.0 [kW]
Cooling capacity = Considering a safety factor of 20 $\%$,
14.0 [kW] x 1.2 = 16.8 [kW]

* This is the calculated value by changing the fluid temperature only. Thus, it varies substantially depending on the water bath or piping shape.

Precautions on Cooling Capacity Calculation

1. Heating capacity

When the circulating fluid temperature is set above room temperature, it needs to be heated by the thermo-chiller. The heating capacity depends on the circulating fluid temperature. Consider the radiation rate and heat capacity of the user's equipment and check beforehand if the required heating capacity is provided.

2. Pump capacity

<Circulating fluid flow rate>

Circulating fluid flow rate varies depending on the circulating fluid discharge pressure. Consider the installation height difference between the thermo-chiller and the user's equipment, and the piping resistance such as circulating fluid pipings, or piping size, or piping curves in the machine. Check beforehand if the required flow is achieved, using the pump capacity curves.

<Circulating fluid discharge pressure>

Circulating fluid discharge pressure has the possibility to increase up to the maximum pressure in the pump capacity curves. Check beforehand if the circulating fluid pipings or circulating fluid circuit of the user's equipment are fully durable against this pressure.

Circulating Fluid Typical Physical Property Values

- 1. This catalogue uses the following values for density and specific heat in calculating the required cooling capacity. Density ρ : 1 [kg/L] (or, using conventional units, weight volume ratio Y = 1 [kgf/L])
 - Specific heat C: 4.19 x 10³ [J/(kg·K)] (or, using conventional units, 1 x 10³ [cal/(kg·°C)])

2. Values for density and specific heat change slightly according to temperature shown below. Use this as a reference.

ſ	Physical property	Density ρ	Specific heat C	Conventio	onal units	
ŀ	Temperature	[kg/L]	[J/(kg·K)]	Weight volume ratio Y [kgf/L]	Specific heat C [cal/(kgf.°C)]	
	5 °C	1.00	4.2 x 10 ³	1.00	1 x 10 ³	
ſ	10 °C	1.00	4.19 x 10 ³	1.00	1 x 10 ³	
ſ	15 °C	1.00	4.19 x 10 ³	1.00	1 x 10 ³	
ſ	20 °C	1.00	4.18 x 10 ³	1.00	1 x 10 ³	
ſ	25 °C	1.00	4.18 x 10 ³	1.00	1 x 10 ³	
ſ	30 °C	1.00	4.18 x 10 ³	1.00	1 x 10 ³	
ſ	35 °C	0.99	4.18 x 10 ³	0.99	1 x 10 ³	
Ī	40 °C	0 99	118×10^{3}	0.99	1×10^3	



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For temperature control equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smc.eu

Design

\land Warning

1. This catalogue shows the specifications of a single unit.

- 1) Check the specifications of the single unit (contents of this catalogue) and thoroughly consider the adaptability between the user's system and this unit.
- 2) Although the protection circuit as a single unit is installed, prepare a drain pan, water leakage sensor, discharge air facility, and emergency stop equipment, depending on the user's operating condition. Also, the user is requested to carry out the safety design for the whole system.

2. When attempting to cool areas that are open to the atmosphere (tanks, pipes), plan your piping system accordingly.

When cooling open-air external tanks, arrange the piping so that there are coil pipes for cooling inside the tanks, and to carry back the entire flow volume of circulating fluid that is released.

3. Use non-corrosive material for fluid contact parts of circulating fluid.

Using corrosive materials such as aluminium or iron for fluid contact parts such as piping may cause clogging or leakage in the circulating fluid circuit. Provide protection against corrosion when you use the product.

Selection

🕂 Warning

Model selection

For selecting a model of thermo-chiller, it is required to know the heat generation amount of the user's equipment. Obtain the heat generation amount, referring to the "Cooling Capacity Calculation" on pages 33 and 34 before selecting a model.

Handling

\land Warning

Thoroughly read the Operation Manual.

Read the Operation Manual completely before operation, and keep this manual where it can be referred to as necessary.

Operating Environment/Storage Environment

A Warning

- 1. Do not use in the following environment as it will lead to a breakdown.
 - 1) In locations where water vapour, salt water, and oil may splash on the product
 - 2) In locations where there are dust and particles
 - 3) In locations where corrosive gases, organic solvents, chemical fluids, or flammable gases are present (This product is not explosion proof.)
 - 4) In locations where the ambient temperature exceeds the limits as mentioned below

During transportation/storage: -15 °C to 50 °C (But as long as water or circulating fluid

are not left inside the pipings)

During operation (Air-cooled type): 2 °C to 45 °C

- 5) In locations where condensation may occur
- 6) In locations which receive direct sunlight or radiated heat
- 7) In locations where there is a heat source nearby and the ventilation is poor
- 8) In locations where temperature substantially changes
- In locations where strong magnetic noise occurs (In locations where strong electric fields, strong magnetic fields, and surge voltage occur)
- 10) In locations where static electricity occurs, or conditions which make the product discharge static electricity
- 11) In locations where high frequency occurs
- 12) In locations where damage is likely to occur due to lightning
- In locations at altitude of 3000 m or higher (Except during storage and transportation)
 - * For altitude of 1000 m or higher Because of lower air density, the heat radiation efficiencies of the devices in the product will be lower in the location at altitude of 1000 m or higher. Therefore, the maximum ambient temperature to use and the cooling capacity will lower according to the descriptions in the table below.
 - Select the thermo-chiller considering the descriptions. ① Upper limit of ambient temperature: Use the product in ambient
 - temperature of the described value or lower at each altitude.
 - ② Cooling capacity coefficient: The product's cooling capacity will lower to one that multiplied by the described value at each altitude.

Altitude [m]	① Upper limit of ambient temperature [°C]	② Cooling capacity coefficient
Less than 1000 m	45	1.00
Less than 1500 m	42	0.85
Less than 2000 m	38	0.80
Less than 2500 m	35	0.75
Less than 3000 m	32	0.70

- 14) In locations where strong impacts or vibrations occur
- 15) In locations where a massive force strong enough to deform the product is applied or the weight from a heavy object is applied
- 16) In locations where there is not sufficient space for maintenance
- 17) Insects or plants may enter the unit
- 2. The product is not designed for clean room usage. It generates particles internally.



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For temperature control equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smc.eu

Transportation/Carriage/Movement

\land Warning

1. This product will require an acceptance with the product not unloaded from the truck, and the user will need to unload the product by himself. Prepare a forklift.

The product will be delivered in the packaging shown below.



Forklift insertion side

Weights and Dimensions When Packaged

Model	Weight [kg]	Dimensions [mm]	
HRL100-A□-20	300	Height 2020 x Width 1200 x Depth 802	
HRL200-A□-20	327	Height 2020 X Width 1200 X Depth 893	
HRL300-A -20	414	Height 2120 x Width 1400 x Depth 1060	

2. Transporting with forklift

- 1) A licensed driver should drive the forklift.
- 2) The proper place to insert the tines of the forklift differs depending on the model of cooler. Check the insert position, and be sure to drive the fork in far enough for it to come out the other side.
- 3) Be careful not to bump the fork to the cover panel or piping ports.

Transportation/Carriage/Movement

\land Warning

3. Hanging transportation

- 1) Crane manipulation and slinging work should be done by an eligible person.
- 2) Do not grip the piping on the right side or the handles of the panel.
- 3) When hanging by the eye bolts, be sure to use a 4-point hanging method. For the hanging angle, use caution regarding the position of the centre of gravity and hold it within 60°.



Forklift insertion side

HRL200-A-20

4. Transporting with casters

- 1) This product is heavy and should be moved by at least two people.
- Do not grip the piping port on the right side or the handles of the panel.
- 3) When transporting using a forklift, be sure not to let it hit the casters or adjusters, and drive the fork all the way through until it comes out the other side.
- 4) Do not get across steps with casters.

Mounting/Installation

A Warning

Do not place heavy objects on top of this product, or step on it.

The external panel can be deformed and danger can result.

▲ Caution

- 1 . Install on a rigid floor which can withstand this product's weight.
- 2. Secure with bolts, anchor bolts, etc.



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For temperature control equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smc.eu

Mounting/Installation

A Caution

3. Refer to the Operation Manual for this product, and secure an installation space that is necessary for the maintenance and ventilation.

<Air-cooled refrigeration>

- 1. The air-cooled type product exhausts heat using the fan that is mounted to the product. If the product is operated with insufficient ventilation, ambient temperature may exceed 45 °C, and this will affect the performance and life of the product. To prevent this ensure that suitable ventilation is available (see below).
- 2. For installation indoors, ventilation ports and a ventilation fan should be equipped as needed.





3. If it is impossible to exhaust heat from the installation area indoors, or when the installation area is conditioned, provide a duct for heat exhaustion to the air outlet port of this product for ventilation. Do not mount the inlet of the duct (flange) directly to the air vent of the product, and keep a space larger than the diameter of the duct. Additionally, consider the resistance of the duct when making the air vent port for the duct.

<heat radiatior<="" th=""><th>amount/Required</th><th>ventilation</th><th>rate></th></heat>	amount/Required	ventilation	rate>
--	-----------------	-------------	-------

	Heat	Required ventilation rate [m ³ /min]		
Model	radiation amount [kW]	Differential temp. of 3°C between inside and outside of installation area	Differential temp. of 6°C between inside and outside of installation area	
HRL100-A□-□	Approx. 18	305	155	
HRL200-A□-□	Approx. 35	590	295	
HRL300-A	Approx. 45	760	380	

Piping

▲ Caution

1. Regarding the circulating fluid piping, consider carefully the suitability for temperature and circulating fluid.

If the operating performance is not sufficient, the pipings may burst during operation. Also, the use of corrosive materials such as aluminium or iron for fluid contact parts, such as piping, may not only lead to clogging or leakage in the circulating fluid circuit but also refrigerant leakage and other unexpected problems. Provide protection against corrosion when you use the product.

2. Select the piping port size which can exceed the rated flow.

For the rated flow, refer to the pump capacity table.

- 3. When tightening at the drain port of this product, use a pipe wrench to clamp the connection ports.
- 4. For the circulating fluid piping connection, install a drain pan and wastewater collection pit just in case the circulating fluid may leak.
- 5. This product series are constant-temperature fluid circulating machines with built-in tanks.

Do not install equipment on your system side such as pumps that forcibly return the circulating fluid to the unit. Also, if you attach an external tank that is open to the air, it may become impossible to circulate the circulating fluid. Proceed with caution.



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For temperature control equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smc.eu

Electrical Wiring

\land Warning

Grounding should never be connected to a water line, gas line or lightning rod.

A Caution

- 1. Power supply and communication cables should be prepared by user.
- 2. Provide a stable power supply which is not affected by surge or distortion.





3. This product is installed with a breaker with the following operating characteristics.

For the user's equipment (on the upstream side), use a breaker whose operating time is equal to or longer than the breaker of this product. If a breaker with shorter operating time is connected, the user's equipment could be cut off due to the inrush current of the motor of this product.



Circulating Fluid

▲ Caution

- 1 . Avoid oil or other foreign matter entering the circulating fluid.
- 2 . When water is used as a circulating fluid, use tap water that conforms to the appropriate water quality standards.

Use tap water that conforms to the standards shown below (including water used for dilution of ethylene glycol aqueous solution).

Tap Water (as Circulating Fluid) Quality Standards

The Japan Refrigeration and Air Conditioning Industry Association JRA GL-02-1994 "Cooling water system – Circulation type – Make-up water"

				Influence	
	Item	Unit	Standard value	Corrosion	Scale generation
	pH (at 25 °C)	—	6.0 to 8.0	0	0
E	Electric conductivity (25 °C)	[µS/cm]	100* ¹ to 300* ¹	0	0
ite	Chloride ion (Cl⁻)	[mg/L]	50 or less	0	
P	Sulfuric acid ion (SO ₄ ²⁻)	[mg/L]	50 or less	0	
da	Acid consumption amount (at pH4.8)	[mg/L]	50 or less		0
an	Total hardness	[mg/L]	70 or less		0
St	Calcium hardness (CaCO ₃)	[mg/L]	50 or less		0
	Ionic state silica (SiO ₂)	[mg/L]	30 or less		0
Е	Iron (Fe)	[mg/L]	0.3 or less	0	0
ite	Copper (Cu)	[mg/L]	0.1 or less	0	
Ce	Sulfide ion (S ₂ ⁻)	[mg/L]	Should not be detected.	0	
Len	Ammonium ion (NH4+)	[mg/L]	0.1 or less	0	
efe	Residual chlorine (Cl)	[mg/L]	0.3 or less	Ó	
ŭ	Free carbon (CO ₂)	[mg/L]	4.0 or less	0	

*1 In the case of [M Ω ·cm], it will be 0.003 to 0.01.

- O: Factors that have an effect on corrosion or scale generation.
- Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.
- When deionised water is used, the electric conductivity should be 1 μS/cm or higher (Electric resistivity: 1 MΩ·cm or lower).

Operation

\land Warning

1. Confirmation before operation

1) The fluid level of a tank should be within the specified range of "HIGH" and "LOW."

When exceeding the specified level, the circulating fluid will overflow.

2) Remove the air.

Conduct a trial operation, looking at the fluid level. Since the fluid level will go down when the air is removed from the user's piping system, supply water once again when the fluid level is reduced. When there is no reduction in the fluid level, the job of removing the air is completed. Pump can be operated independently.

2. Confirmation during operation

Check the circulating fluid temperature.

The operating temperature range of the circulating fluid is between 15 and 25 $^\circ \text{C}.$

When the amount of heat generated from the user's equipment is greater than the product's capability, the circulating fluid temperature may exceed this range. Use caution regarding this matter.

3. Emergency stop method

• When an abnormality is confirmed, stop the machine immediately. After the machine has stopped, make sure to turn off the breaker of the user's equipment (on the upstream side).



Be sure to read this before handling the products. Refer to the back cover for safety instructions. For temperature control equipment precautions, refer to the "Handling Precautions for SMC Products" and the "Operation Manual" on the SMC website: https://www.smc.eu

Operation Restart Time/Operation and Suspension Frequency

A Caution

- 1. Wait five minutes or more before restarting operation after it has been stopped. If the operation is restarted within five minutes, the protection circuit may activate and the operation may not start properly.
- 2. Operation and suspension frequency should not exceed 10 times per day. Frequently switching between operation and suspension may result in the malfunction of the refrigeration circuit.

Protection Circuit

▲ Caution

If operating in the conditions below, the protection circuit will activate and an operation may not be performed or will stop.

- Power supply voltage is not within the rated voltage range of ±10 %.
- In case the water level inside the tank is reduced abnormally.
- Circulating fluid temperature is too high.
- Compared to the cooling capacity, the heat generation amount of the user's equipment is too high.
- Ambient temperature is over 45 °C.
- Ventilation grille is clogged with dust or dirt

Maintenance

▲ Caution

<Periodical inspection every one month>

Clean the ventilation grille.

If the dustproof filter of air-cooled type product becomes clogged with dust or debris, a decline in cooling performance can result. In order to avoid deforming or damaging the dustproof filter, clean it with a long-haired brush or air gun.

<Periodical inspection every three months>

Inspect the circulating fluid.

- 1. When using tap water or deionised water
 - Replacement of circulating fluid

Failure to replace the circulating fluid can lead to the development of bacteria or algae. Replace it regularly depending on your usage conditions.

<Periodical inspection during the winter season>

1. Make water-removal arrangements beforehand.

If there is a risk of the circulating fluid freezing when the product is stopped, release the circulating fluid in advance.

2. Contact a professional.

This product has an "anti-freezing function" and "warming-up function." Read the Operation Manual carefully, and if any additional anti-freezing function (e.g. tape heater) is needed, ask for it from the vendor.

Refrigerant with GWP reference

	Global warming potential (GWP)			
Refrigerant	Regulation (EU) No 517/2014 (Based on the IPCC AR4)	Revised Fluorocarbons Recovery and Destruction Law (Japanese law)		
R134a	1,430	1,430		
R404A	3,922	3,920		
R407C	1,774	1,770		
R410A	2,088	2,090		

 This product is hermetically sealed and contains fluorinated greenhouse gases (HFC). When this product is sold on the market in the EU after January 1, 2017, it needs to be compliant with the quota system of the F-Gas Regulation in the EU.
 * See specification table for refrigerant used in the product.

SMC

\triangle	Safety I	nstructions	damage. These instructions	3 are intended to prevent hazardous situations and/or equipment ions indicate the level of potential hazard with the labels of
			"Caution," "Warning" of followed in addition to In	or "Danger ." They are all important notes for safety and must be international Standards (ISO/IEC) ¹ , and other safety regulations.
	Danger:	Danger indicates a hazard wit which, if not avoided, will resu injury.	th a high level of risk It in death or serious	 ISO 4414: Pneumatic fluid power – General rules and safety requirements for systems and their components. ISO 4413: Hydraulic fluid power – General rules and safety requirements for systems and their components.
\wedge	Warning:	Warning indicates a hazard w which, if not avoided, could re injury.	vith a medium level of risk sult in death or serious	IEC 60204-1: Safety of machinery – Electrical equipment of machines. (Part 1: General requirements) ISO 10218-1: Robots and robotic devices - Safety requirements for industrial robots - Part 1: Robots.
\land	Caution:	Caution indicates a hazard wi which, if not avoided, could re iniury.	ith a low level of risk sult in minor or moderate	etc.

▲ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications. Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

- 3. Do not service or attempt to remove product and machinery/ equipment until safety is confirmed.
 - 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
 - 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
 - 3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.
- Our products cannot be used beyond their specifications.
 Our products are not developed, designed, and manufactured to be used under the following conditions or environments.
 Use under such conditions or environments is not covered.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Use for nuclear power, railways, aviation, space equipment, ships, vehicles, military application, equipment affecting human life, body, and property, fuel equipment, entertainment equipment, emergency shut-off circuits, press clutches, brake circuits, safety equipment, etc., and use for applications that do not conform to standard specifications such as catalogues and operation manuals.
 - Use for interlock circuits, except for use with double interlock such as installing a mechanical protection function in case of failure. Please periodically inspect the product to confirm that the product is operating properly.

∧ Caution

We develop, design, and manufacture our products to be used for automatic control equipment, and provide them for peaceful use in manufacturing industries. Use in non-manufacturing industries is not covered.

Products we manufacture and sell cannot be used for the purpose of transactions or certification specified in the Measurement Act.

The new Measurement Act prohibits use of any unit other than SI units in Japan.

Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".Read and accept them before using the product.

Limited warranty and Disclaimer

- 1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first. ²⁾ Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.
- 2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.
- 2) Vacuum pads are excluded from this 1 year warranty. A vacuum pad is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
- The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulations of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

SMC Corporation (Europe)

Austria Belgium Bulgaria +359 (0)2807670 Croatia Czech Republic +420 541424611 Denmark +45 70252900 Estonia +372 651 0370 Finland +358 207513513 France Germany +49 (0)61034020 Greece +30 210 2717265 Hungary +36 23513000 Ireland Italv +39 03990691 Latvia +371 67817700

+43 (0)2262622800 www.smc.at +32 (0)33551464 www.smc.be www.smc.bg +385 (0)13707288 www.smc.hr www.smc.cz www.smcdk.com www.smcee.ee www.smc.fi +33 (0)164761000 www.smc-france.fr www.smc.de www.smchellas.gr www.smc.hu +353 (0)14039000 www.smcautomation.ie www.smcitalia.it www.smc.lv

office@smc.at info@smc.be office@smc.bg office@smc hr office@smc.cz smc@smcdk.com info@smcee.ee smcfi@smc.fi supportclient@smc-france.fr info@smc.de sales@smchellas.gr office@smc.hu sales@smcautomation.ie mailbox@smcitalia.it info@smc.lv

Lithuania +370 5 2308118 Netherlands +31 (0)205318888 Norway +47 67129020 +48 222119600 Poland +351 214724500 Portugal Romania +40 213205111 Russia +7 (812)3036600 Slovakia +421 (0)413213212 www.smc.sk Slovenia +386 (0)73885412 Spain +34 945184100 Sweden +46 (0)86031240 Switzerland +41 (0)523963131 Turkey UК

www.smclt.lt www.smc.nl www.smc-norge.no www.smc.pl www.smc.eu www.smcromania.ro www.smc.eu www.smc.si www.smc.eu www.smc.nu www.smc.ch +90 212 489 0 440 www.smcturkey.com.tr +44 (0)845 121 5122 www.smc.uk

info@smclt.lt info@smc.nl post@smc-norge.no . sales@smc.pl apoioclientept@smc.smces.es smcromania@smcromania.ro sales@smcru.com office@smc.sk office@smc si post@smc.smces.es smc@smc.nu info@smc.ch info@smcturkey.com.tr sales@smc.uk

South Africa +27 10 900 1233 www.smcza.co.za zasales@smcza.co.za